

# *Concorde*

## MAINTENANCE MANUAL

### CHAPTER 33

#### LIGHTS

#### LIST OF EFFECTIVE PAGES

N, R or D indicates pages which are New, Revised or Deleted respectively.

Remove and insert the affected pages and complete the Record of Revisions and the Record of Temporary Revisions as necessary.

<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>
L.E.P.	R	A	May 31/03				
L.E.P.	R	1	May 31/03				
L.E.P.	R	2	May 31/03				
L.E.P.	R	3	May 31/03				
L.E.P.	R	4	May 31/03				
L.E.P.	R	5	May 31/03				
L.E.P.	R	6	May 31/03				
L.E.P.	R	7	May 31/03				
L.E.P.	R	8	May 31/03				

# *Concorde*

## MAINTENANCE MANUAL

### CHAPTER 33

#### LIGHTS

#### LIST OF EFFECTIVE PAGES

N, R or D indicates pages which are New, Revised or Deleted respectively.

Remove and insert the affected pages and complete the Record of Revisions and the Record of Temporary Revisions as necessary.

<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>
S.B. LIST		1	Feb 29/80	33-00-00		16	May 30/76
S.B. LIST		2	May 30/81	33-00-00		17	May 30/76
S.B. LIST		3	Feb 28/81	33-00-00		18	May 30/76
S.B. LIST		4	Nov 30/81	33-00-00		19	May 30/76
S.B. LIST		5	Nov 30/81	33-00-00		20	May 30/76
S.B. LIST		6	Nov 30/81	33-00-00		21	Feb 29/80
				33-00-00		22	May 30/76
T. of C.		1	Mar 29/96	33-00-00		23	May 30/76
T. of C.		2	Mar 29/96	33-00-00		24	May 30/76
T. of C.		3	Mar 29/96	33-00-00		25	May 30/76
T. of C.		4	Mar 29/96	33-00-00		26	May 30/76
T. of C.		5	Mar 29/96	33-00-00		27	May 30/76
T. of C.		6	Mar 29/96	33-00-00		28	May 30/76
T. of C.		7	Mar 29/96	33-00-00		29	May 30/76
T. of C.		8	Mar 29/96	33-00-00		30	May 30/76
T. of C.		9	Mar 29/96	33-00-00	R	31	May 31/03
T. of C.		10	Mar 29/96	33-00-00		32	May 30/76
T. of C.		11	Mar 29/96	33-00-00		33	May 30/76
T. of C.		12	Mar 29/96	33-00-00		34	May 30/76
T. of C.		13	Mar 29/96	33-00-00		35	May 30/76
T. of C.		14	Mar 29/96	33-00-00		36	May 30/76
T. of C.		15	Mar 29/96	33-00-00		37	Feb 28/78
T. of C.		16	Mar 29/96	33-00-00	R	38	May 31/03
				33-00-00		401	May 30/76
33-00-00		1	May 30/76	33-00-00		402	Jun 30/75
33-00-00		2	May 30/76	33-00-00		403	May 30/76
33-00-00		3	May 30/76	33-00-00		404	May 30/76
33-00-00		4	May 30/76	33-00-00		405	May 30/76
33-00-00		5	May 30/76	33-00-00		406	Jun 30/75
33-00-00		6	May 30/76	33-00-00		407	May 30/76
33-00-00		7	May 30/76	33-00-00		408	May 30/76
33-00-00		8	May 30/76	33-00-00		409	May 30/76
33-00-00		9	May 30/76				
33-00-00		10	May 30/76	33-10-00		401	Feb 28/77
33-00-00		11	May 30/76	33-10-00		402	Feb 28/77
33-00-00		12	May 30/76	33-10-00		403	Feb 28/77
33-00-00		13	May 30/76	33-10-00		404	Feb 28/77
33-00-00		14	May 30/76	33-10-00		405	Feb 28/77
33-00-00		15	May 30/76	33-10-00		406	Feb 28/77

33-L.E.P.  
Page 1  
May 31/03

# *Concorde*

## MAINTENANCE MANUAL

<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>
33-10-00		407	Feb 28/77	33-12-00		416	Aug 30/75
33-10-00		408	Feb 28/77	33-12-00		501	Aug 30/75
				33-12-00		502	Aug 30/75
33-12-00		1	Nov 30/75	33-12-00		503	Aug 30/75
33-12-00		2	Nov 30/75	33-12-00		504	Aug 30/75
33-12-00		3	Jun 30/75	33-12-11		401	Jun 30/75
33-12-00		4	Nov 30/75	33-12-11		402	Jun 30/75
33-12-00		5	Nov 30/75	33-12-11		403	Aug 30/75
33-12-00		6	Nov 30/75	33-12-11		404	Aug 30/75
33-12-00		7	Nov 30/75	33-12-11		405	Aug 30/75
33-12-00		8	Nov 30/75				
33-12-00		9	Jun 30/75	33-14-00		1	Sep 30/92
33-12-00		10	Jun 30/75	33-14-00		2	Sep 30/92
33-12-00		101	Mar 29/96	33-14-00		3	Sep 30/92
33-12-00		102	Mar 29/96	33-14-00		4	Aug 30/80
33-12-00		103	Mar 29/96	33-14-00		5	Sep 30/92
33-12-00		104	Mar 29/96	33-14-00		6	Sep 30/92
33-12-00		105	Mar 29/96	33-14-00		101	Sep 30/81
33-12-00		106	Mar 29/96	33-14-00		102	Jun 30/75
33-12-00		107	Mar 29/96	33-14-00		103	Jun 30/75
33-12-00		108	Mar 29/96	33-14-00		104	Jun 30/75
33-12-00		109	Mar 29/96	33-14-00		105	Nov 30/79
33-12-00		110	Mar 29/96	33-14-00		106	Nov 30/79
33-12-00		111	Mar 29/96	33-14-00		401	Feb 28/81
33-12-00		112	Mar 29/96	33-14-00		402	Feb 28/81
33-12-00		113	Mar 29/96	33-14-00		501	Sep 30/92
33-12-00		114	Mar 29/96	33-14-00		501 A	Sep 30/92
33-12-00		115	Mar 29/96	33-14-00		501 B	Sep 30/92
33-12-00		116	Mar 29/96	33-14-00		502	Aug 30/80
33-12-00		117	Mar 29/96	33-14-00		503	Aug 30/80
33-12-00		118	Mar 29/96	33-14-00		504	Aug 30/80
33-12-00		119	Mar 29/96				
33-12-00		120	Mar 29/96	33-15-00		1	Feb 28/79
33-12-00		121	Mar 29/96	33-15-00		2	Feb 28/79
33-12-00		122	Mar 29/96	33-15-00		3	Sep 30/91
33-12-00		401	Jun 30/75	33-15-00		4	May 30/76
33-12-00		402	Feb 29/76	33-15-00		5	Mar 31/95
33-12-00		403	Jun 30/75	33-15-00		6	Jun 30/75
33-12-00		404	Feb 29/76	33-15-00		7	Sep 30/91
33-12-00		405	Feb 29/76	33-15-00		8	May 30/76
33-12-00		406	Feb 29/76	33-15-00		9	May 30/76
33-12-00		407	Feb 29/76	33-15-00		10	May 30/76
33-12-00		408	Jun 30/75	33-15-00		11	May 30/76
33-12-00		409	Feb 29/76	33-15-00		12	May 30/79
33-12-00		410	Feb 29/76	33-15-00		13	May 30/79
33-12-00		411	Feb 29/76	33-15-00		14	May 30/79
33-12-00		412	Jun 30/75	33-15-00		15	May 30/79
33-12-00		413	Aug 30/75	33-15-00		16	May 30/79
33-12-00		414	Aug 30/75	33-15-00		17	Nov 30/77
33-12-00		415	Aug 30/75	33-15-00		18	Nov 30/77

33-L.E.P.  
Page 2  
May 31/03

# *Concorde*

## MAINTENANCE MANUAL

<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>
33-15-00		19	Nov 30/77	33-15-12		401	Jun 30/75
33-15-00		20	Nov 30/77	33-15-12		402	Jun 30/75
33-15-00		21	Nov 30/77	33-15-12		403	Jun 30/75
33-15-00		22	Nov 30/77	33-15-12		404	Jun 30/75
33-15-00		23	Nov 30/77				
33-15-00		24	Sep 30/91	33-16-00		1	Nov 30/76
33-15-00		25	Sep 30/91	33-16-00		2	Nov 30/76
33-15-00		26	Sep 30/91	33-16-00		3	Nov 30/76
33-15-00		27	Sep 30/91	33-16-00		4	Nov 30/76
33-15-00		28	Sep 30/91	33-16-00		5	Aug 30/76
33-15-00		101	Jun 30/75	33-16-00		6	Aug 30/76
33-15-00		102	Aug 30/78	33-16-00		101	Aug 30/75
33-15-00		103	Aug 30/78	33-16-00		102	Aug 30/75
33-15-00		104	Aug 30/78	33-16-00		103	Jun 30/75
33-15-00		105	Aug 30/78	33-16-00		104	Jun 30/75
33-15-00		106	Aug 30/78	33-16-00		105	Jun 30/75
33-15-00		107	Aug 30/78	33-16-00		106	Jun 30/75
33-15-00		108	Aug 30/78	33-16-00		107	Jun 30/75
33-15-00		109	Nov 30/79	33-16-00		108	Jun 30/75
33-15-00		401	Jun 30/75	33-16-00		109	Jun 30/75
33-15-00		402	Jun 30/75	33-16-00		110	Jun 30/75
33-15-00		501	Sep 30/87	33-16-00		111	Nov 30/79
33-15-00		502	Sep 30/87	33-16-00		112	Nov 30/79
33-15-00		503	Sep 30/88	33-16-00		201	Mar 31/95
33-15-00		504	Sep 30/88	33-16-00		401	Jun 30/75
33-15-00		505	Sep 30/88	33-16-00		402	Jun 30/75
33-15-00		506	Sep 30/87	33-16-00		403	Mar 28/02
33-15-00		507	Sep 30/91	33-16-00		404	Mar 28/02
33-15-00		507 A	Sep 30/91	33-16-00		501	Aug 30/75
33-15-00		507 B	Sep 30/91	33-16-00		502	Aug 30/75
33-15-00		507 C	Sep 30/91				
33-15-00		507 D	Sep 30/91	33-17-00		1	Aug 30/75
33-15-00		508	Sep 30/87	33-17-00		2	Aug 30/75
33-15-00		509	Sep 30/87	33-17-00		3	Aug 30/75
33-15-00		510	Sep 30/87	33-17-00		4	Feb 28/78
33-15-00		511	Sep 30/87	33-17-00		5	Aug 30/75
33-15-00		512	Sep 30/87	33-17-00		6	Nov 30/78
33-15-00		513	Sep 30/87	33-17-00		7	Nov 30/78
33-15-00		514	Sep 30/87	33-17-00		101	Aug 30/77
33-15-00		515	Sep 30/87	33-17-00		102	Aug 30/78
33-15-00		516	Sep 30/87	33-17-00		103	Aug 30/78
33-15-00		517	Sep 30/87	33-17-00		104	Aug 30/78
33-15-00		518	Sep 30/87	33-17-00		105	Aug 30/78
33-15-00		519	Sep 30/87	33-17-00		106	Aug 30/78
33-15-00		520	Sep 30/87	33-17-00		107	Aug 30/78
33-15-00		521	Sep 30/87	33-17-00		108	Aug 30/78
33-15-00		522	Sep 30/87	33-17-00		109	Nov 30/79
33-15-00		523	Sep 30/87	33-17-00		110	Nov 30/79
33-15-11		401	Jun 30/75	33-17-00		111	Nov 30/79
33-15-11		402	Jun 30/75	33-17-00		112	Nov 30/79

33-L.E.P.  
Page 3  
May 31/03



# *Concorde*

## MAINTENANCE MANUAL

<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>
33-17-00		401	Mar 29/96	33-21-00		111	Mar 31/95
33-17-00		501	Jun 30/75	33-21-00		112	Mar 31/95
33-17-00		502	Jun 30/75	33-21-00		401	Mar 31/95
33-17-00		503	Jun 30/75	33-21-00		402	Mar 31/95
33-17-01		401	Feb 29/76	33-21-00		403	Mar 31/95
33-17-01		402	Jun 30/75	33-21-00		404	Mar 31/95
33-17-01		403	Aug 30/75	33-21-00		405	Mar 31/95
33-17-01		404	Feb 29/76	33-21-00		406	Mar 31/95
33-17-01		405	Aug 30/75	33-21-00		407	Mar 31/95
33-17-01		406	Aug 30/77	33-21-00		501	Feb 29/76
33-17-01		407	Aug 30/77	33-21-00		502	Mar 31/95
33-17-01		408	Aug 30/77	33-21-00		503	Mar 31/95
33-17-01		409	Aug 30/77				
33-17-01		410	Aug 30/77	33-22-00		1	Aug 30/75
33-17-12		401	Feb 29/76	33-22-00		2	Aug 30/75
33-17-12		402	Aug 30/75	33-22-00		3	Aug 30/75
33-17-12		403	Aug 30/75	33-22-00		4	Aug 30/75
33-17-12		404	Jun 30/75	33-22-00		101	Mar 29/96
33-17-12		405	Aug 30/75	33-22-00		102	Mar 29/96
33-17-12		406	Aug 30/75	33-22-00		103	Mar 29/96
33-17-12		407	Aug 30/75	33-22-00		104	Mar 29/96
				33-22-00		105	Mar 29/96
33-20-00		401	Jun 30/75	33-22-00		106	Mar 29/96
33-20-00		402	Jun 30/75	33-22-00		107	Mar 29/96
33-20-00		403	Nov 30/75	33-22-00		401	Sep 30/90
33-20-00		404	Jun 30/75	33-22-00		402	Sep 30/90
33-20-00		405	Jun 30/75	33-22-00		403	Sep 30/90
33-20-00		406	Jun 30/75	33-22-00		404	Sep 30/90
33-20-00		407	Feb 28/77	33-22-00		405	Sep 30/90
33-20-00		408	Feb 28/77	33-22-00		406	Sep 30/90
33-20-00		409	Feb 28/77	33-22-00		407	Sep 30/90
33-20-00		410	Feb 28/77	33-22-00		501	Mar 29/96
				33-22-00		502	Mar 29/96
33-21-00		1	Jun 30/75				
33-21-00		2	Jun 30/75	33-23-00		1	Mar 31/95
33-21-00		3	Jun 30/75	33-23-00		2	Mar 31/95
33-21-00		4	Aug 30/76	33-23-00		3	Feb 29/76
33-21-00		5	Jun 30/75	33-23-00		4	Feb 29/76
33-21-00		6	Jun 30/75	33-23-00		5	Nov 30/75
33-21-00		7	Aug 30/76	33-23-00		6	Nov 30/75
33-21-00		101	Mar 31/95	33-23-00		101	Nov 30/75
33-21-00		102	Mar 31/95	33-23-00		102	Nov 30/75
33-21-00		103	Mar 31/95	33-23-00		103	Nov 30/75
33-21-00		104	Mar 31/95	33-23-00		104	Nov 30/75
33-21-00		105	Mar 31/95	33-23-00		105	Nov 30/75
33-21-00		106	Mar 31/95	33-23-00		106	Nov 30/75
33-21-00		107	Mar 31/95	33-23-00		107	Nov 30/79
33-21-00		108	Mar 31/95	33-23-00		401	Mar 31/95
33-21-00		109	Mar 31/95	33-23-00		402	Mar 31/95
33-21-00		110	Mar 31/95	33-23-00		403	Mar 31/95

33-L.E.P.  
Page 4  
May 31/03

# Concorde

## MAINTENANCE MANUAL

<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>
33-23-00		404	Mar 31/95	33-27-00		5	Nov 30/80
33-23-00		405	Mar 31/95	33-27-00		6	Nov 30/80
33-23-00		406	Mar 31/95	33-27-00		7	Sep 30/93
33-23-00		501	Nov 30/79	33-27-00		8	Sep 30/93
33-23-00		502	Nov 30/75	33-27-00		9	Sep 30/93
33-23-00		503	Nov 30/75	33-27-00		10	Jun 30/75
33-23-10		201	Sep 29/89	33-27-00		101	Mar 27/97
33-23-10		202	Sep 29/89	33-27-00		102	Mar 27/97
				33-27-00		103	Mar 27/97
33-24-00		1	Feb 28/77	33-27-00		104	Mar 27/97
33-24-00		2	Jun 30/75	33-27-00		105	Mar 27/97
33-24-00		3	Aug 30/76	33-27-00		106	Mar 27/97
33-24-00		101	Jun 30/75	33-27-00		107	Mar 27/97
33-24-00		102	Jun 30/75	33-27-00		108	Mar 27/97
33-24-00		103	Jun 30/75	33-27-00		109	Mar 27/97
33-24-00		104	Jun 30/75	33-27-00		110	Mar 27/97
33-24-00		105	Nov 30/79	33-27-00		111	Mar 27/97
33-24-00		106	Nov 30/79	33-27-00		112	Mar 27/97
33-24-00		401	Aug 30/75	33-27-00		113	Mar 27/97
33-24-00		402	Aug 30/75	33-27-00		114	Mar 27/97
33-24-00		403	Aug 30/75	33-27-00		115	Mar 27/97
33-24-00		501	Aug 30/75	33-27-00		401	May 30/80
				33-27-00		402	Nov 30/77
33-25-00		1	Aug 30/77	33-27-00		403	May 30/80
33-25-00		2	Aug 30/77	33-27-00		404	May 30/80
33-25-00		3	Nov 30/75	33-27-00		405	Nov 30/77
33-25-00		4	Aug 30/77	33-27-00		406	Nov 30/77
33-25-00		5	Aug 30/77	33-27-00		407	Nov 30/77
33-25-00		6	Aug 30/77	33-27-00		501	Feb 28/77
33-25-00		101	Jun 30/75	33-27-00		502	Nov 30/79
33-25-00		102	Aug 30/78	33-27-00		503	Feb 28/77
33-25-00		103	Aug 30/78				
33-25-00		104	Aug 30/78	33-28-00		1	Mar 31/95
33-25-00		105	Aug 30/78	33-28-00		401	Mar 31/95
33-25-00		106	Aug 30/78				
33-25-00		107	Aug 30/78	33-31-00		1	May 30/77
33-25-00		108	Nov 30/79	33-31-00		2	Feb 28/77
33-25-00		109	Nov 30/79	33-31-00		3	May 30/77
33-25-00		401	Aug 30/77	33-31-00		4	May 30/77
33-25-00		402	Aug 30/77	33-31-00		5	May 30/77
33-25-00		403	Nov 30/75	33-31-00		101	Mar 29/96
33-25-00		404	Nov 30/75	33-31-00		102	Mar 29/96
33-25-00		501	Aug 30/75	33-31-00		103	Mar 29/96
33-25-00		502	Aug 30/77	33-31-00		104	Mar 29/96
33-25-00		503	Aug 30/75	33-31-00		105	Mar 29/96
				33-31-00		106	Mar 29/96
33-27-00		1	Nov 30/80	33-31-00		107	Mar 29/96
33-27-00		2	Sep 30/93	33-31-00		401	Mar 29/96
33-27-00		3	May 30/77	33-31-00		402	Mar 29/96
33-27-00		4	Jun 30/75	33-31-00		403	Mar 29/96

33-L.E.P.  
Page 5  
May 31/03

# *Concorde*

## MAINTENANCE MANUAL

<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>
33-31-00		404	Mar 29/96	33-41-41		404	Sep 30/92
33-31-00		405	Mar 29/96	33-41-41		405	Mar 31/98
33-31-00		406	Mar 29/96	33-41-41		601	Sep 30/92
33-31-00		407	Mar 29/96				
33-31-00		408	Mar 29/96	33-42-00		1	Aug 30/77
33-31-00		409	Mar 29/96	33-42-00		2	May 30/77
33-31-00		410	Mar 29/96	33-42-00		3	Aug 30/77
33-31-00		411	Mar 29/96	33-42-00		4	Aug 30/77
33-31-00		501	Jun 30/75	33-42-00		5	Aug 30/77
33-31-00		502	Feb 29/76	33-42-00		101	Jun 30/75
33-31-00		503	Aug 30/75	33-42-00		102	Aug 30/78
33-31-00		504	Aug 30/75	33-42-00		103	Aug 30/78
				33-42-00		104	Nov 30/76
33-32-00		1	Jun 30/75	33-42-00		105	Nov 30/79
33-32-00		2	Jun 30/75	33-42-00		401	Jun 30/75
33-32-00		3	Jun 30/75	33-42-00		501	Jun 30/75
33-32-00		4	Nov 30/75	33-42-00		502	Jun 30/75
33-32-00		101	Mar 29/96	33-42-11		401	Feb 29/76
33-32-00		102	Mar 29/96	33-42-11		402	Aug 30/75
33-32-00		103	Mar 29/96	33-42-12		401	Aug 30/79
33-32-00		104	Mar 29/96	33-42-12		402	Aug 30/79
33-32-00		105	Mar 29/96	33-42-12		403	Aug 30/79
33-32-00		106	Mar 29/96	33-42-12		404	Aug 30/79
33-32-00		107	Mar 29/96	33-42-13		401	May 30/83
33-32-00		401	Mar 29/96	33-42-13		402	May 30/83
33-32-00		402	Mar 29/96				
33-32-00		403	Mar 29/96	33-43-00		1	Aug 30/77
33-32-00		501	Mar 29/96	33-43-00		2	Nov 30/75
33-32-32		401	Jun 30/75	33-43-00		3	Nov 30/75
33-32-32		402	Jun 30/75	33-43-00		4	Aug 30/77
				33-43-00		5	Jun 30/75
33-41-00		1	Aug 30/77	33-43-00		101	Mar 29/96
33-41-00		2	Jun 30/77	33-43-00		102	Mar 29/96
33-41-00		3	Aug 30/77	33-43-00		103	Mar 29/96
33-41-00		101	Mar 29/96	33-43-00		104	Mar 29/96
33-41-00		102	Mar 29/96	33-43-00		105	Mar 29/96
33-41-00		103	Mar 29/96	33-43-00		106	Mar 29/96
33-41-00		401	Mar 29/96	33-43-00		107	Mar 29/96
33-41-00		501	Mar 29/96	33-43-00		401	Mar 29/96
33-41-21		401	Mar 29/96	33-43-00		501	Jun 30/75
33-41-21		402	Mar 29/96	33-43-00		502	Jun 30/75
33-41-21		403	Mar 29/96	33-43-11		401	Feb 28/77
33-41-21		404	Mar 29/96	33-43-11		402	Feb 28/77
33-41-21		405	Mar 29/96	33-43-11		403	Feb 28/77
33-41-21		406	Mar 29/96	33-43-11		404	Feb 28/77
33-41-21		407	Mar 29/96	33-43-11		405	Feb 28/77
33-41-21		408	Mar 29/96	33-43-11		406	Feb 28/77
33-41-41		401	Nov 30/80	33-43-11		407	Feb 28/77
33-41-41		402	Nov 30/80	33-43-11		501	Feb 28/77
33-41-41		403	Aug 30/80	33-43-11		502	Feb 28/77

33-L.E.P.  
Page 6  
May 31/03

# *Concorde*

## MAINTENANCE MANUAL

<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>
33-43-11		503	Feb 28/77	33-44-11		504	Feb 28/77
33-43-11		504	Feb 28/77	33-44-11		505	Feb 28/77
33-43-11		505	Feb 28/77	33-44-11		506	Feb 28/77
33-43-11		506	Feb 28/77	33-44-11		507	Feb 28/77
33-43-11		507	Feb 28/77	33-44-11		508	Feb 28/77
33-43-11		508	Feb 28/77	33-44-11		509	Feb 28/77
				33-44-11		510	Feb 28/77
33-44-00		1	Aug 30/77	33-44-12		401	Mar 29/96
33-44-00		2	Nov 30/75	33-44-12		402	Mar 29/96
33-44-00		3	Nov 30/75	33-44-12		403	Mar 29/96
33-44-00		4	Nov 30/75	33-44-12		404	Mar 29/96
33-44-00		5	Aug 30/77				
33-44-00		6	Jun 30/75	33-51-00		1	Sep 29/89
33-44-00		7	Aug 30/76	33-51-00		1 A	Sep 29/89
33-44-00		101	Mar 29/96	33-51-00		1 B	Sep 29/89
33-44-00		102	Mar 29/96	33-51-00		2	Sep 29/89
33-44-00		103	Mar 29/96	33-51-00		3	Jun 30/75
33-44-00		104	Mar 29/96	33-51-00		4	Jun 30/75
33-44-00		105	Mar 29/96	33-51-00		5	Jun 30/75
33-44-00		106	Mar 29/96	33-51-00		6	Jun 30/75
33-44-00		107	Mar 29/96	33-51-00		7	Jun 30/75
33-44-00		108	Mar 29/96	33-51-00		8	Jun 30/75
33-44-00		109	Mar 29/96	33-51-00		9	Sep 29/89
33-44-00		110	Mar 29/96	33-51-00		10	Sep 29/89
33-44-00		111	Mar 29/96	33-51-00		11	Sep 29/89
33-44-00		112	Mar 29/96	33-51-00		12	Sep 29/89
33-44-00		113	Mar 29/96	33-51-00		101	Sep 29/89
33-44-00		114	Mar 29/96	33-51-00		102	Sep 29/89
33-44-00		115	Mar 29/96	33-51-00		103	Sep 29/89
33-44-00		116	Mar 29/96	33-51-00		104	Sep 29/89
33-44-00		117	Mar 29/96	33-51-00		105	Sep 29/89
33-44-00		118	Mar 29/96	33-51-00		106	Sep 29/89
33-44-00		401	May 30/76	33-51-00		107	Feb 28/81
33-44-00		402	May 30/76	33-51-00		108	Feb 28/81
33-44-00		403	May 30/76	33-51-00		109	Sep 29/89
33-44-00		404	May 30/76	33-51-00		110	Sep 29/89
33-44-00		405	May 30/76	33-51-00		201	Sep 29/89
33-44-00		406	May 30/76	33-51-00		202	Sep 29/89
33-44-00		501	Feb 29/76	33-51-00		203	Sep 29/89
33-44-00		502	Aug 30/75	33-51-00		301	Sep 29/89
33-44-00		503	Aug 30/75	33-51-00		302	Sep 29/89
33-44-11		401	Feb 28/77	33-51-00		401	Sep 29/89
33-44-11		402	Feb 28/77	33-51-00		402	Jun 30/75
33-44-11		403	Feb 28/77	33-51-00		403	Sep 29/89
33-44-11		404	Feb 28/77	33-51-00		404	Sep 29/89
33-44-11		405	Feb 28/77	33-51-00		405	Sep 29/89
33-44-11		406	Feb 28/77	33-51-00		406	Sep 29/89
33-44-11		501	Feb 28/77	33-51-00		407	Nov 30/78
33-44-11		502	Feb 28/77	33-51-00		408	Nov 30/78
33-44-11		503	Feb 28/77	33-51-00		409	Sep 29/89

33-L.E.P.  
Page 7  
May 31/03

# Concorde

## MAINTENANCE MANUAL

<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>DATE</u>
33-51-00		410	Sep 29/89	33-52-00		131	Mar 31/95
33-51-00		411	May 30/78	33-52-00		201	Mar 31/95
33-51-00		412	Sep 29/89	33-52-00		202	Mar 31/95
33-51-00		413	Sep 29/89	33-52-00		203	Mar 31/95
33-51-00		414	Sep 29/89	33-52-00		204	Mar 31/95
33-51-00		415	Sep 29/89	33-52-00		205	Mar 31/95
33-51-00		416	Sep 29/89	33-52-00		206	Sep 29/89
33-51-00		417	Sep 29/89	33-52-00		501	Mar 31/95
33-51-00		501	Sep 29/89	33-52-00		502	Mar 31/95
33-51-00		502	Sep 29/89	33-52-00		503	Mar 31/95
33-51-00		503	Feb 29/80	33-52-00		504	Mar 31/95
33-51-00		504	Sep 29/89	33-52-00		505	Mar 31/95
33-51-00		505	Sep 29/89	33-52-00		506	Mar 31/95
33-51-00		506	Sep 29/89	33-52-10		401	Sep 29/89
33-51-00		507	Sep 29/89	33-52-10		402	Sep 29/89
33-51-00		508	Sep 30/90	33-52-10		403	Sep 29/89
33-51-00		509	Sep 30/90	33-52-20		401	Sep 29/89
33-51-00		510	Sep 30/90	33-52-20		402	Sep 29/89
33-51-00		511	Sep 30/90	33-52-20		403	Sep 29/89
				33-52-20		404	Mar 31/95
33-52-00		101	Mar 31/95	33-52-20		405	Sep 29/89
33-52-00		102	Mar 31/95	33-52-30		401	Mar 31/95
33-52-00		103	Mar 31/95	33-52-30		402	Mar 31/95
33-52-00		104	Mar 31/95	33-52-30		403	Mar 31/95
33-52-00		105	Mar 31/95	33-52-30		404	Mar 31/95
33-52-00		106	Mar 31/95	33-52-30		405	Mar 31/95
33-52-00		107	Mar 31/95				
33-52-00		108	Mar 31/95				
33-52-00		109	Mar 31/95				
33-52-00		110	Mar 31/95				
33-52-00		111	Mar 31/95				
33-52-00		112	Mar 31/95				
33-52-00		113	Mar 31/95				
33-52-00		114	Mar 31/95				
33-52-00		115	Mar 31/95				
33-52-00		116	Mar 31/95				
33-52-00		117	Mar 31/95				
33-52-00		118	Mar 31/95				
33-52-00		119	Mar 31/95				
33-52-00		120	Mar 31/95				
33-52-00		121	Mar 31/95				
33-52-00		122	Mar 31/95				
33-52-00		123	Mar 31/95				
33-52-00		124	Mar 31/95				
33-52-00		125	Mar 31/95				
33-52-00		126	Mar 31/95				
33-52-00		127	Mar 31/95				
33-52-00		128	Mar 31/95				
33-52-00		129	Mar 31/95				
33-52-00		130	Mar 31/95				

# Concorde

## MAINTENANCE MANUAL

### SERVICE BULLETIN LIST

In the following service bulletin list, SB indicates an aircraft manufacturers bulletin, AEB indicates an airline engineering bulletin and OL indicates an engine manufacturers bulletin (complete identification OL.593-XX-XXX).

*					*
*	R	INC.			*
*SB/AEB NO	E	IN		DESCRIPTION	*
*	V	REVISION			*
*					*
SB 33-001				Not applicable	
SB 33-002		Feb 28/77		Embodied	
				Lights. Floodlamp -To change the existing floodlamp at the forward baggage compartment door to one with a lens over the filament	
SB 33-003				Embodied	
				Lighting. Tail anti-collision and navigation lights -Deletion of inhibition during fuel jettison	
SB 33-003	01			Embodied	
				Lighting. Tail anti-collision and navigation lights -Deletion of inhibition during fuel jettison	
R SB 33-003	02			Embodied	
				Lighting. Tail Anti-Collision and Navigation Lights - Deletion of inhibition during fuel jettison	
SB 33-004				Not applicable	
SB 33-004	01			Not applicable	
SB 33-005		Feb 28/77		Embodied	
				Lights -Flight compartment -To introduce bonding for panels 12-211 and 5-212.	
SB 33-005	01			Embodied	
				Lights -Flight compartment -To introduce bonding for panels 12-211 and 5-212.	
SB 33-005	02			Embodied	
				Lights -Flight compartment -To introduce bonding for panels 12-211 and 5-212.	
SB 33-007		Nov 30/77		Embodied	
				Lights -Anti collision/Navigation -to introduce an improved light assembly at the tail cone position	
SB 33-007	01			Embodied	
				Lights -Anti collision/Navigation -to introduce an improved light assembly at the tail cone position	
SB 33-008				No effect	
				Lights -Change of a wing navigation lamp	

# Concorde

## MAINTENANCE MANUAL

### SERVICE BULLETIN LIST

-----				
*				*
*	R	INC.		*
*SB/AEB NO	E	IN	DESCRIPTION	*
*	V	REVISION		*
-----				*
SB 33-008	01		mirror assemblies No effect Lights - Change of a wing navigation lamp mirror assemblies	
R SB 33-008	02		No effect Lights - Change of a wing navigation lamp mirror assemblies	
SB 33-009			Applicable Lights -To change the colour filters of the wing navigation lights	
SB 33-010			Applicable Lights -Passenger call system -Modified wiring to cater for the appropriate steward "call" when the forward passenger compart- ment divider bulkhead is used	
SB 33-010	01		Applicable Lights -Passenger call system -Modified wiring to cater for the appropriate steward "call" when the forward passenger compart- ment divider bulkhead is used	
SB 33-010	02		Applicable Lights -Passenger call system -Modified wiring to cater for the appropriate steward "call" when the forward passenger compart- ment divider bulkhead is used	
SB 33-011			Not applicable	
SB 33-012			Applicable Lights. Exterior -To install a revised standard of landing and landing/taxi lamps	
SB 33-012	01		Applicable Lights. Exterior - To install a revised standard of Landing and Landing/Taxi Lamps	
SB 33-013			No effect Lights -Fuel quantity indication (FQI) to change type of resistor for FQI integral lighting	
SB 33-013	01		No effect Lights. Fuel quantity indication (FQI) - To change type of resistor for fuel quan- tity indication (FQI) control panel inte- gral lighting	
SB 33-013	02		No effect Lights. Fuel quantity indication -To change type of resistor for fuel quantity indica-	

33-S-B LIST  
Page 2  
May 30/81

BA

Printed in England

# Concorde

## MAINTENANCE MANUAL

### SERVICE BULLETIN LIST

-----				
*				*
*SB/AEB NO	R	INC.		*
	E	IN	DESCRIPTION	*
*	V	REVISION		*
-----				
SB 33-013	03		tion (FQI) integral lighting	
			Applicable	
			Lights. Fuel quantity indication -To change	
			type of resistor for fuel quantity indica-	
			tion (FQI) control panel integral lighting	
SB 33-014		Nov 30/77	Embodied	
			Lights -Boarding vestibule -to introduce	
			a ventilated lightshade and a revised	
			method of locating the ceiling panel to the	
			lantern reflector in the vestibule areas	
SB 33-014	01		Applicable	
			Lights -Boarding vestibule -to introduce	
			a ventilated lightshade and a revised	
			method of locating the ceiling panel to the	
			lantern reflector in the vestibule areas	
R SB 33-014	02		No effect	
			Lights -Boarding vestibule -to introduce	
			a ventilated lightshade and a revised	
			method of locating the ceiling panel to the	
			lantern reflector in the vestibule areas	
SB 33-015		Aug 30/77	Embodied	
			Lights, call systems -To improve attachment	
			and visibility of cabin ceiling Steward's	
			call lights	
SB 33-015	01		Embodied	
			Lights, call systems -To improve attachment	
			and visibility of cabin ceiling Steward's	
			call lights	
SB 33-016			Not applicable	
SB 33-017			Applicable	
			Lights: Exterior -To introduce an isolating	
			transformer into the anti collision light	
			flasher unit supply	
SB 33-017	01		Applicable	
			Lights: Exterior -To introduce an isolating	
			transformer into the anti collision light	
			flasher unit supply	
SB 33-018		Nov 30/78	Embodied	
			Lighting-Distance Measuring Equipment (DME)	
			digital indication -To change supply of	
			dimming circuit from 28VDC normal bus-bar	
			to 28VDC emergency bus-bar, left hand side	
			(LHS) only	
SB 33-018	01		No effect	



# Concorde

## MAINTENANCE MANUAL

### SERVICE BULLETIN LIST

-----			
*			*
*	R	INC.	*
*SB/AEB NO	E	IN	*
*	V	REVISION	*
-----			
			Lighting. Distance Measuring Equipment (DME)
			Digital Indication
			- To change supply of dimming circuit from
			28VDC normal busbar to 28VDC emergency bus-
			bar (L.H. side only)
SB 33-018	02		No effect
			Lighting. Distance Measuring Equipment (DME)
			Digital Indication
			- To change supply of dimming circuit from
			28VDC normal busbar to 28VDC emergency bus-
			bar (L.H. side only)
SB 33-018	03		Embodied
			Lighting. Distance Measuring Equipment (DME)
			Digital Indication
			- To change supply of dimming circuit from
			28VDC normal busbar to 28VDC emergency bus-
			bar (L.H. side only)
SB 33-019		Nov 30/78	Embodied
			Lights. To improve accessibility to emergen-
			cy battery pack located in rear vestibule
SB 33-020			Embodied
			Lights -Master Warning System (MWS) -To
			inhibit green hydraulic low pressure (LP)
			warning input to power flying control (PFC)
			MWS caption during take-off (102 A/C)
SB 33-020	01		Embodied
			Lights -Master Warning System (MWS) -To
			inhibit green hydraulic low pressure (LP)
			warning input to power flying control (PFC)
			MWS caption during take-off (102 A/C)
SB 33-020	02		Embodied
			Lights -Master Warning System (MWS) -To
			inhibit green hydraulic low pressure (LP)
			warning input to power flying control (PFC)
			MWS caption during take-off (102 A/C)
SB 33-020	03		Embodied
			Lights. Master Warning System (MWS) - To
			inhibit "Green Hydraulic low pressure (LP)
			warning input to Power Flying Control (PFC)
			MWS caption during take-off"
SB 33-020	04		Applicable
			Lights - Master Warning System (MWS) - To
			inhibit "Green Hydraulic low pressure (LP)
			warning input to Power Flying Control (PFC)

33-S-B LIST

R Page 4

BA

Nov 30/81

# Concorde

## MAINTENANCE MANUAL

### SERVICE BULLETIN LIST

-----				
*				*
*	R	INC.		*
*SB/AEB NO	E	IN		*
*	V	REVISION		*
-----				*
SB 33-020	05			MWS caption during take-off"
				Applicable
				Lights - Master Warning System (MWS) - To
				inhibit "Green Hydraulic low pressure (LP)
				warning input to Power Flying Control (PFC)
				MWS caption during take-off"
SB 33-021				Not applicable
SB 33-021	01			Not applicable
SB 33-021	02			Not applicable
SB 33-021	03			Not applicable
SB 33-022				Applicable
				Lights. Master Warning System - To introduce
				a new standard of Control Unit
SB 33-023				No effect
				Lights. Master warning display unit -To
				introduce shorter securing bolts
SB 33-024				Embodied
				Lights. Filament test (Roof panel) -
				Improved circuit isolation
SB 33-024	01			Embodied
				Lights. Filament Test (Roof Panel) - Impro-
				ved circuit isolation
SB 33-024	01	Feb 29/80		Embodied
SB 33-025				Not applicable
SB 33-026		Nov 30/80		Embodied
				Lights. Filament Test - To clarify diagnosis
				of essential warning lights
SB 33-026	01			Embodied
				Lights. Filament Test - To clarify diagnosis
				of essential warning lights
SB 33-026	02	Aug 30/80		Embodied
				Lights. Filament Test - To clarify diagnosis
				of essential warning lights
SB 33-026	03			Embodied
				Lights. Filament Test - To clarify diagnosis
				of essential warning lights
SB 33-026	04			Embodied
				Lights. Filament Test - To clarify diagnosis
				of essential warning lights
SB 33-026	05			Embodied
				Lights. Filament Test - To clarify diagnosis
				of essential warning lights
SB 33-027				No effect
				Lights. Master warning system (MWS). To

33-S-B LIST

Page 5

Nov 30/81

R

BA

# Concorde

## MAINTENANCE MANUAL

### SERVICE BULLETIN LIST

-----				
*				*
*	R	INC.		*
*SB/AEB NO	E	IN	DESCRIPTION	*
*	V	REVISION		*
*				*
-----				
			inhibit the trim master warning on the ground	
			at speeds above 60 knots	
SB 33-027	01		No effect	
			Lights. Master warning system (MWS). To	
			inhibit the trim master warning on the ground	
			at speeds above 60 knots	
SB 33-027	02		No effect	
			Lights. Master warning system (MWS). To	
			inhibit the trim master warning on the ground	
			at speeds above 60 knots	
SB 33A006			No effect	
			Lights -Emergency lighting battery packs	

# *Concorde*

## MAINTENANCE MANUAL

### CHAPTER 33

#### LIGHTS

#### TABLE OF CONTENTS

<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
<u>GENERAL</u>	<u>33-00-00</u>			
Description and Operation			1	ALL
General			1	ALL
Internal Lighting			1	ALL
External Lighting			2	ALL
Flight Compartment Safety Check			2	ALL
Flight Compartment Preparation			3	ALL
Check				
Walk Round Check			5	ALL
Sub-system Management			18	ALL
Removal/Installation			401	ALL
General			401	ALL
Switches and Caption Light			401	ALL
Modules - Flight compartment Roof				
Panel				

PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

SUBJECT	CH/SE/SU	C	PAGE	EFFECTIV.
<u>FLIGHT COMPARTMENT</u>	<u>33-10-00</u>			
Removal/Installation			401	ALL
General			401	ALL
Panel-mounted Components			401	ALL
 MAIN LIGHTING	 33-12-00			
Description and Operation			1	ALL
General			1	ALL
Dashboard Panel Floodlights			1	ALL
Centre Console Floodlight			1	ALL
Floor Floodlights			1	ALL
Storm Floodlights			1	ALL
First Supernumerary's Floodlight			1	ALL
Chart Lights			3	ALL
Chart Stowage Lights			3	ALL
Oxygen Mask Stowage Lights			3	ALL
3CM Panel Floodlights			3	ALL
3CM Panel Spotlights			3	ALL
Equipment Rack Inspection			3	ALL
Lights				
3CM Reading Light			5	ALL
Roof Lamps			5	ALL
Operation			5	ALL
Trouble Shooting			101	ALL
General			101	ALL
Preparation			101	ALL
Trouble Shooting			102	ALL
Removal/Installation			401	ALL
General			401	ALL
Forward or Racking Area			401	ALL
Roof Lamp				
Dashboard Floodlamps			402	ALL
LH or RH Dashboard Storm			402	ALL
Floodlamp				
Centre Dashboard Storm			402	ALL
Floodlamp				
Centre Console Floodlamp			405	ALL
Pilot's Chart Lamp			406	ALL
Pilot's Chart Stowage Lamp			407	ALL
Pilot's Floor Floodlamp			409	ALL
Pilot's Oxygen Mask			409	ALL
Stowage Floodlamp				
3CM Panel Floodlamps			411	ALL
3CM Reading Lamp			413	ALL
First Supernumerary's Floodlamp			415	ALL
Adjustment Test			501	ALL
General			501	ALL
Operational Test			501	ALL
Storm Lighting Test			504	ALL

PRINTED IN ENGLAND

# *Concorde*

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
<b>BALLAST UNITS</b>	<b>33-12-11</b>			
Removal/Installation			401	ALL
General			401	ALL
Storm Floodlight Ballast Unit			401	ALL
Racking Area Roof Lights			403	ALL
Ballast Unit				
Flight Compartment Roof Lights			404	ALL
Ballast Unit				
<b>LIGHTS TEST AND DIMMING</b>	<b>33-14-00</b>			
Description and Operation			1	ALL
General			1	ALL
Caption Light Module			1	ALL
Dimming Module			2	ALL
Test Isolation Relay			2	ALL
Operation			2	ALL
Electrical Power Supplies			6	ALL
Trouble Shooting			101	ALL
General			101	ALL
Preparation			101	ALL
Trouble Shooting			102	ALL
Removal/Installation			401	ALL
General			401	ALL
Test Isolation Relay			401	ALL
Adjustment/Test			501	ALL
General			501	ALL
Operational Test			501	ALL
<b>MASTER WARNING SYSTEM (MWS)</b>	<b>33-15-00</b>			
Description and Operation			1	ALL
General			1	ALL
Display Panel			3	ALL
Control Unit			4	ALL
Operation			5	ALL
System Management			27	ALL
Electrical Power Supplies			27	ALL
Trouble Shooting			101	ALL
General			101	ALL
Preparation			101	ALL
Trouble Shooting			102	ALL
Removal/Installation			401	ALL
General			401	ALL
B Adjustment/Test			501	ALL
B General			501	ALL
B Operational Test - Master			501	ALL
Warning System				

# Concorde

## MAINTENANCE MANUAL

	<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
B	Operational Test - Selected			505	ALL
	Master Warnings				
B	System Test			508	ALL
	MASTER WARNING CONTROL UNIT	33-15-11			
	Removal/Installation			401	ALL
	General			401	ALL
	Master Warning Control Unit			401	ALL
	MASTER WARNING DISPLAY PANEL	33-15-12			
	Removal/Installation			401	ALL
	General			401	ALL
	Master Warning Display Panel			401	ALL
	PANEL LIGHTING	33-16-00			
	Description and Operation			1	ALL
	General			1	ALL
	Electroluminescent Panels			1	ALL
	Operation			1	ALL
	Electrical Power Supplies			3	ALL
	Trouble Shooting			101	ALL
	General			101	ALL
	Preparation			102	ALL
	Trouble Shooting			103	ALL
	Maintenance Practices			201	ALL
B	General			201	ALL
	Removal/Installation			401	ALL
	General			401	ALL
	Electroluminescent Panels			401	ALL
	Circuit Breaker Lighting Bars			404	ALL
	Adjustment/Test			501	ALL
	General			501	ALL
	Operational Test			501	ALL
	INSTRUMENT LIGHTING	33-17-00			
	Description and Operation			1	ALL
	General			1	ALL
	Control Transformers			1	ALL
	Rotary 'Dimmer-off' Control			1	ALL
	Operation			1	ALL
	Electrical Power Supplies			6	ALL
	Trouble Shooting			101	ALL
	General			101	ALL
	Preparation			101	ALL
	Trouble Shooting			102	ALL
R	Removal/Installation			401	ALL

PRINTED IN ENGLAND

# *Concorde*

## MAINTENANCE MANUAL

	<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
R	General			401	ALL
	Adjustment/Test			501	ALL
	General			501	ALL
	Operational/Test			501	ALL
	100 VA AND 200 VA TRANSFORMERS	33-17-11			
	Removal/Installation			401	ALL
	General			401	ALL
	Centre Console, Centre Dash			401	ALL
	Panels and Glareshield Instrument				
	Lights 100VA Transformers				
	Right and Left Dash Panels			404	ALL
	Instrument Lights 100 VA				
	Transformers				
	Roof panel Instrument Light 100 VA			406	ALL
	Transformer and 3CM Station				
	(RH Panels) Instrument Lights				
	200 VA Transformer				
	3CM Centre and LH Instrument Lights			408	ALL
	200 VA Transformers				
	50 VA TRANSFORMER	33-17-12			
	Removal/Installation			401	ALL
	General			401	ALL
	50 VA Transformer			401	ALL

PRINTED IN ENGLAND



# Concorde

## MAINTENANCE MANUAL

<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
<b>PASSENGER COMPARTMENTS</b>	<b>33-20-00</b>			
Removal/Installation			401	ALL
General			401	ALL
Steward's Panel Components			401	ALL
<b>MAIN LIGHTING</b>	<b>33-21-00</b>			
Description and Operation			1	ALL
General			1	ALL
Roof Lamp Assembly			1	ALL
Wall Lamp Assembly			1	ALL
Operation			1	ALL
Electrical Power Supplies			4	ALL
B Trouble Shooting			101	ALL
B General			101	ALL
B Preparation			101	ALL
B Trouble Shooting			102	ALL
B Removal/Installation			401	ALL
B General			401	ALL
B Roof Lighting Fluorescent Tube			401	ALL
B Wall Lighting Fluorescent Tube			403	ALL
B Dim Lighting Filament			404	ALL
B Ballast Unit			405	ALL
Adjustment/Test			501	ALL
General			501	ALL
Functional Test			501	ALL
<b>TOILET LIGHTING</b>	<b>33-22-00</b>			
Description and Operation			1	ALL
General			1	ALL
Toilet Lighting Assembly			1	ALL
Operation			1	ALL
R Trouble Shooting			101	ALL
R General			101	ALL
R Preparation			101	ALL
R Trouble Shooting			102	ALL
Removal/Installation			401	ALL
General			401	ALL
Fluorescent Tubes			401	ALL
Standby Filament			403	ALL
Ballast Units			403	ALL
Toilet Door Microswitch			405	ALL
R Adjustment/Test			501	ALL
R General			501	ALL
Operational Test			501	ALL
<b>BOARDING, VESTIBULE AND SUPPLEMENTARY GALLEYS LIGHTING</b>	<b>33-23-00</b>			
Description and Operation			1	ALL
General			1	ALL

PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
Boarding Lamps			1	ALL
Vestibule Lanterns			1	ALL
Supplementary Galley Lighting			3	ALL
Supplies				
Operation			3	ALL
Trouble Shooting			101	ALL
General			101	ALL
Preparation			101	ALL
Trouble Shooting			102	ALL
Removal/Installation			401	ALL
General			401	ALL
Fluorescent Tube and			401	ALL
Standby Filament Renewal				
B Boarding Lamp Filament Renewal			403	ALL
B Vestibule Lantern and			404	ALL
Ballast Unit				
Adjustment/Test			501	ALL
General			501	ALL
Operational Test			501	ALL
Functional Test			502	ALL
WARDROBE LIGHTS	33-23-10			
B Maintenance Practices			201	ALL
B General			201	ALL
B Relamping			201	ALL
B Lamp Unit Removal/Installation			201	ALL
B Door Operated Microswitch			202	ALL
PASSENGER READING LIGHTS	33-24-00			
Description and Operation			1	ALL
General			1	ALL
Reading Lamps			1	ALL
Transformers			1	ALL
Operation			1	ALL
Electrical Power Supplies			3	ALL
Trouble Shooting			101	ALL
General			101	ALL
Preparation			101	ALL
Trouble Shooting			102	ALL
Removal/Installation			401	ALL
General			401	ALL
Reading Lamp Filament			401	ALL
600 VA Transformer			402	ALL
Adjustment/Test			501	ALL
General			501	ALL
Operational Test			501	ALL
PASSENGER SIGNS	33-25-00			
Description and Operation			1	ALL
General			1	ALL
'No Smoking' and 'Fasten			1	ALL
Seat Belts' Signs				

# *Concorde*

## MAINTENANCE MANUAL

<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
'Return to Seat'- Signs			1	ALL
'Toilets Occupied'- Signs			3	ALL
Operation			3	ALL
Trouble Shooting			101	ALL
General			101	ALL
Preparation			101	ALL
Trouble Shooting			102	ALL
Removal/Installation			401	ALL
General			401	ALL
'No Smoking' and 'Fasten Seat Belts' Filament Renewal			401	ALL
'Return to Seat' Filament Renewal			402	ALL
'Toilet Occupied' Ancillary Sign			403	ALL
Adjustment/Test			501	ALL
General			501	ALL
Operational Test			501	ALL
'No Smoking' Signs - Test of Operation in Conjunction with Oxygen System			503	ALL

<b>CALL SYSTEMS</b>	<b>33-27-00</b>			
Description and Operation			1	ALL
General			1	ALL
Operation			1	ALL
Trouble Shooting			101	001-005,
General			101	001-005,
Preparation			101	001-005,
Trouble Shooting - Flight Deck to Steward Call			102	001-005,
Trouble Shooting - Steward to Flight Deck Call			103	001-005,
Trouble Shooting Crew to Crew Call			103	001-005,
Trouble Shooting Passenger Cabin to Steward Call (Fwd. Cabin)			104	001-005,
Trouble Shooting - Passenger Cabin to Steward Call (Rear Cabin)			106	001-005,
Removal/Installation			401	ALL
General			401	ALL
Toilet-to-Steward Call			401	ALL
Indicator Lamp Switch				
Toilet Cancel-call			403	ALL
Indicator Lamp Switch				
Passenger Cabin-to-Steward Call			404	ALL
Indicator Lamp Switch				
Ceiling-mounted Indicator Lamp			406	ALL
Filament Renewal				
Adjustment/Test			501	ALL

# *Concorde*

## MAINTENANCE MANUAL

<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
General			501	ALL
Functional/Test			501	ALL
STEWARDS PANEL LIGHTING	33-28-00			
Description and Operation			1	ALL
General			1	ALL
B				
B				
B				
Removal/Installation			401	ALL
General			401	ALL
Electroluminescent Panels			401	ALL

PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

SUBJECT	CH/SE/SU	C	PAGE	EFFECTIV.
<b>BAGGAGE COMPARTMENT LIGHTING</b>	<b>33-31-00</b>			
Description and Operation			1	ALL
General			1	ALL
Filament Lamps			1	ALL
Floodlamps			1	ALL
Operation			3	ALL
R     Trouble Shooting			101	ALL
R     General			101	ALL
R     Preparation			101	ALL
R     Trouble Shooting			103	ALL
R     Removal/Installation			401	ALL
R     General			401	ALL
R     Baggage Compartment Filaments			401	ALL
R     Baggage Compartment Roof Lamp			403	ALL
R     Forward Baggage Compartment			404	ALL
Door Floodlamp				
R     Rear Baggage Compartment Door			405	ALL
Floodlamp				
R     Forward Baggage Compartment			406	ALL
Light Control Relay				
R     Rear Baggage Compartment			408	ALL
Light Control Relay				
R     Baggage Compartment Light			410	ALL
Control Switches				
Adjustment/Test			501	ALL
General			501	ALL
Operational Test			501	ALL
Functional Test			502	ALL
 <b>SERVICE LIGHTING</b>	 <b>33-32-00</b>			
Description and Operation			1	ALL
General			1	ALL
Service Lamp			1	ALL
Control Transformer			1	ALL
Operation			1	ALL
R     Trouble Shooting			101	ALL
R     General			101	ALL
R     Preparation			101	ALL
R     Trouble Shooting			102	ALL
R     Removal/Installation			401	ALL
R     General			401	ALL
R     Service Lamp Filament			401	ALL
R     Service Lamp			402	ALL
R     Adjustment/Test			501	ALL
R     General			501	ALL
R     Operational Test			501	ALL

PRINTED IN ENGLAND

# *Concorde*

## MAINTENANCE MANUAL

<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
115/5.9 V TRANSFORMER	33-32-32			
Removal/Installation			401	ALL
General			401	ALL
115/5.9 V Transformer			401	ALL

PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

	SUBJECT	CH/SE/SU	C	PAGE	EFFECTIV.
	NAVIGATION LIGHTS	33-41-00			
	Description and Operation			1	ALL
	General			1	ALL
	Wing Lamp Unit			1	ALL
	Tail Lamp Unit			1	ALL
	Operation			1	ALL
R	Trouble Shooting			101	ALL
R	General			101	ALL
R	Preparation			101	ALL
R	Trouble Shooting			102	ALL
R	Removal/Installation			401	ALL
R	General			401	ALL
R	Adjustment/Test			501	ALL
R	General			501	ALL
R	Operational Test			501	ALL
	NAVIGATION LIGHT ASSEMBLY (WINGS)	33-41-21			
R	Removal/Installation			401	ALL
R	General			401	ALL
R	Sealed Beam Unit - Renewal			401	ALL
R	Navigation light Transformer -			405	ALL
	Removal/Installation				
R	Sealed Beam Unit Support			406	ALL
	and Optical Guide -				
	Removal/Installation				
R	Leading Edge Lens Assembly -			407	ALL
	Removal/Installation				
	NAVIGATION/ANTI-COLLISION LIGHT	33-41-41			
	ASSEMBLY (TAIL)				
	Removal/Installation			401	ALL
	General			401	ALL
	Navigation/Anti-collision			401	ALL
	Light Assembly (Tail)				
B	Inspection/Check			601	ALL
	Inspection/Check			601	ALL
	ANTI-COLLISION LIGHTS	33-42-00			
	Description and Operation			1	ALL
	General			1	ALL
	Flasher Unit			1	ALL
	Power Unit			1	ALL
	Flashtube Lamp Assembly			1	ALL
	Operation			3	ALL
	Trouble Shooting			101	ALL
	General			101	ALL
	Preparation			101	ALL
	Trouble Shooting			102	ALL
	Removal/Installation			401	ALL
	General			401	ALL

PRINTED IN ENGLAND

# *Concorde*

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
Adjustment/Test			501	ALL
General			501	ALL
Operational Test			501	ALL
Functional Test			501	ALL
ANTI-COLLISION LIGHT ASSEMBLY	33-42-11			
(WINGS)				
Removal/Installation			401	ALL
General			401	ALL
Anti-collision Lamp			401	ALL
ANTI-COLLISION LIGHT POWER UNIT	33-42-12			
Removal/Installation			401	ALL
General			401	ALL
Anti-collision Light Power Unit			401	ALL
FLASHER UNIT	33-42-13			
B Removal/Installation			401	ALL
B General			401	ALL
B Flasher Unit			401	ALL
MAIN LANDING LIGHTS	33-43-00			
Description and Operation			1	ALL
General			1	ALL
Main Landing Lamps			1	ALL
Operation			1	ALL
Electrical Power Supplies			4	ALL
R Trouble Shooting			101	ALL
R General			101	ALL
R Preparation			101	ALL
R Trouble Shooting			102	ALL
R Removal/Installation			401	ALL
R General			401	ALL
Adjustment/Test			501	ALL
General			501	ALL
Operational Test			501	ALL
LANDING LIGHT ASSEMBLY	33-43-11			
Removal/Installation			401	ALL
General			401	ALL
Glass Cover			401	ALL
Sealed Beam Unit			402	ALL
Landing Lamp			404	ALL
Adjustment/Test			501	ALL
General			501	ALL
Beam Alignment Test			501	ALL
LAND/TAXI AND TURN OFF LIGHTS	33-44-00			
Description and Operation			1	ALL
General			1	ALL
Land/Taxi Lamps			1	ALL
Taxi/Turn-off Lamps			2	ALL
Land/Taxi Contactors			2	ALL



# Concorde

## MAINTENANCE MANUAL

	<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
	Taxi Turn-off Contactors			2	ALL
	Operation			3	ALL
	Electrical Power Supplies			5	ALL
R	Trouble Shooting			101	ALL
R	General			101	ALL
R	Preparation			101	ALL
R	Trouble Shooting			103	ALL
	Removal/Installation			401	ALL
	General			401	ALL
	Land/Taxi Light Control Contactor			401	ALL
	Taxi/Turn-off Lights Control			404	ALL
	Contactor				
	Adjustment/Test			501	ALL
	General			501	ALL
	Operational Test			501	ALL
	LAND/TAXI LIGHT	33-44-11			
	Removal/Installation			401	ALL
	General			401	ALL
	Lens			401	ALL
	Sealed Beam Unit Renewal			402	ALL
	Land/Taxi Lamp -			404	ALL
	Removal/Installation				
	Adjustment/Test			501	ALL
	General			501	ALL
	Beam Alignment Test			501	ALL
	TURN OFF LIGHT	33-44-12			
R	Removal/Installation			401	ALL
R	General			401	ALL
R	Sealed Beam Unit Renewal			401	ALL
R	Turn-off Lamp Removal/			403	ALL
	Installation				

PRINTED IN ENGLAND

# *Concorde*

## MAINTENANCE MANUAL

SUBJECT	CH/SE/SU	C	PAGE	EFFECTIV.
<b>EMERGENCY LIGHTING</b>				
Description and Operation			1	ALL
General			1	ALL
Flight Compartment Roof Lamps			1B	ALL
Emergency Lanterns			1B	ALL
Above-door Exit Signs			3	ALL
Exit Direction Signs			3	ALL
Threshold lamps			6	ALL
Battery Pack			6	ALL
Operation			6	ALL
Electrical Power Supplies			11	ALL
Trouble Shooting			101	ALL
General			101	ALL
Preparation			102	ALL
Trouble Shooting - System A			103	ALL
B Maintenance Practices			201	ALL
B General			201	ALL
B Testing			201	ALL
Additional Information/			203	ALL
Requirements				
Servicing			301	ALL
General			301	ALL
Battery Packs - Charging In Situ			301	ALL
Removal/Installation			401	ALL
General			401	ALL
Emergency Light Filaments -			401	ALL
Renewal				
Emergency Light Batteries -			403	ALL
Renewal				
Emergency Lantern			406	ALL
Exit Direction Sign			409	ALL
Over-Door Exit Sign			412	ALL
Door Threshold Lamp			413	ALL
Emergency Battery Pack			415	ALL
Adjustment/Test			501	ALL
General			501	ALL
System A Filaments - Operational			501	ALL
Test				
Battery Packs - Condition Test			503	ALL
Battery Packs - Capacity Test			504	ALL
System A Circuit - Operational			506	ALL
Test				
System B Circuit - Operational			507	ALL
Test				
<b>EMERGENCY ESCAPE PATH FLOOR</b>				
<b>PROXIMITY LIGHTING SYSTEM</b>				
B Trouble Shooting			101	ALL
B General			101	ALL
B Preparation			101	ALL

# *Concorde*

## MAINTENANCE MANUAL

	<u>SUBJECT</u>	<u>CH/SE/SU</u>	<u>C</u>	<u>PAGE</u>	<u>EFFECTIV.</u>
B	Trouble Shooting			101	ALL
B	Maintenance Practices			201	ALL
B	General			201	ALL
B	Deactivation			201	ALL
B	Reactivation			201	ALL
B	Conclusion			202	ALL
B	Battery Capacity			202	ALL
B	Transmitters (Control Modules)			203	ALL
B	Aisle Floodlights			203	ALL
B	Exit Identifier Lights			203	ALL
B	Adjustment/Test			501	ALL
B	General			501	ALL
B	"OFF TEST"			501	ALL
B	Terminate "OFF TEST"			504	ALL
RB	Functional Test			505	ALL
B	CONTROL MODULE (TRANSMITTER)	33-52-10			
B	Removal/Installation			401	ALL
B	Special Equipment Required			401	ALL
B	Removal			401	ALL
B	Installation			401	ALL
B	EXIT IDENTIFIER LIGHT	33-52-20			
B	Removal/Installation			401	ALL
B	Special Equipment Required			401	ALL
B	Removal			401	ALL
B	Installation			401	ALL
B	Battery Replacement			402	ALL
B	AISLE LIGHT UNIT	33-52-30			
B	Removal/Installation			401	ALL
B	Special Equipment Required			401	ALL
B	Removal			401	ALL
B	Battery Replacement			401	ALL
B	Installation			402	ALL

PRINTED IN ENGLAND

# *Concorde*

## MAINTENANCE MANUAL

### GENERAL - DESCRIPTION AND OPERATION

#### 1. General

Aircraft internal illumination is provided by an assortment of fluorescent, filament, electroluminescent, instrument integral, spot and flood lighting.

External lighting comprises landing and taxiing lights, runway turn-off lights, navigation lights and anti-collision lights.

In the flight compartment, a master warning system provides visible warning of failures within associated systems on an overhead display panel.

A visible/audible call system is provided between the flight compartment and stewards' stations, between stewards' stations, and between passenger and stewards to enable a passenger to summon a steward to any seat or toilet.

#### 2. Internal Lighting

Main lighting in the flight compartment is effected by fluorescent tubes mounted in the roof. Crew members' local areas are lit by spotlights and floodlights, in addition to high intensity storm lights for extra illumination of the dash panels to overcome the effects of glare through the windshields.

Control panel engravings are illuminated by associated electroluminescent panels, and instruments by integral lighting.

Each crew member has independent control of his local area lighting, panel lighting and instrument integral lighting.

Passenger cabins, vestibules and toilets are lit by fluorescent or filament lighting, which provides 'bright' or 'dim' illumination respectively, as selected. Passenger entrances are lit by spotlights, fitted close to floor level, one on each side of the forward and centre passenger doors.

Passengers are provided with individual reading lamps mounted on service panels fitted above each row of passenger seats. The service panels also incorporate steward call facilities. Signs in the passenger cabins and in the toilets, when illuminated, inform passengers that seat belts must be fastened, that smoking is forbidden and that passengers in toilets must return to their seats. Other signs, close to each toilet, indicate toilet availability.

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 1  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

Baggage compartments are lit by filament lamps mounted in the roof, and by a baggage compartment door floodlamp fitted close to each baggage compartment door entrance. Landing gear bays and equipment bays are equipped with service (filament) lamps to facilitate maintenance.

Two emergency lighting circuits are incorporated within the internal lighting system, one to provide internal illumination if the a.c. supplies to the main lighting system fails, the other to illuminate essential areas if the aircraft a.c. main supplies and d.c. essential supplies fail.

Spare filaments are stowed in a sliding stowage box (Ref. 25-13-00) fitted in the knee-hole recess between the forward and rear legs of the third crew member's (3CM) station basic structure.

### 3. External Lighting

One anti-collision lamp is mounted in each wing root leading edge and one in a tail lamp assembly in the tail cone. The three lights flash simultaneously.

One navigation lamp is mounted in the outer leading edge of each wing, and one, comprising two filaments, in the tail lamp assembly, one filament above and one below the tail anti-collision lamp.

Two main landing lamps, one mounted in each wing root leading edge, have retractable/extensible mountings, and when not in use are retracted in the lamp housing. Two land/taxi lamps, similar to the main landing lamps, are attached to the nose landing gear bay doors. The land/taxi lamps extend to an intermediate position for landing, upon which they automatically extend to the full position for taxiing, thus changing the beam angle to compensate for the attitude change.

Two taxi/turn-off lamps, one mounted on each side of the forward fuselage, provide ground illumination to identify runway turn-off points.

### 4. Flight Compartment Safety Check

Roof panel 4-211:

Pilots' EMERG light switch (mechanically locked)	...	OFF
MAIN LANDING LIGHTS switches	...	...
MAIN LANDING LIGHTS EXTEND/RETRACT switches	...	RETRACT
LANDING TAXI LIGHTS switches	...	...
LANDING TAXI LIGHTS EXTEND/RETRACT switches	...	RETRACT

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 2  
May 30/76

# Concorde

## MAINTENANCE MANUAL

TAXI TURN LIGHTS switches L and R...	...	...	OFF
ANTI COLN LIGHTS switch ...	...	...	OFF
NAV LIGHTS switch...	...	...	OFF
FASTEN SEAT BELTS switch ...	...	...	OFF
NO SMKG switch ...	...	...	OFF
ROOF LIGHTS switch ...	...	...	ON

Forward steward's control panel, 1-221:

Steward's EMERG light switch (mechanically locked)	NORMAL
VESTIBULE switch ...	BRIGHT
GROUND SERVICE switch ...	ON
FWD RACKING switch ...	ON
BOARDING light switch ...	ON
	(Night time only)

Oxygen panel, 20-215:

GRD LIGHTING switch ...	ON
RKG AREA LTS ROOF switch ...	ON
RKG AREA LTS INSP switch ...	OFF

### 5. Flight Compartment Preparation Check

CAUTION: TO CONSERVE THE LIFE OF THE ELECTROLUMINESCENT (EL) PANELS, ENSURE THAT THE ASSOCIATED EL PANEL LIGHTING CONTROL SWITCHES ARE OFF WHEN PANELS ARE NOT IN USE.

Roof panel, 4-211:

EMERG light switch ...	OFF - toggle lit
MAIN LANDING LIGHTS switches ...	OFF
MAIN LANDING LIGHTS EXTEND/RETRACT switches	RETRACT
MAIN LANDING LIGHTS EXTENDED caption ...	Extinguished
LANDING TAXI LIGHTS switches ...	OFF
LANDING TAXI LIGHTS EXTEND/RETRACT switches	RETRACT
LANDING TAXI LIGHTS EXTENDED caption ...	Extinguished
NAV LIGHTS switch...	As required
ANTI COLN LIGHTS switch ...	OFF
FASTEN SEAT BELTS switch ...	OFF
NO SMKG switch ...	OFF
STEWARD CALL indicator lamp/switch	Extinguished
Master warning LTS TEST/CANCEL switch	Press to cancel

Forward steward's control panel, 1-221:

EMERG light switch ...	NORMAL
------------------------	--------

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 3  
May 30/76

# Concorde

## MAINTENANCE MANUAL

In the flight compartment, verify:

Roof fluorescent tubes	...	...	... Lit
Emergency lights	...	...	... Extinguished

In the forward vestibule, verify:

Roof fluorescent tubes	...	...	... Lit
Boarding lamps	...	...	... Lit
Cabin emergency lights	...	...	... Extinguished

LH side switch panel, 12-211:

LH DASH INSTRUMENTS rotary switch...	...	...	... OFF
LH AND CENTRE DASH FLOOD rotary switch	...	...	... Rotate as required
CHART LIGHT push-switch	...	...	... Press for 'on'
CHART LIGHT DIM rotary switch	...	...	... Rotate as required
COMPASS toggle switch	...	...	... As required
STOWAGE FLOOD toggle switch	...	...	... As required
D/B LIGHT TEST toggle switch	...	...	... HI (spring-return from TEST)

LH side console, panel 1-211-2:

SIDE CONSOLE rotary switch	...	...	... OFF
DIGITS rotary switch	...	...	... OFF

Roof panel, 4-211:

LIGHTING - STORM rotary switch	...	...	... OFF
LIGHTING - GLARESHIELD rotary switch	...	...	... OFF
LIGHTING - CENTRE CONSOLE PANEL rotary switch	...	...	... OFF
LIGHTING - CENTRE DASH rotary switch	...	...	... OFF
LIGHTING - CENTRE CONSOLE FLOOD switch	...	...	... OFF
LIGHTING - ROOF rotary switch	...	...	... OFF

RH side switch panel, 5-212:

RH DASH INSTRUMENTS rotary switch...	...	...	... OFF
RH DASH FLOOD rotary switch	...	...	... Rotate as required
CHART LIGHT push-switch	...	...	... Press for 'on'
CHART LIGHT DIM rotary switch	...	...	... Rotate as required
RADAR ALERT (if fitted) toggle switch	...	...	... OFF
STOWAGE FLOOD toggle switch	...	...	... As required
D/B LIGHT TEST toggle switch	...	...	... HI (spring-

EFFECTIVITY: ALL

BA

Printed in England

# 33-00-00

Page 4  
May 30/76

# Concorde

## MAINTENANCE MANUAL

return from  
TEST)

RH side console, panel 1-212-2:

SIDE CONSOLE rotary switch	...	...	OFF
DIGITS rotary switch	...	...	OFF
On panel 6-214, MWS CANCEL push-switch	...	...	Press to cancel

3CM lighting control panel, 11-214:

LIGHTING - SPOT rotary switch	...	...	As required
LIGHTING - FLOODS rotary switch	...	...	As required
LIGHTING - C/B toggle switch	...	...	ON
LIGHTING - PANEL rotary switch	...	...	OFF
LIGHTING - DIGITS rotary switch	...	...	OFF

Lighting control panel on CB panel, 3-213:

LIGHTING - PANEL toggle switch	...	...	OFF
LIGHTING - FLOOD rotary switch	...	...	As required

### 6. Walk Round Check

A. Flight Compartment Main Lighting (Ref. Fig.001 and 002)

LH side panel, 12-211:

LH AND CENTRE DASH FLOOD rotary switch	...	Rotate - LH and centre dashboard floodlamps lit dim to bright as selected.
CHART LIGHT push-switch	...	Press - LH chart lamp lit.
CHART LIGHT DIM rotary switch	...	Rotate - LH chart lamp lit dim to bright as selected.
STOWAGE FLOOD toggle switch	...	ON - LH chart stowage and floor floodlamps lit.

Roof panel, 4-211:

CENTRE CONSOLE FLOOD rotary switch	...	Rotate - centre console floodlamp lit dim to bright as selected.
STORM rotary switch	...	Rotate - LH, RH and centre dashboard storm floodlamps lit as selected.
ROOF toggle switch	...	ON - forward roof lamp lit.

RH side switch panel, 5-212:

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 5  
May 30/76



# *Concorde*

## MAINTENANCE MANUAL

RH DASH FLOOD rotary... switch	...	Rotate - RH dashboard floodlamp lit dim to bright as selected.
CHART LIGHT push-switch	...	Press - RH chart lamp lit.
CHART LIGHT DIM rotary switch	...	Rotate - RH chart lamp lit dim to bright as selected.
STOWAGE FLOOD toggle... switch	...	ON - RH chart stowage and floor floodlamps lit.

### 3CM lighting control panel, 11-214:

LIGHTING - FLOODS rotary switch	...	Rotate - 3CM floodlamps lit dim to bright as selected.
LIGHTING - SPOT rotary switch	...	Rotate - 3CM spotlight lit dim to bright as selected.

### Circuit breaker panel, 3-213:

LIGHTING - FLOOD rotary switch	...	Rotate - 1st super. Flood-lamp lit dim to bright as selected.
--------------------------------	-----	---

### Oxygen panel, 20-215:

RKG AREA LTS - ROOF toggle switch	...	ON - racking area roof lamp lit.
RKG AREA LTS - INSP toggle switch	...	ON - racking inspection lamps lit.

### Forward steward's control panel, 1-221:

FWD RACKING toggle switch	...	ON - racking area roof lamp lit.
---------------------------	-----	----------------------------------

### B. Lights Test and Dimming (Ref. Fig.003 and 004)

NOTE: Each test switch has three positions as follows:-

TEST:	associated filaments lit at full brilliance.
HI:	associated filaments lit at full brilliance when activated by their own system.
LO:	associated filaments lit at reduced

EFFECTIVITY: ALL

BA

Printed in England

# 33-00-00

Page 6  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

brilliance when activated by their own system.

### LH side switch panel, 12-211:

D/B LIGHT TEST toggle switch	...	Controls instrument lighting on LH console, LH dashboard and landing display units on LH and RH forward racking shelves.
------------------------------	-----	--

### Roof panel, 4-211:

LIGHTS TEST toggle switch	...	Controls instrument lighting on roof panel, except master warning display.
---------------------------	-----	--

### RH side switch panel, 5-211:

D/B LIGHT TEST toggle switch	...	Controls instrument lighting on RH dashboard and RH console.
------------------------------	-----	--

### Aft centre console, panel 9-211:

LIGHTS TEST toggle switch	...	Controls instrument lighting on centre console and centre dashboard.
---------------------------	-----	--

### Brake panel, 12-214:

LIGHTS TEST toggle switch	...	Controls instrument lighting on 3CM forward panels.
---------------------------	-----	---

### Lower electrical panel, 6-214:

LIGHTS TEST CTR toggle switch	...	Controls instrument lighting on 3CM centre panels.
-------------------------------	-----	--

LIGHTS TEST AFT toggle switch	...	Controls instrument lighting on 3CM aft panels.
-------------------------------	-----	---

### C. Master Warning System (Ref. Fig. 005 )

#### Master warning display panel, 4-211:

LTS TEST/CANCEL	...	Press and hold - all
-----------------	-----	----------------------

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 7  
May 30/76

# MAINTENANCE MANUAL

Lower electrical panel, 6-214:

D. Panel Lighting (Ref. Fig.006 and 007)

Roof panel, 4-211:

LH side switch panel, 12-211:

LH side console panel, 1-211-2:

LH side panel, 5-212:

BA

**33-00-00**

Page 8  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

RH DASH INSTRUMENT rotary ... Rotate - EL panels on  
switch RH dash panel lit.

RH side console panel, 1-212-2:

SIDE CONSOLE rotary ... Rotate - EL panel on  
switch side console and on  
side switch panel lit.

3CM lighting control panel, 11-214:

PANEL rotary switch ... Rotate - EL panels at 3CM  
station lit.  
C/B toggle switch ... ON - lighting bars on  
circuit breaker panels  
in zone 213 lit.

Circuit breaker panel, 3-213:

PANEL toggle switch ... On - local EL panel and  
oxygen EL panel 20-215  
lit.

E. Instrument Lighting (Ref. Fig.008 and 009)

Roof panel, 4-211:

CENTRE CONSOLE PANEL ... Rotate - instruments  
rotary switch integral lighting on  
centre console lit dim  
to bright as selected.  
GLARESHIELD rotary ... Rotate - instruments  
switch integral lighting on  
centre glareshield lit  
dim to bright as  
selected.  
CENTRE DASH rotary ... Rotate - instruments  
switch integral lighting on  
centre dash panel lit  
dim to bright as  
selected.  
ROOF rotary switch ... Rotate - instruments  
integral lighting on  
roof panel lit dim to  
bright as selected.

LH side switch panel, 12-211:

COMPASS toggle switch ... DIM - compass in  
windscreen centre pillar  
lit at reduced brilliance.  
BRIGHT - compass lit

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 9  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

LH DASH INSTRUMENTS ... at full brilliance.  
rotary switch ... Rotate - instruments  
integral lighting on LH  
dash panel lit dim to  
bright as selected.

### LH side console, panel 1-211-2:

SIDE CONSOLE rotary ... Rotate - instruments  
switch ... integral lighting on  
LH side console lit  
dim to bright as  
selected.  
DIGITS rotary switch... Rotate - digital display  
in LH dash panel and  
digital display (if  
fitted) in centre  
glare shield lit as  
selected.

### RH side switch panel, 5-212:

RH DASH INSTRUMENTS ... Rotate - instruments  
rotary switch ... integral lighting on  
RH dash panel lit dim  
to bright as selected.

### RH side console, panel 1-212-2:

SIDE CONSOLE rotary ... Rotate - instruments  
switch ... integral lighting on  
RH side console lit dim  
to bright as selected.  
DIGITS rotary switch... Rotate - digital display  
in RH dash panel and  
digital display (if  
fitted) in centre  
glare shield lit as  
selected.

### 3CM lighting control panel, 11-214:

PANEL rotary switch ... Rotate - instruments  
integral lighting at  
3CM station lit dim to  
bright as selected.

### Circuit breaker panel, 3-213:

PANEL toggle switch ... ON - station box, 7-213,  
and headset jack box,

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 10  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

20-215, lit.

### F. Passenger Cabin Main Lighting (Ref. Fig. 010 )

Forward steward's control panel, 1-221:

LIGHTING CONTROLS - ... ... MAIN

MAIN CABIN FWD toggle  
switch

FWD SELECT toggle switch ... FULL - wall and roof  
fluorescent tubes in  
forward cabin lit.  
CEILING - only roof  
fluorescent tubes in  
forward cabin lit.  
WALL - only wall  
fluorescent tubes in  
forward cabin lit.

MAIN CABIN FWD toggle switch ... DIM - only filament  
lamps in forward cabin  
lit.

MAIN CABIN AFT toggle switch and SELECT AFT  
toggle switch ... As above, but for rear  
cabin.

### G. Toilet Lighting

There are no individual  
switches, but when ground  
power connected ...

... All fluorescent tubes  
in each toilet are lit  
regardless of toilet door  
position.

### H. Boarding and Vestibule Lighting (Ref. Fig. 011 )

Forward steward's control panel, 1-221:

LIGHTING - VESTIBULE... toggle switch ... DIM - filament lamps in  
vestibule lanterns lit.  
BRIGHT - filament lamps  
extinguished, fluorescent  
tubes in vestibule lanterns  
lit.

BOARDING toggle switch ... ON - boarding lamps at  
forward passenger door  
lit.

Centre steward's control panel, 1-223:

EFFECTIVITY: ALL

BA

# 33-00-00

Page 11  
May 30/76

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

LIGHTING - VESTIBULE ... BRIGHT - fluorescent tubes  
toggle switch in centre vestibule lantern  
lit.  
DIM - fluorescent lights  
extinguished; filament  
lamps in vestibule  
lantern lit.

BOARDING toggle switch ... ON - boarding lamps at  
centre passenger door  
lit.

Rear steward's control panel, 1-241:

LIGHTING - VESTIBULE... ... BRIGHT - fluorescent tubes  
toggle switch in rear vestibule lantern  
lit.  
DIM - fluorescent lights  
extinguished; filament  
lamps in vestibule lantern  
lit.

### I. Passenger Reading Lights (Ref. Fig. 012 )

Passenger service unit, above each passenger seat:

Reading lamp switch ... ... Press and release -  
associated reading lamp  
lit. Press and release  
again - reading lights  
extinguished.

### J. Passenger Signs (Ref. Fig. 013 )

Roof panel, 4-211:

NO SMKG toggle switch ... ON - 'no smoking' signs  
in cabins illuminated,  
indicator lamp on each  
steward's panel lit, exit  
signs illuminated  
(Ref. Fig.20) and low  
tone signal relayed  
through PA system.  
OFF - signs and indicator  
lights extinguished  
and low tone signal  
relayed through PA system.

FASTEN SEAT BELTS ... ON - 'fasten seat belts'  
toggle switch signs illuminated,

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 12  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

indicator lamp on each steward's panel lit, low tone signal relayed through PA system and 'return to cabin' sign in each toilet illuminated.

OFF - signs and indicator lights extinguished and low tone signal relayed through PA system.

Forward toilet 'toilet occupied' signs:

Operated by toilet door microswitch	...	...	Toilet door closed and bolted - forward 'toilet occupied' sign illuminated. Door unbolted - sign light extinguished.
-------------------------------------	-----	-----	--

Centre toilets 'toilet occupied' signs:

All toilet door microswitches	...	...	All centre toilet doors closed and bolted - centre 'toilet occupied' signs illuminated. One toilet door open - sign lights extinguished.
-------------------------------	-----	-----	--

K. Call Systems (Ref. Fig.014 and 015)

Roof panel, 4-211:

STEWARD CALL push-switch	...	...	Press and release - tone signal audible through PA system, indicator lamp on each steward's panel and the cabin call ceiling lamps lit.
--------------------------	-----	-----	---

Forward steward's call panel and centre and rear steward's control panels, 2-221, 1-223 and 1-241:

FLIGHT DECK CANCEL push-switch	...	...	Press and release - indicator lights on steward's panels and cabin call ceiling lights extinguished.
FLIGHT DECK CALL push-switch	...	...	Press and release - STEWARD CALL indicator

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 13  
May 30/76



# *Concorde*

## MAINTENANCE MANUAL

lamp on roof panel,  
4-211, lit and then  
extinguished.

CABIN CREW CALL      ...      Press and release -  
push-switch                              tone signal relayed  
   through PA system in  
   vestibule areas.

Passenger service unit (PSU), above passenger seats:

Forward cabin PSU call      ...      Press and release -  
push-switch                              knob lit, tone signal  
   audible in vestibule areas,  
   CABIN CALL indicator lamps  
   on forward and centre  
   steward's panels lit  
   and ceiling indicator lamps  
   in forward cabin lit.  
   Press and release again -  
   all associated indicator  
   lights extinguished.

Rear cabin PSU call ...      Press and release - knob  
push-switch                              lit, tone signal  
   audible in vestibule  
   areas, CABIN CALL  
   indicators on centre and  
   rear steward's panel lit  
   and ceiling indicators  
   in rear cabin lit. Press  
   and release again - all  
   associated indicator  
   lights extinguished.

Forward toilet:

Steward call push-switch      ...      Press and release -  
   knob lit, tone signal  
   audible in vestibule  
   areas, TOILET indicator  
   on each steward's panel  
   lit, ceiling indicator  
   lamps lit and indicator  
   lamp outside the toilet  
   door lit. Press and  
   release indicator lamp  
   outside the toilet door -  
   all associated indicator  
   lights extinguished.

Centre toilets:

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 14  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

Steward call push-switch ... Press and release - knob lit, tone signal audible in vestibule areas, TOILET indicators on each steward's panel lit, ceiling indicator lamps lit, and indicator lamp outside the toilet door lit. Press and release indicator lamp outside the toilet door - all associated lights extinguished.

### L. Baggage Compartment Lighting (Ref. Fig. 016 )

Forward baggage compartment ... Baggage compartment roof door open. Light switched 'on' ... lamps and door flood lamp lit.  
Light switch 'off' ... Light extinguished.  
Rear baggage compartment ... Baggage compartment roof door open. Light switch 'on' ... lamps and door floodlamp lit.  
Light switch 'off' ... Lights extinguished.

### M. Service Lighting

Oxygen panel, 20-215:

GRND LIGHTING control ... ON - all service lamps toggle switch lit.

Refuelling panel access door:

Open ... Door floodlamp lit and instruments on panel integrally lit.

### N. Navigation Lights (Ref. Fig. 017 )

Roof panel, 4-211:

NAV toggle switch ... ON - wing and tail navigation lamps lit.

### O. Anti-collision Lights (Ref. Fig. 017 )

Roof panel, 4-211:

ANTI COLN toggle switch ... ON - wing and tail anti-collision lamps

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 15  
May 30/76

# Concorde

## MAINTENANCE MANUAL

show flashing red light  
working synchronously.

### P. Main Landing Lights (Ref. Fig. 018 )

**CAUTION:** DO NOT LEAVE LANDING LAMPS LIT FOR MORE THAN 5 min  
IN ANY 10 min PERIOD.

Roof panel, 4-211:

MAIN LANDING EXTEND/...	...	Both EXTEND - lamps
RETRACT toggle switches		travel to fully extend
		position.
		EXTEND caption illuminated.
MAIN LANDING LIGHTS ...	...	Both ON - both landing
toggle switches		lamps lit.
MAIN LANDING EXTEND/...	...	RETRACT - both landing
RETRACT toggle switches		lights and EXTENDED
		caption light
		extinguished. Both
		lamps retract into
		their housings.
MAIN LANDING LIGHTS ...	...	OFF
toggle switch		

### Q. Land/Taxi and Turn-off Lights (Ref. Fig. 019 )

**CAUTION:** DO NOT LEAVE LAND/TAXI LAMP LIT FOR MORE THAN  
5 min IN ANY 10 min PERIOD.

Roof panel, 4-211:

LANDING TAXI EXTEND/...	...	Both EXTEND - lamps
RETRACT toggle switches		travel to fully
		extended (taxi)
		position.
		EXTENDED caption
		illuminated.
LANDING TAXI LIGHTS ...	...	Both ON - taxi
toggle switches		filament in both
		lamps lit.
LANDING TAXI EXTEND/...	...	RETRACT - both landing
RETRACT toggle switches		taxi lights and
		EXTENDED caption light
		extinguished. Both
		lamps retract into
		their housings.
LANDING TAXI LIGHTS ...	...	OFF
toggle switches		
TAXI/TURN L and R ...	...	ON - associated taxi
Lights control toggle		turn-off lamp lit.

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 16  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

switches OFF.

### R. Emergency Lighting (Ref. Fig. 020 )

CAUTION: ALL CHECKS WITH 6 V EMERGENCY LIGHTING MUST BE COMPLETED AS SOON AS POSSIBLE TO CONSERVE THE LIFE OF THE BATTERIES.

Forward steward's control panel, 1-221:

EMERG toggle switch ... .. NORMAL.

Roof panel, 4-211:

LIGHTS EMERG toggle switch... OFF - toggle lit.  
ARM - toggle light  
extinguished.

Forward steward's control panel, 1-221:

EMERG toggle switch ... .. Press and hold at  
TEST - 6 V filaments  
in emergency lamps,  
lanterns and exit signs  
lit.  
Release switch to  
NORMAL - all emergency  
filaments extinguished.

Roof panel, 4-211:

LIGHTS EMERG toggle switch... ON - 6 V filaments  
in emergency lamps,  
lanterns and exit signs  
lit.  
OFF - all 6 V emergency  
lights extinguished.

Forward steward's control panel, 1-221:

EMERG toggle switch ... .. ON - 6 V filaments in  
emergency lamps,  
lanterns and exit signs  
lit.  
NORMAL - 6 V filament  
lights extinguished.

Roof panel, 4-211:

LIGHTS EMERG toggle switch... OFF - toggle lit, all  
emergency lights

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 17  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

NO SMKG toggle switch	extinguished.
...	ON - 28 V filaments in
	exit signs and vestibule
	exit signs lit.
	OFF - filament lights in
	signs extinguished.

### 7. Sub-system Management (Ref. Figs.001 to 020)

Management procedures for internal and external lighting, master warning, call systems and warning signs, which enable systems to be operated, either to prove the system or for servicing purposes, are carried out at switches on panels in the flight compartment, on each steward's panel, on passenger service units and at each toilet. To enable these procedures to be carried out, electrical ground power must be connected and switched on as detailed in 24-41-00.

EFFECTIVITY: ALL


BA

Printed in England

**33-00-00**

Page 18  
May 30/76

CB15010/00A



CME 33 00 00 0 AAM0

Sub-system Management  
(Main Lighting, Flight Compartment Forward)  
Figure 001

EFFECTIVITY: ALL

BA

Printed in England


**33-00-00**

Page 19  
May 30/76

# Concorde

## MAINTENANCE MANUAL

CB15011/00A



CMB 33 00 00 0 8AM0

Sub-system Management  
(Main Lighting, Flight Compartment Rear)  
Figure 002

EFFECTIVITY: ALL

BA


Printed in England

33-00-00

Page 20  
May 30/76

# Concorde

## MAINTENANCE MANUAL



### WHEN A SWITCH IS SET AT:-

TEST: all associated filaments, which are serviceable, are lit at full brilliance.

HI: all associated filaments are preset to light at full brilliance when activated by their own systems.

LO: all associated filaments are preset to light at reduced brilliance when activated by their own systems.

NOTE: The following filaments are not dimmed by the Lights Test and Dimming circuit:-

- |                             |                            |
|-----------------------------|----------------------------|
| (a) Inner elevator          | (d) Throttle control       |
| (b) Terrain                 | (e) Jack supplies          |
| (c) Engine shut down detect | (f) Emergency light switch |

- Sub-system Management  
(Lights Test and Dimming, Flight Compartment Forward)  
Figure 003

EFFECTIVITY: ALL

BA

**33-00-00**


Page 21  
Feb 29/80

Printed in England



# Concorde

## MAINTENANCE MANUAL



### WHEN A SWITCH IS SET AT:-

**TEST:** all associated filaments, which are serviceable, are lit at full brilliance.

**HI:** all associated filaments are preset to light at full brilliance when activated by their own systems.

**LO:** all associated filaments are preset to light at reduced brilliance when activated by their own systems.

**NOTE:** The following filaments are not dimmed by the Lights Test and Dimming circuit:-

- (a) Engine starting control
- (b) Torching flame detection
- (c) Fuel flow
- (d) Engine feed LP shut

- Sub-system Management  
(Lights Test and Dimming, Flight Compartment Rear)  
Figure 004

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**

Page 22  
May 30/76

# Concorde

## MAINTENANCE MANUAL



- Sub-system Management (Master Warning)  
Figure 005

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**

Page 23  
May 30/76

# Concorde

## MAINTENANCE MANUAL



Sub-system Management  
(Panel Lighting, Flight Compartment Forward)  
Figure 006

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 24  
May 30/76


# Concorde

## MAINTENANCE MANUAL

### CIRCUIT BREAKER LIGHTING BAR CONTROL SWITCH


Controls the EL  
lighting of the  
circuit breaker  
lighting bars on  
CB panels  
1-213 to 5-213

CB12682/00A





### PANEL LIGHTING SWITCH

Controls EL panel lighting  
at the 3CM station,  
zone 214.



### PANEL LIGHTING SWITCH

Controls EL panel lighting  
on the panel on which the switch  
is mounted and EL lighting at  
the oxygen and jack box panel  
20-215.



CMB 33 00 00 0 G A M O

- Sub-system Management  
(Panel Lighting, Flight Compartment Rear)  
Figure 007

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**

Page 25  
May 30/76

# Concorde

## MAINTENANCE MANUAL



Sub-system Management  
(Instrument Lighting, Flight Compartment Forward)  
Figure 008

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**


Page 26  
May 30/76

# Concorde

## MAINTENANCE MANUAL



HEADSET JACKBOX 20-215



Sub-system Management  
(Instrument Lighting, Flight Compartment Rear)  
Figure 009

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**

Page 27  
May 30/76

# Concorde

## MAINTENANCE MANUAL



- Sub-system Management  
(Main Lighting, Passenger Compartments)  
Figure 010

EFFECTIVITY: ALL


BA

Printed in England

**33-00-00**

Page 28  
May 30/76

CE15012/00A



CMB 33 00 00 0 LAM0

Sub-system Management  
(Boarding and Vestibule Lighting)  
Figure 011

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**


Page 29  
May 30/76



# Concorde

## MAINTENANCE MANUAL

CB12747/008



- Sub-system Management (Passenger Reading Lights)  
Figure 012

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**

Page 30  
May 30/76

# Concorde

## MAINTENANCE MANUAL



Sub-system Management (Passenger Signs)

Figure D13

R

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND


**33-00-00**

Page 31  
May 31/03

# Concorde

## MAINTENANCE MANUAL

CB13055/00A



CMB 33 00 00 0 PANO

- Sub-system Management (Call Systems, Crew-to-Crew)  
Figure 014

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**

Page 32  
May 30/76

# Concorde

## MAINTENANCE MANUAL



Sub-system Management  
(Call Systems, Passenger-to-Crew)  
Figure 015

EFFECTIVITY: ALL

BA

Printed in England


**33-00-00**

Page 33  
May 30/76

# Concorde


## MAINTENANCE MANUAL

CB15014/00A



### FORWARD BAGGAGE COMPARTMENT LIGHT CONTROL SWITCH

Controls the forward  
baggage compartment  
roof lights and the  
door floodlight when  
baggage compartment  
door is open.



### REAR BAGGAGE COMPARTMENT LIGHT CONTROL SWITCH

Controls the rear  
baggage compartment  
roof lights and the  
door floodlight when  
baggage compartment  
door is open.

CMB 33 00 00 0 SAMO

### Sub-system Management (Baggage Compartment Lighting) Figure 016

EFFECTIVITY: ALL

BA

Printed in England


# 33-00-00

Page 34  
May 30/76

# Concorde

## MAINTENANCE MANUAL

CB15015/00A



CMB 33 00 00 0 TAMO

- Sub-system Management  
(Navigation and Anti-Collision Lights)  
Figure 017

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**

Page 35  
May 30/76

# Concorde

## MAINTENANCE MANUAL



CBI 2909/00A

CMB 33 00 00 0 UAM0

- Sub-system Management (Main Landing Lights)  
Figure 018

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**

Page 36  
May 30/76

# Concorde

## MAINTENANCE MANUAL



- Sub-system Management (Land/Taxi and Turn-off Lights)  
Figure 019

R

EFFECTIVITY: ALL

BA

Printed in England


**33-00-00**

Page 37  
Feb 28/78



# Concorde


## MAINTENANCE MANUAL



### SYSTEM A STEWARD'S EMERGENCY LIGHT SWITCH

- ON** - Activates the emergency battery packs to light all exit signs, roof lanterns and door threshold lamps.
- NORMAL** - Connects the battery pack and its associated electronic switching to the ARM circuit on the pilots' roof panel.
- TEST** - As for ON but spring-loaded to return the toggle to NORMAL

AC 001006




### PILOTS' EMERGENCY LIGHT SWITCH

- ON** - Activates the emergency battery packs to light all exit signs, roof lanterns and door threshold lamps.
- ARM** - Connects 28 V d.c. to each battery pack to charge the batteries and to arm the electronic switching so that it is activated if supply fails.
- OFF** - Disarms the electronic switching in each battery pack so that the switching is not activated by subsequent switching off of the 28 V d.c. supply.

**NOTE:** The switch toggle is illuminated in the off position.

**SYSTEM B  
PILOTS' NO SMOKING SWITCH (REF. FIG.13)**  
Additionally illuminates all exit signs and lights the 28 V d.c. filament lighting in each vestibule, cabin and toilet.



AC 007007

Sub-system Management (Emergency Lighting)  
Figure D20

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

33-00-00

Page 38  
May 31/03

# *Concorde*

## MAINTENANCE MANUAL

### GENERAL - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General (Ref. Fig. 401 )

This topic contains general instructions for the removal and installation of sub-system control switches, and landing lamp and land/taxi lamp caption light modules, with the legend EXTENDED, that are fitted to the flight compartment roof panel.

All switches are mounted from the rear of the roof panel, access being gained by lowering the appropriate section of the panel on its hinges (Ref. Chap.31) or by releasing the quick-release fasteners and withdrawing the panel sub-assembly from its mounting to the extent of the cables. Caption light modules are mounted from the front of the panel and clamped to the panel from the rear.

Electrical connections to toggle switches and push-switches are made to screw-type or socket-type terminals, to rotary switches by flying leads, and to caption light modules by socket-type terminals.

Cable formers, which also act as panel stiffeners, on the rear of the roof panel, support the cable looms, tag boards and terminal blocks which may restrict access to terminals or connectors. Tag boards and terminal blocks may be temporarily moved to allow easier access.

R A heat shield comprising two sections encloses the body of  
R the centre console floodlight dimmer/off switch. One  
R section is bolted to the cable former on the rear of the  
R switch panel and the other section to the adjacent diode  
R board.

#### 2. Switches and Caption Light Modules - Flight Compartment Roof Panel (Ref. Fig.402 and 403)

CAUTION: ELECTROLUMINESCENT PANELS ARE VULNERABLE TO DAMAGE BY SCRATCHING AND CRACKING. ENSURE THAT TOOLS USED IN THE FOLLOWING OPERATIONS DO NOT DAMAGE THE POLISHED WALLS OF THE ELECTROLUMINESCENT PANEL.

##### A. Equipment and Materials

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**

Page 401  
May 30/76

# Concorde

## MAINTENANCE MANUAL



- Flight Compartment Roof Panel (4-211) -  
Diagrammatic Rear View  
Figure 401

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 402  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

### B. Prepare

- (1) For switches on the rear switch panel, isolate the electrical generation and external power supplies as detailed in 24-00-00, Servicing. For switches and caption light modules on the forward switch panel, trip all the circuit breakers listed below and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH LDG LT CONT	13-215	L21	B11
LH LDG LT CONT	14-216	L22	D8
LDG LTS POSN IND	15-216	L23	A12
RH LDG LT SUP	13-215	L24	C12
LH LDG LT SUP	14-216	L25	C8
LH LDG/TAXI LT CONT	14-215	L41	E11
RH LDG/TAXI LT CONT	13-216	L42	B9
LDG/TAXI LTS POSN IND	15-215	L43	A13
LH LDG/TAXI LT SUP	14-215	L45	E10
RH LDG/TAXI LT SUP	13-216	L46	B8
TAXI/TURN OFF LTS CONT	15-216	L44	B13
RH TAXI/TURN OFF LT SUP	15-216	L48	B12

EFFECTIVITY: ALL

R

BA

Printed in England

# 33-00-00

Page 403  
May 30/76

# Concorde

## MAINTENANCE MANUAL

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
LH TAXI/TURN OFF LT SUP	15-215	L47	A14
LH W/SCREEN HTR CONT	1-213	1H142	J9
RH W/SCREEN HTR CONT	15-216	2H142	B17
LH FLAT VISOR HTR CONT	15-215	1H222	C11
LH BOTTOM AND CURVED VISOR HTR CONT	15-215	1H224	C12
RH FLAT VISOR HTR CONT	15-216	2H222	C15
RH BOTTOM AND CURVED VISOR HTR CONT	15-216	2H224	C16
LH DV WINDOW HTR CONT	15-215	1H182	C10
RH DV WINDOW HTR CONT	15-216	2H182	C14

- (2) Gain access to the appropriate switch by lowering the rear switch panel on its hinges, or by releasing the quick-release fasteners and withdrawing the forward switch panel from its mounting, as applicable.

### C. Remove Toggle Switch or Push-switch

- (1) On a switch with screw-type terminals, roll back the rubber terminal cover and disconnect the electrical cables from the switch. On a switch with socket-type terminals, using a suitable tool,

EFFECTIVITY: ALL

R

BA

**33-00-00**

Page 404  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

withdraw the pin inserts.

- (2) Where necessary unscrew the push-switch knob. Using a tubular spanner, remove the nut and washer from the front of the panel and withdraw the switch and tab washer from the rear.

### D. Install Toggle Switch or Push-switch

- (1) Comply with the electrical safety precautions.
- (2) Position the tab washer on the switch and insert the switch through the aperture from the rear of the panel, ensuring that the tab on the tab washer engages the locating hole in the panel.
- (3) Secure the switch with the nut and washer. Where necessary, refit the push-switch knob.
- (4) Connect the electrical cables to the switch, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram. Position the rubber terminal cover over the screw-type terminals.

### E. Remove Rotary Switch

- R (1) CENTRE CONSOLE FLOOD light dimmer/off switch only:
- R (a) Remove the bolts securing the terminal block  
R and one section of the heat shield to the  
R cable former.
- R (b) Ease the terminal block clear of the switch  
R and withdraw the section of the heat shield  
R from the switch body.
- R (c) Remove the bolt securing the second section  
R of the heat shield to the diode board and  
R withdraw the section of the heat shield from  
R the switch body.
- R (2) Release the flying leads from the loom ties and,  
using a suitable tool, withdraw the pin inserts  
from the module block.
- R (3) Remove the cap from the end of the switch knob,  
loosen the clutch nut and withdraw the knob from  
the switch spindle.
- R (4) Using a tubular spanner, remove the nut and washer

EFFECTIVITY: ALL

BA


Printed in England

**33-00-00**

Page 405  
May 30/76

# Concorde

## MAINTENANCE MANUAL



Switches - Installation  
Figure 402

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 406  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

from the front of the panel and withdraw the switch from the rear.

### F. Install Rotary Switch

- (1) Comply with the electrical safety precautions.
- (2) Insert the switch through the aperture from the rear of the panel, ensuring that the locating spigot engages the locating hole in the panel.
- (3) Secure the switch with the nut and washer.
- (4) Fit the knob on the switch spindle, ensuring that the spindle spigot is engaged with the slot in the knob. Tighten the clutch nut and fit the end cap.
- (5) Using a suitable tool, connect the flying leads to the module block, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- R (6) CENTRE CONSOLE FLOOD light dimmer/off switch only:
  - R (a) Position both sections of the heat shield  
R around the body of the switch.
  - R (b) Secure one section of the heat shield to the  
R diode board with the attachment bolt.
  - R (c) Ease the terminal block into position on the  
R cable former and secure the terminal block  
R and the second section of the heat shield to  
R the cable former with the attachment bolts.
- R (7) Secure the flying leads to the cable loom with suitable ties in accordance with 20-27-15.

### G. Remove Caption Light Module

- (1) If necessary, release the cable loom ties to gain access to the pin inserts at the rear of the EXTENDED caption module.
- (2) Using a suitable tool, withdraw the pin inserts from the module.
- (3) Disengage the clamp retaining springs at the rear of the module, and withdraw the module from the front of the panel and the clamp from the rear.

EFFECTIVITY: ALL

BA

Printed in England



**33-00-00**

Page 407  
May 30/76



# Concorde

## MAINTENANCE MANUAL



- Caption Light Module - Installation  
Figure 403

EFFECTIVITY: ALL

R

BA

Printed in England

**33-00-00**

Page 408  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

### H. Install Caption Light Module

- (1) Comply with the electrical safety precautions.
- (2) Position the clamp on the rear of the panel and insert the caption light module through the aperture from the front, ensuring that the hinged edge of the module is in alignment with the white-painted line on the back of the panel, and that the clamp is aligned symmetrically with the module.
- (3) Hold the module firmly against the front of the panel and press the clamp into position from the rear until the retaining springs engage the recess in the module body.
- (4) Using a suitable tool, connect the pin inserts to the module, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (5) Refit the cable loom ties, as necessary, in accordance with 20-27-15.

### J. Conclusion

- (1) Close and secure the panel or refit the panel to its mounting and secure it with the quick-release fasteners, as applicable.
- (2) Remove the safety clips and reset the circuit breakers tripped in operation B.(1), if applicable, and check the operation of the switch(es) or caption light module(s) by carrying out the appropriate test procedure.

EFFECTIVITY: ALL

BA

Printed in England

**33-00-00**

Page 409  
May 30/76

# Concorde

## MAINTENANCE MANUAL

### FLIGHT COMPARTMENT - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic contains general instructions for the removal and installation of typical minor electrical components fitted to panels in the flight compartment that are common to sub-systems within this section.

These panels are as listed in Table 1.

DESCRIPTION	PANEL NO.
LH switch panel	12-211
RH switch panel	5-212
LH side console switch panel	1-211-2
RH side console switch panel	1-212-2
Essential d.c. circuit breaker panel (hinged)	3-213
3CM lighting control panel	11-214
3CM brake panel	12-214
3CM lower electrical panel (hinged)	6-214
R Oxygen panel	20-215

Panels  
Table 1

Access to the components is gained by removing the appropriate section of the panel or, where applicable, lowering the panel on its hinges.

Any component can be removed or installed without first removing the associated electroluminescent panelling.

#### 2. Panel-mounted Components (Ref. Fig. 401 )

EFFECTIVITY: ALL

BA

Printed in England

**33-10-00**

Page 401  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

**CAUTION:** ELECTROLUMINESCENT (EL) PANELS ARE VULNERABLE TO DAMAGE BY SCRATCHING AND CRACKING. ENSURE THAT TOOLS DO NOT DAMAGE THE POLISHED WALL OF THE PANEL.

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

### B. Prepare to Remove Panel-mounted Components

- (1) For the 3CM lower electrical panel and the essential d.c. circuit breaker panel, isolate the electrical generation and external power supplies as detailed in 24-00-00, Servicing. For all other panels, trip the circuit breakers associated with the appropriate panel as listed below and fit safety clips

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
LH switch panel			
LH DASH & CTR FLOODS SUP	1-213	L234	M22
STBY MAG COMPASS LT SUP	1-213	L380	P22
LH DASH INST LTS SUP	13-215	L372	A12
DASH & G/SHIELD PNL LTG SUP	13-215	L85	A11
PLT'S LT TEST SUP	15-215	L1001	E14
CHART STOWAGE LTS SUP	15-216	L237	D12
RH switch panel			
RH DASH FLOOD SUP	5-213	L235	A19
RH DASH INST LTS SUP	13-216	L371	E9
DASH & G/SHIELD PNL LTG SUP	13-215	L85	A11

EFFECTIVITY: ALL

BA

# 33-10-00

Page 402  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
PLT'S LT TEST SUP	15-215	L1001	E14
CHART STOWAGE LTS SUP	15-216	L237	D12
LH side console switch panel			
LH DIGITAL DISPLAY DIMMING SUP	15-216	L1211	G14
LH CONSOLE PNL LTG SUP	14-215	L83	F10
LH CONSOLE INST LTS SUP	14-215	L374	B11
RH side console switch panel			
RH DIGITAL DISPLAY DIMMING SUP	15-216	L1216	A13
RH CONSOLE PNL LTG SUP	13-216	L84	D8
RH CONSOLE INST LTS SUP	14-216	L373	E8
Essential d.c. circuit breaker panel			
LH CONSOLE INST LTS SUP	14-215	L374	B11
1st SUPERN'Y SPOT SUP	15-215	L240	B13
ROOF & CB PNL 3-213 LTS SUP	13-216	L81	A8
3CM lighting control panel			
3CM FLOOD & READING LTS SUP	1-213	L238	N22
FUEL CONSUMED TOTAL/WT IND	13-216	E473	D5
3CM STN CB PNL LTS SUP	2-213	L87	A9

EFFECTIVITY: ALL

BA

Printed in England

**33-10-00**

Page 403  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

SERVICE		PANEL	CIRCUIT BREAKER	MAP REF.
3CM STN CTR INST LTS SUP		13-215	L378	C11
3CM STN RH INST LTS SUP		14-215	L376	F11
3CM STN LH INST LTS SUP		13-216	L377	E8
3CM STN PNL LTS SUP		14-216	L86	D9
Brake panel				
R R	RH INBD BRAKE FAN SUP & CONT	13-215	2G351	B1
R R	LH OUTER BRAKE FAN SUP & CONT	14-215	1G352	C2
R R	WHEEL BRAKE A SYS CONT O/LOAD IND	15-215	G131	B7
R	BRAKE ACCUM PRESS IND	13-216	G111	A12
R R	LH INBD BRAKE FAN SUP & CONT	13-216	1G351	E21
R	3CM LH INST LTS SUP	13-216	L377	E8
R R	RH OUTER BRAKE FAN SUP & CONT	14-216	2G352	F20
R	3CM STN PNL LTS SUP	14-216	L86	D9
R	WHEEL BRAKE B SYS CONT	15-216	G132	B18
R	3CM STN LH LT TEST SUP 1	15-216	L1003	C12
R	3CM STN LH LT TEST SUP 2	15-216	L1004	C13
R R	2ND PLT 3CM CLOCK TIMEBASE - BAT SUP	16-216	F56	-
R R	BRAKE EMER/ACCUM PRESS IND	25-216	G118	C6
R	AIDS SUP	2-213	R262	G19
R	Oxygen panel			

EFFECTIVITY: ALL

BA

### 33-10-00

Page 404  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

	SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
R	NO.1 INPH SUP	1-213	R89	K19
R	NO.2 INPH SUP	3-213	R90	H2
R	TOILET ENGAGED SIGN SUP	5-213	M201	C19
R R	FLIGHT DECK ROOF LTS SUP	14-215	L232	C11
R R	RACKING AREA INSPECTION LTS SUP	15-215	L239	B14
R R	ROOF & CB PNL 3-213 LTS SUP	13-216	L81	A8
R	GRND POWER LTS SUP	25-216	X369	B5

- (2) Release the quick-release panel fasteners and withdraw the panel sufficiently to gain access to the component, or, where applicable, lower the panel on its hinges.

C. Remove Typical Toggle Switch or Push-switch

- (1) On a switch with screw-type terminals, roll back the rubber terminal cover and disconnect the electrical cables from the switch.
- (2) On a switch with socket-type terminals, using a suitable tool, withdraw the pin inserts.
- (3) If applicable, remove the knob.
- (4) Using a tubular spanner, remove the nut and washer from the front of the panel and withdraw the switch and tabwasher from the rear.

D. Install Typical Toggle Switch or Push-switch

- (1) Comply with the electrical safety precautions.
- (2) Position the tabwasher on the switch and insert the switch through the aperture from the rear of the panel, ensuring that the tab on the tabwasher

EFFECTIVITY: ALL

BA


Printed in England

**33-10-00**

Page 405  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL



CMB3310004 AAM0

- Typical Component Installation  
Figure 401

EFFECTIVITY: ALL

R

BA

Printed in England

**33-10-00**

Page 406  
Feb 28/77



# *Concorde*

## MAINTENANCE MANUAL

engages the locating hole in the panel.

- (3) Secure the switch with the nut and washer.
- (4) If applicable, refit the knob.
- (5) Connect the electrical cables to the switch, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram. Position the rubber terminal cover over the screw-type terminals.

### E. Remove Typical Rotary Switch

- (1) Release the flying leads from the loom ties and, using a suitable tool, withdraw the pin inserts from the module block.
- (2) Remove the cap from the end of the switch knob, loosen the clutch nut and withdraw the knob from the switch spindle.
- (3) Using a tubular spanner, remove the nut and washer from the front of the panel and withdraw the switch from the rear. Disengage the bonding washer and lead from the switch boss (LH or RH DASH INSTRUMENTS switches only, on LH or RH switch panels).

R  
R  
R

### F. Install Typical Rotary Switch

- (1) Comply with the electrical safety precautions.
- (2) Position the bonding washer over the switch boss (LH or RH DASH INSTRUMENTS switches only) and insert the switch through the aperture from the rear of the panel, ensuring that the locating spigot engages the locating hole in the panel.
- (3) Secure the switch with the nut and washer.
- (4) Fit the knob on the switch spindle, ensuring that the spindle drive spigot is engaged with the slot in the knob. Tighten the clutch nut and fit the end cap.
- (5) Using a suitable tool, connect the flying leads to the module block, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.

R  
R  
R

EFFECTIVITY: ALL

BA

Printed in England

**33-10-00**

Page 407  
Feb 28/77

# *Concorde*

## MAINTENANCE MANUAL

- (6) Secure the flying leads to the cable loom with suitable ties in accordance with 20-27-15.

### G. Conclusion

- (1) Close/refit and secure the panel.
- R (2) Check that the panel is bonded in accordance with  
R 20-27-11.
- R (3) For the 3CM lower electrical panel and the  
essential d.c. circuit breaker panel, cancel the  
electrical safety precautions taken in operation  
B.(1), i.e., remove the warning notices.
- R (4) For all other panels, remove the safety clips and  
reset the circuit breakers tripped in operation  
B.(1).
- R (5) Check the operation of the switch by carrying out  
the appropriate test procedures.

EFFECTIVITY: ALL

BA

Printed in England

**33-10-00**

Page 408  
Feb 28/77

# *Concorde*

## MAINTENANCE MANUAL

### MAIN LIGHTING - DESCRIPTION AND OPERATION

#### 1. General

R Illumination of local areas of the flight compartment which serve the requirements of individual crew members is provided by floodlights, storm floodlights, spotlights, chart lights, stowage lights, racking inspection lights and a reading light.

General illumination of the flight compartment is provided by two fluorescent lamp assemblies mounted in the roof. Location of the associated control switches enables each crew member to control the lights serving his own station.

#### 2. Dashboard Panel Floodlights (Ref. Fig. 001 )

R Banks of filaments fitted in lamp assemblies are used to floodlight the dashboard panels. The assemblies are secured to the underside of the pilots' LH, centre and RH glareshields. Each lamp assembly is fitted with a cover secured by quick-release fasteners to facilitate access to the filaments.

#### 3. Centre Console Floodlight (Ref. Fig. 001 )

R Floodlighting for the centre console is provided by a filament lamp located in an assembly fitted on the roof centre line aft of the rear switch panel 4-211. The reflector assembly can be moved in one plane by turning an associated adjusting screw.

#### 4. Floor Floodlights (Ref. Fig. 001 )

Floodlighting of the floor at the pilot's and co-pilot's positions is provided by two lamp assemblies, one fitted on the LH side and one fitted on the RH side of the centre console.

#### 5. Storm Floodlights (Ref. Fig. 001 )

R Additional floodlighting for the LH and RH dashboard panels is provided by a fluorescent storm floodlight mounted under each side glareshield. The two associated ballast units are fitted behind the centre dashboard panel. Additional floodlighting for the centre dashboard is obtained from a filament storm floodlight fitted in the assembly that accommodates the centre console floodlight.

#### 6. First Supernumerary's Floodlight (Ref. Fig. 001 )

EFFECTIVITY: ALL

BA


Printed in England

**33-12-00**

Page 1  
Nov 30/75

# Concorde

## MAINTENANCE MANUAL



- Main Lighting (Forward) - Equipment  
Figure 001

EFFECTIVITY: ALL

BA

Printed in England

33-12-00

Page 2  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

- R A floodlight for the first supernumerary's station is fitted in the flight compartment roof to the left of the assembly that accommodates the centre console floodlight and centre dashboard storm floodlight. The
- R floodlight is adjusted to project the light through a translucent screen on to the required area.

### 7. Chart Lights (Ref. Fig. 001 )

A chart lamp assembly is fitted in the roof above each pilot's position. These lamp assemblies are the same type as that used for the 1st supernumerary's floodlight.

### 8. Chart Stowage Lights (Ref. Fig. 001 )

- R A filament lamp is fitted in the aft structure of the LH and RH switch panels 12-211 and 5-212 respectively. An associated reflector assembly for each lamp directs the light on to the respective chart stowage area.

### 9. Oxygen Mask Stowage Lights (Ref. Fig. 001 )

- R A lamp assembly is fitted in the forward structure of the LH and RH switch panels 12-211 and 5-212 respectively. Each filament is enclosed in a handed cover which is a push fit on the assembly body. The cover incorporates a translucent window positioned so that the light is directed onto the oxygen mask stowage area.

### 10. 3CM Panel Floodlights (Ref. Fig. 002 )

A bank of filaments fitted in lamp assemblies is used to floodlight the third crew member's (3CM) panels. The assemblies are mounted along the top edge of the panel structure in a reflector, fitted with a metal cover, which directs the light downward.

### 11. 3CM Panel Spotlights (Ref. Fig. 002 )

- R Additional illumination at the 3CM station is provided by two spotlights, located in the roof to the left of the
- R centre line and aligned to project the light on to the 3CM station. These spotlights are the same type as that used for centre console illumination.

### 12. Equipment Rack Inspection Lights (Ref. Fig. 002 )

- R Four filament lamps are used to illuminate the area behind the circuit breaker panels in the LH and RH rack upper structure. The four lamps in each rack are fitted, one on each of four disconnect mountings (plug breaks), on the rack

EFFECTIVITY: ALL

BA


Printed in England

# 33-12-00

Page 3  
Nov 30/75

# Concorde

## MAINTENANCE MANUAL



CMB3312000BAMO

- Main Lighting (Rear) - Equipment  
Figure 002

EFFECTIVITY: ALL

BA

Printed in England

**33-12-00**

Page 4  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

structure behind the associated circuit breaker panels. Each lamp is fitted with a push-on cover containing a clear lens and retained on a lampholder by leaf springs with locating pins that engage in a groove on the cover. The light can be directed by swivelling the cover on the body of the lamp.

### 13. 3CM Reading Light (Ref. Fig. 002 )

- R A reading light is provided for the 3CM and is located to the left of the roof centre line, laterally opposite the 3CM forward floodlight. This unit incorporates a filament lamp and a ball-and-socket mounting principle which allows a 30 deg movement of the filament assembly in any direction from the centre line of the unit.

### 14. Roof Lamps (Ref. Fig. 002 )

- R Two roof lamp assemblies are fitted on the centre line of the flight compartment roof, one forward over the 3CM station and one aft over the racking area. Each assembly comprises two fluorescent tubes, for normal lighting, and three filament lamps which are associated with emergency lighting (Ref. 33-51-00). The assembly is housed in a reflector box which is located above a diffusion panel fitted flush with the roof furnishing. The two ballast units for the forward roof lamp are fitted in the secondary structure of the 3CM station behind panel 3-214 and the two ballast units for the racking area roof lamp are fitted in the RH rack upper structure.

### 15. Operation (Ref. Fig.003 and 004)

#### A. Controls

All flight compartment main lighting control, except for the oxygen mask stowage lights, is effected through direct switching arrangements. Each switch controls the associated lamp or lamps listed in Table 1.

The chart stowage lights, racking inspection lights, racking area roof light and forward roof light are all controlled by ON/OFF toggle switches. The storm floodlights are controlled by a three-position rotary switch engraved OFF - LH/RH DASH - ALL. The LH and RH chart lights are each controlled by a push "on"/push "off" switch and a separate dimmer. The remaining lights are controlled by rotary dimmer/OFF switches. The oxygen mask stowage floodlights are controlled by the LH and RH SIDE CONSOLE instrument lighting switches

EFFECTIVITY: ALL

BA

Printed in England

**33-12-00**

Page 5  
Nov 30/75

# Concorde

## MAINTENANCE MANUAL

(Ref. 33-17-00).

### B. Functional Description (Ref. Table 1)

The function of all switches except the storm floodlight and the chart light switches is self-evident. With the storm floodlight switch set at LH/RH DASH, the fluorescent lamps which illuminate the LH and RH dashboard only are lit. With the switch set at ALL, the roof mounted floodlamp, which illuminates the centre dashboard, and the fluorescent lamps, which illuminate the LH and RH dashboard, are all lit.

When the LH or RH CHART LIGHT push-switch is pressed the associated chart lamp is lit; light intensity is controlled by a separate CHART LIGHT dimmer. When the push-switch is again pressed the associated light goes out.

SWITCH ENGRAVING	SWITCH LOCATION	LAMP(S) CONTROLLED
LH AND CENTRE DASH FLOOD	LH switch panel 12-211	LH and centre dashboard floodlights
RH DASH FLOOD	RH switch panel 5-212	RH dashboard floodlights
FLOODS	3CM lighting control panel 11-214	3CM floodlights and roof spotlights
CENTRE CONSOLE FLOOD	Roof panel 4-211	Centre console floodlight
FLOOD	Circuit breaker panel 3-213	1st supernumer- ary's floodlight
STORM	Roof panel 4-211	LH, RH and centre dashboard storm floodlights
CHART LIGHT	LH switch panel 12-211	Pilot's LH chart lamp
CHART LIGHT	RH switch panel	Pilot's RH chart

EFFECTIVITY: ALL

BA

**33-12-00**

Page 6  
Nov 30/75



# Concorde

## MAINTENANCE MANUAL

SWITCH ENGRAVING	SWITCH LOCATION	LAMP(S) CONTROLLED
	5-212	lamp
STOWAGE FLOOD	LH switch panel 12-211	LH chart stowage and floor floodlights
STOWAGE FLOOD	RH switch panel 5-212	RH chart stowage and floor floodlights
RACKING AREA LTS. - INSP	Oxygen panel 20-215	Racking inspection lights
SPOT	3CM lighting control panel 11-214	3CM reading light
ROOF	Roof panel 4-211	Forward roof lamp
RACKING AREA LTS. - ROOF	Oxygen panel 20-215	Racking area roof lamp
FWD. RACKING	Forward steward's panel 1-221	Racking area roof lamp

Main Lighting Controls  
Table 1

### C. Electrical Supplies

Electrical supplies are listed in Table 2.

SERVICE	BUSBAR	CIRCUIT BREAKER PANEL
LH and centre dashboard floodlights	'A' essential 28 V d.c.	1-213
RH dashboard floodlights	'B' essential 28 V d.c.	5-213
3CM floodlights,	'A' essential	1-213

EFFECTIVITY: ALL

BA

**33-12-00**

Page 7  
Nov 30/75

# Concorde

## MAINTENANCE MANUAL

SERVICE	BUSBAR	CIRCUIT BREAKER PANEL
roof spotlights and reading light	28 V d.c.	
Centre console floodlight	'B' essential 28 V d.c.	5-213
1st supernumerary's floodlight	'A' main 28 V d.c.	15-215
LH and RH dashboard storm floodlights	No.4 Main 115 V a.c.	14-216
Centre dashboard storm floodlight	'A' main 28 V d.c.	15-215
Pilot's and co-pilot's chart lamps; LH and RH chart stowage lamps; LH and RH floor floodlights	'B' main 28 V d.c.	15-216
Racking inspection lights	'A' main 28 V d.c.	15-215
Forward and racking area roof lamps	No.1 ground/ flight 115 V d.c.	14-215

Electrical Supplies  
Table 2

EFFECTIVITY: ALL

R

BA



Printed in England

**33-12-00**


Page 8  
Nov 30/75

# Concorde


## MAINTENANCE MANUAL



**A** ROOF PANEL (4-211)



**B** ROOF PANEL (4-211)



**C** LH SWITCH PANEL (12-211)

**D** RH SWITCH PANEL (5-212)

- Main Lighting (Forward) - Controls  
Figure 003

EFFECTIVITY: ALL

BA




Printed in England

**33-12-00**



Page 9  
Jun 30/75

# Concorde


## MAINTENANCE MANUAL



**B** ROOF PANEL (4-711)




**C** OXYGEN PANEL (20-215)



**D** CIRCUIT BREAKER PANEL (3-213)

**E** FORWARD STEWARD'S CONTROL PANEL (1-221)



Main Lighting (Rear) - Controls  
Figure 004

EFFECTIVITY: ALL

BA

Printed in England

33-12-00

Page 10  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

R

### MAIN LIGHTING - TROUBLE SHOOTING

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para. 3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

Where lighting circuits are similar, procedures and charts are provided which are applicable to either circuit. If two components are involved, i.e., one in each circuit, both references to the associated components listed in Table 101 are given, e.g., 'Renew Switch (14) or (15)'.

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.
- C. Before trouble shooting, renew any faulty fluorescent tube or filament lamp.

R

EFFECTIVITY: ALL

BA

C812195

**33-12-00**


Page 101  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

### 3. Trouble Shooting



R

EFFECTIVITY: ALL

BA

C812196


## 33-12-00

Page 102  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



R EFFECTIVITY: ALL

BA

C812266


**33-12-00**

Page 103  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



R

EFFECTIVITY: ALL

BA

C812267

33-12-00


Page 104  
Mar 29/96



# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



R

EFFECTIVITY: ALL

BA

C812268

**33-12-00**

Page 105  
Mar 29/96

# Concorde


## MAINTENANCE MANUAL

FORWARD ROOF LAMP FAILS TO LIGHT  
WHEN SWITCHED ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



PRINTED IN ENGLAND

Chart 101

R

EFFECTIVITY: ALL

# 33-12-00

BA

C812324

Page 106  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

RACKING AREA ROOF LAMP FAILS TO LIGHT WHEN SWITCHED ON AT THE RACKING AREA ROOF LIGHT SWITCH ON THE FLIGHT COMPARTMENT OXYGEN PANEL.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 102

R

EFFECTIVITY: ALL

BA

C812323

# 33-12-00

Page 107  
Mar 29/96

# Concorde


## MAINTENANCE MANUAL

LH/CENTRE OR RH DASH FLOODLAMPS  
FAIL TO LIGHT WHEN SWITCHED ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



PRINTED IN ENGLAND

Chart 103

R

EFFECTIVITY: ALL

BA

C812325

# 33-12-00

Page 108  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

LH OR RH DASH FLUORESCENT LAMPS  
FAIL TO LIGHT WHEN SWITCHED ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 104

R

EFFECTIVITY: ALL

BA

C812326

# 33-12-00

Page 109  
Mar 29/96

# Concorde


## MAINTENANCE MANUAL

CENTRE DASH FLOODLAMP FAILS TO LIGHT WHEN THE 'STORM' CONTROL SWITCH IS SET TO 'ALL'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



PRINTED IN ENGLAND

Chart 105

# 33-12-00

EFFECTIVITY: ALL

BA

C812327

Page 110  
Mar 29/96

R

# Concorde

## MAINTENANCE MANUAL

CENTRE CONSOLE FLOODLAMP FAILS  
TO LIGHT WHEN SWITCHED ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 106

R EFFECTIVITY: ALL

BA

C812328

# 33-12-00

Page 111  
Mar 29/96

# Concorde


## MAINTENANCE MANUAL

LH OR RH CHART LAMP FAILS TO  
LIGHT WHEN SWITCHED ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



PRINTED IN ENGLAND

Chart 107

R

EFFECTIVITY: ALL

BA

C812329

# 33-12-00

Page 112  
Mar 29/96



# Concorde

## MAINTENANCE MANUAL

LH OR RH CHART STOWAGE AND  
FLOOR FLOODLAMPS FAIL TO  
LIGHT WHEN SWITCHED ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.

Select "ON"  
at the LH or  
RH STOWAGE  
FLOOD control  
switch as  
appropriate.

Check for 28 V  
d.c. at the  
output of  
Switch (22) or  
(23).

YES

\*Renew Lamps  
(43), (44),  
(45) or (46)  
as necessary.

NO

\*Renew Switch  
(22) or (23).

Chart 108

EFFECTIVITY: ALL

BA

C812698

# 33-12-00

Page 113  
Mar 29/96

# Concorde


## MAINTENANCE MANUAL

ROOF SPOT LAMPS AND PANEL MOUNTED  
FLOODLAMPS NOT LIT WHEN SWITCHED  
ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-

NOTE: Before renewal of components (\*), check the preceding run of wiring for continuity.



PRINTED IN ENGLAND

Chart 109

EFFECTIVITY: ALL

BA

C812699

**33-12-00**

Page 114  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

3CM READING LAMP FAILS TO LIGHT  
WHEN SWITCHED ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.

Rotate the 3CM  
reading lamp  
SPOT switch to  
the 'on'  
position.

Check for 28 V  
d.c. at the  
output of Switch  
(25).

YES

\*Renew Lamp  
(52).

NO

\*Renew Switch  
(25).

PRINTED IN ENGLAND

Chart 110

R

EFFECTIVITY: ALL

BA

C812700

**33-12-00**

Page 115  
Mar 29/96

# Concorde


## MAINTENANCE MANUAL

FIRST SUPERNUMERARY'S FLOODLAMP  
FAILS TO LIGHT WHEN SWITCHED ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-

NOTE: Before renewal of components (\*), check the preceding run of wiring for continuity.



PRINTED IN ENGLAND

Chart 111

R

EFFECTIVITY: ALL

BA

C812701

# 33-12-00

Page 116  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

LAMPS IN LH AND RH RACKING FAIL  
TO LIGHT WHEN SWITCHED ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 112

R

EFFECTIVITY: ALL

BA

C812702

# 33-12-00

Page 117  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 115 V	-	14-215	L232	Map ref. C11	24-50-00 R/I	
(2) Circuit breaker 28 V	-	1-213	L234	Map ref. M22	24-50-00 R/I	
(3) Circuit breaker 28 V	-	5-213	L235	Map ref. A19	24-50-00 R/I	
(4) Circuit breaker 115 V	-	14-216	L231	Map ref. A8	24-50-00 R/I	
(5) Circuit breaker 28 V	-	15-215	L305	Map ref. F14	24-50-00 R/I	
(6) Circuit breaker 28 V	-	5-213	L236	Map ref. B19	24-50-00 R/I	
(7) Circuit breaker 28 V	-	15-216	L237	Map ref. D12	24-50-00 R/I	
(8) Circuit breaker 28 V	-	1-213	L238	Map ref. N22	24-50-00 R/I	
(9) Circuit breaker 28 V	-	15-215	L240	Map ref. B13	24-50-00 R/I	
(10) Circuit breaker 28 V	-	15-215	L239	Map ref. B14	24-50-00 R/I	
(11) Fwd ROOF light Switch	-	4-211	L242	Pilots' roof panel	33-12-00 R/I	
(12) Racking area ROOF light switch	-	20-215	L244	Oxygen panel 20-215	33-12-00 R/I	
(13) Racking area ROOF light switch	-	1-221	L243	Fwd steward's panel	33-12-00 R/I	
(14) LH/CENTRE DASH FLOOD dimmer switch	-	12-211	L249	Pilots' LH switch panel	33-12-00 R/I	

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812703

# 33-12-00

Page 118  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(15) RH DASH FLOOD dimmer switch	-	5-212	L250	Pilots' RH switch panel	33-12-00 R/I	
(16) STORM flood control switch	-	4-211	L241	Pilots' roof panel	33-12-00 R/I	
(17) CENTRE CONSOLE FLOOD dimmer switch	-	4-211	L251	Pilots' roof panel	33-12-00 R/I	
(18) LH CHART LIGHT push-switch	-	12-211	L316	LH switch panel	33-12-00 R/I	
(19) LH CHART LIGHT dimmer	-	12-211	L252	LH switch panel	33-12-00 R/I	
(20) RH CHART LIGHT push-switch	-	5-212	L317	RH switch panel	33-12-00 R/I	
(21) RH CHART LIGHT dimmer	-	5-212	L253	RH switch panel	33-12-00 R/I	
(22) LH CHART STOWAGE switch	-	12-211	L245	LH switch panel	33-12-00 R/I	
(23) RH CHART STOWAGE switch	-	5-212	L246	RH switch panel	33-12-00 R/I	
(24) 3CM panel FLOOD lighting switch	-	11-214	L254	3CM station light control panel	33-12-00 R/I	
(25) 3CM reading lamp SPOT switch	-	11-214	L312	3CM station light control panel	33-12-00 R/I	

R

EFFECTIVITY: ALL

BA

C812704

# 33-12-00

Page 119  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(26) First supernumerary's FLOOD lighting control switch.	-	3-213	L255	'B' ess. d.c. CB panel	33-12-00 R/I	
(27) Racking area INSP. lights switch	-	20-215	L248	Oxygen panel	33-12-00 R/I	
(28) Fwd roof light ballast units	-	9-214	L260/ L261	3CM station racking structure	33-12-00 R/I	
(29) Racking area roof light ballast units	-	12-216	L262/ L263	Flt. compt. RH racking	33-12-00 R/I	
(30) Fwd roof lamp	-	214	L267	Flt. compt. roof - fwd	33-12-00 R/I	
(31) Racking area roof lamp	-	215	L268	Flt. compt. roof - aft	33-12-00 R/I	
(32) Centre dash flood-lamp	-	5-211	L308	Above centre dash	33-12-00 R/I	
(33) LH dash floodlamp	-	3-211	L306/ L307	Above LH dash	33-12-00 R/I	
(34) RH dash floodlamp	-	3-212	L309/ L310	Above RH dash	33-12-00 R/I	
(35) LH STORM floodlamp ballast unit	-	5-211	L257	Behind centre dash	33-12-00 R/I	
(36) RH STORM floodlamp ballast unit	-	5-211	L259	Behind centre dash	33-12-00 R/I	
(37) LH STORM floodlamps	-	3-211	L264	LH dash	33-12-00 R/I	

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812705

# 33-12-00

Page 120  
Mar 29/96



# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(38) RH STORM floodlamps	-	3-212	L266	RH dash	33-12-00 R/I	
(39) Centre STORM flood- lamp	-	212	L304	Flt. compt. roof	33-12-00 R/I	
(40) Centre console floodlamp	-	211	L281	Flt. compt. roof	33-12-00 R/I	
(41) Pilot's chart lamp	-	211	L282	Flt. compt. roof	33-12-00 R/I	
(42) Co-pilot's chart lamp	-	212	L283	Flt. compt. roof	33-12-00 R/I	
(43) Pilot's chart stowage lamp	-	12-211	L284	LH switch panel	33-12-00 R/I	
(44) Pilot's floor flood- lamp	-	9-211	L318	Centre console - LH side	33-12-00 R/I	
(45) Co-pilot's chart stowage lamp	-	5-212	L285	RH switch panel	33-12-00	
(46) Co-pilot's -floor flood- lamp	-	9-211	L319	Centre console- RH side	33-12-00 R/I	
(47) Pilot's Oxy. mask stowage lamp	-	12-211	I315	LH switch panel	33-12-00 R/I	
(48) Co-pilot's Oxy. mask stowage lamp	-	5-212	L314	RH switch panel	33-12-00 R/I	
(49) 3CM panel floodlamps	-	214	L288- L294	Top of 3CM management panels	33-12-00 R/I	

PRINTED IN ENGLAND

R EFFECTIVITY: ALL

BA

C812706

# 33-12-00

Page 121  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(50) 3CM panel fwd spot lamp	-	213	L286	Flt. compt. roof	33-12-00 R/I	
(51) 3CM panel aft spot lamp	-	213	L287	Flt. compt. roof	33-12-00 R/I	
(52) 3CM reading lamp	-	214	L313	Flt. compt. roof	33-12-00 R/I	
(53) First supernumerary's floodlamp	-	213	L295	Flt. compt. roof	33-12-00 R/I	
(54) LH racking inspection lamps	-	12-215	L296- L299	Flt. compt. LH rack	33-12-00 R/I	
(55) RH racking inspection lamps	-	12-216	L300- L303	Flt. compt. RH rack	33-12-00 R/I	

Component Identification  
Table 101

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812707

# 33-12-00

Page 122  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

### MAIN LIGHTING - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic contains instructions for the renewal of faulty filaments or fluorescent tubes in the lamp assemblies listed below. Where necessary, instructions are also detailed for the removal and installation of the complete lamp assembly.

Forward and racking area roof lamps.

Dashboard floodlamps.

Dashboard storm floodlamps.

Centre console floodlamp.

Pilots' chart lamps.

Pilots' chart stowage lamps.

Pilots' floor floodlamps.

Pilots' oxygen mask stowage floodlamps.

3CM panel floodlamps.

3CM reading lamp.

First supernumerary's floodlamp.

The removal and installation of associated switches mounted on the pilots' roof panel is detailed in 33-00-00. Removal and installation of switches on all other panels is detailed in 33-10-00.

#### 2. Forward or Racking Area Roof Lamp

##### A. Fluorescent Tube or Emergency Filament Renewal

- (1) Ensure that the appropriate roof lamp switch and the pilots' emergency lighting switch are at 'off' and that the steward's emergency lighting switch is at NORMAL.
- (2) Unscrew the lens securing screws and remove the lens.
- (3) Renew the faulty tube or filament.

EFFECTIVITY: ALL

BA

Printed in England

**33-12-00**

Page 401  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (4) Position the lens and secure it with the screws.
- (5) Check that the filament or tube lights, by carrying out the appropriate test.

### 3. Dashboard Floodlamps (Ref. Fig. 401 )

#### A. Filament Renewal

- (1) Ensure that the LH/CENTRE or RH DASH FLOOD dimmer switch, as appropriate, is at OFF.
- R (2) Release the quick-release fastener(s) securing the  
R appropriate lamp cover to the lamp holder and remove  
R the cover from the lamp.
- R (3) Renew the faulty filament.
- R (4) Refit the lamp cover.
- R (5) Check that the filament lights, by carrying out the  
appropriate test.

### 4. LH or RH Dashboard Storm Floodlamp

#### A. Fluorescent Tube Renewal

- (1) Select "OFF" at the STORM floodlight switch on the pilots' roof panel.
- (2) Renew the fluorescent tube below the LH or RH dashboard as required. There is direct access to each tube.
- (3) Check that both fluorescent tubes light, by carrying out the appropriate test.

### 5. Centre Dashboard Storm Floodlamp (Ref. Fig. 401 )

#### A. Filament Renewal

- (1) Select "OFF" at the STORM floodlight switch on the pilots' roof panel.
- (2) Unscrew the screws securing the square lens to the lamp in the roof floodlamp assembly and remove the lens.
- (3) Renew the faulty filament.
- (4) Refit the lens and secure it with the screws.

EFFECTIVITY: ALL

BA


Printed in England

**33-12-00**

Page 402  
Feb 29/76

# Concorde

## MAINTENANCE MANUAL



- Main Lighting - Chart, Dashboard and Centre Console Lamps  
Figure 401

EFFECTIVITY: ALL

BA

Printed in England

**33-12-00**

Page 403  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (5) Check that the filament lights, by carrying out the appropriate test.

### B. Floodlamp Removal/Installation

#### (1) Equipment and Materials

<u>DESCRIPTION</u>	<u>PART NO.</u>
Circuit breaker safety clips	-

#### (2) Prepare

- (a) Select "OFF" at the STORM and at the CENTRE CONSOLE floodlight switches on the pilots' roof panel.
- (b) Trip the CTR DASH STORM FLOOD SUP circuit breaker L305 on panel 15-215, map ref.F14, and the CTR CONSOLE SPOT SUP circuit breaker L236 on panel 5-213, map ref.B19, and fit safety clips.

#### (3) Remove

- (a) Unscrew the lamp assembly securing screws, withdraw the lamp assembly complete with two floodlamps, and support it at the extent of the electrical cables.
- (b) Disconnect the electrical cables from the appropriate floodlamp.
- (c) Release the screws securing the floodlamp in its bracket and remove the floodlamp.

#### (4) Install

- (a) Comply with the electrical safety precautions.
- (b) Position the floodlamp in its bracket and secure it with the screws.
- (c) Connect the electrical cable to the floodlamp, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (d) Position the lamp assembly, complete with two floodlamps, and secure it with the screws.

EFFECTIVITY: ALL

R

BA

**33-12-00**

Page 404  
Feb 29/76

# *Concorde*

## MAINTENANCE MANUAL

### (5) Conclusion

- (a) Make available electrical ground power as detailed in 24-41-00.
- (b) Remove the safety clips and reset the circuit breakers tripped before removal.
- (c) Select "ALL" at the STORM floodlight switch and check that the filament lights.
- (d) Set the STORM floodlight switch to "OFF".
- (e) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### 6. Centre Console Floodlamp (Ref. Fig. 401 )

#### A. Filament Renewal

- (1) Select "OFF" at the CENTRE CONSOLE FLOOD dimmer switch on the pilots' roof panel.
- (2) Unscrew the screws securing the circular lens to the roof floodlamp assembly and remove the lens.
- (3) Renew the faulty filament.
- (4) Refit the lens and secure it with the screws.
- (5) Check that the filament lights, by carrying out the appropriate test.

#### B. Floodlamp Removal/Installation

##### (1) Equipment and Materials

<u>DESCRIPTION</u>	<u>PART NO.</u>
Circuit breaker safety clips	-

##### (2) Prepare

- (a) Select "OFF" at the STORM and at the CENTRE CONSOLE floodlight switches on the pilots' roof panel.
- (b) Trip the CTR DASH STORM FLOOD SUP circuit breaker L305 on panel 15-215, map ref.F14, and the CTR CONSOLE SPOT SUP circuit breaker L236 on panel 5-213, map ref.B19, and fit safety clips.

EFFECTIVITY: ALL

R

BA

Printed in England

# 33-12-00

Page 405  
Feb 29/76

# *Concorde*

## MAINTENANCE MANUAL

### (3) Remove

- (a) Unscrew the lamp assembly securing screws, withdraw the lamp assembly complete with two floodlamps, and support it at the extent of the electrical cables.
- (b) Disconnect the electrical cables from the appropriate floodlamp.
- (c) Release the screws securing the floodlamp in its bracket and remove the floodlamp.

### (4) Install

- (a) Comply with the electrical safety precautions.
- (b) Position the floodlamp in its bracket and secure it with the screws.
- (c) Connect the electrical cables to the floodlamp, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (d) Position the lamp assembly, complete with two floodlamps, and secure it with the screws.

### (5) Conclusion

- (a) Make available electrical ground power as detailed in 24-41-00.
- (b) Remove the safety clips and reset the circuit breakers tripped before removal.
- (c) Switch on at the CENTRE CONSOLE FLOOD dimmer switch and check that the filament lights.
- (d) Set the CENTRE CONSOLE FLOOD dimmer switch to "OFF".
- (e) Switch off and disconnect electrical ground power as detailed in 24-41-00.

## 7. Pilot's Chart Lamp (Ref. Fig. 401 )

### A. Filament Renewal

- (1) Trip the CHART STOWAGE LTS SUP circuit breaker L237 on panel 15-216, map ref.D12, and fit a safety clip.

EFFECTIVITY: ALL

R

BA

Printed in England

# 33-12-00

Page 406  
Feb 29/76



# *Concorde*

## MAINTENANCE MANUAL

- (2) Unscrew the screws securing the lens covering the appropriate lamp assembly and remove the lens.
- (3) Rotate the wire circlip to release the filament holder.
- (4) Swing the filament holder open on its hinge.
- (5) Renew the faulty filament.
- (6) Close the filament holder and secure it with the circlip.
- (7) Fit the lens and secure it with the screws.
- (8) Remove the safety clip and reset the circuit breaker previously tripped.
- (9) Check that the filament lights, by carrying out the appropriate test.

### 8. Pilots' Chart Stowage Lamp (Ref. Fig. 402 )

#### A. Filament Renewal

- (1) Select "OFF" at the appropriate CHART STOWAGE light switch and renew the filament at the rear end of the switch panel. There is direct access to the filament.
- (2) Check that the filament lights, by carrying out the appropriate test.

#### B. Lamp Removal/Installation

- (1) Prepare
  - (a) Remove the LH or RH switch panel as detailed in 33-10-00.
- (2) Remove
  - (a) Disconnect the electrical cable from the lamp fitting.
  - (b) Unscrew the nut securing the lamp fitting and remove the chart stowage lamp.
- (3) Install
  - (a) Comply with the electrical safety precautions.

EFFECTIVITY: ALL

R

BA


Printed in England

# 33-12-00

Page 407  
Feb 29/76

# Concorde

## MAINTENANCE MANUAL



- Main Lighting - Stowage, Floor and 1st Supernumerary Lamps  
Figure 402

EFFECTIVITY: ALL

BA

Printed in England

**33-12-00**

Page 408  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (b) Position the lamp fitting and secure it with the nut.
- (c) Connect the electrical cable to the lamp fitting, ensuring that the connections are made in accordance with the cable identifications and applicable wiring diagram.
- (d) Position the LH or RH switch panel as appropriate and secure it with the screws.

### (4) Conclusion

- (a) Remove the safety clips and reset the circuit breakers tripped before removal.
- (b) Make available electrical ground power as detailed in 24-41-00.
- (c) Select "ON" at the appropriate CHART STOWAGE light switch and check that the filament lights.
- (d) Select "OFF" at the CHART STOWAGE light switch.
- (e) Switch off and disconnect electrical ground power as detailed in 24-41-00.

## 9. Pilots' Floor Floodlamp (Ref. Fig. 402 )

### A. Filament Renewal

- (1) Select "OFF" at the LH or RH pilot's CHART STOWAGE light switch as appropriate.
- (2) Unscrew the floor floodlamp cover securing screws and remove the cover.
- (3) Renew the filament.
- (4) Position the cover and secure it with the screws.
- (5) Check that the filament lights, by carrying out the appropriate test.

## 10. Pilots' Oxygen Mask Stowage Floodlamp (Ref. Fig. 402 )

### A. Filament Renewal

- (1) Select "OFF" at the LH or RH SIDE CONSOLE switch as appropriate.

EFFECTIVITY: ALL

R

BA

Printed in England

**33-12-00**

Page 409  
Feb 29/76

# *Concorde*

## MAINTENANCE MANUAL

- (2) Pull the cover from the lamp fitting at the forward end of the LH or RH switch panel as appropriate.
- (3) Renew the filament and refit the lamp cover.
- (4) Check that the filament lights, by carrying out the appropriate test. Ensure that the lens in the light cover directs the light at the oxygen mask stowage.
- (5) Select "OFF" at the appropriate SIDE CONSOLE switch.

### B. Floodlamp Removal/Installation

- (1) Prepare
  - (a) Remove the LH or RH switch panel as detailed in 33-10-00.
- (2) Remove
  - (a) Disconnect the electrical cable from the lamp fitting.
  - (b) Unscrew the nut securing the lamp fitting and remove the chart stowage lamp.
- (3) Install
  - (a) Comply with the electrical safety precautions.
  - (b) Position the lamp fitting and secure it with the nut.
  - (c) Connect the electrical cable to the lamp fitting, ensuring that the connections are made in accordance with the cable identifications and applicable wiring diagram.
  - (d) Position the LH or RH switch panel as appropriate and secure it with the screws.
- (4) Conclusion
  - (a) Make available electrical ground power as detailed in 24-41-00.
  - (b) Remove the safety clips and reset the circuit breakers tripped before removal.
  - (c) Select "ON" at the appropriate SIDE CONSOLE

EFFECTIVITY: ALL

R

BA

Printed in England

**33-12-00**

Page 410  
Feb 29/76

# *Concorde*

## MAINTENANCE MANUAL

switch and check that the filament lights.

(d) Select "OFF" at the appropriate SIDE CONSOLE switch.

(e) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### 11. 3CM Panel Floodlamps (Ref. Fig. 403 )

#### A. Filament Renewal

- (1) Select "OFF" at the FLOOD lighting switch on the 3CM switch panel.
- (2) There is direct access to the filaments of the panel mounted floodlamps. For the roof-mounted floodlamps, unscrew the screws securing the lens and remove the lens.
- (3) Renew faulty filament.
- (4) Refit lens if necessary.
- (5) Check that the filament lights, by carrying out the appropriate test.
- (6) Select "OFF" at the FLOOD lighting switch.

#### B. Roof-mounted Floodlamp - Removal/Installation

##### (1) Equipment and Materials

<u>DESCRIPTION</u>	<u>PART NO.</u>
Circuit breaker safety clips	-

##### (2) Prepare

- (a) Select "OFF" at the FLOOD and reading lamp SPOT switches on the 3CM switch panel.
- (b) Trip the 3CM FLOOD & READING LTS SUP circuit breaker L238 on panel 1-213, map ref.N22, and fit a safety clip.

##### (3) Remove

- (a) Unscrew the screws securing the lamp shroud to the aircraft structure.

EFFECTIVITY: ALL

BA




Printed in England

# 33-12-00


Page 411  
Feb 29/76

# Concorde

## MAINTENANCE MANUAL



**B** TYPICAL ROOF MOUNTED  
PANEL FLOODLAMP



**C** 3CM READING LAMP

CMB 33 12 00 4 CAMO

- Main Lighting - 3CM Panel and Reading Lamps  
Figure 403

EFFECTIVITY: ALL

BA

Printed in England

**33-12-00**

Page 412  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (b) Withdraw the shroud complete with lamp sufficiently to gain access to the electrical connections.
  - (c) Using a suitable tool, disconnect the electrical cables from the adjacent terminal block and remove the shroud complete with lamp.
  - (d) Release the lamp pivot screws and remove the lamp from the bracket.
- (4) Install
- (a) Comply with the electrical safety precautions.
  - (b) Position the lamp in the bracket and secure it with the pivot screws.
  - (c) Support the shroud complete with lamp and pass the electrical cables through the ceiling opening.
  - (d) Connect the electrical cables to the associated terminal block, using a suitable tool. Ensure that the connections are made in accordance with the cable identifications and applicable wiring diagram.
  - (e) Position the lamp shroud in the aircraft structure and secure it with the screws.
  - (f) Remove the safety clip and reset the circuit breaker tripped before removal.
- (5) Conclusion
- (a) Make available electrical ground power as detailed in 24-41-00.
  - (b) Switch on at the FLOOD lighting switch and check that the filament lights.
  - (c) Switch off at the FLOOD lighting switch.
  - (d) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### 12. 3CM Reading Lamp (Ref. Fig. 403 )

#### A. Filament Renewal

EFFECTIVITY: ALL

BA

Printed in England

# 33-12-00

Page 413  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (1) Switch off at the reading lamp switch engraved SPOT.
- (2) Remove the push-fit lens.
- (3) Renew the filament.
- (4) Refit the lens.
- (5) Check that the filament lights, by carrying out the appropriate test.

### B. Lamp Removal/Installation

#### (1) Equipment and Materials

<u>DESCRIPTION</u>	<u>PART NO.</u>
Circuit breaker safety clips	-

#### (2) Prepare

- (a) Select "OFF" at the reading lamp SPOT and at the FLOOD lighting switches on the 3CM switch panel.
- (b) Trip the 3CM FLOOD & READING LTS SUP circuit breaker L238 on panel 1-213, map ref.N22, and fit a safety clip.

#### (3) Remove

- (a) Unscrew the screws securing the lamp assembly and withdraw it sufficiently to gain access to the electrical connection.
- (b) Disconnect the electrical cable from the lamp-holder and remove the lamp assembly.

#### (4) Install

- (a) Comply with the electrical safety precautions.
- (b) Support the lamp assembly and connect the electrical cable to the lampholder, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (c) Position the lamp assembly and secure it with the screws.

EFFECTIVITY: ALL

R

BA

**33-12-00**

Page 414  
Aug 30/75



# Concorde

## MAINTENANCE MANUAL

(d) Remove the safety clip and reset the circuit breaker tripped before removal.

### (5) Conclusion

(a) Make available electrical ground power as detailed in 24-41-00.

(b) Switch on at the reading lamp SPOT switch and check that the lamp lights.

(c) Switch off at the reading lamp SPOT switch.

(d) Switch off and disconnect electrical ground power as detailed in 24-41-00.

## 13. First Supernumerary's Floodlamp (Ref. Fig. 402 )

### A. Filament Renewal

(1) Select "OFF" at the first supernumerary's FLOOD lighting switch on circuit breaker panel 3-213.

(2) Unscrew the lens securing screws and remove the lens.

(3) Renew the filament.

(4) Refit the lens and secure it with the screws.

(5) Check that the filament lights, by carrying out the appropriate test.

### B. Floodlamp Removal/Installation

#### (1) Equipment and Materials

##### DESCRIPTION

##### PART NO.

Circuit breaker safety clips -

#### (2) Prepare

(a) Select "OFF" at the first supernumerary's floodlighting switch on circuit breaker panel 3-213.

(b) Trip the 1st SUPERN'Y SPOT SUP circuit breaker L240 on panel 15-215, map ref.B13, and fit a safety clip.

#### (3) Remove

EFFECTIVITY: ALL

BA

**33-12-00**

Page 415  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (a) Unscrew the lamp assembly securing screws and withdraw the lamp assembly sufficiently to gain access to the electrical connections.
  - (b) Disconnect the electrical connections from the adjacent terminal block, using a suitable tool, and remove the lamp assembly complete with shroud and lens.
  - (c) Release the lamp pivot screws and remove the lamp from the bracket.
- (4) Install
- (a) Comply with the electrical safety precautions.
  - (b) Support the lamp assembly and connect the electrical cable to the lampholder, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
  - (c) Position the lamp assembly and secure it with the screws.
  - (d) Remove the safety clip and reset the circuit breaker tripped before removal.
- (5) Conclusion
- (a) Make available electrical ground power as detailed in 24-41-00.
  - (b) Switch on at the reading lamp SPOT switch and check that the lamp lights.
  - (c) Switch off at the reading lamp SPOT switch.
  - (d) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

R

BA

Printed in England

**33-12-00**

Page 416  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

### MAIN LIGHTING - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

R This topic contains an Operational Test which details the  
R procedure to prove the correct operation of the flight  
R compartment main lighting, and a specific self-contained  
R test of the storm lighting. Functional and System Tests  
R are not considered necessary.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test

- (1) Select "ON" at the ROOF switch on the LIGHTS section of the flight compartment roof panel 4-211 and check that both tubes in the forward roof lamp assembly are lit.
- (2) Select "OFF" at the switch and check that the light goes out.
- (3) Slowly rotate the RH DASH FLOOD control switch on the RH switch panel 5-212 and check that the right-hand dashboard floodlamps light and that the light becomes progressively brighter.
- (4) Slowly rotate the LH and CENTRE DASH FLOOD control switch on the left-hand switch panel 12-211 and check that the centre and left-hand floodlamps light and that the light becomes progressively brighter.
- (5) Check that all filament lamps in the dashboard floodlight assemblies are lit.
- (6) Slowly rotate each DASH FLOOD switch toward OFF and check that the associated floodlighting is progressively dimmed and then goes out. Leave each switch at OFF.
- (7) Select "LH/RH DASH" at the STORM control switch on the roof panel 4-211 and check that the two tubes,

EFFECTIVITY: ALL

BA

# 33-12-00

Page 501  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

one under the LH and one under the RH glareshield, are illuminated.

- (8) Select "ALL" at the STORM control switch and check that the centre dashboard storm floodlight in the roof is lit, in addition to the two tubes which illuminate the LH and RH dashboards.
- (9) Select "OFF" at the STORM control switch.
- (10) Rotate the CENTRE CONSOLE FLOOD switch, on the roof panel 4-211, fully clockwise and check that the centre console is illuminated by the associated spotlight in the roof. Check that the light becomes progressively brighter as the control switch is rotated. Return the switch to "OFF".
- (11) Press the CHART LIGHT push-switch on the right-hand switch panel 5-212 and check that the pilot's right-hand chart area is illuminated by the associated chart light in the roof.
- (12) Slowly rotate the CHART LIGHT dimmer control clockwise and check that the chart light becomes progressively brighter.
- (13) Press the CHART LIGHT push-switch and check that the chart light goes out.
- (14) Repeat operations (11), (12) and (13) as applied to the CHART LIGHT control on the left-hand switch panel 12-211 and the pilot's left-hand chart light.
- (15) Select "ON" at the STOWAGE FLOOD control switch on the right-hand switch panel 5-212 and check that the right-hand chart stowage area is illuminated by the associated chart stowage light and that the RH floor floodlights light. Select "OFF" at the switch.
- (16) Select "ON" at the STOWAGE FLOOD control switch on the left-hand switch panel 12-211 and check that the left-hand chart stowage area is illuminated by the associated chart stowage light and that the LH floor floodlights light. Select "OFF" at the switch.
- (17) Slowly rotate the SIDE CONSOLE control switch (Ref. 33-17-00) on the right-hand console 1-212 and check that the right-hand oxygen mask stowage area is illuminated by the associated oxygen mask

EFFECTIVITY: ALL

R

BA

Printed in England

# 33-12-00

Page 502  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

stowage light and that the light becomes progressively brighter. Return the switch to "OFF".

- (18) Slowly rotate the SIDE CONSOLE control switch (Ref. 33-17-00) on the left-hand console 1-211 and check that the left-hand oxygen mask stowage area is illuminated by the associated oxygen mask stowage light and that the light becomes progressively brighter. Return the switch to "OFF".
- (19) Rotate the FLOOD control switch, on the third crew member's (3CM) lighting control panel 11-214, fully clockwise. Check that the 3CM station is illuminated by the filament floodlight assemblies, fitted at the top of the 3CM management panels, and by the two spotlights in the roof. Check that the lights become progressively brighter as the control switch is rotated. Return the switch to "OFF".
- (20) Slowly rotate the SPOT control switch on the 3CM lighting control panel 11-214 and check that the 3CM reading light in the roof is lit and that the light becomes progressively brighter. Return the switch to "OFF".
- (21) Slowly rotate the FLOOD control switch on circuit breaker panel 3-213 and check that the 1st supernumerary's floodlamp in the roof is lit and that the light becomes progressively brighter.
- (22) Switch on at the RACKING AREA LTS. - ROOF switch on the oxygen panel 20-215 and check that both tubes in the racking area roof lamp are lit.
- (23) Switch off at the RACKING AREA switch on the forward steward's control panel and check that the light goes out.
- (24) Repeat operations (22) and (23).
- (25) Switch on at the RACKING AREA LTS. - INSP. control switch on the oxygen panel 20-215 and check that the filament lamps in the rack upper structure on the LH and RH equipment racks are lit.
- (26) Switch off at the RACKING AREA LTS. - INSP. switch.
- (27) Check that all flight compartment main lighting is out.

EFFECTIVITY: ALL

**33-12-00**

Page 503  
Aug 30/75

R

BA

Printed in England



# *Concorde*

## MAINTENANCE MANUAL

### C. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### R 3. Storm Lighting - Test

#### R A. Prepare

- R (1) Make available electrical ground power as detailed  
R in 24-41-00.

#### R B. Test

- R (1) Select "LH/RH DASH" at the STORM control switch  
R on the roof panel 4-211 and check that the two  
R tubes, one under the LH and one under the RH  
R glareshield, are illuminated.
- R (2) Select "ALL" at the STORM control switch and  
R check that the centre dashboard storm floodlight  
R in the roof is lit, in addition to the two tubes  
R which illuminate the LH and RH dashboards.
- R (3) Select "OFF" at the STORM control switch.

#### R C. Conclusion

- R (1) Switch off and disconnect electrical ground  
R power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

# 33-12-00

Page 504  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

### BALLAST UNITS - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General (Ref. Fig. 401 )

This topic details the operations necessary for the removal and installation of six ballast units associated with the flight compartment main lighting system.

Two ballast units associated with the left and right dash storm floodlights are mounted on the underside of the glareshield, two ballast units associated with the flight compartment roof lights are located on the 3CM station secondary structure behind the upper electrical services panel, and two racking area roof lights ballast units are mounted in the flight compartment right hand upper racking on shelf 12-216.

#### 2. Storm Floodlight Ballast Unit

##### A. Equipment and Materials

---

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

---

##### B. Prepare

- (1) Check that the STORM lights selector switch on the flight compartment roof panel is at OFF.
- (2) Trip the RH & LH DASH STORM FLOODS SUP circuit breaker, L231, on panel 14-216, map ref.A8, and fit a safety clip.

##### C. Remove

- (1) From the top of the centre glareshield remove the six screws securing the ballast unit mounting plate to the exterior of the glareshield, and withdraw the mounting plate complete with ballast unit from the aperture in the glareshield to the extent of the cables.
- (2) Disconnect the electrical cables from the ballast unit.

EFFECTIVITY: ALL


BA

**33-12-11**

Page 401  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL



CMB3312114 AAMO

- Ballast Units - Installation  
Figure 401

EFFECTIVITY: ALL

BA

Printed in England

# 33-12-11

Page 402  
Jun 30/75



# *Concorde*

## MAINTENANCE MANUAL

- (3) Separate the ballast unit from the mounting plate by removing the four self-locking nuts.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Secure the ballast unit to the mounting plate with the four self-locking nuts.
- (3) Connect the electrical cables to the ballast unit, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (4) Insert the ballast unit through the aperture in the glareshield and secure the mounting plate to the glareshield exterior with the six screws.
- (5) Check that the ballast unit is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Remove the safety clip and reset the storm flood-light circuit breaker on panel 14-216.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Set the STORM lights selector switch on the flight compartment roof panel to "LH/RH DASH" and check that the LH and RH dash storm floodlamps are lit.
- (4) Set the STORM switch to "OFF".
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

## 3. Racking Area Roof Lights Ballast Unit

### A. Prepare

- (1) Isolate the electrical generation and external power equipment as detailed in 24-00-00, Servicing.
- (2) Gain access to the ballast units on the flight compartment right hand racking upper structure by opening the appropriate circuit breaker panels.

### B. Remove

EFFECTIVITY: ALL

BA

Printed in England

**33-12-11**

Page 403  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (1) Disconnect the electrical cables from the associated ballast unit.
- (2) Remove the four screws and washers securing the ballast unit to the shelf and withdraw the unit from its mounting.

### C. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the ballast unit to its mounting on the upper racking structure and secure it with the four screws and washers.
- (3) Connect the electrical cables to the ballast unit, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (4) Check that the ballast unit is bonded in accordance with 20-27-11.

### D. Conclusion

- (1) Close and secure the circuit breaker panels.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Operate the RKG AREA LTS - ROOF switch on the oxygen panel (20-215) and check that the racking area roof lights are on.
- (4) Switch off the racking area roof lights.
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

## 4. Flight Compartment Roof Lights Ballast Unit

### A. Prepare

- (1) Isolate the electrical generation and external power equipment as detailed in 24-00-00, Servicing.
- (2) Gain access to the ballast units on the 3CM station secondary structure by releasing the quick-release fasteners around the periphery of the upper electrical services panel (3-214), and lowering the panel on its hinges.

EFFECTIVITY: ALL

R  
BA

**33-12-11**

Page 404  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

### B. Remove

- (1) Disconnect the electrical cables from the associated ballast unit.
- (2) Support the ballast unit. Remove the four screws securing the ballast unit to the top of the structure and withdraw the unit from its mounting.

### C. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the ballast unit to its mounting on top of the the 3CM station structure and secure it with the four screws. Cover the screws protruding through the anchor nuts in accordance with 20-25-12.
- (3) Connect the electrical cables to the ballast unit, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (4) Check that the ballast unit is bonded in accordance with 20-27-11.

### D. Conclusion

- (1) Close panel 3-214 and secure it to the structure with the quick-release fasteners.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Set the ROOF lights switch on the flight compartment roof panel to "ON" and check that the flight compartment roof lights are on.
- (4) Set the ROOF Lights switch to "OFF".
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

R

BA

Printed in England

# 33-12-11

Page 405  
Aug 30/75

**END OF THIS  
SECTION**

**NEXT**

# Concorde

## MAINTENANCE MANUAL

### LIGHTS TEST AND DIMMING - DESCRIPTION AND OPERATION

#### 1. General

The lights test and dimming system allows the filaments of caption light modules and warning lamps, mounted in the flight compartment, to be tested or dimmed. For these purposes the filaments are connected in groups and each group is connected to an associated three-position switch engraved LO-HI-TEST. Some lamp units have their own dimmer, fitted as a separate dimming module for warning lights in dashboard-mounted instruments and as an integral part of all other units. "Mod 33 D090" removes the dimming facility from the "brakes fail" caption. When a brake failure is detected the caption will always illuminate at full brilliance. When testing the system the caption will also illuminate at full brilliance when the centre console light test switch is set at "LOW".

RB After SB 33-026 For A/C 006-007,

A relay controls the supply to a group of caption light modules and warning lights on some of the RH panels at the third crew member's (3CM) station.

Individual fuses are provided for the caption light modules and warning light units listed in Table 1. The fuses are located in the loom wiring near their associated caption or warning light.

#### ASSOCIATED CAPTION OR WARNING LIGHT

#### LOCATION

#### PANEL

Engine rating light unit	LH dash panel	2-211
INS warning light unit	LH dash panel	2-211
INNER ELEVON caption	RH dash panel	2-212
FLOW captions (3)	Cabin temperature/air bleed and fuel panel	2-214

Location of In-Line Fuses  
Table 1

RB After CM 42663 For A/C 001-005,

RB Individual fuses are provided for the caption light modules and  
RB warning light units listed in Table 1, the fuses are located in  
RB the loom wiring near their associated caption or warning light.

EFFECTIVITY: ALL

BA

C798216

**33-14-00**

Page 1  
Sep 30/92

# *Concorde*

## MAINTENANCE MANUAL

RB In addition the fuses listed in Table 1, 4 in-line fuses are  
RB located in the Fire Bottle Test Panel (28-214). These fuses are  
RB connected in the lights test supply to 4 of the 5 groups of  
RB smoke detector warning lights.

### 2. Caption Light Module

Each caption light module comprises a rectangular unit housing an electrical terminal block, filament contacts and blocking diodes. Certain modules are fitted with a solid state switching circuit and a dimming resistor. A hinged cover contains two filaments behind a translucent caption screen. Some caption light modules are provided with a press-to-test switching facility which illuminates the caption from a supply in its associated system.

### 3. Dimming Module

Each dimming module comprises a rectangular unit housing terminal blocks, blocking diodes, a solid state switching circuit and a dimming resistor.

RB  
RB After SB 33-026 For A/C 006-007,

### 4. Test Isolation Relay

The relay comprises a rectangular unit housing a 4-pole, 10 A relay, hermetically sealed with plug-in terminals mated to socket contacts in a relay base. It is mounted on the structure behind panel 6-214 (3CM station, lower electrical services panel) and, when energized by the setting of the panel LO-HI-TEST switch to TEST, it controls the supply to a group of caption light modules and warning lights on the following RH panels at the 3CM station:

6-214	-	lower electrical services panel.
3-214	-	upper electrical services panel.
28-214	-	fire bottle test panel.

RB After CM 42663 For A/C 001-005,

RB The Test Isolation Relay introduced by SB 33-026 is not fitted  
RB to aircraft modified to CM 42663.

### 5. Operation (Ref. Fig. 001 and 002)

#### A. Control

EFFECTIVITY: ALL

BA


C798217

**33-14-00**

Page 2  
Sep 30/92

# Concorde

## MAINTENANCE MANUAL



RB

Lights Test and Dimming - Pilot's Station  
Figure 001

EFFECTIVITY: ALL

BA


C798218

**33-14-00**

Page 3  
Sep 30/92

# Concorde

## MAINTENANCE MANUAL



- Lights Test and Dimming - 3CM Station  
Figure 002

EFFECTIVITY: ALL

**33-14-00**

R

BA

Page 4  
Aug 30/80

Printed in England



# Concorde

## MAINTENANCE MANUAL

RB After SB 33-026 For A/C 006-007,

Three position switches, engraved LO-HI-TEST and spring-loaded from TEST to HI, are fitted in the pilot's and 3CM stations. Each switch is associated with the appropriate caption and warning light filaments mounted on the panels (Ref. Fig. 001 and 002). In the TEST position, the switch controls the supply to the filaments either direct, or via in-line fuses or a relay. In the HI and LO positions, the switch controls the supply to the associated dimmers.

RB After CM 42663 For A/C 001-005,

RB Control of the lights test function on post mod CM 42663  
RB aircraft is, with one exception, the same as post mod SB  
RB 33-026 aircraft. The control relay introduced by SB 33-  
RB 026 (L1111) does not exist on post CM 42663 aircraft and the  
RB captions associated with this relay cannot be tested using  
RB the LIGHTS AFT LO-HI-TEST switch on the 3CM station.

### B. Functional Description

RB After SB 33-026 For A/C 006-007

Some captions and warning lights may be lit whenever power is available from the aircraft distribution system.

When a LO-HI-TEST switch is depressed and held at the TEST position, all the associated filaments, if serviceable, light at full brilliance. On release the switch returns to the HI position and the lights go out.

RB

On the pilot's roof panel (4-211) and the centre main power panel (4-214), certain caption light modules and warning lights are not included in the lights test circuit (Ref. Adjustment/Test).

When the switch is set at LO the relay or solid-state dimmer switch, associated with each caption module and warning light, is triggered and disconnects a short-circuiting link from a dimming resistor in the circuit of the associated lamps. In this condition the lamps, if activated by their respective systems, will light at reduced brilliance.

When the switch is set at HI the dimming resistor is short-circuited, and the lamps will light at full brilliance if activated by their respective systems.

Blocking diodes are fitted in the circuit to each caption and warning light to prevent feedback from the associated warning or indication circuit. The diodes are contained within the caption light and dimming modules.

EFFECTIVITY: ALL

BA

C798219

**33-14-00**

Page 5  
Sep 30/92

# Concorde

## MAINTENANCE MANUAL

RB After CM 42663

For A/C 001-005,

RB The operation of the Lights Test facility on aircraft with  
RB CM 42663 embodied is the same as aircraft with SB33-026  
RB embodied, except for captions in Table 2. These captions  
RB will not illuminate when the LIGHTS AFT LO-HI-TEST switch on  
RB the 3CM station is set to TEST.

---

### CAPTION

---

RB	Emergency Generator Overheat	
RB	AC Essential Bus	1
RB	AC Essential Bus	2
RB	AC Essential Bus	3
RB	AC Essential Bus	4
RB	Emerg Generator Fail	
RB	Battery Isolate	A
RB	Battery Isolate	B
RB	DC Essential Bus	A
RB	DC Essential Bus	B
RB	DC Main Bus	
RB	CSD Oil Low Pressure	1
RB	CSD Oil Low Pressure	2
RB	CSD Oil Low Pressure	3
RB	CSD Oil Low Pressure	4
RB	AC Main Bus Fail	1
RB	AC Main Bus Fail	2
RB	AC Main Bus Fail	3
RB	AC Main Bus Fail	4
RB	Generator	1
RB	Generator	2
RB	Generator	3
RB	Generator	4

RB Captions not connected to Lights  
RB Test on Post CM 42663 aircraft

RB Table 2

### 6. Electrical Power Supplies

The filaments and dimmers controlled by the LIGHTS TEST switches on the roof rear switch panel (4-211) and the 3CM brake panel (12-214) are supplied from the 'B' main 28 V d.c. busbar.

All other filament and dimmer-switched supplies are from the 'A' main 28 V d.c. busbar.

Filament and dimmer supplies with switched earths are supplied from the system being monitored.

EFFECTIVITY: ALL

BA

C798220

**33-14-00**

Page 6  
Sep 30/92

# *Concorde*

## MAINTENANCE MANUAL

### LIGHTS TEST AND DIMMING - TROUBLE SHOOTING

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

Except for the 3CM LH panels light testing circuit, all the light testing circuits are similar, therefore the procedures in Chart 101 are applicable to each circuit. Where two identical components are involved, i.e., one in each circuit, references to the associated components listed in Table 101 are given, e.g., 'Renew Switch (10), (12) or (13)'.

RB "Mod 33 D090" removes the dimming facility from the "brakes  
RB fail" caption. When a brake failure is detected the caption  
RB will always illuminate at full brilliance. When testing the  
RB system the caption will also illuminate at full brilliance when  
RB the centre console light test switch is set at "LOW".

#### 2. Preparation

A. Ensure that the associated circuit breakers are set (Ref. Table 101).

B. Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

C751678

**33-14-00**

Page 101  
Sep 30/91

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting

- A. Prepare to trouble shoot (Ref. para.2.). Press and hold at TEST Switches (7) to (13) in turn. Check that all caption and warning lamps, associated with each switch and listed in Adjustment/Test, Table 501, are lit. IF -

NOT OK

1. Individual caption or warning lamp filaments fail to light - renew faulty filaments.
2. All captions and warning lamps associated with any one switch fail to light - renew appropriate Switch (7) to (13).
3. Some of the captions and warning lamps associated with all three Switches (7), (8) and (9), fail to light - renew CB (1).
4. Some of the captions and warning lamps associated with Switch (10), (12) or (13) fail to light - Chart 101.
5. Some of the captions and warning lamps associated with Switch (11) fail to light - Chart 102.

CM83318001AAM0

EFFECTIVITY: ALL

BA

Printed in England

**33-14-00**

Page 102  
Jun 30/75

# Concorde


## MAINTENANCE MANUAL

SOME OF THE CAPTIONS AND WARNING LAMPS ASSOCIATED WITH SWITCH (10), (12) OR (13) FAIL TO LIGHT, WHEN THE SWITCH IS PRESSED AND HELD AT "TEST".

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



CMB3314001BAM0/00B

Chart 101

EFFECTIVITY: ALL

BA

Printed in England

**33-14-00**

Page 103  
Jun 30/75

# Concorde


## MAINTENANCE MANUAL

SOME OF THE CAPTIONS AND WARNING LAMPS ASSOCIATED WITH SWITCH (11) FAIL TO LIGHT WHEN THE SWITCH IS PRESSED AND HELD AT 'TEST'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before removal of components (\*), check the preceding run of wiring for continuity.



CMB3314001CNM0

Chart 102

EFFECTIVITY: ALL

BA

Printed in England

# 33-14-00

Page 104  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 28 V	-	15-215	L1001	Map ref.E14	24-50-00 R/I	
(2) Circuit breaker 28 V	-	15-216	L1002	Map ref.D13	24-50-00 R/I	
(3) Circuit breaker 28 V	-	15-216	L1003	Map ref.C12	24-50-00 R/I	
(4) Circuit breaker 28 V	-	15-216	L1004	Map ref.C13	24-50-00 R/I	
(5) Circuit breaker 28 V	-	15-215	L1005	Map ref.D13	24-50-00 R/I	
(6) Circuit breaker 28 V	-	15-215	L1006	Map ref.D14	24-50-00 R/I	
(7) Pilots' LH LIGHTS test switch	-	12-211	L1007	LH switch panel	33-14-00 R/I	
(8) Centre console lights test switch	-	9-211	L1008	Centre console, rear	33-14-00 R/I	
(9) Pilots' RH LIGHTS test switch	-	5-212	L1009	RH switch panel	33-14-00 R/I	
(10) Pilots' roof panel lights test switch	-	4-211	L1010	Pilots' roof panel	33-14-00 R/I	
(11) 3CM LH panels lights test switch	-	12-214	L1011	3CM brake panel	33-14-00 R/I	
(12) 3CM centre panels lights test switch	-	6-214	L1012	3CM elect. services lower panel	33-14-00 R/I	
(13) 3CM RH	-	6-214	L1013	3CM elect.	33-14-00	

EFFECTIVITY: ALL

BA

# 33-14-00

Page 105  
Nov 30/79

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL/ PANEL ZONE	EQUIP. POSITION IDENT.	MANUAL REF.	
			MAINT. TOPIC	WIRING DIAGRAM
panels lights test switch		services lower panel	R/I	

Component Identification  
Table 101

EFFECTIVITY: ALL

BA

**33-14-00**

Page 106  
Nov 30/79



# *Concorde*

## MAINTENANCE MANUAL

### LIGHTS TEST AND DIMMING - REMOVAL INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Access to faulty filaments in caption modules is gained by swinging the translucent caption open on its hinges. Access to filaments in indicator and warning lamps is gained by unscrewing the translucent lens.

Instructions for the removal and installation of associated switches are detailed in 33-00-00 for switches on the pilots' roof panel and in 33-10-00 for switches on all other panels.

After SB 33-026 For A/C 001-005,007-007,

This topic comprises removal and installation procedures for the test isolation relay.

#### 2. Test Isolation Relay (Ref. Fig. 401 )

##### A. Prepare

- (1) Isolate the electrical generation and external power supplies as detailed in 24-00-00, Servicing.
- (2) Open the lower electrical services panel 6-214 (third crew member's station) to the extent of the tie cord.

##### B. Remove

- (1) Remove the nuts and washers securing the relay to the relay base.
- (2) Remove the relay from the relay base.

##### C. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the relay to the relay base.
- (3) Secure the relay to the relay base with the

EFFECTIVITY: ALL

BA


Printed in England

**33-14-00**

Page 401  
Feb 28/81

# Concorde

## MAINTENANCE MANUAL



- Test Isolation Relay - Installation  
After SB 33-026  
Figure 401

nuts and washers; torque-tighten the nuts to 4 lbf in (0.045 mdaN).

### D. Conclusion

- (1) Close the panel.
- (2) Cancel the electrical safety precautions taken in operation A.(1) and remove the warning notices.
- (3) Carry out an Operational Test of the lights test and dimming circuit (Ref. Adjustment/Test).

EFFECTIVITY: ALL

R

BA

**33-14-00**

Page 402  
Feb 28/81

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

### LIGHTS TEST AND DIMMING - ADJUSTMENT/TEST

#### 1. General

Functional and System Tests are not applicable, so this topic contains only an Operational Test, which details the procedure to prove the filaments in the caption and warning light modules fitted in the flight compartment. "Mod 33 D090" removes the dimming facility from the "brakes fail" caption. When a brake failure is detected the caption will always illuminate at full brilliance. When testing the system the caption will also illuminate at full brilliance when the centre console light test switch is set at "LOW".

RB After SB 33-026 For A/C 006-007,

The text is applicable to all modules on the panels listed in Table 501, except for the pilot's roof panel 4-211 and the centre main power panel 4-214 (third crew member's station). The modules associated with the roof panel test switch are listed in Table 501. All modules on the centre main power panel may be tested by the appropriate switch, except for the TCA/Fuel Temp. warning lights.

The HI and LO switch positions control the supply to the associated caption and warning lamp dimmer circuits, and the lamps, when activated by their own systems, light at full or reduced brilliance accordingly.

With only electrical ground power applied to the aircraft distribution system, certain captions and warning lamps are lit by intrinsic fault conditions, e.g., CSD failure, GEN failure, etc.

RB After CM 42663 For A/C 001-005,

RB Operational testing of post mod CM 42663 aircraft is the same as  
RB post SB33-026 aircraft except that the captions listed in  
RB Table 2 (Ref. page 6 para. 5B) will not illuminate. These  
RB captions are tested by pressing the individual captions.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00

EFFECTIVITY: ALL

BA

C798221

**33-14-00**

Page 501  
Sep 30/92

# *Concorde*

## MAINTENANCE MANUAL

### B. Test

- (1) Press, and hold at TEST each test switch listed in Table 501, in turn, and check that all associated captions and warning lights are fully illuminated and that no master warning signal is initiated.

RB After CM 42663

For A/C 001-005,

- RB (2) Check the operation of the captions listed in Table 2  
RB (Ref. Page 6 para.5B) by using the press to test  
RB facility on each caption.

PRINTED IN ENGLAND

EFFECTIVITY: ALL

BA

C798231

# 33-14-00

Page 501A  
Sep 30/92

***Concorde***  
MAINTENANCE MANUAL

LEFT BLANK INTENTIONALLY

EFFECTIVITY: ALL

BA

C798232

**33-14-00**

Page 501B  
Sep 30/92

# Concorde

## MAINTENANCE MANUAL

**NOTE:** Careful observation may be necessary to ascertain that both filaments in each module are lit. Renew filaments if necessary.

R R	SWITCH LOCATION	ASSOCIATED CAPTION AND WARNING LAMP LOCATION/ TITLE	PANEL
	LH switch panel 12-211	LH dash panel	2-211
		LH glareshield	3-211
		LH forward racking shelf	4-215
		RH forward racking shelf	4-216
	Centre console, rear panel 9-211	Centre dash panel	6-211
		Centre console, rear panel	9-211
	RH switch panel 5-212	RH dash panel	2-212
		RH glareshield	3-212
		LH forward racking shelf	4-215
		RH forward racking shelf	4-216
	Roof, rear switch panel 4-211	THROTTLE MASTER switch toggles (4)	4-211
		LIGHTS EMERG switch toggle	4-211
		WING & INTAKE ANTI-ICING INT 1 + 2, 3 + 4 and CYCLIC captions (4)	4-211
		ICE detector captions (3)	4-211
		FIRE FLAPS caption	4-211
		Windshield, visor and	4-211

EFFECTIVITY: ALL

BA

Printed in England

**33-14-00**

Page 502  
Aug 30/80

# Concorde

## MAINTENANCE MANUAL

R R	SWITCH LOCATION	ASSOCIATED CAPTION AND WARNING LAMP LOCATION/ TITLE	PANEL
		DV window O/HEAT captions (6)	
		ADS/ENGINE PROBE HEATERS captions (15)	4-211
		Drain MAST 1, MAST 2 and MAST 3 captions (3)	4-211
		ENGINE ANTI-ICING IGV PRESS captions (4)	4-211
		Landing/taxi lights EXTENDED caption	4-211
		Main landing lights EXTENDED caption	4-211
	Brake panel 12-214	Pressurization and main power panel, upper	1-214
R R R R R		Main power panel, centre <u>NOTE:</u> After SB 33-026, the TCA/Fuel Temp. warning lights are not included in the test circuit.	4-214
		De-icing indication	8-214
		Wheel overheat indication	8-214
		Intake test system	8-214
		Intake control lane failure	8-214
		Brake panel	12-214
		EPU control panel	14-214
		Engine starting panel	18-214

EFFECTIVITY: ALL

BA

**33-14-00**

Page 503  
Aug 30/80

# *Concorde*

## MAINTENANCE MANUAL

R R	SWITCH LOCATION	ASSOCIATED CAPTION AND WARNING LAMP LOCATION/ TITLE	PANEL
		Fire loop panel	21-214
		Door warning panel	25-214
		Engine vibration indicator panel	2-216
	Electrical services panel, lower 6-214	Cabin temperature/air bleed and fuel panel	2-214
		Fuel panel, lower	5-214
		Electrical services panel, upper	3-214
		Electrical services panel, lower	6-214
		Oxygen panel	7-214
		ADS test panel	15-214
		Fire bottle test panel	28-214

Filament Test Data  
Table 501

### C. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-14-00**

Page 504  
Aug 30/80



# Concorde


## MAINTENANCE MANUAL

### MASTER WARNING SYSTEM - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig. 001 )

The master warning system forms part of a flight compartment warning concept which also includes an audio warning system (Ref. 31-23-00) and visual local system failure warnings which are described in the appropriate system chapters.

The local system failure warnings are classified by degree of importance which is indicated by the colour of the visual indication used:



Controls and Indicators  
Figure 001

- (1) Class 1: Red warnings: indicate a condition which must be brought to the immediate attention of the crew. These warnings generally require immediate remedial action.
- (2) Class 2: Amber warnings: indicate a condition which must be brought to the immediate

EFFECTIVITY: ALL

**33-15-00**

Page 1  
Feb 28/79

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

attention of the crew, but immediate remedial action is not generally required.

- (3) Class 3: Yellow, green, white and blue warnings: indicate a condition which requires monitoring only.

Of these warnings only certain class 1 and 2 warnings are associated with the master warning system (Ref. Tables 1 and 2 respectively). In general, the failures associated with the master warning system are indicated by a distinctive sound accompanied by simultaneous illumination of a failure caption on a centralized warning display, and a local warning light or caption on the appropriate systems panel.

The master warning system comprises a control unit and a display panel. The control unit accepts the various system failure input signals and processes them to produce output signals suitable -

- (1) for controlling individual caption lamps on the display panel, and
- (2) for initiating the sounding of a single stroke gong by the audio warning system.

In addition, output signals to a flight data recording (FDR) system (Ref. 31-31-00) are provided on receipt of certain failure warning signals (Ref. Table 3).

The single stroke gong draws attention to the display panel, which enables rapid identification of the system producing the warning. The precise cause of the warning is then determined by reference to the local system warning indications.

Each caption on the display panel can indicate more than one failure from the associated system, provided that the first failure indication and each successive failure indication is cancelled by depressing the face of the caption. Failure inputs applied to a caption that has not been cancelled are indicated by the sounding of the single stroke gong.

Provided that the failure condition(s) still exist, cancelled warnings can be reinstated by a recall facility on the display panel; the audio warnings are not repeated when this facility is used.

In addition, certain red and all amber master warning

EFFECTIVITY: ALL

R

BA

**33-15-00**

Page 2  
Feb 28/79

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

captions and the associated audible warnings can be inhibited by an inhibit facility on the display panel; two amber indicator lamps on the display panel are illuminated to indicate this condition.

R The TRIM and ADS captions (for incidence comparison warning  
R only) are inhibited when the aircraft speed exceeds 60 knots during the take-off run.

A filament test and a cancel facility, which cancels all illuminated captions, is provided on the display panel to facilitate maintenance procedures.

Each associated system warning circuit has a test facility which provides a master warning test input. This input is applied to the control unit to check the operation of the appropriate warning caption and the accompanying audio warning.

A master warning cancel facility is provided at the third crew member's station to enable all illuminated master warning captions to be cancelled simultaneously to facilitate pre-flight check procedures.

Provision is made at four test connectors, mounted near the control unit on shelf 7-216 (Ref. Fig. 002), for the connection of a test set to facilitate system testing.

### 2. Display Panel (Ref. Fig. 001)

The master warning display panel is mounted on the forward end of the pilots' roof panel (4-211) facing the pilots.

The failure captions are mounted on the front face. Each failure caption assembly comprises an integral switch, two filaments and an engraved filter coloured red or amber to indicate the classification of the warning. Access to the filaments is gained by hinging open the caption face.

The integral switch enables each caption to be cancelled separately by depressing the caption face.

Three push-switches and two amber indicator lamps are also mounted on the panel front face. One push-switch, designated INHIBIT, facilitates inhibition of certain red (Ref. Table 1) and all amber failure captions on the display panel and, in addition, inhibit the sounding of the single-stroke gong associated with the health (serviceability) monitor and the intermittent horn associated with the excessive cabin altitude warning (Ref. 31-23-00). When this facility is used the two amber INHIBIT indicator lamps are lit. A dimming facility (Ref. 33-14-00) enables the two INHIBIT lamps to be dimmed.

The second push-switch, designated LTS TEST/CANCEL,

EFFECTIVITY: ALL

BA

C751730

# 33-15-00

Page 3  
Sep 30/91

# *Concorde*

## MAINTENANCE MANUAL

enables all filaments on the display panel to be tested simultaneously when the switch is held depressed. When the switch is released, all captions are cancelled, including those illuminated prior to the test being made.

The third push-switch, designated RECALL, allows the inhibition to be removed from the failure captions, and/or all cancelled captions to be reinstated, provided that the failure condition has not been cleared.

The display panel engravings associated with the inhibit indicator lamps and the three push-switches are illuminated by integral 'Beta lights' contained within the panel.

Electrical connections to the display panel are made via two connectors mounted on the rear of the panel.

### 3. Control Unit (Ref. Fig. 002 )

The control unit is housed in a 1/2 ATR short case and mounted on shelf 7-216 in the flight compartment right-hand equipment racking. Two Camloc handles, mounted on the front of the case, facilitate fitment of the unit.

The control unit accepts and monitors input lines from the applicable systems throughout the aircraft. These lines are segregated into four sections, each section being processed separately, thus ensuring that interference between lines of different sections cannot occur. Within each section warning inputs are grouped by system to enable one or more failures from a particular system to illuminate a common failure caption on the display panel. This grouping arrangement is detailed in Tables 1 and 2.

The control unit performs the following basic operations:

- (1) Standardizes the various inputs.
- (2) Rejects electrical transients which could cause false warning indications.
- (3) OR-gates signals received from the same system.
- (4) Provides control signals for the display panel failure captions.
- (5) Implements -
  - (a) the inhibition of the audible warnings,

EFFECTIVITY: ALL

R

BA

Printed in England

**33-15-00**

Page 4  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

- (b) the cancel facility, and
- (c) the recall facility.
- (6) Provides, when applicable, an output signal to the FDR system.
- (7) Provides, when applicable, four separate external drive outputs, one to each engine shut-down hand warning caption.
- (8) Provides two separate outputs to a system health (serviceability) monitor for detection and indication of total failure of the master warning system.

Three indicator lamps, PS1, PS2 and CLOCK, are mounted on the front panel. Normally lit, lamps PS1 and PS2 indicate the serviceability of two separate power supplies and the CLOCK lamp indicates the serviceability of both separate clock circuits, all within the control unit.

Provided that one power supply and one clock circuit is maintained the control unit remains fully operational.

#### 4. Operation

##### A. Control and Indication

The master warning controls and indicator are contained on the overhead display panel. Additional monitoring lamps are contained on the control unit, and the pre-flight check cancel control is located at the 3CM station.

Each master warning caption and the related system warning are detailed in Tables 1 and 2, and associated FDR inputs are shown in Table 3. The display panel controls, the control unit monitoring lamps and the pre-flight check cancel control are summarized as follows:

- (1) LTS TEST/CANCEL push-switch.

This switch is used to test the serviceability of all the filaments in the display panel and to cancel all warning captions illuminated prior to commencement of the test.

- (2) INHIBIT push-switch.

This switch is used to inhibit certain red captions

EFFECTIVITY: ALL

BA


C807791

**33-15-00**

Page 5  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL



CMB3315000BAND

Location of Equipment  
Figure 002

EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 6  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

(Ref. Table 1) and all amber captions.

(3) INHIBIT warning lamps.

Two inhibit warning lamps are used to indicate that the operation of certain red and all amber warning captions is inhibited.

(4) RECALL push-switch.

This switch is used to remove the inhibition imposed by operation of the inhibit facility, and to reinstate all inhibited or cancelled warning captions that have a fault signal applied when the recall facility is implemented.

(5) PS1 and PS2 monitor lamps.

These lamps are normally lit and are used to indicate a failure of either or both power supplies in the control unit. A fault is indicated by a lamp being extinguished.

(6) CLOCK monitor lamp.

This lamp is normally lit and is used to indicate a failure of one of the two clock circuits in the control unit. A fault is indicated by the lamp being extinguished.

(7) MWS CANCEL push-switch.

This switch is used to cancel all master warnings displayed on the display panel as required during the pre-flight check procedures.

R B. MWS-TRIM and MWS-ADS Inhibition

R (1) Following application of MWS INHIBIT, the MWS TRIM and ADS  
R captions are inhibited for incidence comparison failures and  
R TRIM (1 and 2) disconnects which occur during the take-off  
R run at airspeeds greater than 60 knots.

R TRIM warnings are reinstated by application of MWS RECALL.

R ADS warnings are reinstated at 'weight off wheels'.

EFFECTIVITY: ALL

BA

C751709

**33-15-00**

Page 7  
Sep 30/91

# Concorde

## MAINTENANCE MANUAL

DISPLAY PANEL CAPTION (RED)	WARNING DESCRIPTION	LOCAL SYSTEM INDICATION	SYSTEM WARNING LOCATION
--------------------------------	------------------------	----------------------------	----------------------------

\* Denotes subject to  
inhibit facility

*FEEL	Failure of artificial feel channels 1 or 2 in roll, pitch or yaw	Switch(es) at OFF position	4-211
PFC	Main jack low pressure (green)	GREEN L/PRESS caption	4-211
	Main jack low pressure (blue)	BLUE L/PRESS caption	4-211
	Main jack spool valve seizure (green)	GREEN FAIL caption (servo controls panel)	4-211
	Main jack spool valve seizure (blue)	Blue FAIL caption (servo controls panel)	4-211
	Relay jack spool valve seizure (green)	GREEN FAIL caption (relay jacks panel)	4-211
	Relay jack spool valve seizure (blue)	BLUE FAIL caption (relay jacks panel)	4-211
	Green inverter failed	FAIL caption	4-211
	Blue inverter failed	FAIL caption	4-211

EFFECTIVITY: ALL

R

BA

Printed in England

**33-15-00**

Page 8  
May 30/76



# Concorde

## MAINTENANCE MANUAL

DISPLAY PANEL CAPTION (RED)	WARNING DESCRIPTION	LOCAL SYSTEM INDICATION	SYSTEM WARNING LOCATION
	Mechanical jam	MECH JAM caption	2-212
	Change of mode	Red light on flight controls indicator	2-212
R R	Inner elevon desynchronized	INNER ELEV caption	2-216
R *STAB	Auto- stabilizer total failure in any one axis, roll, pitch or yaw	Switches at OFF position	4-211
*M/CG	Mach/c.g. warning	-	-
ENG 1, ENG 2, ENG 3 and ENG 4	Engine and gearbox oil low pressure	Red light on engine oil low pressure indicator	4-214
	Engine overheat	ENGINE O/HEAT caption	1-214
	Engine front bearing vibration high	Red light on engine vibration indicator	4-214
	Engine turbine cooling air (TCA) overheat	ENGINE O/HEAT caption	1-214
	Engine fire	Red light on engine shut- down handle	4-211
	Fuel leak over No.1, 2, 3 or 4 engine	LEAK caption	5-214

EFFECTIVITY: ALL

BA

**33-15-00**

Page 9  
May 30/76

Printed in England

# Concorde

## MAINTENANCE MANUAL

DISPLAY PANEL CAPTION (RED)	WARNING DESCRIPTION	LOCAL SYSTEM INDICATION	SYSTEM WARNING LOCATION
*THROT	No.1, 2, 3 or 4 throttle failure or throttles selected OFF with HP cocks selected ON	THROT caption	9-211
*PRESS	Cabin overpressure or cabin altitude excessive	O/PRESS caption; EXCESS ALT caption	1-214
*RAD'N	Radiation level high	Red Light on radiation indicator	19-214
*ICE	Ice detected, de-icing selected OFF	ICE caption	4-211
*INS	Failure of inertial navigation system (INS) 1, 2 or 3	WARN caption on INS display	7-211
	Loss of INS information to the auto- flight control system	INS 1, INS 2 or INS 3 caption	2-211
ADS	Discrepancy between the outputs of the ADC comparators	-	-
TRIM	Failure of both Nos.1 and 2 electrical trim channels	Switches at OFF position	4-211

EFFECTIVITY: ALL

**33-15-00**

R

BA

Page 10  
May 30/76

Printed in England

# Concorde

## MAINTENANCE MANUAL

DISPLAY PANEL CAPTION (RED)	WARNING DESCRIPTION	LOCAL SYSTEM INDICATION	SYSTEM WARNING LOCATION
R *ELEC	D.c. essential busbar failure	DC ESS BUS caption	6-214
	A.c. essential busbar failure	AC ESS BUS caption	6-214
	Emergency generator overheat	O/HEAT caption	6-214
*DOORS	Unlocked door, escape hatch or access hatch	FRONT LEFT, FRONT RIGHT, UPPER CARGO, CENTRE LEFT, CENTRE RIGHT, MISC HATCHES, REAR LEFT, REAR RIGHT or LOWER CARGO caption	25-214
R *INT 1, INT 2, INT 3, or INT 4	Intake automatic control failure or intake on test	INT caption	Intake auto control panel

Class 1 Master Warnings (Red)  
Table 1

EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 11  
May 30/76

# Concorde

## MAINTENANCE MANUAL

DISPLAY PANEL CAPTION (AMBER)	WARNING DESCRIPTION	LOCAL SYSTEM INDICATION	SYSTEM WARNING LOCATION
C/G	CG channel failed	CG channel caption	5-214
ENG 1, ENG 2 ENG 3 or ENG 4	Engine fire detection loop failure	FIRE SENSOR caption No.1, 2, 3 or 4	21-214
	Engine oil overheat	Amber light on oil temperature indicator	4-214
	Engine fuel temperature high	Amber light on fuel temperature indicator	4-214
	Nacelle/wing overheat	NAC/WING O/HEAT caption	1-214
	Engine fuel filter blockage	FUEL FILTER caption	1-214
	Rear bearing vibration high	Amber light on engine vibration indicator	4-214
**ON A/C ALL ENG 1, ENG 2 ENG 3 or ENG 4	Torch flame detected	-	-
**ON A/C ALL			
FUEL	Low level in No.1, 2, 3 or 4 collector tank	LOW LEVEL caption	5-214
	Low fuel pressure No.1, 2, 3 or 4 engine	LOW PRESS caption	5-214

EFFECTIVITY: ALL

**33-15-00**

Page 12  
May 30/79

# Concorde

## MAINTENANCE MANUAL

DISPLAY PANEL CAPTION (AMBER)	WARNING DESCRIPTION	LOCAL SYSTEM INDICATION	SYSTEM WARNING LOCATION
	Tank pressurization failed	TANK PRESS caption	15-214
NAV	Failure of inertial information: No.1, 2 or 3	-	-
ADC	No.1 ADC failed	ADS 1 caption	15-214
	No.2 ADC failed	ADS 2 caption	15-214
AIR	Forward equipment bay flow failed	FLOW caption	2-214
	Rear equipment bay flow failed	FLOW caption	2-214
	Air conditioning failed: No.1, 2, 3, or 4	-	-
	Air conditioning overheat: No.1, 2, 3 or 4	-	-
INT 1, INT 2 INT 3 and INT 4	N1 failed	N1 SIG caption	) ) ) )
	Incidence failed	Alpha (symbol) FAIL caption	) Intake ) auto ) control panel )
	Lane failed	LANE caption	)

EFFECTIVITY: ALL

**33-15-00**

R

BA

Page 13  
May 30/79

Printed in England

# Concorde

## MAINTENANCE MANUAL

DISPLAY PANEL CAPTION (AMBER)	WARNING DESCRIPTION	LOCAL SYSTEM INDICATION	SYSTEM WARNING LOCATION
	Hydraulics failed	HYD caption	) ) )
	Auto N1 reduce failed	Amber light on N1 indicator	6-211
HYD	Pump pressure: Green No.1 or 2 Blue No.3 or 4 Yellow No.2 or 4	PRESS caption	3-214
	Tank low level: Green, Blue or Yellow	L/LEVEL caption	
	Tank overheat: Green (No.1) Blue (No.2) or Yellow (No.3)	O/HEAT caption	3-214
ELEC	No.1, 2, 3 or 4 a.c. main busbar failure	AC MAIN BUS caption	3-214
	No.1, 2, 3 or 4 CSD failure	CSD 1, 2, 3 or 4 caption	3-214
	No.1, 2, 3 or 4 generator failure	GEN 1, 2, 3 or 4 caption	3-214
	DC main busbar failure	DC MAIN BUS caption	6-214
	No.1 or 2 battery isolated	BATT ISOLATE caption	6-214

EFFECTIVITY: ALL

BA

**33-15-00**

Page 14  
May 30/79

Printed in England

# Concorde

## MAINTENANCE MANUAL

DISPLAY PANEL CAPTION (AMBER)	WARNING DESCRIPTION	LOCAL SYSTEM INDICATION	SYSTEM WARNING LOCATION
SMOKE	Smoke detected in:		
	Forward left electronic rack	Smoke A caption	28-214
	Forward pressurization valve	Smoke B caption	28-214
	Underfloor freight hold	Smoke C caption	28-214
	Aft left electronic rack	Smoke D caption	28-214
	Aft pressurization valve	Smoke E caption	28-214
	Aft right electronic rack	Smoke F caption	28-214
	Above floor hold	Smoke G caption	28-214
	Underfloor right electronic rack	Smoke H caption	28-214
	Forward right electronic rack	Smoke J caption	28-214
	Underfloor left electronic rack	Smoke K caption	28-214

EFFECTIVITY: ALL

**33-15-00**

Page 15  
May 30/79

# *Concorde*

## MAINTENANCE MANUAL

DISPLAY PANEL CAPTION (AMBER)	WARNING DESCRIPTION	LOCAL SYSTEM INDICATION	SYSTEM WARNING LOCATION
	No.1, 2, 3 or 4 air conditioning generation main supply duct	Smoke 1, 2 3 or 4 caption	28-214

Class 2 Master Warnings (Amber)  
Table 2

EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 16  
May 30/79



# Concorde

## MAINTENANCE MANUAL

### MASTER WARNING INDICATION

### INPUT SIGNAL TO FDR SYSTEM

ENG 1 (Red)	4 input	)	On application of a master warning
ENG 2 (Red)	'OR gate'	)	signal to any of these captions
ENG 3 (Red)	provides	)	an 'input status' (system state)
ENG 4 (Red)	single output	)	signal is applied to the FDR
		)	System. These signals are
INT 1 (Red)	4 input	)	present whenever a fault warning
INT 2 (Red)	'OR gate'	)	input is applied to the master
INT 3 (Red)	provides	)	warning system and are unaffected
INT 4 (Red)	single output	)	by the inhibit or cancel
		)	facilities.
		)	
PFC (Red)		)	
		)	
THROT (Red)		)	
		)	
TRIM (Red)		)	
		)	
STAB (Red)		)	
		)	
FEEL (Red)		)	
		)	
ICE (Red)		)	When illuminated an 'output status'
		)	(displayed caption state) signal
ADS (Red)		)	is applied to the FDR system.
		)	These signals are representative
ELEC (Red)		)	of the display panel caption state.
		)	
PRESS (Red)		)	
		)	
INS (Red)		)	
		)	
R DOORS (Red)		)	
		)	
R ENG 1 (Red)		)	
R ENG 2 (Red)		)	
R ENG 3 (Red)		)	
R ENG 4 (Red)		)	
		)	
SMOKE (Amber)		)	
		)	
R ENG 1 (Amber)		)	
R ENG 2 (Amber)		)	
R ENG 3 (Amber)		)	
R ENG 4 (Amber)		)	

EFFECTIVITY: ALL

BA

Printed in England

# 33-15-00

Page 17  
Nov 30/77

# *Concorde*

## MAINTENANCE MANUAL

---

MASTER WARNING  
INDICATION

INPUT SIGNAL TO  
FDR SYSTEM

---

FDR Input Signals  
Table 3

EFFECTIVITY: ALL


R

BA

**33-15-00**

Page 18  
Nov 30/77

Printed in England



# *Concorde*

## MAINTENANCE MANUAL

### B. Functional Description (Ref. Fig.003 and 004)

The warning inputs from the related systems are divided into four groups and routed via four connectors to four separate groups of input gating boards in the control unit.

Each input has two signal states, clear or fault, representing the condition of the parameter being monitored. A fault signal must be present for not less than 750 ms in order to overcome a clock-controlled noise rejection delay. This delay eliminates the possibility of false warnings resulting from transients.

The input signals are filtered and conditioned to a standard suitable for wire OR gating with other signals from the same aircraft system, and for interfacing with a caption lamp drive circuit.

Signal conditioning of each input signal is accomplished by a RC filter followed by a clock controlled digital filter. The digital filter produces two outputs referred to as the 'pulse output' and the 'switch output' respectively.

The switch output produces a continuous positive voltage level for the duration of the fault warning.

The pulse output is a momentary positive signal in the form of a 250 ms pulse which has a leading edge coincident with the leading edge of the switch output, and is only produced when the switch output goes positive.

The two outputs from each digital filter associated with a particular aircraft system are interconnected to form two separate 'wired OR gates', one for the switch outputs and one for the pulse outputs. The resulting output from both OR gates is then applied to a caption lamp drive circuit. In addition -

- (a) the switch output of systems associated with the FDR system is applied to an input status buffer which, in turn, provides an 'input status' signal to the FDR system,
- (b) the pulse outputs of all red master warnings are applied to an audio warning pulse generator circuit and, provided that the input is not inhibited, a signal is applied to the audio warning system to

EFFECTIVITY: ALL

**33-15-00**

R


BA

Page 19  
Nov 30/77

# Concorde

## MAINTENANCE MANUAL

CMB3315000CAM0



- Typical Master Warning Control Circuits -  
Simplified Schematic  
Figure 003

EFFECTIVITY: ALL

R


BA

Printed in England

33-15-00

Page 20  
Nov 30/77

CM83315000DAMQ



- Typical Master Warning Signal Chain -  
Simplified Schematic  
Figure 004

EFFECTIVITY: ALL

R

BA

Printed in England

**33-15-00**

Page 21  
Nov 30/77

# *Concorde*

## MAINTENANCE MANUAL

sound a repetitive (one stroke per 10 s) single-stroke gong,

- (c) the pulse outputs of all amber master warnings are applied to an associated audio warning pulse generator circuit and, provided that the input is not inhibited, a signal is applied to the audio warning system to sound the single-stroke gong, and
- (d) the pulsed and switched outputs of engine RED inputs are applied to an external drive circuit that provides a steady state output to an associated engine shut-down handle warning caption.

Each caption lamp drive circuit is associated with a particular caption on the display panel and when switched on completes the 0 V return circuit for the caption lamp load.

The drive circuit contains two switch elements referred to as A and B respectively, and both must assume the 'on' state before the 0 V return circuit to the related caption is completed. Switch element B is controlled by the switch output OR gate and assumes the 'on' condition whenever the switch output is present, i.e., for the duration of the fault conditions. Switch element A is controlled by the pulse output OR gate and assumes the 'on' state for a duration of 250 ms whenever the switch output goes to the positive state, i.e., on initial receipt of the fault input. During this time switch element A applies a signal to the trigger of a silicon-controlled rectifier (SCR) in the 0 V return line of the caption lamp load. Provided that the caption lamp load circuit is otherwise complete, this signal switches the SCR to the conducting state and the SCR is then 'latched on' by the current flow in the circuit, and the associated caption is illuminated. The caption will then remain illuminated until the fault condition is cleared, the caption lamp load circuit is interrupted or the MWS CANCEL facility is used.

In addition, completion of the caption load circuit of certain systems associated with the FDR system also applies a signal to an output status buffer which, in turn, provides an 'output status' signal to the FDR system.

When the fault has been indicated on the display panel it is desirable to cancel the caption by depressing the caption face. Cancelling a caption leaves it free to indicate further warnings from the same aircraft system.

EFFECTIVITY: ALL

R

BA

Printed in England

# 33-15-00

Page 22  
Nov 30/77

# *Concorde*

## MAINTENANCE MANUAL

If however the caption is not cancelled, every additional fault produces warning inputs to the OR gate and the pulse switch output initiates operation of the audio warning only.

Captions cancelled by the caption press-to-cancel facility or the MWS CANCEL switch can be reinstated, provided that the originating fault has not cleared, by using the recall facility. When the RECALL push-switch is pressed a recall pulse circuit in the control panel applies a pulse input to switch element A in the caption lamp drive circuit. This pulse causes the switch element to assume the 'on' state and a signal is applied to the trigger of the SCR. As switch element B is already in the 'on' state (fault signal present) the SCR is latched on and the caption is re-illuminated, but the audio warning is not given.

When the inhibit facility is used the INHIBIT push-switch is pressed and a circuit is completed to -

- (a) illuminate both INHIBIT amber indicating lamps, and
- (b) energize relay RL1.

Energization of relay RL1 -

- (a) completes a latching circuit, via the RECALL push-switch, to maintain the relay energized,
- (b) removes the 28 V d.c. positive supply from those captions affected by the inhibit facility, and
- (c) applies an inhibit clamp signal to the 'inhibited' audio warning signals in the control unit.

In this condition only uninhibited captions and uninhibited audio warnings can effect warnings.

The inhibition is removed by pressing the RECALL push-switch. This action unlatches relay RL1 which, in turn, extinguishes the INHIBIT indicator lamps, removes the inhibit clamp from the audio warning signal inputs and reinstates the 28 V d.c. supply to the inhibited captions. In addition, a recall pulse is applied to switch element A in the control unit and any caption lamp drive circuit that is armed by a fault input, i.e., switch element B in the 'on' state, is latched on and the appropriate caption is illuminated.

When the LTS TEST/CANCEL push-switch is depressed all

EFFECTIVITY: ALL

R

BA

**33-15-00**

Page 23  
Nov 30/77

# *Concorde*

## MAINTENANCE MANUAL

serviceable filaments on the display panel are lit and all master warnings to the display panel are cancelled. In the operated position the push-switch -

- (a) completes a test circuit to each filament, and
- (b) clamps all the caption lamp drive circuits to 0V. This action causes any operating SCR to cease conducting, thus removing the master warning signal from the appropriate caption.

When the switch is released all master warning captions are extinguished; if the inhibit facility was in use prior to the test the inhibit captions will remain illuminated. Use of the recall facility enables all warnings cancelled during this test to be reinstated, provided that the fault condition has not cleared.

When the MWS cancel push-switch is depressed a 0V input is applied to an a.c. isolator in the control unit. A single pulse output is produced by the isolator to momentarily clamp the switch input to each switch element B at 0V, thus causing each conducting switch element to be switched off, the caption lamp drive circuit to be interrupted and all illuminated master-warning captions to be extinguished. The a.c. isolator prevents permanent application of the MWS cancel signal from affecting the system, i.e., the change of state to 0V and not the signal level causes the cancellation. All cancelled captions can be reinstated by use of the RECALL facility.

R MWS-TRIM and MWS-ADS Inhibition during take-off run.

R MWS-TRIM Inhibition

- R (a) A MWS-TRIM caption can only be initiated if both  
R TRIM 1 and TRIM 2 disengaged signals appear at the  
R MWS 'AND' gate inputs.

EFFECTIVITY: ALL

BA

C751731

**33-15-00**

Page 24  
Sep 30/91



# *Concorde*

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

- (b) TRIM 2 engagement signals of -15V are taken to Logic Unit 2 (LU2) terminals 7 and 8 (these signals change to +15V on disengagement of TRIM 2), hence transistor No.2 of LU2 (LU2-TR2) will not turn ON.
- (c) When MWS-INHIBIT is selected a signal of +28V is applied to Resistor No.1 of LU2 (LU2-R1). When the aircraft speed is higher than 60 knots the ground is removed from the cathode of diode No.1 of LU2 (LU2-D1) and provided LU2-TR2 has not been turned ON, transistor No.1 of LU2 (LU2-TR1) will turn ON and relay RL1A will energise and in turn energise relay RL1B.
- (d) When relays RL1A and RL1B are energised, the engagement signals from TRIM 2 are replaced with a simulated "healthy" -15V signal to the MWS-TRIM "AND" gate inputs. This will maintain the MWS-TRIM "AND" gate outputs at 0 regardless of disengagement signals from TRIM 1 and TRIM 2.
- (e) When the MWS is recalled the +28V signal at LU2-R1 will disappear, LU2-TR1 and relays RL1A and RL1B will de-energise and TRIM 2 engagement signal lines will be reconnected to the MWS-TRIM "AND" gate inputs. A MWS-TRIM warning will be given if both TRIM 1 and TRIM 2 are disengaged.
- (f) If before relays RL1A and RL1B are energised, TRIM 2 is disengaged, a +15V signal will appear at terminals 7 and 8 of LU2 and will turn ON LU2-TR2. This will prevent LU2-TR1 from turning ON and relays RL1A and RL1B from energising. A MWS-TRIM warning will then be given if TRIM 1 is disengaged and will not be inhibited when the aircraft has accelerated past 60 knots.

EFFECTIVITY: ALL

BA

C751732

**33-15-00**

Page 25  
Sep 30/91

# *Concorde*

## MAINTENANCE MANUAL

### MWS-ADS Inhibition

The MWS-ADS inhibition circuit operates relay RL2 using Logic Unit No.3 (LU3) similar to that used in the MWS-TRIM inhibition circuit.

- (a) The +28V signal to terminal 4 of LU3 is supplied via the undercarriage weight switch relay.
- (b) The LU3 common ground connection is via relay RL1B and hence LU3 will only be operative if MWS-TRIM inhibited.
- (c) If the MWS-TRIM circuit is in the inhibit state, the "healthy" +28V incidence comparator signal to TRIM 2 will turn transistor No.2 of LU3 (LU3-TR2) ON and hence maintain the base of transistor No.1 of LU3 (LU3-TR1) at ground and relay RL2 will remain de-energised.
- (d) If the incidence comparator detects a discrepancy, the incidence comparator signals to both TRIM 1 and TRIM 2 will go to the non-healthy state (0V) and both Trims will disengage. At this instant, LU3-TR2 will turn OFF and +15V TRIM 2 disengaged signal will appear at resistor No.1 of LU3 (LU3-R1). This will turn LU3-TR1 ON and relay RL2 will energise and "latch" ON. The disengaged signal is then applied via a contact on relay RL2 to simulate a "healthy" incidence signal. The Incidence comparator logic will then revert to "healthy" (+28V) and hence turn LU3-TR2 ON which will cause LU3-TR1 to turn OFF leaving relay RL2 energised via its "latched" ground. This function cycle takes place within a few milli-seconds and although the combined signals to the MWS-ADS go "non-healthy" they will be reset to the "healthy" state well within the MWS delay period and the MWS-ADS caption will not light.
- (e) When the undercarriage weight switch relays change state on aircraft rotation, the 28V excitation supply to LU3 terminal 4 will switch OFF and relay RL2 will de-energise. This will reconnect the Incidence Comparator and should there still be a discrepancy, the MWS-ADS caption will light.
- (f) At no time during the above will the Hp, Vc or M comparator functions be inhibited from displaying a MWS-ADS warning.

EFFECTIVITY: ALL

BA

C751733

# 33-15-00

Page 26  
Sep 30/91

# *Concorde*

## MAINTENANCE MANUAL

- (g) When the MWS is recalled and relays RL1A and RL1B are de-energised, LU3 will not have a "ground" return. It will therefore require a "double" fault condition to occur to cause an electrical malfunction of relay RL2.

### 5. System Management

The master warning system is fully operational whenever power is available from the aircraft distribution system. Management of the system by control switches and captions on the master warning display panel, is detailed on a system management figure (Ref. Fig. 005).

Test signals can be injected into the master warning system by operating the associated system warnings which are detailed in Tables 1 and 2 and described in the related chapter or by using the master warning test set.

### 6. Electrical Power Supplies

Power supplies are provided by the 'A' and 'B' essential 28V d.c. busbars; each busbar feeds a separate power supply in the control unit. This arrangement ensures that the operation of the master warning system is unimpaired by a single power failure.

EFFECTIVITY: ALL

BA


C751734

**33-15-00**

Page 27  
Sep 30/91

# Concorde

## MAINTENANCE MANUAL



System Management  
Figure 005

EFFECTIVITY: ALL

BA

C751720

**33-15-00**

Page 28  
SEP.30/91

R

# *Concorde*

## MAINTENANCE MANUAL

### MASTER WARNING SYSTEM - TROUBLE SHOOTING

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Ensure that the associated audio warning system (Ref. 31-23-00) is serviceable.
- C. Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 101  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting

A.\*\*\*\*\*  
\*Prepare to trouble shoot (Ref. para.2.). \*  
\*Check PS1, PS2 and CLOCK indicator lamps \*  
\*illuminated. IF - \*  
\*\*\*\*\*

OK

NOT OK-----

- 1. PS1 or PS2 not illuminated - Chart 101.
- 2. Clock not illuminated - check filament. If serviceable, renew MWS Control Unit (1).

B.\*\*\*\*\*  
\*Press-to-cancel each illuminated master \*  
\*warning caption. Check that each caption\*  
\*is extinguished. IF - \*  
\*\*\*\*\*

OK

NOT OK-----

Renew MWS Display Panel (2).

C.\*\*\*\*\*  
\*Press, and hold depressed, the LTS TEST/ \*  
\*CANCEL push-switch. Check that all \*  
\*filaments on the MWS display panel are \*  
\*lit. IF - \*  
\*\*\*\*\*

OK

NOT OK-----

- 1. Individual filaments unlit - renew filaments.
- 2. All MWS caption filaments unlit - renew MWS Display Panel (2).
- 3. Both INHIBIT indicator lamps unlit - renew MWS Display Panel (2).

EFFECTIVITY: ALL

**33-15-00**

R

BA

Page 102  
Aug 30/78

Printed in England

# Concorde

## MAINTENANCE MANUAL

D.\*\*\*\*\*  
\*Release the LTS TEST/CANCEL push-switch. \*  
\*Check that all filaments are \*  
\*extinguished. IF - \*  
\*\*\*\*\*

OK

NOT OK-----

-----  
1. All filaments remain lit - renew  
MWS Display Panel (2).  
2. Certain filaments remain lit -  
renew MWS Control Unit (1).  
-----

E.\*\*\*\*\*  
\*Press and release the RECALL push-switch \*  
\*Check that all cancelled captions are \*  
\*re-illuminated. IF - \*  
\*\*\*\*\*

OK

NOT OK-----

-----  
MWS RECALL facility inoperative -  
Chart 102.  
-----

F.\*\*\*\*\*  
\*Press the 3CM MWS CANCEL push-switch. \*  
\*Check that all MWS captions are \*  
\*extinguished. IF - \*  
\*\*\*\*\*

OK

NOT OK-----

-----  
MWS CANCEL facility at 3CM station  
inoperative - Chart 103.  
-----

G.\*\*\*\*\*  
\*With the 3CM MWS CANCEL push-switch held \*  
\*depressed, press the RECALL push-switch. \*  
\*Check that all captions cancelled in \*  
\*previous test are re-illuminated. IF - \*  
\*\*\*\*\*

OK

NOT OK-----

-----  
Renew MWS Control Unit (1).  
-----

EFFECTIVITY: ALL

**33-15-00**

Page 103  
Aug 30/78

Printed in England

# Concorde

## MAINTENANCE MANUAL

H.\*\*\*\*\*  
\*Release 3CM MWS CANCEL switch and press \*  
\*the INHIBIT push-switch. Check that the \*  
\*INHIBIT indicator lamps light. IF - \*  
\*\*\*\*\*

OK NOT OK-----|Renew MWS Display Panel (2).|

I.\*\*\*\*\*  
\*Press, and hold depressed, the LTS TEST/ \*  
\*CANCEL push-switch. Check that only the \*  
\*following red captions are illuminated: \*  
\*ENG 1, ENG 2, ENG 3, ENG 4, TRIM, ADS and \*  
\*PFC. IF - \*  
\*\*\*\*\*

OK NOT OK-----|Renew MWS Control Unit (1).|

J.\*\*\*\*\*  
\*Press and release the WARN caption on the \*  
\*INS display panel (7-211) and check that \*  
\*the single-stroke gong audible warning is \*  
\*not given. IF - \*  
\*\*\*\*\*

OK NOT OK-----|Renew MWS Control Unit (1).|

K.\*\*\*\*\*  
\*Release the LTS TEST/CANCEL push-switch, \*  
\*press and release the RECALL push-switch. \*  
\*Check that the INHIBIT lamps go out. IF - \*  
\*\*\*\*\*

OK NOT OK-----|Renew MWS Display Panel (2).|

L.\*\*\*\*\*  
\*Test fault inputs as detailed in System \*  
\*Test (Ref. Adjustment/Test). IF - \*  
\*\*\*\*\*

EFFECTIVITY: ALL

R  
BA

Printed in England

**33-15-00**

Page 104  
Aug 30/78



# Concorde

## MAINTENANCE MANUAL

OK

NOT OK-----

1. Appropriate MWS caption not illuminated at test positions 001 to 235 inclusive - renew MWS Control Unit (1).
2. Single-stroke gong fails to sound when tests 001 to 235 inclusive are selected - renew MWS Control Unit (1).
3. Appropriate MWS caption is not extinguished when pressed-to-cancel - renew MWS Display Panel (2).
4. Single-stroke gong sounds when RECALL facility is used - renew MWS Control Unit (1).
5. Appropriate MWS caption is not re-illuminated when RECALL facility is used - renew MWS Control Unit (1).

M.\*\*\*\*\*  
\*If directed to the MWS Trouble Shooting \*  
\*from a System Trouble-Shooting Chart, and\*  
\*if after carrying out the above tests the\*  
\*fault remains, i.e., fault signal present\*  
\*in associated system with MWS inactive, \*  
\*perform a continuity test on the \*  
\*appropriate signal input line (Ref. \*  
\*Wiring Diagram Manual, 33-15-02 (red \*  
\*warnings) and 33-15-03 (amber warnings)).\*  
\*\*\*\*\*

EFFECTIVITY: ALL

R

BA

Printed in England

# 33-15-00

Page 105  
Aug 30/78

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
\*PS1 or PS2 NOT ILLUMINATED. \*  
\*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

-----  
Ensure that CBs  
W251 and W252 are  
set and that PS1  
and PS2 filaments  
are serviceable.  
-----

-----

-----  
Remove MWS  
control unit.  
Check that 28 V  
d.c. is available  
at pin 20 on rack  
connectors  
W253-AB and  
W253-BB  
respectively.  
-----

-NO--

-----  
Renew CB (4) or  
(5). Re-install  
MWS control unit.  
-----

|  
YES  
|

-----  
Renew MWS Control  
Unit (1).  
-----

Chart 101

EFFECTIVITY: ALL

**33-15-00**

R

BA

Page 106  
Aug 30/78

Printed in England

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
\*MWS 'RECALL' FACILITY \*  
\*INOPERATIVE. \*  
\*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-

Press and release  
the RECALL push-  
switch.

Press the LTS  
TEST/CANCEL push-  
switch. Check  
that the  
cancelled  
captions are  
illuminated.

-NO--

Renew MWS  
Display Panel  
(2).

YES

Renew MWS Control  
Unit (1). Press  
and release the  
RECALL push-  
switch. If fault  
remains - renew  
MWS Display Panel  
(2).

Chart 102

EFFECTIVITY: ALL

**33-15-00**

Page 107  
Aug 30/78

Printed in England

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
\*'MWS CANCEL' FACILITY AT 3CM \*  
\*STATION INOPERATIVE. \*  
\*\*\*\*\*

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-

Press the 3CM MWS  
CANCEL push-  
switch.

With the MWS  
CANCEL push-  
switch held  
depressed, check  
that pin 71 of  
connector W253-BA  
at the MWS  
Control Unit (1)  
is at earth  
potential.

--NO-- Renew MWS CANCEL  
Switch (3).

YES

Renew MWS Control  
Unit (1).

Chart 103

EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 108  
Aug 30/78

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL/ PANEL ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
				MAINT. TOPIC	WIRING DIAGRAM
(1) MWS control - unit	7-216	W253	RH equipment racking	33-15-11 R/I	
(2) MWS display - panel	4-211	W254	Flight compartment roof panel	33-15-12 R/I	
(3) MWS CANCEL - push-switch	6-214	W276	3CM station	33-15-00 R/I	
(4) Circuit breaker	5-213	W251	Map ref.D15	24-50-00 R/I	
(5) Circuit breaker	1-213	W252	Map ref.N21	24-50-00 R/I	

Component Identification  
Table 101

EFFECTIVITY: ALL

BA

Printed in England

# 33-15-00

Page 109  
Nov 30/79

# Concorde


## MAINTENANCE MANUAL

### MASTER WARNING SYSTEM - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General (Ref. Fig. 401 )

This topic contains instructions for the removal and installation of the remote master warning cancel push-switch located on the lower electrical services panel (6-214). Access to the switch is gained by lowering the appropriate section of the panel on its hinges.



- Master Warning Cancel Push-switch - Installation  
Figure 401

#### A. Prepare

- (1) Isolate the electrical generation and external power supplies as detailed in 24-00-00, Servicing.

#### B. Remove

EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 401  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (1) Release the electrical services panel retaining screws and lower the panel on its hinges.
- (2) CAUTION: ENSURE THAT THE TUBULAR SPANNER DOES NOT DAMAGE THE POLISHED WALL OF THE ELECTROLUMINESCENT PANEL.

Using a suitable tubular spanner, remove the push-switch retaining shroud and locking washer. Withdraw the switch from the rear of the electrical services panel.

- (3) Disconnect the electrical cables from the switch.

### C. Install

- (1) Comply with the electrical safety precautions.
- (2) Connect the electrical cables to the push-switch, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram. Solder connections and apply heat shrink sleeves in accordance with Wiring Diagram Manual, 20-42-23 and 20-41-14.
- (3) Position the switch, through the aperture, from the rear of the electrical services panel.
- (4) Fit the locking washer and secure the switch with the retaining shroud.
- (5) Refit the electrical services panel, taking care to avoid trapping connecting cables, and secure the panel with the retaining screws.

### D. Conclusion

- (1) Cancel, the safety precautions taken before removal.
- (2) Check the operation of the switch by carrying out the appropriate test procedure.

EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 402  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

R

### MASTER WARNING SYSTEM - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED  
IN 24-00-00.

#### 1. General

The following procedure details the Operational and System Tests required to prove the correct operation of the master warning system (MWS). A Functional Test is not considered necessary in this application.

Associated detailed fault indications in the related systems are dealt with in each respective system chapter.

The system provides amber and red master warning indications: each warning is accompanied by the sounding of a single-stroke gong (primary warning) by the associated audio warning system (Ref. 31-23-00); in addition, for all red warnings that are not cancelled or cleared the gong is repeated after a delay of approximately 10 s and then at 8.5 s intervals (auxiliary warning) until the fault is cleared or the warning is cancelled.

For convenience of application the Operational Test has been written as two separate procedures, as follows:-

##### (1) Operational Test - Master Warning System (Ref. para.2.)

This test checks the operation of the master warning system components but does not check the operation of individual master warning inputs from the associated systems.

##### (2) Operational Test - Selected Master Warnings (Ref. para.3.)

This test checks the operation of selected master warning inputs from associated systems. This selection includes certain warnings which are not normally tested by the flight crew during the pre-flight check procedures.

#### 2. Operational Test - Master Warning System

##### A. Prepare

(1) Make available electrical ground power as detailed in 24-41-00.

(2) Press-to-cancel each illuminated master warning

R

EFFECTIVITY: ALL

BA

**33-15-00**

Page 501  
Sep 30/87



# *Concorde*

## MAINTENANCE MANUAL

caption on the MWS display panel.

### B. Test MWS Maintenance Lamps

- (1) Check that indicator lamps PS1, PS2, and CLOCK on the MWS control unit, located on panel 7-216, are lit.

### C. Test MWS Display Panel Filament Test and Cancel Facility

- (1) Press, and hold depressed, the LTS TEST - CANCEL push-switch on the MWS display panel. Check that all filaments in the MWS panel captions and in the INHIBIT indicating lamps are lit.
- (2) Release the LTS TEST - CANCEL push-switch. Check that all filaments are extinguished.

### D. Test Single-stroke Gong, and Primary and Auxiliary Audio Warnings

- (1) Trip the AUDIO WARN SYS SUPPLY 1 circuit breaker W371 on panel 1-213, map ref.M21.
- (2) Press-to-test one of the four AC MAIN BUS captions on panel 3-214. Check that the caption is illuminated, the MWS amber ELEC caption is illuminated and the audio warning single-stroke gong sounds immediately (primary warning); release the AC MAIN BUS caption.
- (3) Hold depressed one of the four AC ESS BUS captions on panel 6-214 for approximately 30 s. During this time check that -
  - (a) the caption is illuminated,
  - (b) the primary audio warning sounds immediately the AC ESS BUS caption is depressed, and
  - (c) after approximately 10 s the gong sounds again and thereafter at 8.5 s intervals until the caption is released (auxiliary warning).
- (4) Reset circuit breaker W371 and trip the AUDIO WARN SYS SUPPLY 2 circuit breaker W372 on panel 5-213, map ref.C17.
- (5) Repeat the tests detailed in paragraphs (2) and (3).
- (6) Reset circuit breaker W372.

R EFFECTIVITY: ALL

BA

**33-15-00**

Page 502  
Sep 30/87

Printed in England

# MAINTENANCE MANUAL

(1) Press and release the RECALL push-switch on the MWS display panel and check that the warning captions cancelled in operation A.(2) are reinstated.

- (1) Press and release the MWS CANCEL push-switch at the third crew member's (3CM) station. Check that all MWS captions are extinguished.
- (2) Press and release the RECALL push-switch on the MWS display panel. Check that all captions extinguished by operation (1) are re-illuminated.

- (1) Press the INHIBIT push-switch on the MWS display panel and check that the INHIBIT indicator lamps are lit.
- (2) Press, and hold depressed, the LTS TEST - CANCEL push-switch. Check that only the following red captions are illuminated: ENG 1, ENG 2, ENG 3, ENG 4, TRIM, ADS and PFC.
- (3) Release the LTS TEST - CANCEL push-switch and check that all captions are extinguished; INHIBIT lamps must remain lit.
- (4) Press and release the RECALL push-switch. Check that the INHIBIT lights go out.

[illegible]

BA

**33-15-00**

Page 503  
Sep 30/88

# *Concorde*

## MAINTENANCE MANUAL

R  
R

### H. Test Cabin Altitude Audio Warning (Intermittent Horn) Inhibit

- (1) Press-to-test the EXCESS ALT caption on panel 1-214. Check that the audio warning intermittent horn sounds; release the caption.
- (2) Press the INHIBIT push-switch on the MWS display panel and check that the INHIBIT indicator lamps are lit.
- (3) Press the EXCESS ALT caption and check that the audio warning intermittent horn does not sound; release the caption.
- (4) Press and release the RECALL push-switch. Check that the INHIBIT indicator lights go out.

### I. Conclusion

- (1) Press and release the LTS TEST - CANCEL push-switch. Check that all captions are extinguished.
- (2) Switch off and disconnect electrical ground power as detailed in 24-41-00.

R

EFFECTIVITY: ALL

BA

**33-15-00**

Page 504  
Sep 30/88

# Concorde

## MAINTENANCE MANUAL

### 3. Operational Test - Selected Master Warnings

#### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Ensure that the throttle levers are on the rear mechanical stops.
- (3) Hold the LTS TEST - CANCEL push-switch on the MWS display panel depressed. Check that all filaments in the MWS panel captions are illuminated and the INHIBIT indicating lamps are lit.
- (4) Release the LTS TEST - CANCEL push-switch and check that all filaments are extinguished.
- (5) At the centre console, panel 9-211, set the Nos.1 and 2 ADC switches to "ON".

#### B. Test

- (1) MWS Maintenance Lamps
  - (a) Check that PS1, PS2 and CLOCK indicator lamps on the MWS control unit, panel 7-216, are lit.
- (2) MWS 'STAB' Caption
  - (a) Press and release the RECALL push-switch. Check that the STAB caption is illuminated.
  - (b) Engage the AUTO STAB 1 PITCH, ROLL and YAW switches. Check that after a short delay the STAB caption is extinguished.
  - (c) Disengage the AUTO STAB 1 PITCH, ROLL and YAW switches and check that the STAB caption is illuminated, accompanied by the single-stroke gong.
  - (d) Press-to-cancel the LTS TEST - CANCEL push-switch. Check that the STAB caption is extinguished and the gong is cancelled.
- (3) MWS 'FUEL' Caption
  - (a) Press the LOW PRESS caption on panel 5-214.

R

EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 505

Sep 30/88

# Concorde

## MAINTENANCE MANUAL

Check that the LOW PRESS and FUEL captions are illuminated, accompanied by the single-stroke gong.

- (b) Release the LOW PRESS caption.
  - (c) Press-to-cancel the LTS TEST - CANCEL push-switch. Check that the FUEL caption is extinguished.
- (4) MWS 'HYD' Caption.
- (a) Check that the L/PRESS captions, on panel 3-214, and the HYD caption are illuminated.
  - (b) Press-to-cancel the LTS TEST - CANCEL push-switch. Check that the HYD caption is extinguished.
  - (c) Press and release the RECALL push-switch. Check that the HYD caption is illuminated.
  - (d) Press-to-cancel the LTS TEST - CANCEL push-switch. Check that the HYD caption is extinguished.
- (5) MWS M/CG Caption
- (a) At the FQI control panel, panel 5-214, note the counter display and rotate the ZFCG selector knob. Check that -
    - a1) the digits on the % counter move,
    - a2) the pointers on the CG % indicators on panels 2-211 and 5-214 move FWD/AFT, and
    - a3) the MWS M/CG caption is illuminated, accompanied by the single-stroke gong.
  - (b) Press-to-cancel the LTS TEST - CANCEL push-switch. Check that the MWS M/CG caption is extinguished and the single-stroke gong is cancelled.
  - (c) Rotate the ZFCG selector knob to return the % counter display to the original setting.
  - (d) At the centre console panel 9-211, set the Nos.1 and 2 ADC switches to "OFF".

EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 506  
Sep 30/87

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

- R (6) MWS - Inhibition of TRIM and ADS Master Warnings during  
R take-off.
- R (a) Connect ADC Input Simulation Test Units to both No.1  
R and No.2 ADC's, OR:  
R Connect separate Pitot Pressure Test equipment to both  
R No.1 and No.2 Pitot probes.
- R (b) Check that the MWS-ADC and MWS-ADS captions on panel  
R 9-211 are not lit.
- R (c) Check that all ADC instruments show steady readings  
R and all failure flags are out of view.
- R (d) On panel 4-211, engage TRIM 1 and TRIM 2 switches and  
R check that the MWS-TRIM caption is not lit.
- R (e) Set the No.1 ADC Test switch to COMP. Check that the  
R No.1 ADC-TEST caption is lit and that the TRIM 1 and  
R TRIM 2 switches have disengaged.  
R Check that the MWS-ADS and MWS-TRIM captions are lit  
R and that the ASI-FAIL flags on Captain's and  
R Co-pilot's dash panels are displayed.
- R (f) Set the No.1 ADC Test switch to NORM. Check that the  
R MWS-TRIM caption is lit and that the No.1 ADC-TEST  
R caption is not lit.  
R Check that the MWS-ADS caption is not lit and the  
R Captain's and Co-pilot's ASI-FAIL flags are not  
R displayed.
- R (g) Engage the TRIM 1 switch and check that the MWS-TRIM R  
R caption is not lit.
- R (h) Engage the TRIM 2 switch. Check that both TRIM 1 and  
R TRIM 2 switches remain engaged.
- R (i) Set the No.2 ADC Test switch to COMP. Check that the  
R No.2 ADC-TEST caption is lit and that the TRIM 1 and  
R TRIM 2 switches have disengaged.  
R Check that the MWS-ADS and MWS-TRIM captions are lit  
R and the Captain's and Co-pilot's ASI-FAIL flags are  
R displayed.
- R (j) Set the No.2 ADC Test switch to NORM. Check that the  
R MWS-TRIM caption is lit and that the No.2 ADC-TEST  
R caption is not lit.  
R Check that the MWS-ADS caption is not lit and the  
R Captain's and Co-pilot's ASI-FAIL flags are not  
R displayed.

EFFECTIVITY: ALL

BA

C751707

**33-15-00**

Page 507  
Sep 30/91

# *Concorde*

## MAINTENANCE MANUAL

- R (k) Engage TRIM 2 switch and check that the MWS-TRIM  
R caption is not lit.
- R (l) Engage TRIM 1 switch and check that both TRIM 1 and  
R TRIM 2 switches remain engaged.
- R (m) Drive both No.1 and No.2 ADC's to 50 knots  
R simultaneously.
- R (n) Select INHIBIT on the MWS display panel and check  
R that the MWS-INHIBIT lights are lit.
- R (o) Check that the MWS-ADS and MWS-TRIM captions are  
R not lit.
- R (p) Disengage TRIM 1 and TRIM 2 switches and check that  
R the MWS-TRIM caption is lit.
- R (q) Drive both No.1 and No.2 ADC's to 80 knots  
R simultaneously and check that the MWS-TRIM caption  
R remains lit.
- R (r) Engage TRIM 1 switch and check that the MWS-TRIM  
R caption is not lit.
- R (s) Engage TRIM 2 switch and check that both TRIM 1 and  
R TRIM 2 switches remain engaged.
- R (t) Drive both No.1 and No.2 ADC's to 110 knots and  
R adjust the No.1 and No.2 Incidence sensors to  
R indicate +3.0 on the Captain's and Co-pilot's  
R incidence indicators.  
R Check that the MWS-ADS caption is not lit,  
R re-engage TRIM 1 and TRIM 2 switches if necessary  
R and check that the MWS-TRIM caption is not lit.
- R (u) Drive both No.1 and No.2 ADC's to ZERO and set the  
R No.4 Engine N1 limiter switch to 88%.
- R (v) Select INHIBIT on the Master Warning System display  
R panel and check that the MWS-INHIBIT lights are  
R lit.
- R (w) Drive both No.1 and No.2 ADC's to 65 knots  
R simultaneously and check that the No.4 Engine N1  
R limiter switch is off.
- R (x) Disengage TRIM 1 and TRIM 2 switches and check that  
R the MWS-TRIM caption is not lit.
- R (y) Engage TRIM 1 and TRIM 2 switches.

EFFECTIVITY: ALL

BA

C751739

**33-15-00**

Page 507A

Sep 30/91

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

- R (z) Drive both No.1 and No.2 ADC's to 110 knots  
R simultaneously and check that the Captain's and  
R Co-pilot's incidence indicators read +3.0.
- R (aa) Adjust the No.1 Incidence sensor to indicate +10  
R on the Captain's Incidence indicator. Check that Trim  
R 1 and TRIM 2 switches have disengaged and that the  
R MWS-ADS and MWS-TRIM captions are not lit.
- R (ab) Adjust the No.1 Incidence sensor to indicate +3.0 on  
R the Captains Incidence indicator. Check that the  
R MWS-ADS caption is not lit.
- R (ac) Drive the No.2 ADC to 130 knots and check that the  
R MWS-ADS caption is lit and the Captain's and Co-pilot's  
R ASI-FAIL flags are displayed.
- R (ad) Drive the No.1 ADC to 130 knots and check that the  
R MWS-ADS caption is not lit and the Captain's and  
R Co-pilot's ASI-FAIL flags are not displayed.
- R (ae) Operate the undercarriage weight switches to simulate  
R flight conditions and check that the MWS-ADS and  
R MWS-TRIM captions are not lit.
- R (af) Select RECALL on the MWS display panel and check that  
R the MWS-TRIM caption is lit and the MWS-INHIBIT lights  
R are not lit.
- R (ag) Engage the TRIM 1 and TRIM 2 switches and check that  
R the MWS-TRIM caption is not lit.
- R (ah) Drive both No.1 and No.2 ADC's to ZERO and return the  
R undercarriage weight switches to ground conditions.
- R (ai) Select INHIBIT on the Master Warning System display  
R panel and check that the MWS-INHIBIT lights are lit.
- R (aj) Drive both No.1 and No.2 ADCs to 110 knots  
R simultaneously.
- R (ak) Adjust the No.2 Incidence sensor to indicate +10 on the  
R Co-pilots Incidence indicator. Check that both TRIM 1  
R and TRIM 2 switches have disengaged and that the  
R MWS-ADS and MWS-TRIM captions are not lit.
- R (al) Operate the undercarriage weight switches to simulate  
R flight condition and check that the MWS-ADS caption is  
R lit and the MWS-TRIM caption is not lit.

EFFECTIVITY: ALL

BA

C751769

**33-15-00**

Page 507B  
Sep 30/91



# *Concorde*

## MAINTENANCE MANUAL

- R (am) Select RECALL on the Master Warning System display  
R panel and check that the MWS-ADS and the MWS-TRIM  
R captions are lit and that the MWS-INHIBIT lights  
R are not lit.
- R (an) Return the undercarriage weight switches to ground  
R conditions. Check that the MWS-TRIM caption and  
R MWS-ADS caption are lit.
- R (ao) Drive both No.1 and No.2 ADCs to ZERO and check  
R that the MWS-TRIM caption is lit and the MWS-ADS  
R caption is not lit.
- R (ap) Switch off all systems, trip the necessary circuit-  
R breakers and remove all test equipment.
- R (7) Switch off and disconnect electrical ground power as  
R detailed in 42-41-00.

EFFECTIVITY: ALL

BA

C751770

**33-15-00**

Page 507C  
Sep 30/91

*Concorde*  
MAINTENANCE MANUAL

PRINTED IN ENGLAND

THIS PAGE  
INTENTIONALLY LEFT BLANK

RB

EFFECTIVITY: ALL

BA

C751860

**33-15-00**

Page 507D  
Sep 30/91

# Concorde

## MAINTENANCE MANUAL

### 4. System Test

#### A. Equipment and Materials

---

DESCRIPTION	PART NO.
-------------	----------

---

Circuit breaker safety clips	-
------------------------------	---

Master warning system test set	TE6044
--------------------------------	--------

---

#### B. Prepare (Ref. Fig. 501 )

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Trip and fit safety clips to the circuit breakers listed below:-

---

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
---------	-------	--------------------	-------------

---

MWS SUP 2	5-213	W251	D15
-----------	-------	------	-----

MWS SUP 1	1-213	W252	N21
-----------	-------	------	-----

FWD RACKING TEST SKT DC SUP	15-216	M242	E22
--------------------------------	--------	------	-----

---

- (3) Remove the protective covers from the master warning test connectors W272-A, W273-A, W274-A and W275-A on panel 7-216 and from the 28 V d.c. power supply connector M246 on panel 18-216.
- (4) Connect the test set to the connectors detailed in paragraph (3).
- (5) Ensure that both push-switches on the test set are in the released position and that the test selector is set to 000.
- (6) Remove the safety clips and reset the circuit breakers tripped in operation (2).
- (7) On the test set, press the power ON switch.

R EFFECTIVITY: ALL


BA

**33-15-00**

Page 508  
Sep 30/87

# Concorde

## MAINTENANCE MANUAL



CMB3315005AAM0

- Master Warning System Test Set TE6044 - Interconnections  
Figure 501

R EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 509  
Sep 30/87

# *Concorde*

## MAINTENANCE MANUAL

Check that the switch is illuminated and all the captions on the MWS display panel are extinguished.

- (8) Press the RECALL push-button on the MWS display panel. Check that all captions remain extinguished.

### C. Test - Fault Inputs

- (1) Ensure that all captions on the MWS display panel are cancelled. Refer to Table 501 and select, in turn, each individual test position numbered 001 to 236. At each test position:-

- (a) Hold the EVENT push-switch depressed and check that -
- a1) the associated master warning caption on the display panel is illuminated and
  - a2) the single-stroke gong sounds.
- (b) Press-to-cancel the face of the illuminated caption. Check that the caption is extinguished.
- (c) Press and release the RECALL push-switch. Check that the cancelled warning caption is re-illuminated and that the single-stroke gong does not sound.
- (d) Release the EVENT push-switch and check that the appropriate master warning caption is extinguished.

NOTE: During checks 029, 030, 031, 032, 033, 036, 037, 038, 039, 040, 043, 044, 045, 046, 047, 050, 051, 052, 053 and 054 the appropriate engine shut down handle lamps are lit.

During checks 034, 041, 048 and 055 the appropriate engine shut down handle lamps are lit and the fire bell sounds.

During test 058 the audio warning cabin pressure klaxon may operate.

R EFFECTIVITY: ALL

BA

Printed in England

# 33-15-00

Page 510  
Sep 30/87

***Concorde***  
**MAINTENANCE MANUAL**

TEST SELECTION	CAPTION	COLOUR
001	INS	Red
002	INS	Red
003	INS	Red
004	INS	Red
005	INS	Red
006	INS	Red
007	FEEL	Red
008	FEEL	Red
009	FEEL	Red
010	FEEL	Red
011	FEEL	Red
012	FEEL	Red
013	STAB	Red
014	STAB	Red
015	STAB	Red
016	STAB	Red
017	STAB	Red
018	STAB	Red
019	PFC	Red
020	PFC	Red
021	PFC	Red
022	PFC	Red
023	PFC	Red

R EFFECTIVITY: ALL

BA

Printed in England

**33-15-00**

Page 511  
Sep 30/87

***Concorde***  
**MAINTENANCE MANUAL**

TEST SELECTION	CAPTION	COLOUR
024	PFC	Red
025	PFC	Red
026	PFC	Red
027	PFC	Red
028	PFC	Red
029	ENG 1	Red
030	ENG 1	Red
031	ENG 1	Red
032	ENG 1	Red
033	ENG 1	Red
034	ENG 1	Red
035	N/A	-
036	ENG 2	Red
037	ENG 2	Red
038	ENG 2	Red
039	ENG 2	Red
040	ENG 2	Red
041	ENG 2	Red
042	N/A	-
043	ENG 3	Red
044	ENG 3	Red
045	ENG 3	Red
046	ENG 3	Red
047	ENG 3	Red

R EFFECTIVITY: ALL

BA

**33-15-00**

Page 512  
Sep 30/87

# *Concorde*

## MAINTENANCE MANUAL

TEST SELECTION	CAPTION	COLOUR
048	ENG 3	Red
049	N/A	-
050	ENG 4	Red
051	ENG 4	Red
052	ENG 4	Red
053	ENG 4	Red
054	ENG 4	Red
055	ENG 4	Red
056	N/A	-
057	RADN	Red
058	PRESS	Red
059	PRESS	Red
060	THROT	Red
061	THROT	Red
062	THROT	Red
063	THROT	Red
064	ICE	Red
065	ICE	Red
066	MC/G	Red
067	MC/G	Red
068	MC/G	Red
069	MC/G	Red
070	N/A	-
071	ADS	Red

R EFFECTIVITY: ALL

BA

**33-15-00**

Page 513  
Sep 30/87



# Concorde

## MAINTENANCE MANUAL

TEST SELECTION	CAPTION	COLOUR
072	TRIM	Red
073	TRIM	Red
074	CG	Amber
075	N/A	-
076	ENG 1	Amber
077	ENG 1	Amber
078	ENG 1	Amber
079	ENG 1	Amber
080	N/A	-
081	ENG 1	Amber
082	ENG 1	Amber
083	ENG 1	Amber
084	ENG 2	Amber
085	ENG 2	Amber
086	ENG 2	Amber
087	ENG 2	Amber
088	ENG 2	Amber
089	N/A	-
090	ENG 2	Amber
091	ENG 2	Amber
092	ENG 3	Amber
093	ENG 3	Amber
094	ENG 3	Amber
095	ENG 3	Amber

R EFFECTIVITY: ALL

BA

**33-15-00**

Page 514  
Sep 30/87

# Concorde

## MAINTENANCE MANUAL

TEST SELECTION	CAPTION	COLOUR
096	N/A	-
097	ENG 3	Amber
098	ENG 3	Amber
099	ENG 3	Amber
100	ENG 4	Amber
101	ENG 4	Amber
102	ENG 4	Amber
103	ENG 4	Amber
104	N/A	-
105	ENG 4	Amber
106	ENG 4	Amber
107	ENG 4	Amber
108	N/A	-
109	N/A	-
110	N/A	-
111	N/A	-
112	FUEL	Amber
113	FUEL	Amber
114	FUEL	Amber
115	FUEL	Amber
116	FUEL	Amber
117	FUEL	Amber
118	FUEL	Amber
119	FUEL	Amber

R EFFECTIVITY: ALL

BA

**33-15-00**

Page 515  
Sep 30/87

# *Concorde*

## MAINTENANCE MANUAL

TEST SELECTION	CAPTION	COLOUR
120	FUEL	Amber
121	ELEC	Red
122	ELEC	Red
123	ELEC	Red
124	ELEC	Red
125	ELEC	Red
126	ELEC	Red
127	ELEC	Red
128	N/A	-
129	N/A	-
130	N/A	-
131	N/A	-
132	DOORS	Red
133	N/A	-
134	N/A	-
135	N/A	-
136	N/A	-
137	N/A	-
138	N/A	-
139	N/A	-
140	N/A	-
141	N/A	-
142	NAV	Amber
143	NAV	Amber

R

EFFECTIVITY: ALL

BA

**33-15-00**

Page 516  
Sep 30/87

# *Concorde*

## MAINTENANCE MANUAL

TEST SELECTION	CAPTION	COLOUR
144	NAV	Amber
145	ADC	Amber
146	ADC	Amber
147	N/A	-
148	N/A	-
149	N/A	-
150	N/A	-
151	AIR	Amber
152	AIR	Amber
153	AIR	Amber
154	AIR	Amber
155	AIR	Amber
156	AIR	Amber
157	AIR	Amber
158	AIR	Amber
159	AIR	Amber
160	AIR	Amber
161	AIR	Amber
162	INT 1	Amber
163	INT 1	Amber
164	N/A	-
165	INT 1	Amber
166	INT 1	Amber
167	INT 1	Amber

R EFFECTIVITY: ALL

BA

**33-15-00**

Page 517  
Sep 30/87

# *Concorde*

## MAINTENANCE MANUAL

TEST SELECTION	CAPTION	COLOUR
168	INT 2	Amber
169	INT 2	Amber
170	N/A	-
171	INT 2	Amber
172	INT 2	Amber
173	INT 2	Amber
174	INT 3	Amber
175	INT 3	Amber
176	N/A	-
177	INT 3	Amber
178	INT 3	Amber
179	INT 3	Amber
180	INT 4	Amber
181	INT 4	Amber
182	N/A	-
183	INT 4	Amber
184	INT 4	Amber
185	INT 4	Amber
186	HYD	Amber
187	HYD	Amber
188	HYD	Amber
189	HYD	Amber
190	HYD	Amber
191	HYD	Amber

R EFFECTIVITY: ALL

BA

# 33-15-00

Page 518  
Sep 30/87

Printed in England

# Concorde

## MAINTENANCE MANUAL

TEST SELECTION	CAPTION	COLOUR
192	HYD	Amber
193	HYD	Amber
194	HYD	Amber
195	HYD	Amber
196	HYD	Amber
197	HYD	Amber
198	ELEC	Amber
199	ELEC	Amber
200	ELEC	Amber
201	ELEC	Amber
202	ELEC	Amber
203	ELEC	Amber
204	ELEC	Amber
205	ELEC	Amber
206	ELEC	Amber
207	ELEC	Amber
208	ELEC	Amber
209	ELEC	Amber
210	ELEC	Amber
211	ELEC	Amber
212	ELEC	Amber
213	N/A	-
214	N/A	-
215	N/A	-

R EFFECTIVITY: ALL

BA

**33-15-00**

Page 519  
Sep 30/87

# *Concorde*

## MAINTENANCE MANUAL

TEST SELECTION	CAPTION	COLOUR
216	N/A	-
217	SMOKE	Amber
218	SMOKE	Amber
219	SMOKE	Amber
220	SMOKE	Amber
221	SMOKE	Amber
222	SMOKE	Amber
223	SMOKE	Amber
224	SMOKE	Amber
225	SMOKE	Amber
226	SMOKE	Amber
227	SMOKE	Amber
228	SMOKE	Amber
229	SMOKE	Amber
230	SMOKE	Amber
231	INT 1	Red
232	INT 2	Red
233	INT 3	Red
234	INT 4	Red
235	INT 1, 2, 3 and 4	Red
236	PFC	Red

Individual Test Positions  
Table 501

R EFFECTIVITY: ALL

BA

**33-15-00**

Page 520  
Sep 30/87

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

### D. Test - Power Supplies

- (1) Trip circuit breaker W251 on panel 5-213, map ref.D15, and check that the MWS control unit PS2 indicator lamp is extinguished.
- (2) Set the TEST SELECT switch on the test position to "000". Check that all captions on the MWS display panel are extinguished.
- (3) Press and hold depressed the LTS TEST - CANCEL push-switch on the MWS display panel. Check that -
  - (a) all filaments on the MWS panel are lit, and
  - (b) all filaments are extinguished when the LTS TEST - CANCEL push-switch is released.
- (4) Reset circuit breaker W251 and check that lamp PS2 on the MWS control unit is illuminated.
- (5) Trip circuit breaker W252 on panel 1-213, map ref.N21, and check that the MWS control unit PS1 indicator lamp is extinguished.
- (6) Repeat operation (3).
- (7) Reset circuit breaker W252 and check that lamp PS1 on the MWS control unit is illuminated.

### E. Test - Recall and 3CM Cancel Facility

- (1) Set the TEST SELECT switch on the test set to "001". Press the EVENT push-switch and hold it depressed; check that the red INS caption on the MWS display panel is illuminated and the primary and auxiliary audio warnings are given.
- (2) Press and release the red INS caption and check that the caption is extinguished and the audio warning ceases.
- (3) Press and release the RECALL push-switch on the MWS display panel. Check that the red INS caption is illuminated and that after a delay of approximately 10 s the auxiliary audio warning operates and continue to repeat at approximately 8.5 s intervals.
- (4) Press the MWS CANCEL push-switch on panel 6-214

R EFFECTIVITY: ALL

BA

**33-15-00**

Page 521  
Sep 30/87



# *Concorde*

## MAINTENANCE MANUAL

at the third crew member's station. Check that the red INS caption is extinguished and the auxiliary audio warning ceases.

- (5) Press and release the RECALL push-switch. Check that the red INS caption is illuminated.
- (6) Press and release the LTS TEST - CANCEL push-switch on the MWS display panel. Check that the red INS caption is extinguished; release the EVENT push-switch on the test set.
- (7) Set the TEST SELECT switch on the test set to "000" and switch off the power supply at the test set.
- (8) Disconnect and remove the test set; replace the protective covers on the MWS test connectors W272-A, W273-A, W274-A and W275-A.

### F. Test - Inhibit Facility

- (1) Press-to-test the EXCESS ALT caption on panel 1-214. Check that the primary and auxiliary audio warnings are given; release the caption.
- (2) Press the INHIBIT push-switch on the MWS display panel and check that the INHIBIT indicator lamps are lit.
- (3) Press the EXCESS ALT caption and check that the primary and auxiliary audio warnings are not given; release the caption.
- (4) Press, and hold depressed, the LTS TEST - CANCEL push-switch. Check that only the following red captions are illuminated: ENG 1, ENG 2, ENG 3, ENG 4, TRIM, ADS and PFC.
- (5) Release the LTS TEST - CANCEL push-switch and check that all captions are extinguished; INHIBIT lamps must remain lit.
- (6) Press and release the RECALL push-switch. Check that the INHIBIT lamps go out.

\*\*ON A/C 001-005,

After SB 33-020                      For A/C 001-005,

R EFFECTIVITY: ALL

BA

Printed in England

# 33-15-00

Page 522  
Sep 30/87

# *Concorde*

## MAINTENANCE MANUAL

- (7) At the flying controls SERVO CONTROLS panel, check that the hydraulic selectors are in the NORMAL position.
- (8) At the GROUND HYD CHECK-OUT panel, set both ON - OFF switches to "ON" and the rotary selector switch to "GREEN-BLUE".
- (9) Ensure that the GREEN L PRESS caption on the flying controls SERVO CONTROLS panel (Ref. 27-34-00) is extinguished.
- (10) Press the RECALL push-switch on the MWS display panel and check that the PFC caption is extinguished.
- (11) At the GROUND HYD CHECK-OUT panel, set the rotary selector to "BLUE-YELLOW" and check that the GREEN L PRESS caption on the flying controls SERVO CONTROLS panel and the MWS PFC caption are illuminated, accompanied by the sounding of the single-stroke gong.
- (12) At the GROUND HYD CHECK-OUT panel, set the rotary selector to "GREEN-BLUE" and check that the warnings given in operation (11) are cancelled.
- (13) Press the INHIBIT push-switch at the MWS display panel and check that the INHIBIT indicator lamps are lit.
- (14) At the GROUND HYD CHECK-OUT panel, set the rotary selector to "BLUE-YELLOW". Check that the GREEN L PRESS caption is illuminated and the MWS PFC caption remains extinguished.
- (15) At the GROUND HYD CHECK-OUT panel, set both ON - OFF switches to "OFF".
- (16) Press and release the RECALL push-switch; check that the INHIBIT indicator lamps go out.

\*\*ON A/C 001-005,

### G. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

R EFFECTIVITY: ALL

BA

**33-15-00**

Page 523  
Sep 30/87

# Concorde

## MAINTENANCE MANUAL

### MASTER WARNING CONTROL UNIT - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

The master warning control unit is situated in the flight compartment right-hand racking, on shelf 7-216, and is retained by two lever fasteners that engage with fork-ends on the racking.

#### 2. Master Warning Control Unit

##### A. Equipment and Materials

###### DESCRIPTION

###### PART NO.

Circuit breaker safety clips

-

##### B. Prepare

- (1) Electrically isolate the control unit by tripping the associated circuit breakers listed below. Fit a safety clip to each tripped circuit breaker.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
No.1 power supply	5-213	W251	D15
No.2 power supply	1-213	W252	N21

- (2) Remove the appropriate cover from the racking and locate the control unit on shelf 7-216.

##### C. Remove

- (1) Release the thumb catches retaining the lever fasteners on the unit and draw the levers downward, simultaneously, until the unit is free from the backplate connectors.
- (2) Withdraw the unit sufficiently to clear the rack fork-ends and lock the lever fasteners back in the

EFFECTIVITY: ALL

BA

# 33-15-11

Page 401  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

upright position with the thumb catches. Remove the unit from the rack.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Remove the protective blanks from the backplate connectors and ensure that all pins, inserts and mating surfaces are clean and undamaged.
- (3) Place the unit on the mounting tray and align the rear connectors with the backplate connectors. Release the thumb catches retaining the lever fasteners and draw the levers downward to engage the rack fork-ends, then lock the levers back in the upright position to mate the connectors and retain the unit. Ensure that the unit is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Refit and secure the cover to the rack.
- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- (3) Carry out an Operational Test of the system as detailed in 33-15-00, Adjustment/Test.

EFFECTIVITY: ALL

BA

Printed in England

**33-15-11**

Page 402  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

### MASTER WARNING DISPLAY PANEL - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS AS DETAILED IN 24-00-00.

#### 1. General

The master warning display panel is situated at the forward end of the pilots' roof panel in the flight compartment.

#### 2. Master Warning Display Panel

##### A. Equipment and Materials

###### DESCRIPTION

###### PART NO.

Circuit breaker safety clips

-

##### B. Prepare

- (1) Electrically isolate the display panel by tripping the associated circuit breakers listed below. Fit a safety clip to each tripped circuit breaker.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
No.1 power supply	5-213	W251	D15
No.2 power supply	1-213	W252	N21

- (2) Remove the pilots' windscreen roof panel (Ref. 25-12-00) to gain access to the display panel.

##### C. Remove

- (1) Support the display panel and remove the four recessed attachment bolts.
- (2) Partially withdraw the display panel and disconnect the electrical connectors. Remove the display panel.

EFFECTIVITY: ALL

BA

Printed in England

# 33-15-12

Page 401  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the display panel and connect the electrical connectors to the panel, ensuring that the mating surfaces are clean and undamaged.
- (3) Place the display panel in position and secure it with the four attachment bolts. Ensure that the panel is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Refit the pilots' windscreen roof panel (Ref. 25-12-00).
- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- (3) Carry out an Operational Test of the system as detailed in 33-15-00, Adjustment/Test.

EFFECTIVITY: ALL

BA

Printed in England

**33-15-12**

Page 402  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

### PANEL LIGHTING - DESCRIPTION AND OPERATION

#### 1. General

Panel lighting is provided by electroluminescent (EL) panels which illuminate legends and other markings engraved on them.

#### 2. Electroluminescent Panels

Electroluminescent panels, shaped to accommodate instruments and indicators, are fitted to those panels requiring illuminated engravings. Each panel comprises a phosphor-impregnated electroluminescent layer sandwiched between two electrically-conducting layers, one of which is transparent. On the outer face of the transparent conducting layer is a clear Perspex panel surfaced with a thin opaque sheet of PVC coloured grey. The whole assembly is bonded together to form one panel. Legends and other markings are engraved through the grey opaque surface to the clear layer below.

Electrical connections to the conducting layer are made at the back of the panel either by flying leads or by a coaxial connector.

#### 3. Operation (Ref. Fig.001 and 002)

##### A. Control

The EL panels are supplied from one phase of an associated 115 V a.c. busbar, through the contacts of a lighting control switch. The lighting control switches are mounted on switch panels located close to the EL panels they control. Table 1 lists the lighting control switches and the associated panels on which EL panels are mounted.

SWITCH LOCATION	SWITCH ENGRAVING	ELECTROLUMINESCENT PANEL LOCATION
LH switch panel 12-211	LH DASH INSTRUMENTS	LH dash panel 2-211  LH side console 1-211
RH switch panel 5-212	RH DASH INSTRUMENTS	RH dash panel 2-212  RH side console

EFFECTIVITY: ALL

BA

**33-16-00**

Page 1  
Nov 30/76

# Concorde

## MAINTENANCE MANUAL

SWITCH LOCATION	SWITCH ENGRAVING	ELECTROLUMINESCENT PANEL LOCATION
		1-212
Roof panel 4-211	CENTRE CONSOLE PANEL	Aft centre console 9-211
	GLARESHIELD	Centre glareshield 5-211
	CENTRE DASH	Centre dash panel 6-211
	ROOF	Roof panel 4-211
LH side console 1-211-2	SIDE CONSOLE	LH side console 1-211-2
		LH switch panel 12-211
RH side console 1-212-2	SIDE CONSOLE	RH side console 1-212-2
		RH switch panel 5-212
Circuit breaker panel 3-213	PANEL	Lighting panel on circuit breaker panel 3-213
		Oxygen and jack box panel 20-215
Lighting control panel 11-214	PANEL	3rd crew member's station, zone 214
	C/B	Circuit breaker panels 1-213 to 5-213 (lighting bars)

Electroluminescent Panel Lighting  
Table 1

The C/B switch on lighting control panel 11-214 and the

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 2  
Nov 30/76



# Concorde

## MAINTENANCE MANUAL

PANEL switch on circuit breaker panel 3-213 are two-position (ON-OFF) toggle switches. The remaining switches are multi-wafer rotary switches, each having one wafer connected as an 'off-on' switch for EL panel lighting control; other wafers are associated with instrument lighting (Ref. 33-17-00).

### B. Functional Description

When a suitable a.c. voltage is applied to the electroluminescent panel the phosphor particles are excited into luminescence and the entire area of the panel is illuminated, but light shows only through the engraved portions of the opaque panel.

### 4. Electrical Power Supplies

Table 2 lists the busbars and circuit breaker locations for the various EL panels.

PANEL	BUSBAR SUPPLY	CIRCUIT BREAKER PANEL
LH dash panel ) 2-211 ) )	No.2 main 115 V a.c.	13-215
LH side ) console 1-211 ) )		
RH dash panel ) 2-212 ) )		
RH side ) console 1-212 ) )		
Centre glare- ) shield 5-211 ) )		
Centre dash ) 6-211 ) )		
Aft centre ) console 9-211 )		
Roof panel ) 4-211 ) )	No.3 main 115 V a.c.	13-216
RH switch )		

EFFECTIVITY: ALL

**33-16-00**

R

BA

Page 3  
Nov 30/76

Printed in England

# Concorde

## MAINTENANCE MANUAL

PANEL	BUSBAR SUPPLY	CIRCUIT BREAKER PANEL
panel 5-212 ) ) Lighting panel ) on CB panel ) 3-213 ) ) Oxygen and ) jack box panel ) 20-215 )		
LH side ) console ) 1-211-2 ) ) LH side ) console ) 1-211-3 ) ) LH switch ) panel 12-211 )	No.1 main 115 V a.c.	14-215
3CM station, zone 214	No.4 main 115 V a.c.	14-216
CB panels 1-213 to 5-213	No.1 essential 115 V a.c.	2-213

Electrical Power Supplies  
Table 2

EFFECTIVITY: ALL

R

BA

Printed in England

**33-16-00**

Page 4  
Nov 30/76

# Concorde


## MAINTENANCE MANUAL

GLARE SHIELD  
PANEL LIGHTING  
SWITCH


CENTRE CONSOLE  
PANEL LIGHTING  
SWITCH

CENTRE-DASH  
PANEL LIGHTING  
SWITCH

ROOF PANEL  
LIGHTING SWITCH




**A** ROOF PANEL 4-211




**B** ROOF PANEL 4-211

LH DASH  
PANEL LIGHTING  
SWITCH




**C** LH SWITCH PANEL 12-211

SIDE CONSOLE  
PANEL LIGHTING  
SWITCH




**E** LH SIDE CONSOLE PANEL 1-211-2

SIDE CONSOLE  
PANEL LIGHTING  
SWITCH




**F** RH SIDE CONSOLE PANEL 1-212-2

RH DASH  
PANEL LIGHTING  
SWITCH



**D** RH SWITCH PANEL 5-212



Panel Lighting Controls -  
Flight Compartment (Forward)  
Figure 001


R EFFECTIVITY: ALL

BA


Printed in England

33-16-00



Page 5  
Aug 30/76



**A** LIGHTING CONTROL PANEL 11-214



3CM STATION - ZONE 214



**B** LIGHTING CONTROL PANEL ON CB PANEL 3-213

Panel Lighting Controls -  
Flight Compartment (Rear)  
Figure 002

R EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 6  
Aug 30/76

# *Concorde*

## MAINTENANCE MANUAL

### PANEL LIGHTING - TROUBLE SHOOTING

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

R CAUTION: SWITCH OFF PANEL LIGHTING, WHEN NOT IN USE, TO CONSERVE  
R THE LIFE OF THE ELECTROLUMINESCENT PANELS.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

Where more than one group of electroluminescent (EL) panels are supplied from the same power source, through a common circuit breaker, those circuits are considered similar, therefore the procedures and charts are applicable to each circuit. Where identical components are involved, i.e., one in each circuit, the references to the associated components are listed thus: 'Renew Switch (1), (2), (3) or (4)'. Where one group of EL panels only is supplied from an individual power source, a separate chart is shown for that circuit.

Each panel lighting control switch and the associated panels on which the group of EL panels is mounted, are listed in Adjustment/Test.

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 101  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

R

BA

Printed in England

**33-16-00**

Page 102  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting

- A. Prepare to trouble shoot (Ref. para.2.).  
Switch on each electroluminescent (EL)  
panel lighting control switch, in turn,  
and check that all associated panel  
engravings are illuminated. IF -

1. The engravings on one panel  
only not illuminated -  
check electrical connectors  
at rear of the panel.  
Retest. If fault not cleared,  
renew panel.
2. All EL panels, controlled by  
following associated switches,  
not illuminated:

NOT OK

- (a) Switch (1), (2), (3) or (4) -  
Chart 101.
- (b) Switch (5) - Chart 102.
- (c) Switch (6) or (7) - Chart 103.
- (d) Switch (8) - Chart 104.
- (e) Switch (9) - Chart 105.
- (f) Switch (10) - Chart 106.
- (g) Switch (11) - Chart 107.

CMB3316001AAM0

EFFECTIVITY: ALL

BA


Printed in England

# 33-16-00

Page 103  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL



CMB3316001BAM0

Chart 101

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 104  
Jun 30/75




# Concorde

## MAINTENANCE MANUAL

ALL 'EL' PANELS CONTROLLED BY SWITCH (5), NOT ILLUMINATED WHEN SWITCH IS ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-



CMB3316001CAM0

Chart 102

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 105  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

ALL 'EL' PANELS CONTROLLED BY ASSOCIATED SWITCH (6) OR (7), NOT ILLUMINATED WHEN SWITCH IS ON

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

Switch on appropriate panel light control switch.

Switch on alternative Switch (6) or (7) and check that associated EL panels are illuminated.

YES

Check for 115 V a.c. output at terminal 2b of Switch (6) or terminal 1 of Switch (7) as appropriate.

YES

Locate and rectify O/C in wiring between Switch (6) or (7) and first EL panel in associated group.

NO

NO

Check for O/C in wiring between CB (13) and Switch (6) or (7).

YES

Check for 115 V output from CB (13).

NO

Renew CB (13).

Check for 115 V input at terminal 2s of Switch (6) or terminal 2 of Switch (7) as appropriate.

YES

Renew Switch (6) or (7).

NO

Locate and rectify O/C in wiring between Switch (6) or (7) and CB (13).

CMB3316001DAM0

Chart 103

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 106  
Jun 30/75


# Concorde

## MAINTENANCE MANUAL

ALL 'EL' PANELS CONTROLLED BY SWITCH (8), NOT ILLUMINATED WHEN SWITCH IS ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-



CMB3316001EAMG

Chart 104

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 107  
Jun 30/75


# Concorde

## MAINTENANCE MANUAL

ALL 'EL' PANELS CONTROLLED BY SWITCH (9), NOT ILLUMINATED WHEN SWITCH IS ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-



CMB3316001FAM0

Chart 105

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 108  
Jun 30/75


# Concorde

## MAINTENANCE MANUAL

ALL 'EL' PANELS CONTROLLED BY SWITCH (10), NOT ILLUMINATED WHEN SWITCH IS ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-



CMB3316001GAM9

Chart 106

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 109  
Jun 30/75


# Concorde

## MAINTENANCE MANUAL

ALL 'EL' PANELS CONTROLLED BY SWITCH (11), NOT ILLUMINATED WHEN SWITCH IS ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-



CMB3316001HAM0

Chart 107

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 110  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Switch - LH DASH INSTRUMENTS	-	12-211	L382	LH switch panel	33-16-00 R/I	
(2) Switch - RH DASH INSTRUMENTS	-	5-212	L381	RH switch panel	33-16-00 R/I	
(3) Switch - GLARESHIELD	-	4-211	L402	Roof panel	33-16-00 R/I	
(4) Switch - CENTRE DASH	-	4-211	L401	Roof panel	33-16-00 R/I	
(5) Switch - CENTRE CONSOLE PANEL	-	4-211	L383	Roof panel	33-16-00 R/I	
(6) Switch - ROOF	-	4-211	L384	Roof panel	33-16-00 R/I	
(7) Switch - PANEL	-	3-213	L91	Circuit breaker panel 3-213	33-16-00 R/I	
(8) Switch - SIDE CONSOLE	-	1-211 -2	L89	LH side console	33-16-00 R/I	
(9) Switch - SIDE CONSOLE	-	1-212 -2	L90	RH side console	33-16-00 R/I	
(10) Switch - PANEL	-	11-214	L385	Lighting control panel 11-214	33-16-00 R/I	
(11) Switch - C/B	-	11-214	L92	Lighting control panel 11-214	33-16-00 R/I	
(12) Circuit breaker 115 V	-	13-215	L85	Map ref.A11	24-50-00 R/I	
(13) Circuit breaker 115 V	-	13-216	L81	Map ref.A8	24-50-00 R/I	

EFFECTIVITY: ALL

BA

Printed in England

# 33-16-00

Page 111  
Nov 30/79

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(14) Circuit breaker 115 V	-	13-215	L82	Map ref.B12	24-50-00 R/I	
(15) Circuit breaker 115 V	-	14-216	L86	Map ref.D9	24-50-00 R/I	
(16) Circuit breaker 115 V	-	14-215	L83	Map ref.F10	24-50-00 R/I	
(17) Circuit breaker 115 V	-	13-216	L84	Map ref.D8	24-50-00 R/I	
(18) Circuit breaker 115 V	-	2-213	L87	Map ref.A9	24-50-00 R/I	

Component Identification  
Table 101

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 112  
Nov 30/79



*Concorde*  
British airways  
MAINTENANCE MANUAL

PANEL LIGHTING - MAINTENANCE PRACTICES

1. General

- A. The following sub-panels electroluminescent lighting must be maintained serviceable:

Location	Sub-panels
Roof Panel	Auto Stab/Artificial Feel/ Electric Trim/Flying Control Inverter/Signal Mode/Anti-Stall

- B. The remaining panels on the Flight Engineer's station, Pilots' centre, side or dash panels, need not be changed, if only the electroluminescent lighting is unserviceable.

On panels 1-213 to 5-213 the Circuit Breaker titling area panels need not be changed if only the electroluminescent lighting is unserviceable.

EFFECTIVITY: ALL

BA

C807793

**33-16-00**

Page 201  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

### PANEL LIGHTING - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

WHEN DISCONNECTING FLYING LEADS FROM THE ASSOCIATED MODULE BLOCK, ENSURE THAT THE CORRECT PIN INSERTS ARE WITHDRAWN FROM THE SOCKET.

#### 1. General

This topic contains instructions necessary for the removal and installation of electroluminescent (EL) panels fitted on all instrument and switch panels in the flight compartment, and circuit breaker lighting bars fitted on circuit breaker panels in zone 213.

Electrical connections are made at the back of each EL panel either by flying leads or by a coaxial connector, and at the back of each circuit breaker lighting bar by screw-type terminals.

Instructions for the removal and installation of associated switches on the flight compartment roof panel are detailed in 33-00-00, and for all other associated switches in 33-10-00.

#### 2. Electroluminescent Panels

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

##### B. Prepare

- (1) Ensure that the associated light control switch, as listed in Adjustment/Test, Table 501, is at OFF.
- (2) Trip the appropriate circuit breaker listed below, and fit a safety clip.

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 401  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
EL panel supplies			
ROOF & CB PNL 3-213 LTS SUP	13-216	L81	A8
CTR CONSOLE PNL LTG SUP	13-215	L82	B12
LH CONSOLE PNL LTG SUP	14-215	L83	F10
RH CONSOLE PNL LTG SUP	13-216	L84	D8
DASH & G/SHIELD PNL LTG SUP	13-215	L85	A11
3CM STN PNL LTG SUP	14-216	L86	D9

**CAUTION:** 'EL' PANELS ARE VULNERABLE TO DAMAGE BY SCRATCHING AND CRACKING. ENSURE THAT THE SCREWDRIVER DOES NOT DAMAGE THE POLISHED WALL OF THE PANEL.

- (3) Remove the cap, unscrew the clutch nut and withdraw the knob from any rotary switch fitted on the EL panel.

**C. Remove an EL Panel Fitted with a Coaxial Connector**

- (1) Remove the screws and washers securing the EL panel to its mounting and withdraw the panel sufficiently to gain access to the coaxial connector.
- (2) Withdraw the coaxial connector from the panel and remove the panel from its mounting.

**D. Install an EL Panel Fitted with a Coaxial Connector**

- (1) Comply with the electrical safety precautions.
- (2) Fit the coaxial connector to the EL panel.
- (3) Position the EL panel on its mounting and secure it with the screws and washers.

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 402  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

### E. Remove an EL Panel Fitted with Flying Leads

- (1) Release the backing plate quick-release fasteners, or remove the screws and washers, as appropriate, and withdraw the complete panel assembly from its housing.
- (2) Release the flying leads from the loom ties and, using a suitable tool, withdraw the pin inserts from the module block.
- (3) Disengage the EL panel from the backing plate by removing the securing screws and washers.

### F. Install an EL Panel Fitted with Flying Leads

- (1) Comply with the electrical safety precautions.
- (2) Fit the EL panel to its backing plate with the flying leads through the aperture.
- (3) Secure the EL panel to the backing plate with the screws and washers.
- (4) Using a suitable tool, connect the flying leads to the module block, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (5) Secure the flying leads to the cable loom with suitable ties in accordance with 20-27-15.
- (6) Fit the panel assembly to its mounting and secure it with the quick-release fasteners, or screws and washers, as appropriate.

### G. Conclusion

- (1) Where appropriate, fit each switch knob on its spindle, ensuring that the spindle drive spigot is engaged with the slot in the knob. Tighten the clutch nut and fit the end cap to the knob.
- (2) Remove the safety clip and set the circuit breaker tripped before removal.
- (3) Make available electrical ground power as detailed in 24-41-00, Servicing.
- (4) Switch on the associated panel light control switch and check that EL panel engravings are illuminated.

EFFECTIVITY: ALL

R BA

**33-16-00**

Page 403  
Mar 28/02

# *Concorde*

## MAINTENANCE MANUAL

- (5) Set the switch to "OFF".
- (6) Switch off and disconnect electrical ground power as detailed in 24-41-00, Servicing.

### 3. Circuit Breaker Lighting Bars

#### A. Prepare

- (1) Set the C/B (ON - OFF) switch on the 3CM switch panel (panel 11-214) to "OFF".
- (2) Trip the 3CM STN CB PNL LTS SUP circuit breaker L87, on panel 2-213, map ref. A9, and fit a safety clip.

#### B. Remove

- (1) Remove the screws securing the appropriate lighting bar to the circuit breaker panel and withdraw the bar from the mounting brackets.
- (2) Disconnect the electrical cables from the back of the lighting bars.

#### C. Install

- (1) Comply with the electrical safety precautions.
- (2) Connect the electrical cables to the circuit breaker lighting bar, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (3) Fit the lighting bar on the mounting brackets and secure it with the screws.

#### D. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00, Servicing.
- (2) Remove the safety clip and reset the circuit breaker tripped before removal.
- (3) Set the C/B switch, on the 3CM switch panel, to "ON" and check that the lighting bar is illuminated.
- (4) Set the C/B switch to "OFF".
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00, Servicing.

EFFECTIVITY: ALL

**33-16-00**

Page 404  
Mar 28/02

# *Concorde*

## MAINTENANCE MANUAL

- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 405  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL

### PANEL LIGHTING - ADJUSTMENT/TEST

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

R **CAUTION:** SWITCH OFF PANEL LIGHTING, WHEN NOT IN USE, TO  
R CONSERVE THE LIFE OF THE ELECTROLUMINESCENT PANELS.

#### 1. General

This topic contains an Operational Test only, which details the procedure to prove the correct operation of the electroluminescent panels in the flight compartment. Functional and System Tests are not considered necessary in this application.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test

- (1) Switch on each control switch listed in Table 501, in turn, and check that the associated electroluminescent panel engravings are adequately illuminated.

SWITCH LOCATION	SWITCH ENGRAVING	ELECTROLUMINESCENT PANELS LOCATION
LH switch panel 12-211	LH DASH INSTRUMENTS	LH dash panel 2-11 LH side console 1-211
RH switch panel 5-212	RH DASH INSTRUMENTS	RH dash panel 2-212 RH side console 1-212
Roof panel 4-211	CENTRE CONSOLE PANEL	Aft centre console 9-211
	GLARESHIELD	Centre glareshield 5-211
	CENTRE DASH	Centre dash panel 6-211

EFFECTIVITY: ALL

BA

Printed in England

**33-16-00**

Page 501  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL

SWITCH LOCATION	SWITCH ENGRAVING	ELECTROLUMINESCENT PANELS LOCATION
	ROOF	Roof panel 4-211
LH side console 1-211-2	SIDE CONSOLE	LH side console 1-211-2  LH switch panel 12-211
RH side console 1-212-2	SIDE CONSOLE	RH side console 1-212-2  RH switch panel 5-212
Circuit breaker panel 3-213	PANEL	Lighting panel on circuit breaker panel 3-213  Oxygen and jack box 20-215
Lighting control panel 11-214	PANEL	3rd crew member's station, zone 214
	C/B	Circuit breaker panels 1-213 to 5-213 (Lighting bars)

### Electroluminescent Panel Lighting Table 501

- (2) Return all control switches to the 'off' position and check that all electroluminescent panel lighting is extinguished.

#### C. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

# 33-16-00

Page 502  
Aug 30/75



# *Concorde*

## MAINTENANCE MANUAL

### INSTRUMENT LIGHTING - DESCRIPTION AND OPERATION

#### 1. General

Instrument lighting is provided by miniature filaments contained within each instrument, magnetic indicator and control unit. Except for the standby COMPASS control toggle switch on the left switch panel, and the PANEL jack and station box light control toggle switch on circuit breaker panel 3-213, all instrument lighting controls are multi-wafer rotary switches. Two or more filaments are fitted in each instrument, magnetic indicator and control unit to maintain illumination if one filament fails. The standby compass contains only one filament.

Control transformers, mounted close to associated instruments, provide stepped-down integral lighting supplies.

R Dimming facilities for the digital displays associated  
R with the distance measuring equipment (DME) and the  
R horizontal situation indicators (HSIs)(Ref. Chap.34),  
R are provided by rotary 'dimmer-off' controls, one of which  
R is mounted on the left console and one on the right  
R console.

#### 2. Control Transformers

The primary of each transformer is stepped in five stages to give an output at the secondary of 2.5 V, 3.4 V, 4.2 V, 5.0 V and 5.9 V a.c. from a primary input of 115 V a.c. Each output is protected by fuses fitted in the transformer case and electrical connections are made at terminals on top of the transformer.

#### R 3. Rotary 'Dimmer-off' Control

R Each rotary 'dimmer-off' control comprises a rotary control  
R switch and three variable resistors. Each variable  
R resistor is connected in series with a fixed resistor to  
R provide a reduced and variable voltage output from a 28 V  
R d.c. input supply.

#### R 4. Operation (Ref. Fig.001 and 002)

##### A. Control

The input of each control transformer is taken from one phase of an associated 115 V a.c. busbar through the contacts of an appropriate lighting control switch. The stepped-down output of each transformer is fed to the associated instruments, magnetic indicators or

EFFECTIVITY: ALL

BA

Printed in England

# 33-17-00

Page 1  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL

control units. The lighting control switches are mounted on switch panels located close to the instrument lighting they control. The standby compass integral lighting is supplied from the 'A' essential 28 V d.c. busbar through the contacts of a lighting control switch.

The standby COMPASS lighting control switch on panel 12-211 is a double-pole three-position (BRIGHT - DIM - OFF) toggle switch. The PANEL switch on lighting control panel 3-213 is a two-position (ON - OFF) toggle switch. The remaining switches are multi-wafer rotary switches. In each rotary switch the contacts of one wafer connect the 115 V a.c. supply to the tapped primary of the associated transformer and act as a dimmer control for the integral lighting supplies from the transformer secondary. The contacts of the other wafers are associated with panel lighting (Ref. 33-16-00).

R The input to each variable resistor in the rotary  
R 'dimmer/off' controls is connected to the associated  
R main 28 V d.c. busbar via a fixed resistor. The  
R variable voltage outputs, determined by the setting  
R of the appropriate DIGITS rotary control switch, are  
R fed to the associated instruments to control the bright-  
R ness of the digital display.

R Table 1 lists the lighting control and digital dimming  
R control switches and the associated panels on which  
R illuminated components are mounted.

SWITCH LOCATION.	SWITCH ENGRAVING	LOCATION OF ILLUMINATED COMPONENTS
LH switch panel 12-211	COMPASS (toggle switch)	Windscreen centre pillar
	LH DASH INSTRUMENTS	LH dash panel 2-211
RH switch panel 5-212	RH DASH INSTRUMENTS	RH dash panel 2-212
Roof panel 4-211	CENTRE CONSOLE PANEL	Aft centre console 9-211 Forward centre console 7-211
	GLARESHIELD	Centre glareshield 5-211

EFFECTIVITY: ALL

BA

**33-17-00**

Page 2  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL

SWITCH LOCATION	SWITCH ENGRAVING	LOCATION OF ILLUMINATED COMPONENTS
	CENTRE DASH	Centre dash panel 6-211
	ROOF	Roof panel 4-211
LH side console 1-211-2	SIDE CONSOLE	LH side console 1-211
R	DIGITS	LH dash panel 2-211
R R		Centre glareshield 5-211 (If digital display fitted)
RH side console 1-212-2	SIDE CONSOLE	RH side console 1-212
R	DIGITS	RH dash panel 2-212
R R		Centre glareshield 5-211 (If digital display fitted)
Circuit breaker panel 3-213	PANEL (toggle switch)	Headset jack box 7-213 Station box 7-213 Headset jack box 20-215
Lighting control panel 11-214	PANEL	3rd crew member's station, zone 214 - RH instruments, centre instruments and LH instruments

Instrument Lighting  
Table 1

### B. Functional Description

R  
R  
R  
R

With electrical supplies available, when a lighting control rotary switch is rotated the 115 V a.c. supply is connected to each of the five tapplings on the associated control transformer primary, in turn, to provide a varying output which controls the brightness of the associated instrument, magnetic indicator and control unit integral lighting. 28 V d.c. is applied to the fixed resistor in each of the dimming control circuits, the output of which is fed through the associated variable resistor to control the brightness

EFFECTIVITY: ALL

BA


Printed in England

# 33-17-00

Page 3  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL



- Instrument Lighting Controls and Equipment -  
Flight Compartment (Forward)  
Figure 001

EFFECTIVITY: ALL

BA


Printed in England

33-17-00

Page 4  
Feb 28/78

# Concorde

## MAINTENANCE MANUAL



- Instrument Lighting Controls and Equipment -  
Flight Compartment (Rear)  
Figure 002

EFFECTIVITY: ALL

**33-17-00**

R

BA

Page 5  
Aug 30/75

Printed in England

# Concorde

## MAINTENANCE MANUAL

of the appropriate digital display, depending on the setting of the DIGITS control switch.

When DIM is selected at the standby COMPASS light control toggle switch the 28 V d.c. supply is connected to the standby compass integral filament, through the switch contacts and a dimming resistor, and the filament lights at reduced brightness. When BRIGHT is selected the dimming resistor is bypassed and the filament lights at full brightness.

When ON is selected at the PANEL toggle switch on panel 3-213, the 115 V a.c. is connected to No.5 tapping on the primary winding of the associated transformer, through the switch contact, to provide a stable output to the appropriate headset jack box and station box integral lighting.

### 5. Electrical Power Supplies

Table 2 lists the busbars and circuit breaker locations for the panels on which illuminated components are mounted.

LOCATION OF ILLUMINATED COMPONENTS	BUSBAR SUPPLY	CIRCUIT BREAKER PANEL
Windscreen centre pillar	'A' essential 28 V d.c. busbar	1-213
LH dash panel 2-211	No.2 main 115 V a.c. busbar	13-215
R Before SB 33-018		
R	'A' main 28 V d.c. busbar (Digital display dimming)	15-215
R		
R		
R After SB 33-018	For A/C 001-004,	
R		
R	'A' essential 28 V d.c. busbar (Digital display dimming)	1-213
R		
LH side console	No.1 main 115 V a.c.	14-215

EFFECTIVITY: ALL

BA

Printed in England

# 33-17-00

Page 6  
Nov 30/78

# Concorde

## MAINTENANCE MANUAL

LOCATION OF ILLUMINATED COMPONENTS	BUSBAR SUPPLY	CIRCUIT BREAKER PANEL
1-211	busbar	
RH dash panel 2-212	No.3 main 115 V a.c. busbar	13-216
	'B' main 28 V d.c. busbar (Digital display dimming)	15-216
RH side console 1-212	No.4 main 115 V a.c. busbar	14-216
Centre glareshield 5-211	No.4 main 115 V a.c. busbar	14-216
	'A' and 'B' main 28 V d.c. busbars (If digital display fitted)	15-215 15-216
Centre dash 6-211	No.4 main 115 V a.c. busbar	14-216
Forward centre console 7-211	No.4 main 115 V a.c. busbar	14-216
Rear centre console 9-211	No.4 main 115 V a.c. busbar	14-216
Roof panel 4-211	No.2 main 115 V a.c. busbar	13-215
Headset jackbox 20-215	No.1 main 115 V a.c. busbar	14-215
Station jackbox 7-213	No.1 main 115 V a.c. busbar	14-215
3CM station, zone 214	No.3 main 115 V a.c. busbar	13-216

Electrical Power Supplies  
Table 2

EFFECTIVITY: ALL

BA

Printed in England

**33-17-00**

Page 7  
Nov 30/78

# *Concorde*

## MAINTENANCE MANUAL

### INSTRUMENT LIGHTING - TROUBLE SHOOTING

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED  
IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

Where circuits are similar, they are grouped so that the procedures and charts are applicable to each circuit of the associated group. Where identical components are involved, i.e., one in each circuit, the references to the associated components listed in Table 101 are given, e.g., 'Renew associated Switch (1), (2), (3) or (4)'.

Each instrument lighting control switch and the associated panels on which instruments are mounted, are listed in Adjustment/Test.

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

**33-17-00**

Page 101  
Aug 30/77



# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting

#### A. \*\*\*\*\*

\*Prepare to trouble shoot (Ref. para.2.). \*  
\*Switch on at each instrument light control\*  
\*switch, in turn, and check that the as- \*  
\*sociated instruments are illuminated and \*  
\*that the lights vary in brightness when \*  
\*the switch is rotated. IF - \*  
\*\*\*\*\*

OK

NOT OK-----

1. One instrument only not lit - change instrument.
2. Instruments on LH or RH dash, centre console or roof panel not lit - Chart 101.
3. Instruments on glareshield or centre dash not lit - Chart 102
4. Instruments on LH console, oxygen mask stowage or jack/station box filaments not lit - Chart 103.
5. Instruments on RH console and oxygen mask stowage not lit - Chart 104.
6. Instruments at 3CM station RH, LH or centre areas not lit - Chart 105.
7. Standby compass not lit when switch is set to BRIGHT or DIM - Chart 106.
8. Digital dimming control of DME only, HSI only or VOR/DME controller only when associated DIGIT control switch rotated - renew Switch (37) or (38).
9. No digital dimming control of DME, HSI and VOR/DME controller when associated DIGIT control switch is rotated - check for 28 V d.c. output from associated CB (35) or (36). If NOT OK - renew CB (35) or (36). IF OK - check associated wiring.

EFFECTIVITY: ALL

**33-17-00**

R

BA

Page 102  
Aug 30/78

Printed in England

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*INSTRUMENTS ON LH DASH OR RH \*  
 \*DASH, CENTRE CONSOLE OR ROOF \*  
 \*PANEL NOT LIT WHEN ASSOCIATED\*  
 \*SWITCH SET TO 'ON'. \*  
 \*\*\*\*\*

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 101

EFFECTIVITY: ALL

BA

Printed in England

**33-17-00**

Page 103  
 Aug 30/78

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*INSTRUMENTS ON GLARESHIELD \*  
 \*OR CENTRE DASH NOT LIT WHEN \*  
 \*ASSOCIATED SWITCH SET TO 'ON'\*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 102

EFFECTIVITY: ALL

**33-17-00**

Page 104  
 Aug 30/78

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*INSTRUMENTS ON LH CONSOLE, \*  
 \*OXYGEN MASK STOWAGE OR JACK/ \*  
 \*STATION BOX FILAMENTS NOT LIT\*  
 \*WHEN ASSOCIATED SWITCH SET TO\*  
 \*'ON'. \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	
MULTIMETER	

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 103

EFFECTIVITY: ALL

**33-17-00**

R

BA

Page 105  
 Aug 30/78

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
\*INSTRUMENTS ON RH CONSOLE AND\*  
\*OXYGEN MASK STOWAGE NOT LIT \*  
\*WHEN SWITCH IS SET TO 'ON'. \*  
\*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

NOTE: Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 104

EFFECTIVITY: ALL

R BA

33-17-00

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*INSTRUMENTS AT 3CM STATION, \*  
 \*RH, LH OR CENTRE AREAS NOT \*  
 \*LIT WHEN SWITCH IS SET TO \*  
 \*'ON'. \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 105

EFFECTIVITY: ALL

**33-17-00**

Page 107  
 Aug 30/78

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*STANDBY COMPASS NOT LIT WHEN \*  
 \*SWITCH IS SET TO 'BRIGHT' OR \*  
 \*'DIM'. \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-




Chart 106

EFFECTIVITY: ALL

**33-17-00**

R

BA

Page 108  
 Aug 30/78

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Switch - LH DASH INSTRUMENTS	-	12-211	L382	LH switch panel	33-17-00 R/I	33-17-02
(2) Switch - RH DASH INSTRUMENTS	-	5-212	L381	RH switch panel	33-17-00 R/I	33-17-01
(3) Switch - CENTRE CONSOLE PANEL	-	4-211	L383	Roof panel	33-17-00 R/I	33-17-04
(4) Switch - ROOF	-	4-211	L384	Roof panel	33-17-00 R/I	33-17-06
(5) Switch - GLARESHIELD	-	4-211	L402	Roof panel	33-17-00 R/I	33-17-07
(6) Switch - CENTRE DASH	-	4-211	L401	Roof panel	33-17-00 R/I	33-17-03
(7) Switch - PANEL	-	3-213	L91	Circuit breaker panel	33-17-00 R/I	33-16-02
(8) Switch - SIDE CONSOLE	-	1-211 -2	L89	LH side console	33-17-00 R/I	33-16-13
(9) Switch - SIDE CONSOLE	-	1-212 -2	L90	RH side console	33-17-00 R/I	33-16-13
(10) Switch - PANEL	-	11-214	L385	Lighting control panel	33-17-00 R/I	33-17-05
(11) Switch - COMPASS	-	12-211	L400	Windscreen centre pillar	33-17-00 R/I	33-17-06
(12) Circuit breaker 115 V	-	13-215	L372	Map ref.A12	24-50-00 R/I	33-17-02
(13) Circuit breaker 115 V	-	13-216	L371	Map ref.E9	24-50-00 R/I	33-17-01

EFFECTIVITY: ALL

# 33-17-00

R

BA

Page 109  
Nov 30/79

Printed in England



# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(14) Circuit breaker 115 V	-	13-215	L379	Map ref.F11	24-50-00 R/I	33-17-06
(15) Circuit breaker 115 V	-	14-216	L405	Map ref.B8	24-50-00 R/I	33-17-04
(16) Circuit breaker 115 V	-	14-216	L375	Map ref.D10	24-50-00 R/I	33-17-03 33-17-07
(17) Circuit breaker 115 V	-	14-215	L374	Map ref.B11	24-50-00 R/I	33-17-04
(18) Circuit breaker 115 V	-	14-216	L373	Map ref.E8	24-50-00 R/I	33-17-04
(19) Circuit breaker 115 V	-	13-216	L377	Map ref.E7	24-50-00 R/I	33-17-05
(20) Circuit breaker 28 V	-	1-213	L380	Map ref.P22	24-50-00 R/I	33-17-06
(21) Instrument lights control transformer	-	10-211	L392	Dash panel support structure	33-17-11 R/I	33-17-02
(22) Instrument lights control transformer	-	10-211	L393	Dash panel support structure	33-17-11 R/I	33-17-01
(23) Instrument lights control transformer	-	10-211 -1	L403	Dash panel support structure	33-17-11 R/I	33-17-04
(24) Instrument lights control transformer	-	9-214	L394	3CM station secondary structure	33-17-11 R/I	33-17-06
(25) Instrument lights control transformer	-	10-211 -1	L404	Dash panel support structure	33-17-11 R/I	33-17-07
(26) Instrument lights control transformer	-	10-211 -1	L391	Dash panel support structure	33-17-11 R/I	33-17-03

EFFECTIVITY: ALL

# 33-17-00

R

BA

Page 110  
Nov 30/79

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(27) Instrument - lights control transformer		18-215	L388	Flight compartment LH racking	33-17-12 R/I	33-17-04
(28) Instrument - lights control transformer		1-211	L389	LH console	33-17-12 R/I	33-17-04
(29) Instrument - lights control transformer		1-212	L390	RH console	33-17-12 R/I	33-17-04
(30) Instrument - lights control transformer		9-214	L395	3CM station secondary structure	33-17-11 R/I	33-17-05
(31) Instrument - lights control transformer		9-214	L396	3CM station secondary structure	33-17-11 R/I	33-17-05
(32) Instrument - lights control transformer		9-214	L397	3CM station secondary structure	33-17-11 R/I	33-17-05
(33) Dimming resistor		12-211	L407	Windscreen centre pillar	33-17-00 R/I	33-17-06
(34) Standby compass		15-211	F50	Windscreen centre pillar	Ref. Chap.34	34-25-11
Before SB 33-018						
(35) Circuit breaker 28 V		15-215	L1211	Map ref.614	24-50-00 R/I	33-17-81
After SB 33-018						
For A/C 001-004,						
(35) Circuit breaker 28 V		1-213	L1211	Map ref.R22	24-50-00 R/I	33-17-81

EFFECTIVITY: ALL

# 33-17-00

R

BA

Page 111  
Nov 30/79

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(36) Circuit breaker 28 V	-	15-216	L1216	Map ref.A13	24-50-00 R/I	33-17-81
(37) Switch - DIGITS	-	1-211 -2	L1215	LH side console	33-10-00	33-17-81
(38) Switch - DIGITS	-	1-212 -2	L1220	RH side console	33-10-00	33-17-81

Component Identification  
Table 101

EFFECTIVITY: ALL

BA

Printed in England

**33-17-00**

Page 112  
Nov 30/79

# *Concorde*

## MAINTENANCE MANUAL

R

### INSTRUMENT LIGHTING - REMOVAL/INSTALLATION

#### 1. General

Any faulty filament, integral to an instrument, necessitates the replacement of the instrument in which it is mounted. Instructions for the removal and installation of an instrument are detailed in the chapter dealing with the system in which the instrument occurs.

Instructions for the removal and installation of associated switches are detailed in 33-00-00 for switches on the pilots' roof panel and in 33-10-00 for switches on all other panels.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812215

# 33-17-00

Page 401  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### INSTRUMENT LIGHTING - ADJUSTMENT/TEST

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic contains an Operational Test only, which details the procedure to prove the correct operation of the integral lighting and digital display dimming, where appropriate, of the instruments in the flight compartment.

Functional and System Tests are not considered necessary in this application.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test

- (1) Switch on each control switch listed in Table 501, in turn, and check that the associated instruments are illuminated. Ensure that each rotary control switch functions correctly throughout its travel.

SWITCH LOCATION	SWITCH ENGRAVING	LOCATION OF ILLUMINATED COMPONENTS
LH switch panel 12-211	COMPASS (toggle-switch)	Windscreen centre pillar
	LH DASH INSTRUMENTS	LH dash panel 2-211
RH switch panel 5-212	RH DASH INSTRUMENTS	RH dash panel 2-212
Roof panel 4-211	CENTRE CONSOLE PANEL	Aft centre console 9-211
		Forward centre console 7-211
	GLARESHIELD	Centre glareshield 5-211

EFFECTIVITY: ALL

BA

Printed in England

**33-17-00**

Page 501  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

SWITCH LOCATION	SWITCH ENGRAVING	LOCATION OF ILLUMINATED COMPONENTS
	CENTRE DASH	Centre dash panel 6-211
	ROOF	Roof panel 4-211
LH side console 1-211-2	SIDE CONSOLE	LH side console 1-211
	DIGITS	LH dash panel  Centre glareshield
RH side console 1-212-2	SIDE CONSOLE	RH side console 1-212
	DIGITS	RH dash panel  Centre glareshield
Circuit breaker panel 3-213	PANEL (toggle-switch)	Headset jack box 7-213  Station box 7-213  Headset jack box 20-215
Lighting control panel 11-214	PANEL	3rd crew member's station, zone 214 -  RH panels  Centre panels  LH panels

### Instrument Lighting Table 501

- (2) Return all control switches to the 'off' position and check that all instrument integral lighting is extinguished.

EFFECTIVITY: ALL

BA

Printed in England

# 33-17-00

Page 502  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

### C. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-17-00**

Page 503  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

### 100 VA and 200 VA TRANSFORMERS - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS  
DETAILED IN 24-00-00.

#### 1. General (Ref. Fig. 401 )

Six 100 VA transformers and three 200 VA transformers are associated with the instrument lighting system.

Five 100 VA transformers are mounted on the dashboard support structure behind the centre dash panel 6-211 and supply power for the integral lighting of components on the centre console, centre glareshield, and the centre, left and right dash panels. One 100 VA transformer is installed at the rear of the forward leg of the third crew member's (3CM) station, zone 214, and supplies power for the integral lighting of components on the roof panel.

Two 200 VA transformers are installed at the rear of the aft leg of the 3CM station and one at the rear of the forward leg; these transformers supply power for the integral lighting of components on the left, centre and right panels of the 3CM station.

Each transformer is secured to a mounting plate by screws entering the body of the transformer from the reverse side of the plate. Electrical connections are made at terminals on top of each transformer.

#### 2. Centre Console, Centre Dash Panels and Glareshield Instrument Lights 100 VA Transformers

##### A. Equipment and Materials

---

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

---

##### B. Prepare


- (1) Ensure that the GLARESHIELD, CENTRE CONSOLE and CENTRE DASH rotary lighting control switches on the flight compartment roof panel are at OFF.
- (2) Trip the CENTRE DASH & G/SHIELD INST LTS SUP and the CENTRE CONSOLE INST LTS SUP circuit breakers,

EFFECTIVITY: ALL

**33-17-11**

Page 401  
Feb 29/76





CMB3317114AAM0

- 100 VA and 200 VA Transformer - Installation  
Figure 401

EFFECTIVITY: ALL

BA

Printed in England

# 33-17-11

Page 402  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

R  
R

L375 and L405, on panel 14-216, map refs.D10 and B8, and fit safety clips.

- (3) Gain access to the transformers on the dashboard upper support structure by removing the cover from the top of the centre glareshield.

### C. Remove

- (1) Disconnect each of the transformer electrical connectors from the associated connectors on the dashboard structure.
- (2) Release the four quick-release fasteners securing the transformer mounting plate to its support bracket.
- (3) Using the lifting handle, withdraw the mounting plate, with the three transformers attached, clear of the structure.
- (4) Remove the terminal cover from the appropriate transformer and disconnect the cables from the terminals.
- (5) Refit the terminal cover.
- (6) Cut the locking wire, remove the transformer securing screws and washers from the reverse side of the mounting plate and remove the transformer.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the transformer to the mounting plate and secure it with the screws and washers. Wire-lock the securing screws in accordance with 20-21-13.
- (3) Remove the terminal cover from the transformer.
- (4) Connect the electrical cables to the transformer terminals, ensuring that the connections are made in accordance with the cable identification and the applicable wiring diagram.
- (5) Refit the terminal cover.
- (6) Fit the transformer mounting plate to its bracket on the dashboard upper support structure and secure it with the quick-release fasteners.

EFFECTIVITY: ALL

BA

**33-17-11**

Page 403  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (7) Connect each of the three transformer electrical connectors to their associated connectors on the dashboard structure, ensuring that the mating surfaces are clean and undamaged.
- (8) Check that the transformer is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Remove the safety clips and reset the circuit breakers tripped before removal.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Switch on the GLARESHIELD, the CENTRE DASH and the CENTRE CONSOLE integral lighting control switches on the flight compartment roof panel. Check that the integral filaments of components on the glareshield, the centre dash and the centre console are lit.
- (4) Rotate each switch in turn, and check that the associated lights vary in brightness.
- (5) Set the control switches to "OFF".
- (6) Refit the cover to the top of the centre glareshield.
- (7) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### 3. Right and Left Dash Panels Instrument Lights 100 VA Transformers

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Ensure that the LH DASH INSTRUMENTS and the RH DASH INSTRUMENTS lighting control switches on the left and right switch panels, respectively, are at

EFFECTIVITY: ALL

BA

# 33-17-11

Page 404  
Feb 29/76

# *Concorde*

## MAINTENANCE MANUAL

OFF.

R (2) Trip the RH DASH INST LTS SUP circuit breaker,  
R L371, on panel 13-216, map ref.E9, and the LH  
R DASH INST LTS SUP circuit breaker, L372, on  
R panel 13-215, map ref.A12, and fit safety clips.

(3) Gain access to the transformers on the dashboard lower support structure by removing the access panels from the left and right sides of the dashboard structure.

### C. Remove

(1) Remove the screws and washers securing the transformer mounting plate to its support brackets and lower the mounting plate to the extent of the transformer electrical cables.

(2) Remove the terminal cover from the appropriate transformer and disconnect the cables from the terminals.

(3) Refit the terminal cover.

(4) Cut the locking wire and remove the transformer securing screws and washers from the reverse side of the mounting plate. Remove the transformer from the mounting plate.

### D. Install

(1) Comply with the electrical safety precautions.

(2) Fit the transformer to the mounting plate and secure it with the screws and washers. Wire-lock the securing screws in accordance with 20-21-13.

(3) Remove the terminal cover from the transformer.

(4) Connect the electrical cables to the transformer terminals, ensuring that the connections are made in accordance with the cable identification and the applicable wiring diagram.

(5) Refit the terminal cover.

(6) Fit the transformer mounting plate to its support brackets and secure it with the screws and washers.

(7) Check that the transformer is bonded in accordance

EFFECTIVITY: ALL

BA

# 33-17-11

Page 405  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL

with 20-27-11.

### E. Conclusion

- (1) Remove the safety clips and reset the circuit breakers tripped before removal.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Switch on the LH or RH DASH INSTRUMENTS switches on the left or right switch panels, as appropriate, and check that the integral filaments of components on the left or right dash panels are lit.
- (4) Rotate the switch and check that the associated lights vary in brightness.
- (5) Set the control switch to "OFF".
- (6) Fit the access panels to the left and right sides of the dashboard structure.
- (7) Switch off and disconnect electrical ground power as detailed in 24-41-00.

#### 4. Roof Panel Instrument Lights 100 VA Transformer, and 3CM Station (RH Panels) Instrument Lights 200 VA Transformer

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

##### B. Prepare

- (1) Ensure that the ROOF lighting control switch on the flight compartment roof panel and the PANEL lighting control switch on the lighting control panel, 11-214, at the 3CM station, are at OFF.
- (2) Trip the ROOF PNL INST LTS SUP circuit breaker, L379, on panel 13-215, map ref.F11, and the 3CM STN INST LTS SUP circuit breaker, L377, on panel 13-216, map ref.E7, and fit safety clips.
- (3) Trip circuit breaker F56, labelled 2ND PLT 3CM CLOCK

EFFECTIVITY: ALL

BA

Printed in England

# 33-17-11

Page 406  
Aug 30/77

# *Concorde*

## MAINTENANCE MANUAL

R TIME BASE - BAT SUP, on panel 16-216 and fit a safety  
R clip (Ref. 31-21-12).

- (4) Remove the upper fairing panel from the forward end of the 3CM station.

### C. Remove

- (1) Remove the screws securing the transformer mounting plate to the support brackets of the 3CM station structure and withdraw the plate and transformers.
- (2) Remove the terminal cover from the appropriate transformer and disconnect the cables from the terminals.
- (3) Refit the terminal cover.
- (4) Remove the appropriate transformer securing screws and washers from the reverse side of the mounting plate and remove the transformer from the plate.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the transformer to the mounting plate and secure it with the screws and washers.
- (3) Remove the terminal cover from the transformer.
- (4) Connect the electrical cables to the transformer terminals, ensuring that the connections are made in accordance with the cable identification and the applicable wiring diagram.
- (5) Refit the terminal cover.
- (6) Fit the transformer mounting plate to its support bracket and secure it with the screws.
- (7) Check that the transformer is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Remove the safety clips and reset the circuit breakers tripped before removal.
- (2) Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

# 33-17-11

Page 407  
Aug 30/77

# Concorde

## MAINTENANCE MANUAL

- (3) Switch on the ROOF lighting control switch on the flight compartment roof panel or the PANEL lighting control switch on the lighting control panel 11-214, as appropriate, and check that the integral filaments of associated components are lit.
- (4) Rotate the switch and check that the associated lights vary in brightness.
- (5) Set the control switch to "OFF".
- (6) Fit the upper fairing panel to the forward end of the 3CM station.
- (7) Switch off and disconnect electrical ground power as detailed in 24-41-00.
- (8) Reset the three clocks to GMT (Ref. 31-21-00).

### 5. 3CM Centre and LH Instrument Lights 200 VA Transformers

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Ensure that the PANEL lighting control switch on lighting control panel 11-214 at the 3CM station is at OFF.
- (2) Trip the 3CM STN INST LTS SUP circuit breaker, L377, on panel 13-216, map ref.E7, and fit a safety clip.
- (3) At the 3CM station, slide the table inward to its full extent.
- (4) Remove the sliding stowage box from its housing in the 3CM station knee-hole recess (Ref. 25-13-00) to gain access to the transformers in the aft leg of the 3CM station secondary structure.

#### C. Remove

- (1) Remove the screws securing the transformer mounting

EFFECTIVITY: ALL

BA

Printed in England

**33-17-11**

Page 408  
Aug 30/77

# *Concorde*

## MAINTENANCE MANUAL

plate to its support brackets and withdraw the plate and transformers.

- (2) Remove the terminal cover from the appropriate transformer and disconnect the cables from the terminals.
- (3) Refit the terminal cover.
- (4) Remove the transformer securing screws and washers from the reverse side of the transformer mounting plate. Remove the transformer from the mounting plate.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the transformer to the mounting plate and secure it with the screws and washers.
- (3) Remove the terminal cover from the transformer.
- (4) Connect the electrical cables to the transformer terminals, ensuring that the connections are made in accordance with the cable identification and the applicable wiring diagram.
- (5) Refit the terminal cover.
- (6) Fit the transformer mounting plate to its support brackets and secure it with the screws.
- (7) Check that the transformer is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Remove the safety clips and reset the circuit breakers tripped before removal.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Switch on the PANEL lighting control switch on lighting control panel 11-214. Check that the integral filaments of associated components are lit.
- (4) Rotate the switch and check that the lights vary in brightness.

EFFECTIVITY: ALL

**33-17-11**

Page 409  
Aug 30/77



# *Concorde*

## MAINTENANCE MANUAL

- (5) Set the control switch to "OFF".
- (6) Refit the sliding stowage box into its housing in the 3CM station knee-hole recess (Ref. 25-13-00) and withdraw the table to its full extent.
- (7) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

R

BA

Printed in England

**33-17-11**

Page 410  
Aug 30/77

# Concorde

## MAINTENANCE MANUAL

### 50 VA TRANSFORMER - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General (Ref. Fig. 401 )

Three 50 VA transformers are associated with the instrument lighting system. One transformer is mounted in the left console, panel 1-211, and one in the right console, panel 1-212, each transformer supplying power for the integral lighting of components on its associated console.

The third transformer is mounted on the rear face of the forward wall of the flight compartment left-hand racking, zone 215, and supplies power for the integral lighting of components on the left-hand racking.

Each transformer is secured to a mounting plate/bracket by screws entering the transformer from the reverse side of the plate/bracket. Electrical connections are made at terminals on top of each transformer, the terminals being protected by a terminal cover.

#### 2. 50 VA Transformer

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

##### B. Prepare

- (1) Ensure that the appropriate SIDE CONSOLE rotary switch on the left or right console, or the PANEL toggle-switch on panel 3-213 is at OFF.
- (2) Trip the associated circuit breaker listed below, and fit a safety clip.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
LH CONSOLE INST LTS SUP	14-215	L374	B11

EFFECTIVITY: ALL

**33-17-12**

Page 401  
Feb 29/76

# *Concorde*

## MAINTENANCE MANUAL

R  
R

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH CONSOLE INST LTS SUP	14-216	L373	E8

### C. Remove Transformer from Left Console

- (1) Gain access to the transformer in the left console by removing the cover plate from the inboard side of the console structure.
- (2) Remove the transformer terminal cover and disconnect the cables from the terminals.
- (3) Refit the terminal cover.
- (4) Remove the two screws securing the top of the transformer mounting plate to the upper support bracket.
- (5) Ease the mounting plate with attached transformer upwards sufficiently to disengage the mounting plate spigots from the lower support bracket. Withdraw the mounting plate and transformer clear of the console.
- (6) Remove the screws and washers securing the transformer to the mounting plate.

### D. Install Transformer in Left Console

- (1) Comply with the electrical safety precautions.
- (2) Support the transformer on its mounting plate and secure it with the screws and washers.
- (3) Engage the mounting plate spigots in their housings in the lower support bracket within the console. Press the mounting plate down to secure the bottom end.
- (4) Secure the upper end of the mounting plate to the upper support bracket with the screws and washers.
- (5) Check that the transformer is bonded in accordance

EFFECTIVITY: ALL

BA

Printed in England

**33-17-12**

Page 402  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

with 20-27-11.

- (6) Remove the terminal cover from the transformer.
- (7) Connect the electrical cables to the transformer terminals, ensuring that the connections are made in accordance with the cable identification and the applicable wiring diagram.
- (8) Refit the terminal cover.
- (9) Refit the cover plate to the side of the console.

### E. Conclusion

- (1) Remove the safety clip and reset the associated circuit breaker.
- (2) Make available electrical ground power as detailed in 24-21-00.
- (3) Switch on the SIDE CONSOLE rotary switch on the left side console and check that the integral filaments of components on the left side console, panel 1-211, are lit. Rotate the switch and check that the lights vary in brightness.
- (4) Set the switch to "OFF".
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### F. Remove Transformer from Right Console

- (1) Gain access to the transformer in the right console by removing the cover plate from the inboard side of the console structure.
- (2) Remove the terminal cover from the uppermost transformer on the transformer mounting plate and disconnect the cables from the terminals.
- (3) Refit the terminal cover.
- (4) Remove the two screws securing the transformer mounting plate to the upper support bracket.
- (5) Ease the mounting plate with the attached transformers upwards sufficiently to disengage the mounting plate spigots from the lower support bracket.

EFFECTIVITY: ALL

R


BA

# 33-17-12

Page 403  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL



- 50 VA Transformer - Installation  
Figure 401

EFFECTIVITY: ALL

BA

Printed in England

**33-17-12**

Page 404  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (6) Remove the screws and washers securing the transformer to the mounting plate and withdraw the transformer from the console.

### G. Install Transformer in Right Console

- (1) Comply with the electrical safety precautions.
- (2) Support the transformer on its mounting plate and secure it with the screws and washers.
- (3) Engage the mounting plate spigots in their housings in the lower support bracket and press the mounting plate down to secure the bottom end.
- (4) Secure the upper end of the mounting plate to the upper support bracket with the screws and washers.
- (5) Check that the transformer is bonded in accordance with 20-27-11.
- (6) Remove the terminal cover from the transformer.
- (7) Connect the electrical cables to the transformer terminals, ensuring that the connections are made in accordance with the cable identification and the applicable wiring diagram.
- (8) Refit the terminal cover.
- (9) Refit the cover plate to the side of the console.

### H. Conclusion

- (1) Remove the safety clip and reset the associated circuit breaker.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Switch on the SIDE CONSOLE rotary switch on the right side console and check that the integral filaments of components on the right side console, panel 1-212, are lit. Rotate the switch and check that the lights vary in brightness.
- (4) Set the switch to "OFF".
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

**33-17-12**

R

BA

Page 405  
Aug 30/75

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

### I. Remove Transformer from Flight Compartment LH Racking

- (1) Gain access to the transformer on the rear face of the forward wall of the flight compartment LH racking, by removing the appropriate cover from the front of the racking.
- (2) Remove the transformer terminal cover and disconnect the cables from the terminals.
- (3) Refit the terminal cover.
- (4) Remove the screws and washers securing the transformer to the mounting bracket and lift the transformer clear of the racking.

### J. Install Transformer in Flight Compartment LH Racking

- (1) Comply with the electrical safety precautions.
- (2) Place the transformer on its mounting bracket, on the rear face of the forward wall of the flight compartment LH racking, and secure it with the screws and washers.
- (3) Check that the transformer is bonded in accordance with 20-27-11.
- (4) Remove the terminal cover from the transformer.
- (5) Connect the electrical cables to the transformer terminals, ensuring that the connections are made in accordance with the cable identification and the applicable wiring diagram.
- (6) Refit the terminal cover.
- (7) Refit the cover to the racking.

### K. Conclusion

- (1) Remove the safety clip and reset the associated circuit breaker.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Switch on the PANEL toggle-switch on circuit breaker panel, 3-213, and check that the integral filaments of the headset jack box and station box at panel 7-213, and the headset jack box at panel 20-215, are

EFFECTIVITY: ALL

**33-17-12**

Page 406  
Aug 30/75

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

lit.

- (4) Set the PANEL switch to "OFF".
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

R

BA

Printed in England

# 33-17-12

Page 407  
Aug 30/75



**END OF THIS  
SECTION**

**NEXT**

# *Concorde*

## MAINTENANCE MANUAL

### PASSENGER COMPARTMENTS - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General (Ref. Fig.401 and 402)

This topic contains general instructions for the removal and installation of minor electrical components, e.g., toggle switches, indicator lamp/switches, push-switches, indicator lamps, circuit breakers, and transformers, that are fitted to panels common to sub-systems of 30-20-00 (Passenger Compartments). These panels are as follows:-

Forward steward's call panel (2-221)

Forward steward's control panel (1-221)

Centre steward's control panel (1-223)

Rear steward's control panel (1-241)

Access to components on each panel is gained by releasing the quick-release fasteners and lowering the front of the panel on its hinges to the extent of the tie-cord. Access to components on the top section of the rear steward's control panel is gained by unscrewing the upper panel and withdrawing it from its mounting.

The box which houses the forward steward's control panel accommodates reading light transformers (Ref. 33-24-00) and plug-in relays associated with main lighting (Ref. 33-21-00) and call systems (Ref. 33-27-00). The box behind the centre steward's control panel houses plug-in relays associated with call systems only. Two reading light transformers are mounted in the upper section of the rear steward's control panel on the rear of a mounting panel.

All toggle switches, indicator lamp/switches, push-switches and circuit breakers are mounted from the rear of the associated panel, and all indicator lamps from the front.

Electrical connections to indicator lamp/switches, push-switches, indicator lamps and transformers are made to screw-type terminals, and to toggle switches by screw-type or socket-type terminals.

#### 2. Steward's Panel Components (Ref. Fig. 403 )

##### A. Equipment and Materials

EFFECTIVITY: ALL

BA



Printed in England

# 33-20-00


Page 401  
Jun 30/75

# Concorde


## MAINTENANCE MANUAL




**A** FORWARD STEWARD'S CALL PANEL - REAR VIEW



**B** FORWARD STEWARD'S CONTROL PANEL - REAR VIEW



**C** CENTRE STEWARD'S CONTROL PANEL - REAR VIEW



**D** REAR STEWARD'S CONTROL PANEL - REAR VIEW

CMB3320004 AANO

Minor Electrical Components -  
Mounted on Steward's Panels  
Figure 401

EFFECTIVITY: ALL

BA




Printed in England

**33-20-00**

Page 402  
Jun 30/75


# Concorde

## MAINTENANCE MANUAL



**A** INSIDE OF FORWARD STEWARD'S CONTROL PANEL BOX (FRONT PANEL REMOVED)

**B** INSIDE OF CENTRE STEWARD'S CONTROL PANEL BOX (FRONT PANEL REMOVED)



**C** UPPER PANEL OF REAR STEWARD'S CONTROL PANEL

CMB3320004 BANO

Minor Electrical Components -  
Mounted behind Steward's Panels  
Figure 402

EFFECTIVITY: ALL

**33-20-00**

R

BA

Page 403  
Nov 30/75

Printed in England

# Concorde

## MAINTENANCE MANUAL

### DESCRIPTION

### PART NO.

Circuit breaker safety clips

-

#### B. Prepare

(1) Carry out the following isolation procedures, as appropriate:-

- (a) For components on the forward steward's call panel, trip the PASS CALL SUP circuit breaker, M78, on panel 15-216, map ref.A22, and fit a safety clip.
- (b) For components on the forward steward's control panel, isolate the electrical generation and external power equipment as detailed in 24-00-00, Servicing.
- (c) For components on the centre steward's control panel, trip all circuit breakers listed below and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
PASS CALL SUP	15-216	M78	A22
FASTEN S/BLTS SUP	1-213	W191	L8
NO SMOKING SUP	1-213	W192	L9
VESTIBULE & BOARDING LTS SUP	25-216	L692	C1
CABIN NIGHT LTS SUP	5-213	L455	D19
FLT DECK ROOF LTS SUP	14-215	L232	C11

- (d) For components on the rear steward's control panel, trip all circuit breakers listed below and fit safety clips.

EFFECTIVITY: ALL

BA


Printed in England

# 33-20-00

Page 404  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL



- Minor Electrical Components - Installation  
Figure 403

EFFECTIVITY: ALL

BA

Printed in England

**33-20-00**

Page 405  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
PASS CALL SUP	15-216	M78	A22
FASTEN S/BLTS SUP	1-213	W191	L8
NO SMOKING SUP	1-213	W192	L9
CABIN NIGHT LTS SUP	5-213	L455	D19
FLT DECK ROOF LTS SUP	14-215	L232	C11

(e) For components on the upper section of the rear steward's control panel, trip the LH and RH AFT PASS RDG LTS TRANS SUP circuit breakers L886 and L887 on panel 13-215, map refs.E11 and E12, and fit safety clips.

- (2) Release the quick-release fasteners and lower the appropriate steward's panel on its hinges, or remove the rear steward's upper panel from its mounting, as applicable.

### C. Remove Toggle Switch

- (1) On a switch with screw-type terminals, disconnect the electrical cables from the switch. On a switch with socket-type terminals, using a suitable tool, withdraw the pin inserts.
- (2) Using a suitable spanner, remove the nut and washer from the front of the panel and withdraw the switch and tabwasher from the rear.

NOTE: Some large switches are fitted with a tabwasher at the front and rear of the panel.

### D. Install Toggle Switch

- (1) Comply with the electrical safety precautions.

EFFECTIVITY: ALL

BA

Printed in England

# 33-20-00

Page 406  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (2) Position the tabwasher on the switch and insert the switch through the aperture from the rear of the panel, ensuring that the tab on the tabwasher engages the locating hole in the panel.
- (3) If applicable, fit another tabwasher to the switch from the front of the panel, ensuring that the tab engages the locating hole in the panel. Secure the switch with the nut and washer.
- (4) Connect the electrical cables to the switch, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.

### E. Remove Indicator Lamp/Switch or Push-switch

- (1) Unscrew the knob from the indicator lamp/switch or push-switch. Using a tubular spanner, remove the nut and washer from the front of the panel. Where applicable, remove the switch guard.
- (2) Disconnect the electrical cables from the indicator lamp/switch and withdraw the switch from the rear of the panel.

### F. Install Indicator Lamp/Switch or Push-switch

- (1) Comply with the electrical safety precautions.
- (2) Insert the indicator lamp/switch or push-switch through the aperture from the rear of the panel. From the front, refit the switch guard, where applicable, and secure the switch and guard, friction-tight, with the nut and washer.
- (3) Orientate the switch body as required, and connect the electrical cables to the switch, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (4) Tighten the securing nut. Ensure that the lamp/switch knob contains a filament, then refit the knob to the switch.

### G. Remove Indicator Lamp

- (1) Unscrew the knob from the indicator lamp.
- (2) Disconnect the electrical cable from the screw

EFFECTIVITY: ALL

BA

Printed in England

**33-20-00**

Page 407  
Feb 28/77



# *Concorde*

## MAINTENANCE MANUAL

terminal.

- (3) Using a tubular spanner, remove the nut and washer from the rear of the panel and withdraw the electrical cable tags from the body of the indicator lamp.
- (4) Withdraw the indicator lamp from the front of the panel.

### H. Install Indicator Lamp

- (1) Comply with the electrical safety precautions.
- (2) Insert the indicator lamp through the aperture from the front of the panel and fit the electrical cable tags over the lamp body from the rear.
- (3) Secure the indicator lamp with the nut and washer.
- (4) Connect the electrical cable to the indicator lamp terminal.
- (5) Ensure that the indicator lamp knob contains a filament, then refit the knob to the lamp.

### I. Remove Reading Light Circuit Breaker

- (1) Disconnect the electrical cables from the circuit breaker terminal lugs.
- (2) Using a tubular spanner, remove the nut and washer from the front of the panel and withdraw the circuit breaker from the rear of the panel.

### J. Install Reading Light Circuit Breaker

- (1) Comply with the electrical safety precautions.
- (2) Insert the circuit breaker through the aperture from the rear of the panel, ensuring that the locating dowel on the circuit breaker body engages the hole in the panel.
- (3) Secure the circuit breaker with the nut and washer.
- (3) Connect the electrical cables to the circuit breaker, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.

EFFECTIVITY: ALL

R

BA

**33-20-00**

Page 408  
Feb 28/77

# *Concorde*

## MAINTENANCE MANUAL

### K. Remove Plug-in Relay

CAUTION: SOME RELAYS ARE PHYSICALLY INTERCHANGEABLE BUT ARE NOT ELECTRICALLY INTERCHANGEABLE. DURING RELAY REPLACEMENT ENSURE THAT THE CORRECT RELAY IS FITTED TO THE APPROPRIATE SOCKET.

- (1) Remove the nuts and washers securing the relay to the relay socket.
- (2) Withdraw the relay from its socket.

### L. Install Plug-in Relay

- (1) Comply with the electrical safety precautions.
- (2) Fit the relay into its socket, ensuring that the locating pin on the relay body engages the hole in the socket.
- (3) Secure the relay with the nuts and washers.

### M. Remove Transformer

- (1) Remove the terminal cover from the transformer and disconnect the cables from the terminals.
- (2) Refit the terminal cover.
- (3) Remove the bolts and washers securing the transformer to its mounting plate and remove the transformer from its mounting.

### N. Install Transformer

- (1) Comply with the electrical safety precautions.
- (2) Fit the transformer to its mounting and secure it with the bolts and washers.
- (3) Remove the terminal cover.
- (4) Connect the electrical cable to the terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (5) Refit the terminal cover.
- (6) Check that the transformer is bonded in accordance

EFFECTIVITY: ALL

BA

Printed in England

**33-20-00**

Page 409  
Feb 28/77

# *Concorde*

## MAINTENANCE MANUAL

with 20-27-11.

### 0. Conclusion

- (1) Close and secure the appropriate steward's panel, or refit the upper section of the rear steward's panel to its mounting as applicable.
- (2) Remove the safety clips and reset the associated circuit breakers tripped before removal and make available electrical ground power as detailed in 24-41-00, as applicable.
- (3) Check the operation of the component(s) by carrying out the appropriate test procedures.
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

R

BA

Printed in England

**33-20-00**

Page 410  
Feb 28/77

# *Concorde*

## MAINTENANCE MANUAL

### MAIN LIGHTING - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig. 001 )

The main cabin lighting is provided by fluorescent tubes forming a continuous strip at ceiling level along each side of both cabins, and a fluorescent tube over each window. Filament lamps spaced at intervals along the ceiling strips provide 'dim' or 'night' lighting.

Separate FWD and AFT (BRIGHT - DIM - OFF) switches on the forward steward's control panel provide primary control of the associated cabin fluorescent and filament lighting. Secondary control of the forward and rear cabin fluorescent lighting is provided by separate FWD and AFT (FULL - ROOF - WALL) switches on the forward steward's control panel.

The filaments in both cabins are lit automatically if the aircraft 115 V a.c. fails or when the NO SMKG switch (Ref. 33-25-00 and 33-51-00) is set to ON.

#### 2. Roof Lamp Assembly (Ref. Fig. 002 )

Each roof lamp assembly comprises two fluorescent tubes, a 28 V filament lamp, and ballast units mounted on the upper section of a service panel located behind a luggage bin. A light lens above the luggage bin, secured to the service panel by screws, directs light from the tubes and filament into the passenger cabin. A lamp access panel with a reflector fitted on the inside, and forming part of the cabin decor on the outside, is hinged to the service panel and retained in the closed position by slide catches which engage the bottom edge of the light lens. The hinged access panel facilitates component replacement.

#### 3. Wall Lamp Assembly (Ref. Fig. 002 )

Each wall lamp assembly comprises four fluorescent tubes and a reflector mounted on the lower section of a service panel fitted behind a luggage bin. Each fluorescent tube is positioned over a window, and the four tubes are concealed by an air vane and fairing assembly, the interior surface of which directs light from the tubes to the wall below the luggage bins.

The air vane and fairing assembly is open-hinged to the service panel and bolted to a triform member, and is removable to facilitate tube replacement.

#### 4. Operation (Ref. Fig. 003 )

EFFECTIVITY: ALL

BA

Printed in England


**33-21-00**

Page 1  
Jun 30/75



# Concorde

## MAINTENANCE MANUAL

CMB3321000AAM0



- ROOF LIGHTING (FLUORESCENT TUBE)
- WALL LIGHTING (FLUORESCENT TUBE)
- 'DIM' LIGHTING (FILAMENT)



- Main Lighting - Location of Lamps  
Figure 001

EFFECTIVITY: ALL

BA


Printed in England

**33-21-00**

Page 2  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL



Main Lighting - Equipment  
Figure 002

EFFECTIVITY: ALL

BA

Printed in England

**33-21-00**

Page 3  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

### A. Control

The fluorescent and filament lighting for the forward and rear passenger cabins is controlled by MAIN CABIN - CONTROL and SELECT switches on the LIGHTING CONTROLS section of the forward steward's control panel.

Primary control of the forward and rear cabin roof lights, wall lights and filament lights is by two BRIGHT - DIM - OFF control switches engraved FWD and AFT respectively. Secondary control is through the contacts of associated front or rear roof and wall light control relays, and two associated FULL - ROOF - WALL selector switches engraved FWD and AFT. The four relays are mounted on the forward steward's control panel.

The filament lights in both cabins are also controlled by the contacts of a passenger/standby lights control relay which is energized when the NO SMK6 switch is at ON (Ref. 33-24-00).

### B. Functional Description (Ref. Fig. 004 )

When the electrical supplies are available and the FWD or AFT steward's CONTROL switch is set to DIM, a 28 V d.c. supply is directly connected to light the associated filaments. When BRIGHT is selected the 28 V d.c. associated filament lighting is extinguished and a 115 V a.c. supply is connected to energize the appropriate forward or aft roof and wall lighting control relays, the contacts of which change over and connect a 115 V a.c. supply to the associated FWD or AFT SELECT switch. When FULL is selected at a SELECT switch, a 115 V a.c. supply is connected to light the roof and wall fluorescent lamps in the associated cabin. When ROOF is selected at a SELECT switch, the roof fluorescent lamps in the associated cabin are lit, and when WALL is selected, only the wall fluorescent lamps are lit.

If the aircraft 115 V a.c. fails, the roof and wall lamp relays are de-energized and the contacts interrupt the supply to the associated fluorescent lamp. If a CONTROL switch is at BRIGHT, a 28 V d.c. supply is connected to light the associated forward or aft filament lamps.

R

### R 5. Electrical Power Supplies

The main cabin roof lights in both cabins are supplied from

EFFECTIVITY: ALL



BA

**33-21-00**

Page 4  
Aug 30/76

# Concorde

## MAINTENANCE MANUAL



**A** FORWARD STEWARD'S PANEL

CMB3321000CAND

Main Lighting - Controls  
Figure 003

EFFECTIVITY: ALL

BA

Printed in England


**33-21-00**

Page 5  
Jun 30/75



# Concorde

## MAINTENANCE MANUAL



- Main Lighting - Simplified Schematic  
Figure 004

EFFECTIVITY: ALL

BA

Printed in England

**33-21-00**

Page 6  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

the No.1 ground/flight 115 V a.c. busbar, through circuit breakers on panel 14-215. The wall lights in both cabins are supplied from No.2 ground/flight 115 V a.c. busbar through circuit breakers on panel 14-216. All filament lights are fed from 'B' essential 28 V d.c. busbar through a circuit breaker on panel 5-213.

EFFECTIVITY: ALL

R

BA

Printed in England

**33-21-00**

Page 7  
Aug 30/76

# Concorde

## MAINTENANCE MANUAL

RB

### MAIN LIGHTING - TROUBLE SHOOTING

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para. 3), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

The forward and aft cabin main lighting circuits are similar, therefore the procedures and charts are applicable to either. Where two identical components are involved, i.e., one in each circuit, both references to the associated components listed in Table 101 are given, e.g., 'Renew Relay (10) or (12)'.

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

RB

EFFECTIVITY: ALL

BA

C808845

**33-21-00**

Page 101  
Mar 31/95


PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

### 3. Trouble Shooting



RB

EFFECTIVITY: ALL

BA

C808846

33-21-00

Page 102  
Mar 31/95

*Concorde*  
MAINTENANCE MANUAL

OK

F.

Set FWD or AFT cabin CONTROL Switch to "DIM". Check that filaments in associated cabin are lit. IF -

NOT OK

1. No dim lighting - Chart 107.

PRINTED IN ENGLAND

RB

EFFECTIVITY: ALL

BA

C808847

**33-21-00**

Page 103  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

NO ROOF LIGHTING IN FORWARD OR AFT CABIN WHEN ASSOCIATED 'CONTROL' AND 'SELECT' SWITCHES SET TO 'BRIGHT' AND 'FULL' RESPECTIVELY.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 101

RB

EFFECTIVITY: ALL

BA

C808848

**33-21-00**

Page 104  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

NO WALL LIGHTING IN FORWARD OR AFT CABIN WHEN ASSOCIATED 'CONTROL' AND 'SELECT' SWITCHES SET TO 'BRIGHT' AND 'FULL' RESPECTIVELY.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 102

EFFECTIVITY: ALL

BA

C808849

# 33-21-00

Page 105  
Mar 31/95

RB

# Concorde

## MAINTENANCE MANUAL

NO ROOF LIGHTING IN FORWARD OR AFT CABIN WHEN ASSOCIATED 'CONTROL' AND 'SELECT' SWITCHES SET TO 'BRIGHT' AND 'ROOF' RESPECTIVELY.

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

Set FWD or AFT cabin CONTROL and SELECT switches to "BRIGHT" and "ROOF" respectively.

Set Switch (7) or (9) to "FULL". Check that roof tubes in associated cabin are lit.

YES

Renew Switch (7) or (9).

NO

See Chart 101.

Chart 103

RB

EFFECTIVITY: ALL

BA

C808850

**33-21-00**

Page 106  
Mar 31/95



# Concorde

## MAINTENANCE MANUAL

NO WALL LIGHTING IN FORWARD OR AFT CABIN WHEN ASSOCIATED 'CONTROL' AND 'SELECT' SWITCHES SET TO 'BRIGHT' AND 'WALL' RESPECTIVELY.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
-------------	----------

GROUND POWER SUPPLY	-
MULTIMETER	-

Set FWD or AFT cabin CONTROL and SELECT switches to "BRIGHT" and "WALL" respectively.

Set Switch (7) or (9) to "FULL". Check that roof tubes in associated cabin are lit.

YES  
Renew Switch (7) or (9).

NO

See Chart 102.

Chart 104

EFFECTIVITY: ALL

BA

C808851

33-21-00

Page 107  
Mar 31/95

RB

# Concorde

## MAINTENANCE MANUAL

NO DIM LIGHTING IN FORWARD OR AFT CABIN WHEN ASSOCIATED 'CONTROL' SWITCH SET TO 'BRIGHT' AND ROOF LIGHTING POWER SUPPLY FAILURE SIMULATED.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 105

EFFECTIVITY: ALL

BA

C808852

**33-21-00**

Page 108  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

NO DIM LIGHTING IN FORWARD OR AFT CABIN WHEN ASSOCIATED 'CONTROL' SWITCH SET TO 'BRIGHT' AND WALL LIGHTING POWER SUPPLY FAILURE SIMULATED.

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 106

RB

EFFECTIVITY: ALL

BA

C808856

**33-21-00**

Page 109  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

NO DIM LIGHTING IN FORWARD  
OR AFT CABIN WITH ASSOCIATED  
'CONTROL' SWITCH SET TO  
'DIM'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
-------------	----------

GROUND POWER SUPPLY	-
MULTIMETER	-

Set FWD or AFT  
cabin CONTROL  
switch to  
"DIM".

Check for 28 V  
d.c. output at  
terminal 6 of  
Switch (6) or  
(8).

YES  
Locate and  
rectify open  
circuit in  
wiring between  
Switch (6) or  
(8) and  
filaments.

NO

Check for 28 V  
input at  
terminal 5 of  
Switch (6) or  
(8).

YES  
Renew Switch  
(6) or (8).

NO

Check for 28 V  
output from  
CB (5).

YES  
Locate and  
rectify open  
circuit in  
wiring between  
CB (5) and  
Switch (6) or  
(8).

NO

Renew CB (5).

PRINTED IN ENGLAND

Chart 107

EFFECTIVITY: ALL

BA

C808857

33-21-00

Page 110  
Mar 31/95

RB

# Concorde

## MAINTENANCE MANUAL

	ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
						MAINT. TOPIC	WIRING DIAGRAM
RB	(1) Circuit breaker 115 V	-	14-215	L9130	Map ref. D10	24-50-00 R/I	
	(2) Circuit breaker 115 V	-	14-216	L452	Map ref. C9	24-50-00 R/I	
RB	(3) Circuit breaker 115 V	-	14-215	L9131	Map ref. C10	24-50-00 R/I	
	(4) Circuit breaker 115 V	-	14-216	L451	Map ref. B9	24-50-00 R/I	
	(5) Circuit breaker 28 V	-	5-213	L455	Map ref. D19	24-50-00 R/I	
	(6) FWD CONTROL switch	-	1-221	L608	Fwd. stewards' control panel	33-21-00 R/I	
	(7) FWD SELECT switch	-	1-221	L1254	Fwd. stewards' control panel	33-21-00 R/I	
	(8) AFT CONTROL switch	-	1-221	L607	Fwd. stewards' control panel	33-21-00 R/I	
	(9) AFT SELECT switch	-	1-221	L1255	Fwd. stewards' control panel	33-21-00 R/I	
	(10) Fwd. cabin - roof lamp control relay	-	1-221	L1250	Fwd. stewards' control panel	33-21-00 R/I	
	(11) Fwd. cabin - wall lamp control relay	-	1-221	L1251	Fwd. stewards' control panel	33-21-00 R/I	

RB

EFFECTIVITY: ALL

BA

C808858

**33-21-00**Page 111  
Mar 31/95

# *Concorde*

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(12) Aft cabin roof lamp control relay	-	1-221	L1252	Fwd. stewards' control panel	33-21-00 R/I	
(13) Aft cabin wall lamp control relay	-	1-221	L1253	Fwd. stewards' control panel	33-21-00 R/I	

Component Identification  
Table 101

PRINTED IN ENGLAND

EFFECTIVITY: ALL

BA

C808859

# 33-21-00

Page 112  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

RB

### MAIN LIGHTING - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

RB

#### 1. General (Ref. Fig. 401)

This topic contains instructions for the renewal of fluorescent tubes and filaments in the passenger compartments, and for the removal and installation of ballast units associated with the passenger compartment main lighting.

Fluorescent tubes, filaments and ballast units are fitted to service panels located behind luggage bins along both sides of the passenger compartments. The roof lighting fluorescent tubes, associated ballast units and filaments are mounted on the upper section of the service panels behind hinged access covers. The wall lighting fluorescent tubes are fitted to the lower section of the service panels and are concealed by air vane and fairing assemblies. Associated ballast units are mounted on the upper section of the service panels close to the roof light ballast units.

RB  
RB  
RB

A slow blow fuse is contained within a fuse holder mounted externally on the ballast unit. This allows easy replacement of the fuse without disassembling the unit.

RB  
RB  
RB  
RB

NOTE: On A/C 002 and 006 some ballast units have a normal fuse mounted internally. A fuse failure on these units will necessitate the ballast unit assembly being replaced with a modified unit.

Instructions for removal and installation of main lighting control switches and control relays are contained in 32-20-00.

#### 2. Roof Lighting Fluorescent Tube

##### A. Prepare

RB

- (1) Set the FWD or AFT lighting CONTROL switch, as appropriate, on the forward Stewards' control panel, to "OFF".

RB

- (2) Lower the appropriate luggage bin.

RB

EFFECTIVITY: ALL

BA

C807752


**33-21-00**

Page 401  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



Cabin Lighting Equipment - Installation  
Figure 401

EFFECTIVITY: ALL

BA

**33-21-00**

Page 402  
Mar 31/95

CMB 33 21 00 4 AAMD 00



# *Concorde*

## MAINTENANCE MANUAL

- (3) Operate the slide catches to disengage the access panel from the light lens and lower the panel on its hinges.

### B. Renew

- (1) Disconnect the electrical connectors from the ends of the tube and withdraw the tube from the spring clips.
- (2) Fit a replacement and connect the electrical connectors to the ends of the tube.

### C. Conclusion

- (1) Set the appropriate FWD or AFT lighting CONTROL switch to "BRIGHT" and the associated FWD or AFT SELECT switch to "ROOF". Check that the fluorescent tube is lit. Return the CONTROL switch to "OFF".

- (2) Close the access panel and ensure that the slide catches engage the bottom edge of the light lens.

- (3) Close the luggage bin.

## 3. Wall Lighting Fluorescent Tube

### A. Prepare

- (1) Set the FWD or AFT lighting CONTROL switch, as appropriate, on the forward Stewards' control panel, to "OFF".

- (2) Remove the air vane and fairing assembly to gain access to the fluorescent tube, by supporting the assembly and inserting a screwdriver in the space between the air vane and the fairing at the fixing points, and releasing the quick-release fasteners securing the assembly to the triform member.

- (3) Withdraw the air vane and fairing sufficiently to disengage the air vane hinges from their attachment brackets on the service panel and remove the assembly from the panel.

EFFECTIVITY: ALL

BA

C807753

**33-21-00**

Page 403  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

### B. Renew

- (1) Disconnect the electrical connectors from the ends of the tube and withdraw the tube from the spring clips.
- (2) Fit a replacement and connect the electrical connectors to the ends of the tube.

### C. Conclusion

RB

- (1) Set the appropriate FWD or AFT lighting CONTROL switch to "BRIGHT", and the associated FWD or AFT SELECT switch to "WALL" and check that the fluorescent tube is lit. Return the CONTROL switch to "OFF".

RB

- (2) Fit the air vane and fairing assembly to the service panel by engaging the air vane hinges with the attachment brackets, and securing the quick-release fasteners to the triform member.

## 4. Dim Lighting Filament

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clip	-

### B. Prepare

- (1) Trip the CABIN NIGHT LTS SUP circuit breaker L455, on panel 5-213, map ref. D19, and fit a safety clip.
- (2) Lower the appropriate luggage bins.
- (3) Operate the slide catches on the access panels to disengage the panels from the light lens, and lower the panels on their hinges.

### C. Renew

- (1) Ease the lampholder mounting plate from the filament lamp housing and withdraw it from the housing.
- (2) Fit a replacement filament.

RB

EFFECTIVITY: ALL

BA

C807754

# 33-21-00

Page 404  
Mar 31/95

PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

- (3) Fit the lampholder mounting plate to the filament lamp housing and press the plate firmly into position to ensure proper attachment to its mounting.

### D. Conclusion

- (1) Remove the safety clip and reset the CABIN NIGHT LTS SUP circuit breaker, L455.

RB

- (2) Set the appropriate FWD or AFT lighting CONTROL switch on the forward Stewards' control panel to "DIM" and check that the filament is lit. Return the switch to "OFF".

RB

- (3) Close the access panels and ensure that the slide catches engage the bottom edge of the light lens.

- (4) Close the luggage bins.

## 5. Ballast Unit

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clip	-

### B. Prepare

RB

- (1) Set the FWD or AFT lighting CONTROL switch, as appropriate, on the forward Stewards' control panel, to "OFF".
- (2) Trip the associated circuit breakers listed below and fit safety clips.

	SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RB	FWD CABIN CEILING LTS SUP	14-215	L9130	D10
RB	AFT CABIN CEILING LTS SUP	14-215	L9131	C10

RB

EFFECTIVITY: ALL

BA

C807755

# 33-21-00

Page 405  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
FWD CABIN WALL LTS SUP	14-216	L452	C9
AFT CABIN WALL LTS SUP	14-216	L451	B9

RB

- (3) Lower the appropriate luggage bin.
- (4) Operate the slide catches on the access panel to disengage the panel from the light lens, and lower the panel on its hinges.

RB

### C. Replace Fuse

RB

- (1) Unscrew fuse holder cap.

RB

- (2) Replace fuse.

RB

- (3) Refit fuse holder cap.

RB

RB

NOTE: Recurring fuse failures must be actioned by replacing the suspect ballast unit.

RB

RB

Replacement caps and holders can be obtained by ordering Pt. No. 3104101.

RB

### D. Remove

- (1) Disconnect the electrical cables from the ballast unit.
- (2) Support the ballast unit. Remove the screws and washers securing the ballast unit to the service panel and remove the unit from the panel.

RB

### E. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the ballast unit to its mounting on the service panel and secure it with the screws and washers.
- (3) Connect the electrical cables to the ballast unit, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.

RB

EFFECTIVITY: ALL

BA

C807756

**33-21-00**

Page 406  
Mar 31/95

# *Concorde*

## MAINTENANCE MANUAL

- (4) Check that the ballast unit is bonded in accordance with 20-27-11.

RB F. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clips and reset the associated circuit breakers tripped before removal.

RB

- (3) Set the FWD or AFT lighting CONTROL switch, as appropriate, to "BRIGHT" and the associated FWD or AFT SELECT switch to "FULL". Check that the fluorescent tubes associated with the ballast unit are lit.

RB

- (4) Close the access panel and ensure that the slide catches engage the bottom edge of the light lens.
- (5) Close the luggage bin.
- (6) Switch off and disconnect electrical ground power as detailed in 24-41-00.

RB

EFFECTIVITY: ALL

BA

C807757

**33-21-00**

Page 407  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

### MAIN LIGHTING - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic contains a Functional Test only, which details the procedure to prove that the fluorescent and filament lighting in the forward and rear cabins functions correctly. Operational and System Tests are not considered necessary in this application.

#### 2. Functional Test

##### A. Equipment and Materials

---

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

---

##### B. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### C. Test

- (1) At the forward steward's control panel, set the FWD cabin SELECT switch to "FULL" and the FWD cabin CONTROL switch to "BRIGHT". Check that the roof and wall fluorescent lighting in the forward cabin is on and that the filament lighting is off.
- (2) Set the FWD cabin SELECT switch to "WALL" and check that the roof fluorescent lighting is off and the wall fluorescent lighting remains on.
- (3) Set the FWD cabin SELECT switch to "ROOF". Check that the wall fluorescent lighting is off and that the roof fluorescent lighting is on. Set the FWD cabin CONTROL and SELECT switches to "OFF".
- (4) Repeat operations (1), (2) and (3) with respect to the aft cabin, using the AFT cabin CONTROL and SELECT switches.
- (5) Trip the appropriate roof lighting supply circuit

EFFECTIVITY: ALL

R

BA

**33-21-00**

Page 501  
Feb 29/76

# Concorde

## MAINTENANCE MANUAL

breaker, listed below, and fit a safety clip.

	SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RB	FWD CABIN CEILING LTS SUP	14-215	L9130	D10
RB	AFT CABIN CEILING LTS SUP	14-215	L9131	C10

- (6) Set the FWD cabin SELECT switch to "FULL" and the FWD cabin CONTROL switch to "BRIGHT". Check that the filament and wall fluorescent lighting in the forward cabin is on and the roof fluorescent lighting is off. Set both switches to "OFF". Check that the filament lighting is off.
- (7) Trip the appropriate wall lighting supply circuit breaker, listed below, and fit a safety clip.

	SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
	FWD CABIN WALL LTS SUP	14-216	L452	C9
	AFT CABIN WALL LTS SUP	14-216	L451	B9

- (8) Set the FWD cabin SELECT switch to "FULL" and the FWD cabin CONTROL switch to "BRIGHT". Check that the filament lighting in the forward cabin is on and that the wall and roof fluorescent lighting is off. Set both switches to "OFF".
- (9) Remove the safety clips and reset the associated cabin roof and wall fluorescent lighting supply circuit breakers.
- (10) Repeat operations (5) to (9) with respect to the aft cabin, using the AFT cabin CONTROL and SELECT switches.

EFFECTIVITY: ALL

BA

C807794

33-21-00

Page 502  
Mar 31/95

# *Concorde*

## MAINTENANCE MANUAL

- (11) Set the FWD cabin CONTROL switch to "DIM". Check that the forward cabin filament lighting is on, and that the roof and wall fluorescent light is off regardless of the position of the FWD cabin SELECT switch. Return the CONTROL switch to "OFF".
- (12) Repeat operation (11) with respect to the aft cabin, using the AFT cabin CONTROL and SELECT switches.

### D. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

C807795

**33-21-00**

Page 503  
Mar 31/95



# *Concorde*

## MAINTENANCE MANUAL

### TOILET LIGHTING - DESCRIPTION AND OPERATION

#### 1. General

Each toilet has fluorescent lights for normal illumination, and a standby filament lamp to provide lighting automatically in the event of an a.c. power failure.

In flight, with a.c. power available, one fluorescent tube in each toilet is permanently lit. The remaining fluorescent tubes are controlled by a microswitch operated by the toilet door locking rod.

With the aircraft on the ground and ground power connected, all fluorescent tubes in each toilet are lit regardless of the position of the toilet door.

#### 2. Toilet Lighting Assembly (Ref. Fig. 001 )

The toilet lighting assembly comprises two separate lamp units, one mounted vertically on the inboard console at the side of the mirror, and the other mounted horizontally below the bottom edge of the mirror.

The horizontal lamp unit consists of a mounting plate supporting one fluorescent tube behind a translucent cover which slots into the upper edge of the mounting plate and is secured by screws at the bottom.

The vertical lamp unit incorporates a mounting plate on which two fluorescent tubes are fitted end to end and recessed into the console. A translucent cover is fitted to the flanged edges of the mounting plate and retained by the console trim. The three associated fluorescent tube ballast units are housed in the console behind the vertical lamp unit, and the standby filament lamp is mounted on the upper end of the vertical lamp unit mounting plate.

#### 3. Operation

(Ref. Fig. 002 )

##### A. Control

One fluorescent tube in each toilet is supplied direct from No.2 ground/flight 115 V a.c. busbar. The remaining tubes are supplied from the same source but the supply is routed through an auxiliary contact of No.2 ground/flight change-over contactor (Ref. 24-41-00) and either through separate contacts of a ground power 'on' relay or, depending on the position of the toilet

EFFECTIVITY: ALL

BA



Printed in England

**33-22-00**

Page 1  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL



CMB3322000A4N0

Toilet Lighting  
Figure 001

EFFECTIVITY: ALL

BA

Printed in England

**33-22-00**

Page 2  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

R door, through the associated toilet door microswitch.

The standby filament lamp in each toilet is supplied from 'B' essential 28 V d.c. busbar through a contact of the a.c. power failure relay (Ref. 33-23-00) which is controlled by No.1 ground/flight 115 V a.c. busbar output.

### B. Functional Description

With the aircraft in flight and a.c. power available, one fluorescent tube in each toilet is supplied with 115 V a.c. direct and remains lit. No.2 ground/flight change-over contactor is de-energized to route the a.c. power supply to each toilet door microswitch. When the associated toilet door is closed and bolted the microswitch is operated, closing a double set of contacts, one set completing the light circuit and lighting the remaining fluorescent tubes, the other set completing the 'toilet engaged' sign circuitry (Ref. 33-25-00).

R On the ground, with ground power connected to the  
R aircraft (Ref. 24-41-00), one fluorescent tube in each  
R toilet is supplied direct and remains lit. With ON  
R selected at the GROUND SERVICE control switch  
R (Ref. 24-41-00), No.2 ground/flight change-over contactor  
R is energized to connect the supply to energize the ground  
R power 'on' relay. Power is now routed through each  
R contact of the ground power 'on' relay to the unlit  
R fluorescent tubes in the associated toilet, bypassing  
R the door microswitch. All fluorescent tubes in each  
R toilet are now lit regardless of the toilet door  
position.

R Setting the GROUND SERVICE control switch (Ref. 24-41-00)  
R de-energizes the No.2 ground/flight change-over contactor  
R and therefore the ground power 'on' relay, and the toilet  
R lights are then supplied as for the in-flight con-  
R figuration.

When a.c. power is available the a.c. power failure relay is energized, opening a set of contacts to interrupt the standby filament lamp circuit. If the a.c. power supply fails the relay is de-energized and the contacts change over to connect the 28 V d.c. supply to each standby filament lamp.

EFFECTIVITY: ALL


BA

# 33-22-00

Page 3  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL



- Toilet Lighting - Simplified Schematic  
Figure 002

EFFECTIVITY: ALL

BA

Printed in England

**33-22-00**

Page 4  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

R

### TOILET LIGHTING - TROUBLE SHOOTING

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

R

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

All toilet lighting circuits are similar, therefore the procedures and charts are applicable to each circuit. When identical components are involved, i.e., one in each circuit, the references to the associated components listed in Table 101 are given, e.g., 'Renew Microswitch (8), (9) or (10)'.

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

R

EFFECTIVITY: ALL

BA

C812216


# 33-22-00

Page 101  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting



PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812217

**33-22-00**

Page 102  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

ONLY ONE FLUORESCENT TUBE LIT IN EACH TOILET WHEN 'GROUND SERVICE' CONTROL SWITCH SET TO 'ON'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 101

R EFFECTIVITY: ALL

BA

C812244

# 33-22-00

Page 103  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

ONLY ONE FLUORESCENT TUBE LIT IN A TOILET WITH 'GROUND SERVICE' CONTROL SWITCH SET TO 'OFF' AND TOILET DOOR CLOSED AND BOLTED.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 102

**33-22-00**

EFFECTIVITY: ALL

BA

C812245

Page 104  
Mar 29/96



# Concorde

## MAINTENANCE MANUAL

FILAMENT IN A TOILET NOT LIT WHEN AC POWER FAILURE SIMULATED.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 103

R EFFECTIVITY: ALL

R BA

C812246

# 33-22-00

Page 105  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

R

ITEM NO. AND DESCRIPTION	ACCESS PANEL/ PANEL	ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 115 V	-	14-216	L985	Map ref. C10	24-50-00 R/I	
(2) Circuit breaker 115 V	-	25-216	X363	Map ref. A5	24-50-00 R/I	
(3) Circuit breaker 115 V	-	14-215	L232	Map ref. C11	24-50-00 R/I	
(4) Circuit breaker 28 V	-	5-213	L455	Map ref. D19	24-50-00 R/I	
(5) No.2 ground/flight change-over contactor	-	12-216	X365	Flight compartment RH racking	24-41-00 R/I	
(6) Ground power 'ON' relay	-	12-216	L986	Flight compartment RH racking	33-22-00 R/I	
(7) AC power failure relay	-	1-221	L698	Fwd. steward's control panel	33-23-00 R/I	
(8) Toilet door microswitch	-	222	Toilet L981	Fwd. toilet, fwd. of front cabin	33-22-00 R/I	
(9) Toilet door microswitch	-	223	Toilet L983	LH toilet, rear of front cabin	33-22-00 R/I	
(10) Toilet door microswitch	-	224	Toilet L984	RH toilet, rear of front cabin	33-22-00 R/I	

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

R

BA

C812247

# 33-22-00

Page 106  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL/ PANEL ZONE	EQUIP. POSITION IDENT.	MANUAL REF.	
			MAINT. TOPIC	WIRING DIAGRAM
(11) Toilet door microswitch	-	224	Toilet RH centre L982 toilet	33-22-00 R/I

Component Identification  
Table 101

PRINTED IN ENGLAND

R EFFECTIVITY: ALL

R  
BA

C812248

# 33-22-00

Page 107  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### RB TOILET LIGHTING - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### RB 1. General

This topic contains instructions for the renewal of fluorescent tubes and filament lamps associated with toilet lighting, and for the removal and installation of ballast units, microswitches and a 'ground power on' relay.

RB Two vertically mounted fluorescent tubes fitted end to end are recessed into an inboard console at the side of the mirror, behind a translucent cover that is hinged on the cosmetic rack. A standby filament lamp is mounted in the console above the fluorescent tubes.

RB One fluorescent tube is mounted horizontally inside the shelf, behind a translucent cover that slots into the upper section of the lamp mounting plate and is secured by screws at the bottom.

RB The associated fluorescent tube ballast units are mounted within the hinged cosmetic rack door behind the fluorescent tubes.

RB Toilet door microswitches are fixed in the fore-and-aft bulkhead of each toilet. Access to the microswitch is described on page 405.

A 'ground power on' plug-in relay associated with the toilet main lighting system is located in the flight compartment right-hand upper racking on shelf 12-216.

#### 2. Fluorescent Tubes

##### A. Equipment and Materials

<u>DESCRIPTION</u>	<u>PART NO.</u>
Circuit breaker safety clips	-

##### B. Prepare

- (1) Isolate the toilet main lighting power supply by tripping the TOILET MAIN LTS SUP circuit breaker L985, on panel 14-216, map ref.C10. Fit a circuit breaker safety clip.

RB EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C763997

# 33-22-00

Page 401  
SEP.30/90

# *Concorde*

## MAINTENANCE MANUAL

RB

### C. Renew Fluorescent Tube Below Mirror

RB

- (1) Remove the screw securing the bottom edge of the translucent cover to the lamp mounting plate and withdraw from the horizontal shelf.

RB

- (2) Disconnect the electrical connectors from the ends of the tube and withdraw the tube from the spring clips.

- (3) Fit a replacement tube and connect the electrical connectors to the ends of the tube.

- (4) Refit the translucent cover to the lamp mounting plate and secure it with the screw.

RB

RB

RB

### D. Renew Fluorescent Tubes in the Cosmetic Rack

RB

- (1) Gain access to rear of ashtray, pull down the latch pin and the translucent cover will hinge open.

RB

- (2) Disconnect the electrical connectors from the ends of the tube and withdraw the tube from the spring clips.

- (3) Fit a replacement tube and connect the electrical connectors to the ends of the tube.

- (4) Close the translucent cover by pulling down on the latch pin, the door is secured when the pin is released.

RB

RB

RB

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clip and reset the TOILET MAIN LTS SUP circuit breaker L985.
- (3) Check that the GROUND SERVICE control switch on the forward steward's control panel is at ON.
- (4) Check that all fluorescent tubes in the toilet are lit.
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

RB

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C763998

# 33-22-00

Page 402  
SEP.30/90

# *Concorde*

## MAINTENANCE MANUAL

### 3. Standby Filament

#### A. Equipment and Materials

##### DESCRIPTION

##### PART NO.

Circuit breaker safety clips

-

#### B. Prepare

- (1) Isolate the standby filament lamp supply by tripping the CABIN NIGHT LTS SUP circuit breaker L455, on panel 5-213, map ref.D19. Fit a circuit breaker safety clip.

#### C. Renew

- (1) Press in the sides of the translucent cover to release it from the console trim and withdraw the cover from the console.
- (2) Remove the filament and fit a replacement.
- (3) Refit the translucent cover to the console by easing the edges of the cover behind the console trim.

#### D. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clip and reset the CABIN NIGHT LTS SUP circuit breaker, L455.
- (3) Simulate an a.c. power failure by tripping the FLT DECK ROOF LTS SUP circuit breaker L232, on panel 14-215 map ref.C11.
- (4) Check that the standby filament is lit.
- (5) Reset circuit breaker L232.
- (6) Switch off and connect electrical ground power as detailed in 24-41-00.

### 4. Ballast Units

#### A. Equipment and Materials

##### DESCRIPTION

##### PART NO.

Circuit breaker safety clips

-

RB

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C763999

# 33-22-00

Page 403  
SEP.30/90

# *Concorde*

## MAINTENANCE MANUAL

### B. Prepare

- RB (1) Isolate the toilet main lighting power supply by tripping the TOILET MAIN LTS SUP circuit breaker L985, on panel 14-216, map ref.C10. Fit a circuit breaker safety clip.
- RB (2) Gain access to the ballast units, at the rear of the inboard console door, by pulling the console door to disengage the magnetic catches. Swing open the console door on its hinges.

### C. Remove

- (1) Disconnect the electrical cables from the ballast unit.
- (2) Remove the nuts and screws securing the ballast unit to the mounting plate and withdraw the ballast unit from the console door.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the ballast unit to its mounting at the rear of the inboard console door and secure it with the screws and nuts.
- (3) Connect the electrical cables to the ballast unit, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (4) Check that the ballast unit is bonded in accordance with 20-27-11.

### E. Conclusion

- RB (1) Close the inboard console door, ensuring that the magnetic catches engage.
- RB (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Remove the safety clip and reset the TOILET MAIN LTS SUP circuit breaker, L985.
- (4) Check that the GROUND SERVICE control switch on the forward steward's panel is at ON.
- (5) Check that all fluorescent tubes in the toilet are lit.

RB EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C764000

# 33-22-00

Page 404  
SEP.30/90

# *Concorde*

## MAINTENANCE MANUAL

- (6) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### 5. Toilet Door Microswitch (Ref. Fig. 401)

#### A. Equipment and Materials

##### DESCRIPTION

##### PART NO.

Circuit breaker safety clips

-

#### B. Prepare

- (1) Isolate the toilet main lighting power supply by tripping the TOILET MAIN LTS SUP circuit breaker L985, on panel 14-216, map ref.C10. Fit a circuit breaker safety clip.

#### RB C. Remove

- RB (1) Remove screws (2) from the vertical face of the  
RB fore-and-aft bulkhead (10).

- RB (2) With care ease away the brush seal capping strip (1).

- RB (3) Remove screws (3) from the switch box (4).

- RB NOTE: There will be sufficient cable loom to ease switch  
RB box out, giving access to change microswitches.

- RB (4) Carefully slide switch box (4) out from aperture in  
RB fore-and-aft bulkhead.

- RB (5) Support the switch box and remove the screws (5) from  
RB coverplate (7) giving access to microswitches.

- RB NOTE: Mark spade connectors for location purposes.

- RB (6) Ease spade connectors off microswitch pins.

- RB (7) Remove screws (6) and ease out microswitch from switch  
RB box (4).

#### D. Install

- (1) Comply with the electrical safety precautions.

- RB (2) Position microswitch (8) in switch box (4) and secure  
RB with screws (6).

- RB (3) Push on wire spades to appropriate microswitch  
RB connections.

RB EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C765001


# 33-22-00

Page 405  
SEP.30/90



# Concorde

## MAINTENANCE MANUAL



Toilet Door Microswitch - Installation  
Figure 401

R

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C765002

**33-22-00**

Page 406  
SEP.30/90

CM 33 22 00 001A 5007

# *Concorde*

## MAINTENANCE MANUAL

- RB (4) Position switch box cover (7) and install screws  
RB (3).
- RB (5) Slide switch box (4) and ease cable loom (9) into aperture  
RB and secure with screws (3).
- RB (6) Position brush seal capping against vertical edge of  
RB fore-and-aft bulkhead, secure with screws.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clip and reset the TOILET MAIN LTS SUP circuit breaker, L985.
- (3) Set the GROUND SERVICE control switch on the forward steward's control panel to "OFF", and check that:
  - (a) with the toilet door open, one fluorescent tube is lit and all other tubes are out,
  - (b) with the toilet door closed and bolted, all fluorescent tubes are lit,
  - (c) with all the central toilet doors closed and bolted, the 'toilets occupied' signs at the rear end of the forward cabin and the forward end of the rear cabin are lit or, with the forward toilet door closed and bolted the 'toilets occupied' signs at the forward end of the forward cabin are lit.
- (4) Set the GROUND SERVICE control switch on the forward steward's control panel to "ON".
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

RB  
RB

RB

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C765003

# 33-22-00

Page 407  
SEP.30/90

# Concorde

## MAINTENANCE MANUAL

R

### TOILET LIGHTING - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

R

#### 1. General

This topic details the procedure for an Operational Test only. Functional and System Tests are not considered necessary in this application.

#### 2. Operational Test

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

##### B. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Check that the GROUND SERVICE control switch on the forward steward's panel is at ON.

##### C. Test

- (1) Check that all fluorescent tubes in each toilet are lit, regardless of the toilet door position.
- (2) Set the GROUND SERVICE control switch to OFF. In each toilet check that:
  - (a) with the toilet door open, only one fluorescent tube is lit, and all other fluorescent tubes are out, and
  - (b) with the toilet door closed and bolted, all fluorescent tubes are lit.

R

- (3) Trip the a.c. power failure relay supply circuit breaker L451, on panel 14-216, map ref. B9, and fit a safety clip.

R

EFFECTIVITY: ALL

BA

C812213

# 33-22-00

Page 501  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

R

- (4) In each toilet, check that the standby filament lamp is lit.
- (5) Remove the safety clip and reset the a.c. power failure relay supply circuit breaker L451, on panel 14-216.
- (6) In each toilet, check that the standby filament lamp is extinguished.

### D. Conclusion

- (1) Set the GROUND SERVICE control switch on the forward steward's panel to ON.
- (2) Switch off and disconnect electrical ground power as detailed in 24-41-00.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812214

**33-22-00**

Page 502  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### BOARDING, VESTIBULE AND SUPPLEMENTARY GALLEYS LIGHTING - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig. 001)

Boarding lamps, to illuminate the door thresholds, are fitted near floor level on the bulkheads on each side of the forward and centre passenger doors. Vestibule lighting is provided by two lanterns in the forward vestibule and one lantern each in the centre and rear vestibule ceilings.

The boarding lights are controlled by an associated switch on a stewards' control panel in the forward and centre vestibules. Control of vestibule lights is by a switch on the associated stewards' control panel at which filament (DIM) or fluorescent (BRIGHT) lighting can be selected. In the event of an a.c. power failure, with BRIGHT lighting selected at the control switch, the filament dim lighting is automatically switched on to provide vestibule illumination.

If the 'no smoking' signs are activated (Ref. 33-21-00 and 33-25-00) the filament lamps in each vestibule lantern are lit regardless of the position of the vestibule light control switch.

Electrical supplies to provide lighting for the supplementary galleys located close to the forward and rear vestibules, are available at electrical connectors mounted on bulkheads close to the associated galley.

#### 2. Boarding Lamps

Each boarding lamp comprises a filament lamp contained in a glass-fibre assembly with a grille on one side for ventilation and a small aperture at the base to direct the light onto the threshold of the passenger doors. The assemblies are mounted low down on the bulkheads each side of the door in such a manner that a direct light will not be visible to passengers ascending the boarding stairs.

#### 3. Vestibule Lanterns

Each vestibule lantern comprises a reflector box containing two fluorescent tubes, the associated ballast units and two filament lamps. The reflector box aperture is covered by a translucent shade which fits flush with the ceiling furnishings. The shade is secured by two pan head screws with plastic packing washers fitted above the lens to prevent distortion when the screws are tightened.

RB  
RB  
RB  
RB  
RB

EFFECTIVITY: ALL

BA



C807792

**33-23-00**

Page 1  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL



Boarding and Vestibule Lights  
Figure 001

EFFECTIVITY: ALL

BA

**33-23-00**

Page 2  
Mar 31/95

PRINTED IN ENGLAND

CMB 33 23 00 D AAMD 00

RB

# *Concorde*

## MAINTENANCE MANUAL

### 4. Supplementary Galley Lighting Supplies

A supply of 115 V from No.1 ground/flight 115 V a.c. busbar is available at electrical connectors to light a fluorescent tube in each supplementary galley. One connector is fitted to an amenity stowage bulkhead at the left side of the forward vestibule and there is one at each side of the rear vestibule, close to the associated galley. The source of supply is common with that for vestibule lighting.

When not in use, the connectors are fitted with blanking caps.

### 5. Operation

#### A. Control (Ref. Fig. 002 )

The boarding lamps are supplied from the ground power services 28 V a.c. busbar and are controlled by a two-position (ON - OFF) toggle switch engraved BOARDING, one on the steward's control panel in each of the forward and centre vestibules.

The fluorescent tubes and the filament lamps in the vestibule lanterns are supplied from the No.1 ground/flight 115 V a.c. busbar and the 'B' essential 28 V d.c. busbar respectively. The lantern lights are controlled by a double-pole three-position (OFF - DIM - BRIGHT) toggle switch, engraved VESTIBULE, on each steward's control panel. One pole of the switch controls the a.c. supply to the fluorescent tubes, and the other the d.c. supply to the filaments.

Two further d.c. power supplies are available from the 'B' essential 28 V d.c. busbar to control filament dim lighting. One supply is connected to the filament lamps in each vestibule lantern through a normally open contact of a passenger warning/standby light relay (Ref. 33-21-00) and bypasses the vestibule light control switches; the other supply is connected to the 'bright' terminal of each vestibule light control switch through a contact of an a.c. power failure relay which is open when the relay is energized.

The a.c. power failure relay is supplied from No.1 ground/flight 115 V a.c. busbar, and is mounted in the box of the forward vestibule steward's control panel.

EFFECTIVITY: ALL

**33-23-00**


R

BA

Page 3  
Feb 29/76

# Concorde

## MAINTENANCE MANUAL



- Boarding and Vestibule Lights Control  
Figure 002

### B. Functional Description (Ref. Fig. 003 )

With electrical supplies available and DIM selected at a vestibule lights control switch, the 28 V d.c. supply is connected through one pole of the switch to light the filament lamps in the associated vestibule lantern(s).

When BRIGHT is selected at a vestibule lights control switch, the 28 V d.c. supply is interrupted and a supply from the ground/flight 115 V a.c. busbar is connected through the second pole of the switch to light the fluorescent tubes in the associated vestibule lantern(s).

A failure of the 115 V a.c. power supply will de-energize the a.c. power failure relay to complete the circuit from the essential 28 V d.c. busbar, through the vestibule light control switch, to light the vestibule lantern filament lamps.

EFFECTIVITY: ALL

**33-23-00**

R

BA

Page 4  
Feb 29/76

Printed in England



# *Concorde*

## MAINTENANCE MANUAL

Initiation of a 'no smoking' warning (Ref. 33-25-00 and 33-21-00) energizes the passenger warning/standby lights relay and completes the circuit from the essential 28 V d.c. busbar, direct to the vestibule lantern filament circuits to light the filament lamps.

Power is available at the boarding lights control switches only when ground power is connected to the aircraft.


EFFECTIVITY: ALL

BA

Printed in England

**33-23-00**

Page 5  
Nov 30/75



- Boarding and Vestibule Lights -  
Simplified Schematic  
Figure 003

EFFECTIVITY: ALL

BA

Printed in England

**33-23-00**

Page 6  
Nov 30/75

# *Concorde*

## MAINTENANCE MANUAL

### BOARDING, VESTIBULE AND SUPPLEMENTARY GALLEYS LIGHTING - TROUBLE SHOOTING

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED  
IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

The forward, centre and rear vestibule lighting circuits are similar, therefore the procedures and charts are applicable to each. The boarding lights circuits in the forward and centre vestibules are similar, therefore the procedures and charts are applicable to either. Where identical components are involved, i.e., one in each circuit, references to the associated components listed in Table 101 are given thus, 'Renew Switch (6), (7) or (8)'.

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England


**33-23-00**

Page 101  
Nov 30/75

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting



CMB3323001FAMO

EFFECTIVITY: ALL

BA

Printed in England

**33-23-00**

Page 102  
Nov 30/75


# Concorde

## MAINTENANCE MANUAL

BOARDING LAMPS NOT LIT WHEN SWITCHED ON.

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



CMB3323001GAM0

Chart 101

EFFECTIVITY: ALL

BA

Printed in England

**33-23-00**

Page 103  
Nov 30/75

# Concorde


## MAINTENANCE MANUAL

BOTH FILAMENTS IN VESTIBULE  
LANTERN NOT LIT WHEN VESTIBULE  
LIGHTS SWITCH AT 'DIM'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



CMB3323001HAM0

Chart 102

EFFECTIVITY: ALL

BA

Printed in England

**33-23-00**

Page 104  
Nov 30/75

# Concorde


## MAINTENANCE MANUAL

BOTH FLUORESCENT TUBES IN VESTIBULE LANTERN NOT LIT WHEN VESTIBULE LIGHT SWITCH AT 'BRIGHT'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



CMB3323001JAM0

Chart 103

EFFECTIVITY: ALL

BA

Printed in England

**33-23-00**

Page 105  
Nov 30/75

# Concorde


## MAINTENANCE MANUAL

BOTH FILAMENTS IN VESTIBULE LANTERN NOT LIT DURING AN AC POWER FAILURE, WITH VESTIBULE LIGHTS SWITCH AT 'BRIGHT'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



CMB3323001KAM0

Chart 104

EFFECTIVITY: ALL

BA

Printed in England

**33-23-00**

Page 106  
Nov 30/75



# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 28 V	-	25-216	L692	Map ref.C1	24-50-00 R/I	
(2) Circuit breaker 28 V	-	5-213	L455	Map ref.D19	24-50-00 R/I	
(3) Circuit breaker 115 V	-	14-215	L232	Map ref.C11	24-50-00 R/I	
(4) Forward boarding lights switch	-	1-221	L696	Forward vestibule	33-23-00 R/I	
(5) Central boarding lights switch	-	1-223	L697	Centre vestibule	33-23-00 R/I	
(6) Forward vestibule lights switch	-	1-221	L693	Forward vestibule	33-23-00 R/I	
(7) Central vestibule lights switch	-	1-223	L694	Centre vestibule	33-23-00 R/I	
(8) Rear vestibule lights switch	-	1-241	L695	Rear vestibule	33-23-00 R/I	
(9) AC failure relay	-	1-221	L698	Forward vestibule	33-23-00 R/I	

Component Identification  
Table 101

EFFECTIVITY: ALL

BA

# 33-23-00

Page 107  
Nov 30/79

Printed in England

# Concorde

## MAINTENANCE MANUAL

### BOARDING, VESTIBULE AND SUPPLEMENTARY GALLEYS LIGHTING- REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN  
24-00-00.

(Ref. Fig. 401)

#### 1. General

This topic contains instructions for the renewal of fluorescent tubes and filaments associated with boarding and vestibule lighting, and for the removal and installation of vestibule lanterns and associated ballast units.

Each vestibule lantern contains two fluorescent tubes and two standby filaments. The two associated ballast units are mounted on top of the lantern reflector which necessitates the removal of the complete lantern assembly from the vestibule roof to gain access to a ballast unit.

A boarding lamp, comprising a filament protected by a cover, is mounted low down on the bulkhead on each side of the forward and centre vestibule passenger doors.

Instructions for the removal and installation of boarding and vestibule lighting control switches and an associated 'a.c. failure' relay are contained in 33-20-00.

#### 2. Fluorescent Tube and Standby Filament Renewal

##### A. Prepare

- (1) For fluorescent tube renewal, set the VESTIBULE light switch on the forward, centre or rear stewards' control panel, as appropriate, to "OFF".
- (2) For standby filament renewal, set the VESTIBULE light switch on the forward, centre and rear stewards' control panel, to "OFF".
- (3) Unscrew the two pan head screws and remove the lantern shade together with the plastic packing washers fitted above the lens.

RB  
RB  
RB  
RB

EFFECTIVITY: ALL

BA

C807796


**33-23-00**

Page 401  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



Boarding and Vestibule Lighting - Installation  
Figure 401

EFFECTIVITY: ALL

BA

**33-23-00**

Page 402  
Mar 31/95

CMB 33 23 00 4 AAMO 00

RB

# Concorde

## MAINTENANCE MANUAL

### B. Renew Fluorescent Tube

- (1) Rotate the fluorescent tube and pull it downward to disengage the tube from the end connectors.
- (2) Fit a replacement.

### C. Renew Standby Filament

- (1) Remove the standby filament and fit a replacement.

### D. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Set the appropriate VESTIBULE light switch to "BRIGHT" and check that the fluorescent tube is lit, or set the VESTIBULE light switch to "DIM" and check that the filament is lit, as applicable. Return the switch to "OFF".
- (3) Switch off and disconnect electrical ground power as detailed in 24-41-00.
- (4) Fit the two pan head retaining screws and packing washers to the lantern shade. Position the lantern shade on the light reflector and tighten the two retaining screws ensuring that the packing washers are not dislodged.

RB  
RB  
RB  
RB  
RB

RB

## 3. Boarding Lamp Filament Renewal

### A. Prepare

- (1) Set the BOARDING light switch on the forward or centre stewards' control panel, as appropriate, to "OFF".
- (2) Remove the screw, at the bottom of the boarding lamp, securing the lamp cover to the baseplate. Pull downward on the cover, to release it from the locating spigot on the adjustable console fairing, and remove the cover from the baseplate.

### B. Renew Boarding Lamp Filament

- (1) Remove the boarding lamp filament and fit a replacement.

EFFECTIVITY: ALL

BA

C807797

**33-23-00**

Page 403  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

### C. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Set the appropriate BOARDING light switch to "ON" and check that the boarding lamp filament is lit. Return the switch to "OFF".
- (3) Switch off and disconnect electrical ground power as detailed in 24-41-00.
- (4) Position the boarding lamp cover on the baseplate and push upward to engage the locating spigot. Secure the cover to the baseplate with the screw, at the bottom of the cover.

### 4. Vestibule Lantern and Ballast Unit

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Set the VESTIBULE light switch on the forward, centre or rear stewards' control panel, as appropriate, to "OFF".
- (2) Trip the FLT DECK ROOF LTS SUP circuit breaker, L232, on panel 14-215, map ref. C11, and the CABIN NIGHT LTS SUP circuit breaker, L455, on panel 5-213, map ref. D19, and fit safety clips.

#### C. Remove Vestibule Lantern

- (1) Unscrew the two pan head screws and remove the lantern shade together with the plastic packing washers fitted above the lens.
- (2) Remove the two fluorescent tubes and filaments.

EFFECTIVITY: ALL

BA

C807798

**33-23-00**

Page 404  
Mar 31/95

# *Concorde*

## MAINTENANCE MANUAL

- (3) Support the lantern and release the four screws securing the reflector to the vestibule roof. Lower the lantern to the extent of the electrical cables, ensuring that the locating springs on the reflector are clear of the associated ceiling panels. Remove the securing screws, washers and spacers.
- (4) Disconnect the electrical connector from the lantern.
- (5) Disconnect the bonding lead from the ballast unit securing screw, and remove the lantern, complete with ballast units, from the vestibule roof.

RB

### D. Remove Ballast Unit from Vestibule Lantern

- (1) Disconnect the electrical cables from the ballast unit.
- (2) Remove the screws and nuts securing the ballast unit to the top of the lantern reflector and remove the ballast unit from the reflector.

### E. Install Ballast Unit in Vestibule Lantern

- (1) Fit the ballast unit to its mounting on top of the vestibule lantern reflector and secure it with the screws and nuts.
- (2) Connect the electrical cables to the ballast unit, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.

### F. Install Vestibule Lantern

- (1) Comply with the electrical safety precautions.
- (2) Support the vestibule lantern and connect the bonding lead to a ballast unit fixing screw. Tighten the screw.
- (3) Connect the electrical connector to the vestibule lantern, ensuring that the mating surfaces are clean and undamaged.
- (4) Check that the ballast unit and lantern are bonded in accordance with 20-27-11.

EFFECTIVITY: ALL

BA

C807799

**33-23-00**

Page 405  
Mar 31/95

# *Concorde*

## MAINTENANCE MANUAL

- (5) Position the lantern (Ref. Fig. 401) on its mounting in the vestibule roof, ensuring that the associated ceiling panel engages in the locating springs at each end of the light reflector. Secure the lantern with the screws, washers and spacers.

- (6) Refit the fluorescent tubes and filaments to the lantern reflector.

### G. Conclusion

- (1) Remove the safety clips and reset the circuit breakers tripped before removal.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Set the appropriate VESTIBULE light switch to "BRIGHT" and check that both fluorescent tubes are lit.
- (4) Set the VESTIBULE light switch to "DIM" and check that the fluorescent tubes are out and that both standby filaments are lit. Return the switch to "OFF".
- (5) Fit the two pan head retaining screws and packing washers to the lantern shade. Position the lantern shade on the light reflector and tighten the two retaining screws ensuring that the packing washers are not dislodged.
- (6) Switch off and disconnect electrical ground power as detailed in 24-41-00.0

PRINTED IN ENGLAND

EFFECTIVITY: ALL

BA

C807800

**33-23-00**

Page 406  
Mar 31/95

# *Concorde*

## MAINTENANCE MANUAL

### BOARDING VESTIBULE AND SUPPLEMENTARY GALLEYS LIGHTING - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Boarding and vestibule lights tests are contained under two headings: Operational Test, and Functional Test. A System Test is not considered necessary. The Operational Test details the procedure for checking the operation of the boarding and vestibule lights. The Functional Test checks the vestibule lights in more detail to prove that they are electrically and functionally correct.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test Boarding Lights

- (1) Set the BOARDING lights control switch on the forward vestibule steward's control panel to "ON", and check that the boarding lamp on each side of the forward passenger door is lit and illuminates the door threshold.
- (2) Set the BOARDING lights control switch to "OFF".
- (3) Set the BOARDING lights control switch on the centre vestibule steward's control panel to "ON" and check that the boarding lamp on each side of the central passenger door is lit and illuminates the door threshold.
- (4) Set the BOARDING lights control switch to "OFF".

##### C. Test Vestibule Lights

- (1) Set the VESTIBULE lights control switch on the forward steward's control panel to "DIM", and check that the two filament lamps in each of the two forward vestibule lanterns are lit.
- (2) Set the VESTIBULE lights control switch to "BRIGHT", and check that the filament lights are extinguished and the two fluorescent tubes in each of the forward

EFFECTIVITY: ALL

**33-23-00**

Page 501  
Nov 30/79

Printed in England



# Concorde

## MAINTENANCE MANUAL

vestibule lanterns are lit.

- (3) Set the VESTIBULE lights control switch to "OFF" and check that the filament and fluorescent lights in each lantern are extinguished.
- (4) Repeat operations (1) to (3) from the centre and rear vestibule steward's panels, in turn, to test the associated centre and rear vestibule lanterns.

### D. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

## 3. Functional Test

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

### B. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

### C. Test Vestibule Lights

- (1) Check that the VESTIBULE lights control switch on the forward vestibule steward's control panel is at OFF.
- (2) Electrically isolate the supplies to the a.c. power failure relay by tripping the FLT DECK ROOF LTS SUP circuit breaker L232, on panel 14-215, map ref.C11, and fit a safety clip.
- (3) Set the VESTIBULE lights control switch on the forward steward's panel to "DIM". Check that the two filament lamps in each of the two forward vestibule lanterns are lit.
- (4) Set the VESTIBULE lights control switch to "BRIGHT". Check that the filament lamps in the vestibule lanterns remain lit, and that the fluorescent tubes remain unlit.

EFFECTIVITY: ALL

BA

**33-23-00**

Page 502  
Nov 30/75

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

- (5) Remove the safety clip and reset the FLT DECK ROOF LTS SUP circuit breaker. Check that the filament lamps in each forward vestibule lantern are extinguished and that the fluorescent tubes are lit.
- (6) Set the VESTIBULE lighting control switch to "OFF".
- (7) Repeat operations (1) to (7) from the centre and rear steward's panels, in turn, to test the associated centre and rear vestibule lanterns.

### D. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-23-00**

Page 503  
Nov 30/75

# *Concorde*

## MAINTENANCE MANUAL

### WARDROBE LIGHTS - MAINTENANCE PRACTICES

#### 1. General

- A. Each wardrobe is provided with an internal illumination flood light. The light is mounted in the roof panel of the wardrobe.
- B. The light has two 28V 8W lamps.
- C. Control of the lamps is provided automatically by a microswitch operated by the righthand wardrobe door.
- D. Power supplies for the lamps are derived from the adjacent reading light supply.

#### 2. Relamping

- A. Isolate the power supply to the relevant wardrobe, see Table 201.

WARNING: OBSERVE ELECTRICAL PRECAUTIONS DETAILED IN 24-00-00.

<u>WARDROBE</u>	<u>CIRCUIT BREAKER</u>	<u>LOCATION</u>
LH FWD	L890 Reading lt. fwd left	1-221
RH FWD	L889 Reading lt. fwd right	1-221
LH MID	L897 Reading lt. aft left	1-241
RH MID	L894 Reading lt. aft right	1-241

TABLE 201

- B. Access to the filament is gained by removing the screws in either end of the lamp bezel. The lamp can then be replaced in the normal fashion.
- C. Refit bezel.
- D. Reset circuit breakers and check operation of lamp.

#### 3. Lamp Unit Removal/Installation

- A. Isolate electrical supplies as appropriate. See Table 201.
- B. Remove bezel.
- C. Remove a further 4 screws to release the reflector with the lamp holder attached.
- D. Disconnect the wire to the lamp holders.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737240

**33-23-10**

Page 201  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

E. Pass the cables through the grommet.

F. Remove the lamp housing.

G. Replacement is the reverse of the above procedure.

#### 4. Door Operated Microswitch

##### A. General

- (1) A door operated microswitch controls the interior wardrobe flood light.
- (2) The microswitch is operated by a block attached to the upper righthand corner of the righthand double door.
- (3) The switch is mounted under a cover for protection and cosmetic purposes.

##### B. Removal/Replacement

- (1) Isolate electrical supplies see Table 201.
- (2) Remove cover over microswitch.
- (3) Disconnect wiring to switch - ensure wires are identified for replacement.
- (4) Remove the microswitch.
- (5) Replacement is the reverse of removal.

##### C. Adjustment

- (1) No adjustment is specified for this microswitch.

# *Concorde*

## MAINTENANCE MANUAL

### PASSENGER READING LIGHTS - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig. 001 )

Passengers are provided with individual reading lamps mounted on passenger service units (PSUs) fitted above each row of passenger seats on both sides of the aircraft. Each light is controlled by a push-switch mounted close to the reading lamp. Four transformers, two at the forward steward's position and two at the rear steward's position, provide outputs to supply all the reading lamps in the forward and rear cabins respectively.

#### 2. Reading Lamps

Two reading lamps are fitted in each PSU, each lamp comprising a spherical filament housing which moves in a mounting constructed on the ball-and-socket principle. Each lamp is fitted with a hinged translucent lens which is retained in the closed position by a small retaining catch.

The ball-and-socket mounting allows the filament housing to move 45 deg laterally and 18 deg fore and aft. The hinged lens facilitates filament replacement.

#### 3. Transformers

R Four 600 VA step-down transformers are associated with the reading lamps.

Two transformers mounted in the forward steward's panel are connected to No.3 main 115 V a.c. busbar, and supply 28 V d.c. for the reading lamps on the left and right sides of the forward cabin.

Two transformers mounted above the rear steward's panel are connected to No.2 main 115 V a.c. busbar, and supply 28 V d.c. for the reading lamps on the left and right sides of the rear cabin.

#### 4. Operation

##### A. Control

The supply for the reading lamps is controlled by a push-to-make push-to-break switch mounted close to each reading lamp.

##### B. Functional Description

EFFECTIVITY: ALL

BA


Printed in England

**33-24-00**

Page 1  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL



Passenger Reading Lights -  
Control and Equipment  
Figure 001

EFFECTIVITY: ALL

BA

Printed in England

**33-24-00**

Page 2  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

When electrical supplies are available and a reading lamp switch is pressed and released, a supply is connected to the associated filament lamp. The lamp supply is terminated when the switch is pressed and released once again.

R

### R 5. Electrical Power Supplies

The passenger reading lamps in the forward passenger cabin are supplied (primarily) from the No.3 main 115 V a.c. busbar, through circuit breakers on panel 13-216 and on the forward steward's control panel. The reading lamps in the rear cabin are supplied (primarily) from No.2 main 115 V a.c. busbar, through circuit breakers on panel 13-215 and on the rear steward's control panel.

EFFECTIVITY: ALL

BA

Printed in England

**33-24-00**

Page 3  
Aug 30/76

# *Concorde*

## MAINTENANCE MANUAL

### PASSENGER READING LIGHTS - TROUBLE SHOOTING

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

The lighting circuits for the reading lamps on the left and right sides of the forward and rear passenger cabins are similar, therefore the procedures and charts are applicable to each. Where identical components are involved, i.e., one in each circuit, the references to the associated components listed in Table 101 are given thus, 'Renew Transformer (13) or (14), fwd. cabin, or Transformer (15) or (16), rear cabin'.

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

**33-24-00**

Page 101  
Jun 30/75



# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting

- A. Prepare to trouble shoot (Ref..para.2.).  
Push reading light control switches on each PSU and check that associated reading lamps are lit. IF -

OK

NOT OK

1. One reading lamp fails to light - change filament. If fault not cleared, check for 28 V at associated switch terminal. If power available and lamp still fails to light - renew PSU (17).
2. A group of reading lamps in forward or rear cabin fails to light - Chart 101.
3. All reading lamps on one side of cabin fail to light - Chart 102.

- B. Check that each lamp rotates smoothly in its ball and socket mounting, for approximately 45 deg laterally, and 18 deg fore and aft. IF -

NOT OK

Renew PSU (17).

CMB3324001AAM0/00B

EFFECTIVITY: ALL

BA

Printed in England

# 33-24-00

Page 102  
Jun 30/75


# Concorde

## MAINTENANCE MANUAL

ALL INDIVIDUAL READING LAMPS OF A GROUP FAIL TO LIGHT WHEN ASSOCIATED SWITCHES ARE PRESSED.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-



CMB3324001BAM0

Chart 101

EFFECTIVITY: ALL

BA

Printed in England

**33-24-00**

Page 103  
Jun 30/75

# Concorde


## MAINTENANCE MANUAL

ALL INDIVIDUAL READING LAMPS ON ONE SIDE OF CABIN (FWD. OR REAR) FAIL TO LIGHT WHEN ASSOCIATED SWITCHES ARE PRESSED.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



CMB3324001C/M0

Chart 102

EFFECTIVITY: ALL

BA

Printed in England

# 33-24-00

Page 104  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 115 V	-	13-216	L884	Map ref.C8	24-50-00 R/I	
(2) Circuit breaker 115 V	-	13-216	L885	Map ref.C9	24-50-00 R/I	
(3) Circuit breaker 115 V	-	13-215	L886	Map ref.E11	24-50-00 R/I	
(4) Circuit breaker 115 V	-	13-215	L887	Map ref.E12	24-50-00 R/I	
(5) Circuit breaker 28 V	-	1-221	L888	Fwd. steward's panel	24-50-00 R/I	
(6) Circuit breaker 28 V	-	1-221	L889	Fwd. steward's panel	24-50-00 R/I	
(7) Circuit breaker 28 V	-	1-221	L890	Fwd. steward's panel	24-50-00 R/I	
(8) Circuit breaker 28 V	-	1-221	L891	Fwd. steward's panel	24-50-00 R/I	
(9) Circuit breaker 28 V	-	1-241	L894	Rear steward's panel	24-50-00 R/I	
(10) Circuit breaker 28 V	-	1-241	L895	Rear steward's panel	24-50-00 R/I	
(11) Circuit breaker 28 V	-	1-241	L896	Rear steward's panel	24-50-00 R/I	
(12) Circuit breaker 28 V	-	1-241	L897	Rear steward's panel	24-50-00 R/I	
(13) 600 VA	-	1-221	L892	Fwd.	33-24-00	

EFFECTIVITY: ALL

# 33-24-00

R

BA

Page 105  
Nov 30/79

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
transformer				steward's panel	R/I	
(14) 600 VA transformer	-	1-221	L893	Fwd. steward's panel	33-24-00 R/I	
(15) 600 VA transformer	-	241	L898	Above rear steward's panel	33-24-00 R/I	
(16) 600 VA transformer	-	241	L899	Above rear steward's panel	33-24-00 R/I	
(17) Passenger service units (PSUs)	-	Vari- ous		Above each Passenger seat in fwd. and rear cabins	25- R/I	

Component Identification  
Table 101

EFFECTIVITY: ALL

R

BA

# 33-24-00

Page 106  
Nov 30/79

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

### PASSENGER READING LIGHTS - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic details the operations necessary for the replacement of passenger reading lamp filaments and for the removal and installation of the reading lamp 600 VA transformers.

Two transformers supplying the forward cabin reading lamps are mounted in the box behind the forward steward's control panel, and two transformers, supplying the rear cabin reading lamps, are mounted above the rear steward's control panel.

The outputs of the transformers at the forward steward's station are connected to circuit breakers engraved READING - FWD CABIN LEFT and READING - FWD CABIN RIGHT on the forward steward's control panel. The outputs of the transformers at the rear steward's station are connected to circuit breakers engraved READING LIGHT CIRCUIT BREAKERS - LEFT and RIGHT on the rear steward's control panel.

Electrical connections are made at terminals on top of each transformer, the terminals being protected by a cover secured to the transformer case by screws.

#### 2. Reading Lamp Filament

##### A. Equipment and Materials

---

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

---

##### B. Prepare

- (1) Ensure that all reading lights in the forward or rear cabin, as appropriate, are extinguished.
- (2) Trip the associated LEFT or RIGHT reading light circuit breakers on the forward or rear steward's control panel, as appropriate, and fit safety clips.

EFFECTIVITY: ALL

**33-24-00**

R

BA

Page 401  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL

### C. Replace Filament

- (1) Depress the catch on the side of the reading lamp housing and swing open the lens.
- (2) Remove the filament and fit a replacement. Close the lens.

### D. Conclusion

- (1) Remove the safety clips and reset the associated circuit breakers.
- (2) Push the associated reading light control switch and check that the reading lamp lights.
- (3) Push the switch again and check that the light is extinguished.

## 3. 600 VA Transformer

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

### B. Prepare

- R (1) Trip the RH and LH FWD PASS RDG LTS TRANS SUP  
R circuit breakers L884 and L885, respectively,  
R on panel 13-216, map refs.C8 and C9, or the RH  
R and LH AFT PASS RDG LTS TRANS SUP circuit breakers  
R L886 and L887, respectively, on panel 13-215, map  
R refs.E11 and E12, and fit safety clips.

### C. Remove

- (1) Gain access to the forward cabin reading light transformers by opening the forward steward's control panel, or gain access to the rear cabin reading light transformers by opening the panel immediately above the rear steward's control panel.
- (2) Remove the transformer terminal cover and disconnect the cables from the terminals.
- (3) Refit the terminal cover.

EFFECTIVITY: ALL

BA

Printed in England

**33-24-00**

Page 402  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

- (4) Remove the bolts and washers securing the transformer to its mounting plate and lift the transformer from its housing.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Position the transformer on its mounting plate and secure it with the bolts and washers.
- (3) Remove the terminal cover from the transformer.
- (4) Connect the electrical cables to the transformer terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (5) Refit the terminal cover.
- (6) Check that the transformer is bonded in accordance with 20-27-11.
- (7) Close and secure the associated panel.

### E. Conclusion

R  
R

- (1) Remove the safety clips and reset the circuit breakers tripped before removal.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Push a reading light control switch on the appropriate side of the forward or rear cabin and check that the associated reading lamp lights.
- (4) Push the switch again and check that the light is extinguished.
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

# 33-24-00

Page 403  
Aug 30/75



# *Concorde*

## MAINTENANCE MANUAL

### PASSENGER READING LIGHTS - ADJUSTMENT/TEST

#### 1. General

This topic contains an Operational Test only, which details the procedure to prove the correct operation of the passenger reading lights in each passenger service unit (PSU). Functional and System Tests are not considered necessary in this application.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test

- (1) Push the reading light control switches on each PSU, in turn, and check that the associated reading lamps are lit.
- (2) Check that each lamp rotates smoothly in its ball and socket mounting, for approximately 45 deg laterally, and 18 deg fore and aft.
- (3) Adjust each lamp until the light is directed on to the front edge of the associated passenger seat.
- (4) Push the reading light control switches again and check that the associated reading lights are extinguished.

##### C. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

# 33-24-00

Page 501  
Aug 30/75

### PASSENGER SIGNS - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig. 001 )

R

Signs above each row of passenger seats, when illuminated, inform the passengers that smoking is forbidden and seat belts must be fastened. A sign in each toilet, operating in conjunction with the 'fasten seat belts' signs requests the occupant to return to seat. Signs close to the toilets, and an additional sign on the forward cabin curtain lintel, indicate toilet availability. A 'toilet occupied' caption is located in the flight compartment for the benefit of crew members.

Warning lamps at each steward's position provide visual indication when the 'no smoking' and 'fasten seat belts' signs are illuminated, and an audible warning relayed through the public address system (Ref. 23-31-00) attracts the stewards' attention to these warning lamps.

The lights, in the 'no smoking' and 'fasten seat belts' signs, are controlled by their respective switches on the flight compartment roof panel.

The lights in the toilet availability signs are controlled by the bolt on each of the associated toilet doors.

If the cabin oxygen supply rises to emergency pressure (Ref. 35-21-00) the 'no smoking' and 'fasten seat belts' signs are automatically lit.

#### 2. 'No Smoking' and 'Fasten Seat Belts' Signs

'No smoking' and 'fasten seat belts' sign mounting assemblies are fitted in the loudspeaker panels above each row of seats but staggered so that signs at adjacent seat rows are on opposite sides of the aircraft. The sign filament lamps are mounted behind a translucent sign panel which is hinged to facilitate replacement of filaments.

Two warning lamps, engraved respectively NO SMOKING and FASTEN SEAT BELTS, are mounted on each steward's control panel.

R

#### 3. 'Return to Seat' Signs

R

The 'return to seat' sign assembly in each toilet is recessed into the panelling of the inboard toilet console. A translucent sign panel is retained by the lipped edges of the removable sides of the assembly,

EFFECTIVITY: ALL

BA

# 33-25-00


Page 1  
Aug 30/77

# Concorde



## MAINTENANCE MANUAL

CMB 33 25 00 0 AAMO

CB12752/00B



- 'RETURN TO SEAT' SIGNS
- ▲ 'NO SMOKING/FASTEN SEAT BELTS' SIGNS
- 'TOILETS OCCUPIED' SIGNS



Passenger Signs  
Figure 001

R

EFFECTIVITY: ALL

BA

Printed in England

**33-25-00**

Page 2  
Aug 30/77

# Concorde

## MAINTENANCE MANUAL

each of which is secured by two screws.

### 4. 'Toilets Occupied' Signs

R A 'toilets occupied' sign is fitted in each 'exit' sign  
R assembly mounted in the roof of the forward end of each  
R cabin and at the rear end of the forward cabin. A  
R translucent sign panel, which includes the 'exit' sign,  
R is located in each assembly by a groove along the lower  
R edge and secured by pressing the upper edge into an associated  
R retaining strip.

R An additional 'toilet occupied' ancillary sign, comprising  
R four 28 V, non-replacement filaments, enclosed in a plastic  
R body, is located in the forward cabin in the forward curtain  
R lintel.

A 'toilet occupied' caption is mounted on the flight compartment oxygen panel for the benefit of flight compartment crew members.

### 5. Operation (Ref. Fig. 002 )

#### A. Control and Indication

The 'no smoking' and 'fasten seat belts' signs are supplied from the 'A' essential 28 V d.c. busbar and controlled by two toggle switches on the flight compartment roof panel engraved NO SMKG and FASTEN SEAT BELTS respectively. Two warnings lamps, one engraved NO SMOKING, and the other FASTEN SEAT BELTS, are mounted on each stewards' control panel and light when the associated signs in the cabin are illuminated. A low tone warning signal, initiated by the operation of the NO SMKG and the FASTEN SEAT BELTS switches, is audible through the public address system.

The 'toilets occupied' signs are supplied from 'B' essential 28 V d.c. busbar and controlled by one pole of a double-pole door microswitch. The other pole is associated with toilet lighting (Ref. 33-22-00).

#### B. Functional Description (Ref. Fig. 003 )

When ON is selected at the NO SMKG switch -

- (1) the NO SMOKING warning lamp on each stewards' panel is lit,
- (2) the 'no smoking' signs are illuminated,

EFFECTIVITY: ALL

BA

Printed in England


**33-25-00**

Page 3  
Nov 30/75

# Concorde

## MAINTENANCE MANUAL





CB12783/00C



'TOILETS OCCUPIED' SIGNS (TYPICAL)

ROOF 'EXIT' SIGN (TYPICAL)

PART OF REAR CABIN LOOKING FORWARD



CMB 33 25 00 0 BANO

FASTEN SEAT BELTS ON  
OFF

NO SMOKING ON  
OFF

PASSENGER SIGN SWITCHES

CALL FWD TOILET NO SMOKING FASTEN SEAT BELTS  
PASSENGER SIGN INDICATOR LAMPS

Passenger Signs - Controls, Indicators and Equipment  
Figure 002

EFFECTIVITY: ALL

BA

Printed in England

33-25-00

Page 4  
Aug 30/77

# *Concorde*

## MAINTENANCE MANUAL

- (3) a low tone warning signal is relayed through the aircraft public address system and
- (4) filament lamps associated with emergency lighting are lit (Ref. 33-51-00).

When OFF is selected the low tone warning signal is again relayed through the public address system and all 'no smoking' signs and associated warning lights go out, together with those lights associated with emergency lighting.

When ON is selected at the FASTEN SEAT BELTS switch -

- (1) the FASTEN SEAT BELTS warning lamp on each stewards' panel is lit,
- (2) the 'fasten seat belts' signs are illuminated,
- (3) a low tone warning signal is relayed through the aircraft public address system and
- R (4) the 'return to seat' sign in each toilet is illuminated.

R When OFF is selected the low tone warning signal is again relayed through the public address system, and all 'fasten seat belts' and 'return to seat' signs and associated warning lights go out.

The 'toilets occupied' sign at the forward vestibule, the 'toilet occupied' sign on the forward lintel and the TOILET OCCUPIED caption in the flight compartment are illuminated when the forward toilet door is closed and bolted.

The 'toilets occupied' signs at the rear end of the forward cabin and the forward end of the rear cabin are illuminated when all centre toilet doors are closed and bolted.

If the cabin oxygen supply rises to emergency pressure the emergency oxygen services relay (Ref. 35-21-00) is energized and connects a supply to operate the audible warning and to light the 'no smoking' and 'fasten seat belts' warning signs, thereby overriding the NO SMKG and FASTEN SEAT BELTS control switches.

EFFECTIVITY: ALL

BA


**33-25-00**

Page 5  
Aug 30/77


# Concorde

## MAINTENANCE MANUAL

CB12719/008



CMB 33 25 00 0 CANO



- Passenger Signs - Simplified Schematic  
Figure 003

R

EFFECTIVITY: ALL

BA

Printed in England

**33-25-00**

Page 6  
Aug 30/77

# *Concorde*

## MAINTENANCE MANUAL

### PASSENGER SIGNS - TROUBLE SHOOTING

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.
- C. Renew any faulty filaments in indicators or warning signs.

EFFECTIVITY: ALL

BA

Printed in England

**33-25-00**

Page 101  
Jun 30/75



# Concorde

## MAINTENANCE MANUAL

### Trouble Shooting

\*\*\*\*\*  
\*Prepare to trouble shoot (Ref. para.2.) \*  
\*Select "ON" at the NO SMKG control switch \*  
\*on the pilots' roof panel and check that - \*  
\*(1) a low tone warning sounds throughout \*  
\* the PA system, \*  
\*(2) the NO SMOKING indicator on each \*  
\* steward's panel is lit and \*  
\*(3) all 'no smoking' signs in the \*  
\* forward and rear cabins are lit. \*  
\*(4) the lamps associated with emergency \*  
\* lighting are lit. IF - \*  
\*\*\*\*\*  
\*\*\*\*\*

OK	NOT OK-----	<div>1. A low tone warning does not sound - Ref. 23-31-00. 2. Any one NO SMOKING indicator or sign not lit - check for 28 V d.c. input at lamp and renew lamp or check wiring as necessary. 3. All NO SMOKING indicators fail to light - Chart 101. 4. Lamps associated with emergency lighting not lit - Ref. 33-51-00</div>

\*\*\*\*\*  
\*Select "ON" at the FASTEN SEAT BELTS \*  
\*control switch and check that - \*  
\*(1) a low tone warning sounds throughout \*  
\* the PA system, \*  
\*(2) the FASTEN SEAT BELTS indicator on \*  
\* each steward's panel is lit and \*  
\*(3) all 'fasten seat belts' signs in the \*  
\* forward and rear cabins and the \*  
\* 'return to seat' sign in each toilet \*  
\* are lit. IF - \*  
\*\*\*\*\*  
\*\*\*\*\*

FECTIVITY: ALL

**33-25-00**

Page 102  
Aug 30/78

# Concorde

## MAINTENANCE MANUAL

OK

NOT OK-----

1. A low tone warning does not sound - Ref. 23-31-00.
2. Any one FASTEN SEAT BELTS indicator or sign or 'return to seat' sign not lit - check for 28 V d.c. input at lamp and renew lamp or check wiring as necessary.
3. ALL FASTEN SEAT BELTS signs and indicators and 'return to seat' signs fail to light - Chart 102.

C.\*\*\*\*\*  
\*Close and bolt all toilet doors and check \*  
\*that all 'toilet engaged' signs light and \*  
\*that - \*  
\*(1) when the forward toilet door is open \*  
\* the associated signs in the forward \*  
\* cabin go out and \*  
\*(2) when any one of the centre toilet \*  
\* doors is open the associated signs in \*  
\* the forward and aft cabins go out. \*  
\* IF - \*  
\*\*\*\*\*

EFFECTIVITY: ALL

**33-25-00**

Page 103  
Aug 30/78

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

NOT OK-----

1. All 'toilet engaged' signs fail to light. Check for 28 V d.c. output from CB (3) and renew CB (3) or check wiring as necessary.
2. Sign associated with forward toilet does not light. Check for 28 V d.c. input at Sign (15). Renew Sign (15) or Microswitch (11) as necessary.
3. Sign associated with forward toilet does not go out when door is unbolted. Renew Microswitch (11).
4. One sign associated with centre toilets does not light. Check for 28 V d.c. input at Sign (16) or (17) and renew Sign (16) or (17) or check wiring as necessary.
5. All signs associated with centre toilets fail to light - Chart 103.
6. Both signs associated with centre toilets light when only one centre toilet door is bolted. Renew microswitch in other toilet.

EFFECTIVITY: ALL

**33-25-00**

Page 104  
Aug 30/78

Printed in England

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*'NO SMOKING' INDICATORS FAIL \*  
 \*TO LIGHT WHEN SWITCHED ON. \*  
 \*\*\*\*\*

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-




Chart 101

EFFECTIVITY: ALL

**33-25-00**

Page 105  
 Aug 30/78

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*ALL 'FASTEN SEAT BELTS' SIGNS\*  
 \*AND INDICATORS AND 'RETURN TO\*  
 \*SEAT' SIGNS FAIL TO LIGHT \*  
 \*WHEN SWITCHED ON. \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-




Chart 102

EFFECTIVITY: ALL

**33-25-00**

R

BA

Page 106  
 Aug 30/78

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
\*ALL ASSOCIATED SIGNS FAIL TO \*  
\*LIGHT WHEN CENTRE TOILET \*  
\*DOORS ARE CLOSED AND BOLTED. \*  
\*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

NOTE: Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 103

EFFECTIVITY: ALL

**33-25-00**

R

BA

Page 107  
Aug 30/78

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL/ PANEL	ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 28 V	-	1-213	W191	Map ref. L8	24-50-00 R/I	
(2) Circuit breaker 28 V	-	1-213	W192	Map ref. L9	24-50-00 R/I	
(3) Circuit breaker 28 V	-	5-213	M201	Map ref. C19	24-50-00 R/I	
(4) 'Fasten seat belts' switch	-	4-211	W193	Pilots' roof panel	33-25-00 R/I	
(5) 'No smoking' switch	-	4-211	W194	Pilots' roof panel	33-25-00 R/I	
(6) 'Fasten seat belts' indicator lamps	-	1-221 1-223 1-241	W233 W229 W231	Fwd., Centre and Rear steward's panels	33-25-00 R/I	
(7) 'No smoking' indicator lamps	-	1-221 1-223 1-241	W234 W230 W232	Fwd., Centre and Rear steward's panels	33-25-00 R/I	
(8) 'Return to seat' signs	-	222 223 224	L981 L983 L984	No.1, No.2, No.3 and (when fitted) No.3a toilets	33-25-00 R/I	
(9) Cabin 'fasten seat belts' sign	-	Various		Loud-speaker panels	33-25-00 R/I	
(10) Cabin 'no smoking' signs	-	Various		Loud-speaker panels	33-25-00 R/I	
(11) No.1	-	222	-	Door	33-25-00	

EFFECTIVITY: ALL

BA

# 33-25-00

Page 108  
Nov 30/79

Printed in England

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
toilet door microswitch				Lintel	R/I	
(12) No.2 toilet door microswitch	-	223	-	Door lintel	33-25-00 R/I	
(13) No.3 toilet door microswitch	-	224	-	Door lintel	33-25-00 R/I	
(14) No.3a toilet (when fitted) microswitch	-	224	-	Door lintel	33-25-00 R/I	
(15) Fwd. 'toilet engaged' sign	-	221	L852	Fwd. end, fwd. cabin	33-25-00 R/I	
(16) Centre 'toilets engaged' sign	-	223	L854	Rear end, fwd. cabin	33-25-00 R/I	
(17) Centre 'toilets engaged' sign	-	223	L881	Fwd. end, rear cabin	33-25-00 R/I	
(18) 'Toilet occupied' sign	-	20-215	M202	Flight compt., oxygen panel	33-25-00 R/I	
(19) Fwd. 'toilet occupied' ancillary sign	-	222	M204	Fwd. end, fwd. cabin	33-25-00 R/I	

Component Identification  
Table 101

EFFECTIVITY: ALL

**33-25-00**

R

BA

Page 109  
Nov 30/79



# *Concorde*

## MAINTENANCE MANUAL

### PASSENGER SIGNS - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

R This topic contains instructions for the renewal of filaments in the 'no smoking' and 'fasten seat belts' signs mounted in the loudspeaker panels (Ref. 23-31-00) above the passenger seats, and in the 'return to seat' sign in each toilet, and for the removal and installation of 'toilet occupied' ancillary signs mounted in the curtain lintels in the forward cabin. The filaments in the 'toilet occupied' sign in the curtain lintel are not replaceable.

The 'toilets occupied' signs mounted in the roof at the end of each cabin and at the rear end of the forward cabin form part of the exit direction signs. Instructions for the renewal of filaments and for the removal and installation of the sign are contained in Emergency Lighting (Ref. 33-51-00).

Instructions for the removal and installation of the NO SMKG and FASTEN SEAT BELTS light control switches, mounted on the pilots' roof panel, are contained in 33-00-00, and for the NO SMOKING and FASTEN SEAT BELTS warning lamps, mounted on each steward's panel, in 33-20-00.

#### 2. 'No Smoking' and 'Fasten Seat Belts' Filament Renewal

##### A. Prepare

- (1) Ensure that the NO SMKG and FASTEN SEAT BELTS light control switches on the flight compartment roof panel are at OFF.

##### B. Renew Filament

- (1) Using the lip on the bottom edge of the sign panel, lift the panel to swing the mounting backward on its pivots.
- (2) Renew the filament.
- (3) Close the sign panel.

##### C. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

**33-25-00**

Page 401  
Aug 30/77

# *Concorde*

## MAINTENANCE MANUAL

- (2) Set the NO SMKG switch or the FASTEN SEAT BELTS switch, as appropriate, to "ON" and check that the filament is lit. Return the switch to "OFF".
- (3) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### R 3. 'Return to Seat' Filament Renewal

#### A. Prepare

- (1) Ensure that the FASTEN SEAT BELTS light control switch on the flight compartment roof panel is at OFF.
- (2) Open the toilet inboard console door.

#### B. Renew Filament

- (1) Remove the screws securing the cover to the top of the wash basin top assembly and remove the cover to gain access to the back of the sign.
- (2) Remove the screws and washers securing the cover plate to the top of the sign assembly and remove the cover plate.
- (3) Renew the filament.
- (4) Secure the cover plate to the top of the sign assembly with the screws and washers.
- (5) Secure the cover to the wash basin top assembly with the screws.
- (6) Close the console door.

#### C. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Set the FASTEN SEAT BELTS light control switch to "ON" and check that the 'return to seat' sign filament is lit. Return the switch to "OFF".
- (3) Switch off and disconnect electrical ground power as detailed in 24-41-00.

R

EFFECTIVITY: ALL

BA

Printed in England

**33-25-00**

Page 402  
Aug 30/77

# Concorde

## MAINTENANCE MANUAL

### R 4. 'Toilet Occupied' Ancillary Sign

#### R A. Equipment and Materials

R

R

R

DESCRIPTION

PART NO.

R

R

Circuit breaker safety clips

-

R

#### B. Prepare

R

R

(1) Trip the TOILET ENGAGED SIGN SUP circuit breaker M201, on panel 5-213, map ref.C19, and fit a safety clip.

R

R

R

R

(2) Remove the bolts and washers securing the curtain rail to the bottom side of the curtain lintel, and remove the curtain rail to gain access to the body of the 'toilet occupied' sign.

R

#### C. Remove

R

R

(1) Label the sign electrical flying leads to assist installation.

R

R

(2) Using a suitable tool, disconnect the flying leads from the terminal block on the adjacent bulkhead.

R

R

R

R

(3) Remove the nuts securing the sign retention bracket to the studs inside the lintel. Support the sign, remove the bracket and withdraw the sign from its housing.

R

#### D. Install

R

(1) Comply with the electrical safety precautions.

R

R

R

R

R

(2) Orientate the sign and fit it in the housing, from inside the curtain lintel. Refit the retention bracket to the studs, ensuring that the rubber face of the bracket correctly supports the rear of the sign body. Secure the bracket with the nuts.

R

R

R

(3) Route the electrical flying leads through the cable clips in the lintel to the terminal block on the adjacent bulkhead.

R

R

R

(4) Using a suitable tool, connect the electrical cables to the terminal block, ensuring that the connections are made in accordance with the cable

EFFECTIVITY: ALL

BA

**33-25-00**

Page 403  
Nov 30/75

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

R identifications and the applicable wiring diagram.

R E. Conclusion

R (1) Reset the circuit breaker tripped before removal.

R (2) Close and lock the associated toilet door(s) and  
R check that the sign is evenly illuminated.

R (3) Refit the curtain rail to the bottom side of the  
R lintel and secure it with the bolts and washers.

EFFECTIVITY: ALL

BA

Printed in England

**33-25-00**

Page 404  
Nov 30/75

# *Concorde*

## MAINTENANCE MANUAL

### PASSENGER SIGNS - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

R  
R  
R  
R  
R  
R  
R

This topic contains an Operational Test which details the procedure to prove the correct operation of the passenger signs and associated indicator lamps. A specific self-contained test, comprising a check to prove that the 'no smoking' signs are automatically lit when the emergency oxygen services relay is activated, is also included in this topic, but as the relay is a part of the Oxygen System (Ref. Chap.35) the procedures for carrying out the check are detailed in 35-21-00, Adjustment/Test. Functional and System Tests are not considered necessary in this application.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test

- (1) Select "ON" at the NO SMKG control switch on the flight compartment roof panel 4-211 and check that -
  - (a) a low tone warning is relayed through the public address system (Ref. 23-31-00),
  - (b) the NO SMOKING indicator lamp on each steward's panel is lit,
  - (c) all the 'no smoking' signs in the forward and rear cabins are illuminated and
  - (d) lamps associated with emergency lighting are lit (Ref. 33-51-00).
- (2) Select "OFF" at the NO SMKG control switch and check that -
  - (a) the low tone warning is again relayed through the public address system (Ref. 23-31-00) and
  - (b) all indicator lights, emergency lights and the

EFFECTIVITY: ALL

BA

Printed in England

**33-25-00**

Page 501  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

lights in the 'no smoking' signs are extinguished.

- (3) Select "ON" at the FASTEN SEAT BELTS control switch and check that -

- (a) a low tone warning is relayed through the public address system (Ref. 23-31-00),
- (b) the FASTEN SEAT BELTS indicator lamp on each steward's panel is lit,
- (c) all 'fasten seat belts' signs in the forward and rear cabins are illuminated and
- R (d) the 'return to seat' sign in each toilet is illuminated.

- (4) Select "OFF" at the FASTEN SEAT BELTS switch and check that -

- (a) the low tone warning signal is again relayed through the public address system (Ref. 23-31-00) and
- R (b) all indicator lights and the lights in all the 'fasten seat belts' and 'return to seat' signs are extinguished.

- (5) Close and bolt both centre right toilet doors and check that the lights in the 'toilets occupied' signs at the rear end of the forward cabin and the forward end of the rear cabin are extinguished.

- (6) Close and bolt the centre left toilet door and check that the 'toilets occupied' signs are lit.

- (7) Unbolt and open one of the two centre right toilet doors and check that the lights in the 'toilets occupied' signs are extinguished.

- (8) Unbolt and open all centre toilet doors.

- (9) Close and bolt the forward toilet door and check that the 'toilets occupied' signs at the forward end of the forward cabin are lit, and that the TOILET OCCUPIED caption on the flight compartment oxygen panel (panel 20-215) is illuminated.

- (10) Unbolt and open the forward toilet door and check

EFFECTIVITY: ALL

BA

Printed in England

**33-25-00**

Page 502  
Aug 30/77

# *Concorde*

## MAINTENANCE MANUAL

that the lights in the 'toilets occupied' signs are extinguished and that the TOILET OCCUPIED caption is not illuminated.

R (11) Carry out an Operational Test of the Passenger  
R System (Ref. 35-21-00) and check that the  
R passenger signs and the emergency lights  
R (Ref. 33-51-00) are activated as detailed in  
R paragraphs (1)(a) to (d), and (3)(a) to (d), above,  
R when the emergency oxygen services relay is energized.

R C. Conclusion

R (1) Switch off and disconnect electrical ground power  
R as detailed in 24-41-00.

R 3. 'No Smoking' Signs - Test of Operation in Conjunction with  
R Oxygen System

R A. Test

R (1) Carry out the 'No Smoking' Signs Test as detailed  
R in 35-21-00, in Adjustment/Test, and check that the  
R 'no smoking' signs are automatically illuminated when  
R the oxygen system is activated.

EFFECTIVITY: ALL

BA

Printed in England

**33-25-00**

Page 503  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

### CALL SYSTEMS - DESCRIPTION AND OPERATION

#### 1. General

The aircraft call systems comprise two-way call facilities between the flight compartment and each steward's position, and between any one steward's position and the other two; and one-way call facilities which enable a passenger to summon a steward to any cabin seat or toilet.

Visible indication of all calls is given by lights, and audible indication by a tone signal through the public address system (Ref. 23-31-00), in the vestibule areas. Audible indication of a steward-to-flight compartment call is given by a pilot call audible indicator in the flight compartment (Ref. 23-42-00).

The toilet and flight compartment call indicator lamps on the stewards' control panels operate in conjunction with associated relays, and remain lit after the appropriate call push-switch has been released, until an associated reset switch is pressed.

R B NOTE: Post CM42018 HI chime from PA system deleted.

#### 2. Operation

All call systems are supplied from the 'B' main 28 V d.c. busbar.

##### A. Control and Indication (Ref. Fig.001 and 002)

###### (1) Flight Compartment-to-Steward Call

A STEWARD CALL indicator lamp/switch on the flight compartment roof panel is a double-pole press-to-make spring-return switch fitted with a translucent knob illuminated by an internal filament.

A FLIGHT DECK CALL indicator lamp/switch and a CANCEL switch are mounted on the forward steward's call panel and on each of the centre and rear steward's control panels. The FLIGHT DECK CALL indicator lamp/switch is a single-pole press-to-make spring-return switch fitted with a translucent knob illuminated by an internal filament. The switch is guarded to protect against accidental operation of the FLIGHT DECK CALL button. The CANCEL switch is a press-to-break single-pole spring-return switch

EFFECTIVITY: ALL

BA

**33-27-00**

Page 1  
Nov 30/80

Printed in England



# Concorde

## MAINTENANCE MANUAL

with a knob which is not illuminated.

A hold-on relay that operates in conjunction with the flight compartment-to-steward call system is mounted in the forward steward's control panel.

### (2) Cabin Crew Call

A CABIN CREW CALL switch used in a steward-to-steward call system is mounted on the forward steward's control panel and on the centre and rear steward's control panels.

Following Mod.33D103 the call switch is a 3 pole press-to-make spring-return switch.

Selection of either up or down position of the switch at any stewards station allows selective signalling of one of the other two stations. The station being called is indicated by illumination of the cabin ceiling light indicator(s) nearest the called station.

A two tone chime is also activated through the public address system but only emanates from the three vestibule areas.

### (3) Passenger Cabin-to-Steward Call

A call switch, mounted on a passenger service unit (PSU) above each row of seats, is a press-to-make plus momentary contact, press-to-break switch fitted with a translucent knob illuminated by an internal filament.

A FWD CABIN CALL indicator lamp is mounted on the forward and the centre steward's control panels. A REAR CABIN CALL indicator lamp is mounted on the centre and rear steward's control panels.

Four cabin call ceiling indicator lamps are fitted, two in the forward cabin aisle and two in the rear cabin aisle.

After SB 33-015 For A/C 001-001,

Four cabin call ceiling indicator lamps, each under a blue domed lens, are fitted, two in the forward cabin aisle and two in the rear cabin aisle.

### (4) Toilet-to-Steward Call

A steward call indicator lamp/switch mounted on the console unit in each toilet is a double

EFFECTIVITY: ALL

BA


C804114

**33-27-00**

Page 2  
Sep 30/93

# Concorde

## MAINTENANCE MANUAL



CMB 33 27 00 0 AANO

- Call Systems - Flight Compartment/Cabin Crew  
Figure 001

EFFECTIVITY: ALL


**33-27-00**

Page 3  
May 30/77

Printed in England

# Concorde

## MAINTENANCE MANUAL



- Call Systems - Passenger/Cabin Crew  
Figure 002

EFFECTIVITY: ALL

BA

Printed in England

**33-27-00**

Page 4  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

pole press-to-make spring-return switch fitted with a translucent cover illuminated by an internal filament.

A toilet indicator/cancel call lamp/switch is mounted outside each toilet above the toilet door. Each indicator lamp/switch is a single-pole press-to-break spring-return switch fitted with a translucent knob illuminated by an internal filament.

A FWD TOILET and a CENTRE TOILET call indicator lamp are mounted on each of the forward, centre and rear steward's control panels. The ceiling indicator lamps are those used in the passenger cabin-to-steward call.

A hold-on relay that operates in conjunction with the forward toilet call system is mounted in the forward steward's control panel, and three relays associated with the centre toilets call system are mounted in the centre steward's control panel.

### B. Functional Description

#### (1) Flight Compartment-to-Steward Call (Ref. Fig. 003 )

With the aircraft 28 V d.c. supply available, when the STEWARD CALL switch is pressed, one set of contacts connects the supply to the public address (PA) system to operate the tone generator. The other set of contacts connects the supply to light the filaments in the FLIGHT DECK CALL indicator lamp/switch at each steward's panel and to energize the hold-on relay through the normally closed contact of the CANCEL switch on each steward's panel.

With the relay energized, the relay contacts complete the hold-on circuit to the relay coil, which maintains the contacts in the closed position and the FLIGHT DECK CALL lamps at steward's panels lit.

When the STEWARD CALL switch is released the supply to the PA system is interrupted, but the FLIGHT DECK CALL lamps at each steward's position remain lit until the CANCEL switch at any one of the steward's panels is pressed and interrupts the supply to the hold-on relay.

EFFECTIVITY: ALL

**33-27-00**

R


BA

Page 5  
Nov 30/80

Printed in England

# Concorde

## MAINTENANCE MANUAL



- Flight Compartment-to-Steward Call -  
Simplified Schematic  
Figure 003

When the FLIGHT DECK CALL indicator lamp/switch at any one of the steward's panels is pressed, the normally open contact of the switch closes and connects a supply to light the STEWARD CALL indicator lamp on the flight compartment roof panel and to operate the pilot call audible indicator (Ref. 23-42-00). When the switch is released the supply is interrupted, the light is extinguished and the audible indication is terminated.

### (2) Cabin Crew Call (Ref. Fig. 003 )

When the CABIN CREW CALL switch at any steward's panel is pressed the contacts of the switch connect a supply to operate the PA system tone generator in the vestibule area. When the switch is released the supply to the PA system is interrupted.

EFFECTIVITY: ALL

**33-27-00**

R


BA

Page 6  
Nov 30/80

Printed in England

# Concorde

## MAINTENANCE MANUAL



CMC 33 27 00 1 DANO 4

RE

Passenger Cabin-to-Steward Call  
Simplified Schematic  
Figure 004

EFFECTIVITY: ALL

BA

C804080

33-27-00

Page 7  
Sep 30/93

# Concorde

## MAINTENANCE MANUAL

### (3) Passenger Cabin-to-Steward Call (Ref. Fig. 004)

When a call switch at any PSU is pressed the momentary contact connects the supply to operate the PA system tone generator and a second set of contacts connects the supply to light the filament in the call switch knob and:

- (a) for calls originating in the forward cabin, to light the FWD CABIN CALL indicator lamp on the forward and centre steward's control panels, and the foremost cabin ceiling indicator lamps, or
  - (b) for calls originating in the rear cabin, to light the REAR CABIN CALL indicator lamp on the centre and rear steward's control panels, and the rearmost cabin ceiling indicator lamps.
- When the call switch is pressed again the supply is interrupted and all the associated indicator lights are extinguished.

### (4) Toilet-to-Steward Call (Ref. Fig. 005)

#### (a) Forward Toilet

When the call switch in the forward toilet (No.1) is pressed, one set of contacts connects the supply to operate the PA system tone generator, and a second set of contacts connects the supply to:

- (i) light the call indicator lamp/switch in No.1 toilet,
- (ii) light the toilet indicator/cancel call lamp/switch outside No.1 toilet door,
- (iii) energize the associated hold-on relay, and
- (iv) light the FWD TOILET call indicator lamp on the forward, centre and rear steward's control panels, and the ceiling indicator lamps in the forward and rear cabins through a contact of the hold-on relay.

EFFECTIVITY: ALL

33-27-00

Page 8  
Sep 30/93

C804081

R

BA

# *Concorde*

## MAINTENANCE MANUAL

### (b) Centre Toilets

When a call switch in any centre toilet (No.2, 3 or 3A) is pressed, one set of contacts connects a supply to operate the PA system tone generator, and the other set connects a supply to:

- (i) light the call indicator lamp/switch in the associated toilet,
- (ii) light the toilet indicator/cancel call lamp/switch outside the associated toilet door,
- (iii) energize the associated hold-on relay, and
- (iv) light the CENTRE TOILET call indicator lamp on the forward, centre and rear steward's control panels, and the ceiling indicator lamps in the forward and rear cabins through a contact of the hold-on relay.

With the relay energized, a relay contact completes the hold-on circuit to the relay coil, through the normally closed contact of the toilet indicator/cancel call lamp/switch, which maintains the relay contacts in the closed position and, therefore, the associated toilet call indicator lamps lit.

When the toilet call switch is released, the supply to the PA system is interrupted, but the associated toilet call indicator lamps remain lit until the toilet indicator/cancel call lamp/switch is pressed and interrupts the hold-on relay supply.

When the appropriate toilet indicator/cancel call lamp/switch is pressed, the supply to the hold-on relay is interrupted, the relay is de-energized and the associated toilet call indicator lights are extinguished.

EFFECTIVITY: ALL

BA

C805623

**33-27-00**


Page 9  
Sep 30/93



# Concorde

## MAINTENANCE MANUAL

CMG 33.27.00.00.00



Toilet-to-Steward Call -  
Simplified Schematic  
Figure 005

EFFECTIVITY: ALL

BA

Printed in England

33-27-00

Page 10  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

R

### CALL SYSTEMS - TROUBLE SHOOTING

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

R

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

Where call system circuits are similar, procedures and charts are provided which are applicable to each circuit. Where identical components are involved, i.e., one in each circuit, the references to the associated components listed in Table 101 are given, e.g., 'Renew Lamp/Switch (3), (4) or (5)'.

#### 2. Preparation

- A. Ensure that the associated circuit-breaker is set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

R

EFFECTIVITY: ALL

BA

C817404

# 33-27-00

Page 101  
Mar 27/97

# Concorde

## MAINTENANCE MANUAL

R

### 3. Trouble Shooting - Flight Deck to Steward Call

A.\*\*\*\*\*  
\*Prepare to trouble shoot (Ref. para.2.)\*  
\*Press and release the STEWARD CALL \*  
\*indicator lamp/switch on the pilots' \*  
\*roof panel. Check that a tone signal is\*  
\*audible through the public address \*  
\*system in the vestibule areas, the \*  
\*FLIGHT DECK CALL lamp/switch on each \*  
\*steward's panel is lit. IF - \*  
\*\*\*\*\*

NOT OK——

1. One FLIGHT DECK CALL Indicator Lamp/Switch (3), (4) or (5) not lit - renew filament.
2. All indicator lamp/switches lit but no tone signal - check public address system (Ref. 23-31-00) output from CB (1). If OK -
3. Indicator lamp switches not lit and no tone signal - check for 28 V d.c. output from CB (1). If OK - renew Switch (2). If not OK - renew CB (1).
4. Indicator lamp/switches lit when Switch (2) depressed but lights go out when Switch (2) released - renew Relay (6). If fault not cleared - check continuity across terminals of Switches (7), (8) and (9).

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C817605

# 33-27-00

Page 102  
Mar 27/97

# Concorde

## MAINTENANCE MANUAL

### 4. Trouble Shooting - Steward to Flight Deck Call

- A. \*\*\*\*\*  
\*Prepare to trouble shoot (Ref. para.2.).\*  
\*Press the FLIGHT DECK CALL lamp switch \*  
\*on each steward's panel and check that \*  
\*the STEWARD CALL indicator lamp/switch \*  
\*on the pilots' roof panel is lit whilst \*  
\*the switch is pressed. IF - \*  
\*\*\*\*\*

NOT OK

1. Flight deck STEWARD CALL  
indicator lamp/switch not lit  
- Chart 101.

### 5. Trouble Shooting - Crew to Crew Call

- A. \*\*\*\*\*  
\*Prepare to trouble shoot (Ref. para.2.).\*  
\*Press and release the CABIN CREW CALL \*  
\*switch on each steward's panel and check\*  
\*for a tone signal through the public \*  
\*address system. IF - \*  
\*\*\*\*\*

NOT OK

1. No tone signal - Chart 102.

PRINTED IN ENGLAND

R EFFECTIVITY: ALL

BA

C817606

# 33-27-00

Page 103  
Mar 27/97

# Concorde

## MAINTENANCE MANUAL

### 6. Trouble Shooting - Passenger Cabin to Steward Call (Fwd. Cabin)

A.\*\*\*\*\*  
\*Prepare to trouble shoot (Ref. para.2.)\*  
\*Press and release the call switch on \*  
\*each passenger service unit (PSU) in the\*  
\*forward cabin. Check that the filament \*  
\*in the knob is lit, a tone signal is \*  
\*audible through the public address \*  
\*system, the FWD CABIN CALL Indicator \*  
\*Lamps (13) and (14) on the forward and \*  
\*centre steward's panels are lit, and the\*  
\*two ceiling Indicator Lamps (35) and \*  
\*(36) in the forward cabin aisle are lit.\*  
\*\*\*\*\*

NOT OK

1. Indicator lamps lit but filament in knob not lit - renew filament.
2. One indicator lamp not lit - renew filament.
3. Indicator lamps lit but no tone signal - disconnect PSU electrical connector, press switch and check for continuity between pin C and pins B and E of fixed connector. If OK - check public address system (Ref. 23-31-00). If not OK - renew call switch.
4. Tone signal audible but no indicator lights - renew call switch.
5. No tone signal and no indicator lights - Chart 103.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C817615

# 33-27-00

Page 104  
Mar 27/97

# Concorde

## MAINTENANCE MANUAL

### 7. Trouble Shooting - Passenger Cabin to Steward Call (Rear Cabin)

A. \*\*\*\*\*  
\*Prepare to trouble shoot (Ref. para.2.)\*  
\*Press and release the call switch on \*  
\*each PSU in the rear cabin. Check that \*  
\*the filament in the knob is lit, a tone \*  
\*signal is available through the public \*  
\*address system, the REAR CABIN CALL \*  
\*Indicator Lamps (15) and (16) on the \*  
\*centre and rear steward's panels are lit\*  
\*and the two Indicator Lamps (37) and \*  
\*(38) in the rear cabin aisles are lit. \*  
\*IF - \*  
\*\*\*\*\*

NOT OK

1. Indicator lamps lit but filament in knob not lit - renew filament.
2. One ceiling indicator lamp not lit - renew filament.
3. Indicator lamps lit but no tone signal - disconnect PSU electrical connector, press switch and check for continuity between pin C and pins B and E of fixed connector. If OK - check public address system (Ref. 23-31-00). If not OK - renew call switch.
4. Tone signal audible but no indicator lights - renew call switch.
5. No tone signal and no indicator lights - Chart 103.

R EFFECTIVITY: ALL

BA

C817616

# 33-27-00

Page 105  
Mar 27/97

# Concorde

## MAINTENANCE MANUAL

### 8. Trouble Shooting - Toilet to Steward Call

A.\*\*\*\*\*

\*Prepare to trouble shoot (Ref. para.2.)\*  
\*Press and release the steward call lamp/\*  
\*switch in each toilet. Check that a \*  
\*tone signal is audible through the \*  
\*public address system and that the \*  
\*following lamps are lit: \*

\*  
\*(a) The filament in the call switch. \*  
\*(b) The FWD TOILET Indicator Lamps (21), \*  
\* (23) and (25) on the fwd., centre \*  
\* and rear steward's panels (forward \*  
\* toilet), or the CENTRE TOILET \*  
\* Indicator Lamps (22), (24) and (26) \*  
\* on the fwd., centre and rear \*  
\* steward's panels (centre toilets). \*  
\*(c) All four Ceiling Indicator Lamps \*  
\* (35), (36), (37) and (38) in the \*  
\* cabin aisles are lit. \*  
\*(d) The Cancel Call Lamp/Switch (27), \*  
\* (28), (29) or (30) outside the \*  
\* associated toilet door. IF - \*

\*\*\*\*\*

NOT OK——

1. One indicator lamp or lamp/switch not lit - renew filament.
2. Indicator lamps lit but no tone signal - check for tone signal via other steward call lamp/switches. If OK - renew Switch (17), (18), (19) or (20). If not OK - check public address system (Ref. 23-31-00).
3. Tone signal audible but no indicator lights - Chart 104.
4. No tone signal and no indicator lights - Chart 105.

R

EFFECTIVITY: ALL

BA

C817617

# 33-27-00

Page 106  
Mar 27/97

PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*FLIGHT DECK 'STEWARD CALL' \*  
 \*INDICATOR LAMP/SWITCH NOT \*  
 \*LIT WHEN STEWARD'S 'FLIGHT \*  
 \*DECK CALL' SWITCH IS \*  
 \*PRESSED. \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 101

R

EFFECTIVITY: ALL

BA

C817618

**33-27-00**

Page 107  
Mar 27/97




# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*NO TONE SIGNAL THROUGH \*  
 \*PUBLIC ADDRESS SYSTEM WHEN \*  
 \*'CABIN CREW CALL' SWITCH IS\*  
 \*PRESSED. \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
GROUND POWER SUPPLY	-
MULTIMETER	-

NOTE: Before renewal of components (\*), check the preceding run of wiring for continuity.



PRINTED IN ENGLAND

Chart 102

R

EFFECTIVITY: ALL

BA

C817620

# 33-27-00

Page 108  
 Mar 27/97

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*NO TONE SIGNAL AND NO \*  
 \*INDICATOR LIGHTS WHEN \*  
 \*PASSENGER TO STEWARD CALL \*  
 \*SWITCH PRESSED. \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 103

R EFFECTIVITY: ALL

BA

C817621

**33-27-00**

Page 109  
Mar 27/97


# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*TONE SIGNAL AUDIBLE BUT NO \*  
 \*TOILET CALL INDICATOR \*  
 \*LIGHTS WHEN STEWARD CALL \*  
 \*LAMP/SWITCH PRESSED AND \*  
 \*RELEASED. \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.



PRINTED IN ENGLAND

Chart 104

R

EFFECTIVITY: ALL

BA

C817622

# 33-27-00

Page 110  
Mar 27/97

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*NO TONE SIGNAL AND NO \*  
 \*INDICATOR LIGHT WHEN \*  
 \*STEWARD CALL LAMP/SWITCH \*  
 \*PRESSED AND RELEASED. \*  
 \*\*\*\*\*

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 105

R EFFECTIVITY: ALL

BA

C817623

# 33-27-00

Page 111  
Mar 27/97

# Concorde

## MAINTENANCE MANUAL

R

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 28 V	-	15-216	M78	Map ref.A22	24-50-00 R/I	33-27-11 33-27-12 33-27-13
(2) STEWARD CALL lamp/switch	-	4-211	M79	Pilots' roof panel	33-00-00 R/I	33-27-11
(3) FLIGHT DECK CALL lamp/switch	-	2-221	M90	Fwd. steward's call panel	33-20-00 R/I	33-27-11
(4) FLIGHT DECK CALL lamp/switch	-	1-223	M177	Centre steward's control panel	33-20-00 R/I	33-27-11
(5) FLIGHT DECK CALL lamp/switch	-	1-241	M186	Rear steward's control panel	33-20-00 R/I	33-27-11
(6) Flight deck call relay	-	1-221	M86	Fwd. steward's control panel	33-20-00 R/I	33-27-11
(7) Flight deck call CANCEL switch	-	2-221	M96	Fwd. steward's call panel	33-20-00 R/I	33-27-11
(8) Flight deck call CANCEL switch	-	1-223	M179	Centre steward's control panel	33-20-00 R/I	33-27-11
(9) Flight deck call CANCEL switch	-	1-241	M185	Rear steward's control panel	33-20-00 R/I	33-27-11
(10) CABIN CREW CALL switch	-	2-221	M88	Fwd. steward's call panel	33-20-00 R/I	33-27-11 33-27-12

Component Identification  
Table 101 (continued)

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C817624

# 33-27-00

Page 112  
Mar 27/97

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(11) CABIN CREW CALL switch	-	1-223	M178	Centre steward's control panel	33-20-00 R/I	33-27-11 33-27-12
(12) CABIN CREW CALL switch	-	1-241	M184	Rear steward's control panel	33-20-00 R/I	33-27-11 33-27-12
(13) FWD CABIN CALL indicator lamp	-	1-221	M93	Fwd. steward's control panel	33-20-00 R/I	33-27-12
(14) FWD CABIN CALL indicator lamp	-	1-223	M97	Centre steward's control panel	33-20-00 R/I	33-27-12
(15) REAR CABIN CALL lamp	-	1-223	M91	Centre steward's control panel	33-20-00 R/I	33-27-12
(16) REAR CABIN CALL lamp	-	1-241	M98	Rear steward's control panel	33-20-00 R/I	33-27-12
(17) Toilet to steward call lamp/ switch	-	222	L981	Toilet 1	33-27-00 R/I	33-27-13
(18) Toilet to steward call lamp/ switch	-	223	L983	Toilet 2	33-27-00 R/I	33-27-13
(19) Toilet to steward call lamp/ switch	-	224	L984	Toilet 3	33-27-00 R/I	33-27-13

Component Identification  
Table 101 (continued)

R

EFFECTIVITY: ALL

BA

C817625

# 33-27-00

Page 113  
Mar 27/97

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(20) Toilet to steward call lamp/ switch	-	224	L982	Toilet 3A	33-27-00 R/I	33-27-13
(21) FWD TOILET indicator lamp	-	1-221	M89	Fwd. steward's control panel	33-20-00 R/I	33-27-13
(22) CENTRE TOILET indicator lamp	-	1-221	M199	Fwd. steward's control panel	33-20-00 R/I	33-27-13
(23) FWD TOILET indicator lamp	-	1-223	M187	Centre steward's control panel	33-20-00 R/I	33-27-13
(24) CENTRE TOILET indicator lamp	-	1-223	M94	Centre steward's control panel	33-20-00 R/I	33-27-13
(25) FWD TOILET indicator lamp	-	1-241	M176	Rear steward's control panel	33-20-00 R/I	33-27-13
(26) CENTRE TOILET indicator lamp	-	1-241	M175	Rear steward's control panel	33-20-00 R/I	33-27-13
(27) Cancel call lamp/ switch	-	222	L981 (item 21)	Toilet 1	33-27-00 R/I	33-27-13
(28) Cancel call lamp/ switch	-	223	L983 (item 21)	Toilet 2	33-27-00 R/I	33-27-13

Component Identification  
Table 101 (continued)

R

EFFECTIVITY: ALL

BA

C817626

# 33-27-00

Page 114  
Mar 27/97

PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(29) Cancel call lamp/switch	-	224	L984 (item 21)	Toilet 3	33-27-00 R/I	33-27-13
(30) Cancel call lamp/switch	-	224	L982 (item 21)	Toilet 3A	33-27-00 R/I	33-27-13
(31) Toilet 1 relay	-	1-221	M83	Fwd. steward's control panel	33-20-00 R/I	33-27-13
(32) Toilet 2 relay	-	1-223	M85	Centre steward's control panel	33-20-00 R/I	33-27-13
(33) Toilet 3 relay	-	1-223	M84	Centre steward's control panel	33-20-00 R/I	33-27-13
(34) Toilet 3A relay	-	1-223	M200	Centre steward's control panel	33-20-00 R/I	33-27-13
(35) Fwd. centre aisle indicator lamp	-	221	M95	Fwd. cabin roof	-	33-27-12 33-27-13
(36) Centre aisle indicator lamp	-	223	M193	Fwd. cabin roof	-	33-27-12 33-27-13
(37) Centre aisle indicator lamp	-	231	M194	Rear cabin roof	-	33-27-12 33-27-13
(38) Aft centre aisle indicator lamp	-	242	M180	Rear cabin roof	-	33-27-12 33-27-13

Component Identification  
Table 101 (concluded)

R EFFECTIVITY: ALL

BA

C817627

# 33-27-00

Page 115  
Mar 27/97



# Concorde

## MAINTENANCE MANUAL

### CALL SYSTEMS - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic contains instructions for the removal and installation of the toilet-to-steward call indicator lamp/switch mounted in each toilet, the cancel-call indicator lamp/switch outside each toilet door and the passenger cabin-to-steward call indicator lamp/switch on each passenger service unit (PSU) above the seats in the passenger cabins.

After SB 33-015                      For A/C 001-001,

The topic also includes instructions for the renewal of a faulty cabin-call ceiling-mounted indicator lamp filament.

Instructions for the removal and installation of call system switches, indicator lamps and relays, mounted on the steward's panels, are contained in 33-20-00 and, for the steward call indicator lamp/switch on the flight compartment roof panel, in 33-00-00.

#### 2. Toilet-to-Steward Call Indicator Lamp/Switch

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

##### B. Prepare

- R
- (1) Trip the PASS CALL SUP circuit breaker M78, on panel 15-216, map ref.A22, and fit a safety clip.
  - (2) Open the toilet inboard console door.
  - (3) Remove the screws securing the top cover to the wash basin top assembly and remove the cover to gain access to the switch.

EFFECTIVITY: ALL

BA

**33-27-00**

Page 401  
May 30/80

# *Concorde*

## MAINTENANCE MANUAL

### C. Remove

- (1) Unscrew the knob from the switch.
- (2) Using a tubular spanner, remove the nut and washer from the front of the switch.
- (3) Disconnect the electrical cables from the terminals and withdraw the switch from the rear of the mounting bracket. Label the cables to assist identification for reconnection.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the indicator lamp/switch to the switch mounting bracket. Orientate the switch body and, from the front, secure it friction-tight with the nut and washer.
- (3) Connect the electrical cables to the switch terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (4) Tighten the securing nut.
- (5) Ensure that the switch knob contains a filament, then refit the knob to the switch.

### E. Conclusion

- (1) Refit the cover to the wash basin top assembly and secure it with the screws.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Remove the safety clip and reset the circuit breaker tripped before removal.
- (4) Press and release the indicator lamp/switch and check that the filament in the knob is lit, a tone signal is audible through the public address system, the associated toilet call indicator lamps are lit, and the cancel-call indicator lamp/switch outside the toilet door is lit.
- (5) Press and release the cancel-call indicator lamp/switch and check that all associated toilet call

EFFECTIVITY: ALL

R

BA

**33-27-00**

Page 402  
Nov 30/77

# *Concorde*

## MAINTENANCE MANUAL

indicator lights are extinguished.

(6) Close the toilet console door.

(7) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### 3. Toilet Cancel-call Indicator Lamp/Switch

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

R (1) Trip the PASS CALL SUP circuit breaker M78, on panel 15-216, map ref.A22, and fit a safety clip.

(2) Pull the toilet roof panel downward to release the spire fasteners and remove the panel to gain access to the rear of the switch on the fore-and-aft bulkhead above the toilet door.

#### C. Remove

(1) Unscrew the knob from the switch.

(2) Using a tubular spanner, remove the nut and washer from the front of the switch and withdraw the switch from its housing in the bulkhead sufficiently to gain access to the terminal screws.

(3) Disconnect the electrical cables from the switch terminals and remove the switch. Label the cables to assist identification for reconnection.

#### D. Install

(1) Comply with the electrical safety precautions.

(2) Support the switch and connect the electrical cables to the switch terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.

(3) Place the switch in its housing in the bulkhead

EFFECTIVITY: ALL

BA

**33-27-00**

Page 403  
May 30/80

# *Concorde*

## MAINTENANCE MANUAL

and, from the front, secure it to the mounting plate with the nut and washer.

- (4) Ensure that the switch knob contains a filament, then refit the knob to the switch.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clip and reset the circuit breaker tripped before removal.
- (3) Press and release the associated steward call indicator lamp/switch in the toilet and check that the filament in the cancel-call indicator lamp/switch and the associated toilet call indicator lamps are lit.
- (4) Press and release the cancel-call indicator lamp/switch and check that all associated toilet call indicator lights are extinguished.
- (5) Place the toilet roof panel in position and push it upward to engage the spire fasteners.
- (6) Switch off and disconnect the electrical ground power as detailed in 24-41-00.

## 4. Passenger Cabin-to Steward Call Indicator Lamp/Switch

### A. Equipment and Materials

---

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

---

### B. Prepare

R

- (1) Trip the PASS CALL SUP circuit breaker M78, on panel 15-216, map ref.A22, and fit a safety clip.
- (2) Trip the appropriate reading lights transformer supply circuit breaker listed below and fit a safety clip.

EFFECTIVITY: ALL

BA

**33-27-00**

Page 404  
May 30/80

Printed in England

# Concorde

## MAINTENANCE MANUAL

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH FWD PASS RDG LTS TRANS SUP	13-216	L884	C8
LH FWD PASS RDG LTS TRANS SUP	13-216	L885	C9
RH AFT PASS RDG LTS TRANS SUP	13-215	L886	E11
LH AFT PASS RDG LTS TRANS SUP	13-215	L887	E12

- (3) Remove the appropriate air-vane and fairing assembly from the service panel. Pull the PSU inboard to release it from the locating and fixing brackets and lower the PSU on its hinges (Ref. 25-21-00) to gain access to the rear of the switch mounting plate.

### C. Remove

- (1) Unscrew the knob from the switch.
- (2) Using a tubular spanner, remove the nut and washer from the front of the switch.
- (3) Disconnect the electrical cables from the switch terminal and withdraw the switch from the rear of the mounting plate. Label the electrical cables to assist identification for reconnection.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the indicator lamp/switch to the mounting plate and, from the front, secure it friction-tight with the nut and washer.
- (3) Connect the electrical cables to the switch terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.

EFFECTIVITY: ALL

**33-27-00**

R

BA

Page 405  
Nov 30/77

# Concorde

## MAINTENANCE MANUAL

- (4) Tighten the securing nut.
- (5) Ensure that the switch knob contains a filament, then refit the knob to the switch.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- (3) Press and release the call switch. Check that the filament in the knob is lit, a tone signal is audible through the public address system and that the associated cabin call indicator lamps are lit.
- (4) Press and release the call switch again and check that all associated cabin call indicator lights are extinguished.
- (5) Close the PSU and push it upward to engage it with the locating and fixing brackets (25-21-00). Fit the air-vane and fairing assembly to the service panel.
- (6) Switch off and disconnect electrical ground power as detailed in 24-41-00.

R After SB 33-015 For A/C 001-001,

### R 5. Ceiling-mounted Indicator Lamp Filament Renewal

#### R A. Equipment and Materials

R

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### R B. Prepare to Renew Filament

- (1) Trip the PASS CALL SUP circuit breaker M78, on panel 15-216, map ref.A22, and fit a safety clip.

EFFECTIVITY: ALL

BA

# 33-27-00

Page 406  
Nov 30/77

# *Concorde*

## MAINTENANCE MANUAL

### R C. Renew Filament

R (1) Ease the lamp lens downward to release the rim  
R of the lens from the mounting in the ceiling  
R panel.

R (2) Renew the faulty filament.

R (3) Fit the lens to its opening in the ceiling panel  
R and push the lens upward until the rim of the  
R lens is engaged in its mounting in the ceiling  
R panel.

### R D. Conclusion

R (1) Reset the circuit breaker tripped before renewal.

R (2) Press and release the call switch on any passenger  
R service unit (PSU) in the appropriate forward or  
R rear cabin and verify that the filament is lit.  
R Press and release the call switch again to switch  
R the light off.

EFFECTIVITY: ALL

BA

Printed in England

**33-27-00**

Page 407  
Nov 30/77

# *Concorde*

## MAINTENANCE MANUAL

### CALL SYSTEMS - ADJUSTMENT/TEST

#### 1. General

This topic details the procedure for a Functional Test only, to prove that the call systems are electrically and functionally correct. Operational and System Tests are not considered necessary in this application.

#### 2. Functional Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test Flight Compartment (Deck) Steward-call System

- (1) Press and release the STEWARD CALL indicator lamp/switch on the flight compartment roof panel and check that a tone signal is audible through the public address system (Ref. 23-31-00) in the vestibule areas only, and that the FLIGHT DECK CALL indicator lamp on the forward steward's call panel and on each of the centre and rear steward's control panels light. Check that the four roof indicator repeater lamps light.
- (2) Press and release the CANCEL switch on the forward steward's call panel and check that the FLIGHT DECK CALL indicator light at each steward's panel is extinguished.
- (3) Repeat operations (1) and (2) at the centre and rear steward's control panels, in turn.
- (4) Press the FLIGHT DECK CALL indicator lamp/switch at the forward steward's call panel and check that the STEWARD CALL indicator lamp/switch on the flight compartment roof panel lights and that an audible warning is given through the pilot audible indicator in the flight compartment (Ref. 23-42-00). Release the lamp and check that the light is extinguished and the audible warning is terminated.
- (5) Repeat operation (4) at the centre and rear steward's control panels, in turn.

##### C. Test Cabin Crew Call System

- (1) Press and release the CABIN CREW CALL switch at the

EFFECTIVITY: ALL

BA

**33-27-00**

Page 501  
Feb 28/77

Printed in England



# *Concorde*

## MAINTENANCE MANUAL

forward steward's call panel and check for a tone signal through the public address system, in the vestibule areas only.

- (2) Repeat operation (1) at the centre and rear steward's control panels, in turn.

### D. Test Passenger Cabin Steward-call System

- (1) Press and release the call switch on any passenger service unit (PSU) in the forward cabin and check that the filament in the knob lights, a tone signal is audible through the public address system in the vestibule areas only, and that the following indicator lamps light:
  - (a) The FWD CABIN CALL indicator lamp on each of the forward and centre steward's control panels.
  - (b) The three forward ceiling indicator lamps in the cabin aisle.
- (2) Press the call switch again and check that all associated indicator lights are extinguished.
- (3) Repeat operations (1) and (2) at each forward cabin PSU, in turn.
- (4) Press and release the call switch on any PSU in the rear cabin and check that the filament in the knob lights, a tone signal is audible through the public address system in the vestibule areas only, and that the following indicator lamps light:
  - (a) The REAR CABIN CALL indicator lamp on each of the centre and rear steward's control panels.
  - (b) The three rear ceiling indicator lamps in the cabin aisle.
- (5) Press the call switch again and check that all associated indicator lights are extinguished.
- (6) Repeat operations (4) and (5) at each rear cabin PSU in turn.

### E. Test Toilet Steward-call System

- (1) Press and release the steward call indicator lamp/switch in the forward toilet and check that the filament in the knob lights, a tone signal is audible through the public address system in the

EFFECTIVITY: ALL

BA

**33-27-00**

Page 502  
Feb 28/77

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

vestibule areas only, and that the following indicator lamps light:

- (a) The FWD TOILET call indicator lamp on each of the forward, centre and rear steward's control panels.
  - (b) All the ceiling indicator lamps in the cabin aisle.
  - (c) The indicator lamp/switch outside the forward toilet door.
- (2) Press the indicator lamp/switch outside the forward toilet door and check that all toilet call indicator lights are extinguished.
- (3) Press and release the steward call indicator lamp/switch in the centre left toilet and check that the filament in the knob lights, a tone signal is audible through the public address system in the vestibule areas only, and that the following indicator lamps light:
- (a) The CENTRE TOILET call indicator lamp/switch on each of the forward, centre and rear steward's control panels.
  - (b) All the ceiling indicator lamps in the cabin aisle.
  - (c) The indicator lamp/switch outside the centre left toilet door.
- (4) Press the indicator lamp/switch outside the centre left toilet door and check that all toilet call indicator lights are extinguished.
- (5) Repeat operations (3) and (4) with respect to the two centre right toilets.

### F. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

R

BA

**33-27-00**

Page 503  
Feb 28/77

*Concorde*  
British airways  
MAINTENANCE MANUAL

STEWARDS' PANEL LIGHTING - DESCRIPTION AND OPERATION

1. General

RB Panel lighting was provided by electroluminescent (EL) panels  
RB which illuminated legends and other markings engraved on them.  
RB Mod 33F085 removes the power supplies to the EL panel and also  
RB the associated circuit breaker L9003 and panel connector L9008A.

PRINTED IN ENGLAND

EFFECTIVITY: ALL

BA

C808832

**33-28-00**

Page 1  
Mar 31/95

*Concorde*  
British airways  
MAINTENANCE MANUAL

RB

PANEL - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED  
IN 24-00-00.

1. General

This topic contains instructions necessary for the removal and installation of electroluminescent (EL) panels fitted on the Stewards' panel (1-221).

RB

2. Electroluminescent Panels

CAUTION: 'EL' PANELS ARE VULNERABLE TO DAMAGE BY SCRATCHING  
AND CRACKING. ENSURE THAT THE SCREWDRIVER DOES  
NOT DAMAGE THE POLISHED WALL OF THE PANEL.

RB

A. Prepare

- (1) Remove the cap, unscrew the clutch nut and withdraw the knob from any rotary switch fitted on the EL panel.

RB

B. Remove an EL Panel

- (1) Remove the screws and washers securing the EL panel to its mounting and remove the panel.

RB

RB

C. Install an EL Panel

- (1) Position the EL panel on its mounting and secure it with the screws and washers.

RB

RB

D. Conclusion

- (1) Where appropriate, fit each switch knob on its spindle, ensuring that the spindle drive spigot is engaged with the slot in the knob. Tighten the clutch nut and fit the end cap to the knob.

RB

EFFECTIVITY: ALL

BA

C808833

**33-28-00**

Page 401  
Mar 31/95

PRINTED IN ENGLAND

**END OF THIS  
SECTION**

**NEXT**

# *Concorde*

## MAINTENANCE MANUAL

### BAGGAGE COMPARTMENT LIGHTING - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig. 001 )

There are two baggage compartments, one forward under the floor aft of the nosewheel bay, and one at the rear of the passenger compartment. Lighting of the forward baggage compartment is by five filament lamps for general illumination, and a floodlamp to illuminate the baggage door area. Lighting of the rear baggage compartment is by six filament lamps, and a floodlamp to illuminate the rear baggage door area.

Primary control of the front and rear baggage compartment lighting is by an associated lighting control relay which is operated by the respective baggage door microswitch. Secondary control is by a light control switch in each baggage compartment.

The forward baggage compartment lighting control relay is mounted in the ground power panel (panel 10-123) in the forward underfloor racking, and the rear baggage compartment lighting control relay is mounted in panel 7-244 in the right-hand rear racking main structure.

#### 2. Filament Lamps

Each filament lamp is contained in a separate assembly with a protective translucent cover. The assemblies fit flush on to mounting plates fitted in each baggage compartment roof and spaced along the left and right sides.

#### 3. Floodlamps

The floodlamp assembly in the forward baggage compartment comprises a single contact bayonet lamp in an elliptical reflector housing containing a white diffused glass lens behind a protective metal grille. The lamp assembly is secured to a mounting plate which is fitted in the baggage compartment roof above the baggage compartment door.

The floodlamp assembly in the rear baggage compartment comprises a single contact bayonet lamp within a cover assembly, which forms a reflector housing, and is fitted with an adjustable visor. The lamp assembly is secured to a mounting plate fitted to a furnishing panel on the baggage compartment after bulkhead, above the baggage compartment door, and is guarded by a protective metal cage.

EFFECTIVITY: ALL

R


BA

**33-31-00**

Page 1  
May 30/77

# Concorde

## MAINTENANCE MANUAL



- Baggage Compartment Lamps and Equipment  
Figure 001

R EFFECTIVITY: ALL

BA

Printed in England

**33-31-00**


Page 2  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

### 4. Operation

#### A. Control (Ref. Fig. 002 )



- Baggage Compartment Lighting - Control  
Figure 002

The forward and rear baggage compartment filament lamps and door floodlamps are supplied from the ground power services 28 V a.c. busbar, through the contacts of the associated baggage compartment lighting control relay and the appropriate double-pole, two position (on-off) light control switch in each baggage compartment. Each relay is supplied from one phase of the ground power 115 V a.c. busbar, and is controlled by the operation of the associated baggage compartment door microswitch.

#### B. Functional Description (Ref. Fig. 003 )

With electrical supplies available, the opening of a baggage compartment door operates a microswitch which activates a door warning circuit (Ref. 52-71-00), and connects a 115 V a.c. supply to energize the associated lights control relay. When energized, the relay

EFFECTIVITY: ALL

R

BA

Printed in England


**33-31-00**

Page 3  
May 30/77



# Concorde

## MAINTENANCE MANUAL



CMB333100CAMD

- Baggage Compartment Lighting - Simplified Schematic  
Figure 003

EFFECTIVITY: ALL

**33-31-00**

R

BA

Page 4  
May 30/77

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

contacts close and connect a 28 V a.c. supply to the contacts of the associated double-pole lighting control switch. With the switch on, one set of contacts connects a supply to light the appropriate baggage compartment filament lamps and the other set of contacts connects a supply to light the door floodlamp.

EFFECTIVITY: ALL

R

BA

**33-31-00**

Page 5  
May 30/77

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

R

### BAGGAGE COMPARTMENT LIGHTING - TROUBLE SHOOTING

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. GENERAL

Faults are dealt with on a probability basis and identified as a result of testing. They can also develop on the ground or during flight.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para. 3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

The forward and the rear baggage compartment lighting circuits are similar, therefore the procedures and charts are applicable to either. Where two identical components are involved, i.e., one in each circuit, both references to the associated components listed in Table 101 are given, e.g., 'Renew Microswitch (10) or (11)'.

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

R

EFFECTIVITY: ALL

BA

C812188

**33-31-00**

Page 101  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

- C. Open the forward or rear baggage compartment door, as appropriate.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812189

**33-31-00**

Page 102  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting

- A. Prepare to trouble shoot (Ref. para. 2.).  
As appropriate, set forward or rear baggage compartment lights control switch to 'ON'. Check that all associated baggage compartment filament lamps and the door floodlamp are lit.

OK

NOT OK

1. One compartment filament fails to light - change filament. Retest.
2. Baggage compartment filaments lit but door floodlamp not lit - Chart 101.
3. Door floodlamp lit but compartment filaments not lit - Chart 102.
4. Compartment filaments and door floodlamp not lit - Chart 103.

- B. As appropriate, depress forward or rear baggage door microswitch, manually, and check that the associated baggage compartment lights and door floodlight go out.

NOT OK

Adjust or renew Microswitch (10) or (11).

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812190

# 33-31-00

Page 103  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

BAGGAGE COMPARTMENT  
FILAMENTS LIT BUT DOOR  
FLOODLAMP NOT LIT WHEN  
SWITCHED ON

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 101

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812191

# 33-31-00

Page 104  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

DOOR FLOODLAMP LIT BUT  
COMPARTMENT FILAMENTS NOT  
LIT WHEN SWITCHED ON

### GROUND EQUIPMENT REQUIRED

DESCRIPTION

PART NO.

GROUND POWER SUPPLY -  
MULTIMETER -

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 102

R

EFFECTIVITY: ALL

BA

C812192

# 33-31-00

Page 105  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

COMPARTMENT FILAMENTS  
AND DOOR FLOODLAMP NOT  
LIT WHEN SWITCHED ON

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.

Open baggage door  
and switch on  
light control  
switch.

Open other  
baggage door,  
front or rear,  
switch on light  
control switch,  
check all lamps  
lit.

YES

Remove Relay (8)  
or (9). Check for  
115 V a.c.  
between X1 and X2  
on relay socket.

NO

Refit Relay (8)  
or (9). \*Renew  
Micro-switch  
(10) or (11).  
Test lighting.

NO

YES

Check for open  
circuit in  
wiring between  
CB (3) and  
terminal block  
UG2746 on panel  
26-216.

YES

Check for 115 V  
a.c. output from  
CB (3).

NO

Renew relay (8)  
or (9). Is  
fault cleared?

NO

\*Renew Circuit  
Breaker (3). Test  
lighting.

\*Renew Switch  
(6) or (7).  
Test lighting.

Chart 103

R

EFFECTIVITY: ALL

BA

C812193

# 33-31-00

Page 106  
Mar 29/96

PRINTED IN ENGLAND



# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit Breaker 28 V	-	25-216	L763	Map ref.C2	24-50-00 R/I	
(2) Circuit Breaker 28 V	-	25-216	L762	Map ref.C3	24-50-00 R/I	
(3) Circuit Breaker 115 V	-	25-216	X368	Map ref.B4	24-50-00 R/I	
(4) Circuit Breaker 28 V	-	25-216	L764	Map ref.C5	24-50-00 R/I	
(5) Circuit Breaker 28 V	-	25-216	L765	Map ref.C4	24-50-00 R/I	
(6) Forward lights control switch	-	131	L771	Forward baggage compartment		
(7) Rear lights control switch	-	244	L772	Rear baggage compartment		
(8) Forward lights control relay	123 AB	10-213	L768	Forward underfloor racking	33-31-00 R/I	
(9) Rear lights control relay	-	7-244	L769	Rear racking	33-31-00 R/I	
(10) Forward door micro-switch	-	131	W308	Forward baggage compartment	52-31-21 R/I	
(11) Rear door microswitch	-	244	W304	Rear baggage compartment	52-31-11 R/I	

Component Identification  
Table 101

R

EFFECTIVITY: ALL

BA

C812265

# 33-31-00

Page 107  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

R

### BAGGAGE COMPARTMENT LIGHTING - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic contains instructions for the renewal of filaments in the forward and rear baggage compartments, and for the removal and installation of associated lamp assemblies, light control relays and light control switches.

Instructions for the removal and installation of each baggage compartment door microswitch are contained in Chapter 52.

#### 2. Baggage Compartment Filaments

##### A. Roof Lamp Filament Renewal

- (1) Ensure that the forward or rear baggage compartment light control switch is off.
- (2) Release the two quick-release fasteners securing the lamp cover to the lamp assembly and lower the cover on its hinges to gain access to the filament.
- (3) Renew the filament.
- (4) Close the lamp cover and secure it with the quick-release fasteners.
- (5) Make available electrical ground power as detailed in 24-41-00.
- (6) With the appropriate baggage compartment door open, switch on the light control switch and check that the filament is lit.
- (7) Switch off and disconnect electrical ground power as detailed in 24-41-00.

##### B. Forward Baggage Compartment Door Floodlamp Filament Renewal

- (1) Ensure that the forward baggage compartment light control switch is off.
- (2) Rotate the door floodlamp cover counter-clockwise and withdraw the cover from the lamp.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812668

# 33-31-00

Page 401  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

- (3) Renew the filament.
- (4) Refit the cover to the lamp and rotate the cover clockwise to lock the retainer spring.
- (5) Make available electrical ground power as detailed in 24-41-00.
- (6) With the forward baggage compartment door open, switch on the light control switch and check that the filament is lit.
- (7) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### C. Rear Baggage Compartment Door Floodlamp Filament Renewal

- (1) Ensure that the rear baggage compartment light control switch is off.
- (2) Remove the bolts and washers securing the protective cage to the furnishing panel on the rear baggage compartment aft bulkhead and remove the cage.
- (3) Remove the screws and washers securing the floodlamp cover to the baseplate and withdraw the cover sufficiently to gain access to the lampholder.
- (4) Remove the lampholder from the retainer clip and renew the filament.
- (5) Refit the lampholder to the retainer clip.
- (6) Refit the cover to the baseplate and secure it with the screws and washers.
- (7) Fit the cage to its mounting on the furnishing panel and secure it with the bolts and washers.
- (8) Make available electrical ground power as detailed in 24-41-00.
- (9) With the rear baggage compartment door open, switch on the light control switch, and check that the filament is lit.
- (10) Switch off and disconnect electrical ground power as detailed in 24-41-00.

R

EFFECTIVITY: ALL

BA

C812669

# 33-31-00

Page 402  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### 3. Baggage Compartment Roof Lamp

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Trip the FWD BAGGAGE LTS SUP circuit breaker L763, on panel 25-216, map ref.C2, or the AFT BAGGAGE LTS SUP circuit breaker L764 on panel 25-216, map ref.C5, as appropriate, and fit a safety clip.

#### C. Remove

- (1) Release the two quick-release fasteners securing the lamp cover to the lamp assembly and lower the cover on its hinges.
- (2) Remove the screws securing the lamp to its roof mounting and withdraw the lamp sufficiently to gain access to the terminal screws.
- (3) Disconnect the electrical cables from the terminals and remove the lamp.

#### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the lamp and connect the electrical cables to the terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (3) Fit the lamp to its roof mounting and secure it with the screws.
- (4) Close the lamp cover and secure it with the quick-release fasteners.

#### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812670

# 33-31-00

Page 403  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

- (2) Remove the safety clips and reset the circuit breaker tripped before removal.
- (3) With the appropriate baggage compartment door open and the light control switch on, check that the lamp is lit.
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.

#### 4. Forward Baggage Compartment Door Floodlamp

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clip	-

##### B. Prepare

- (1) Trip the FWD BAGGAGE DOOR FLOOD LT SUP circuit breaker L762, on panel 25-216, map ref.C3, and fit a safety clip.

##### C. Remove

- (1) Rotate the floodlamp cover counter-clockwise and withdraw the cover from the lamp.
- (2) Remove the screws securing the lamp to its roof mounting and withdraw the lamp sufficiently to gain access to the terminal screws.
- (3) Disconnect the electrical cables from the lamp terminals and remove the lamp.

##### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the lamp and connect the electrical cables to the lamp terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (3) Fit the lamp to its roof mounting and secure it with the screws.

R

EFFECTIVITY: ALL

BA

C812671

**33-31-00**

Page 404  
Mar 29/96

PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

- (4) Fit the cover to the lamp and rotate the cover clockwise to lock the retainer spring.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clip and reset the circuit breaker tripped before removal.
- (3) With the forward baggage compartment door open and the light control switch on, check that the floodlamp is lit.
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.

## 5. Rear Baggage Compartment Door Floodlamp

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clip	-

### B. Prepare

- (1) Trip the AFT BAGGAGE DOOR FLOOD LT SUP circuit breaker L765, on panel 25-216, map ref.C4, and fit a safety clip.

### C. Remove

- (1) Remove the bolts and washers securing the protective cage to the furnishing panel on the rear baggage compartment aft bulkhead and remove the cage.
- (2) Remove the screws and washers securing the floodlamp cover to the baseplate and withdraw the cover sufficiently to gain access to the lampholder.
- (3) Remove the lampholder from the retainer clip and disconnect the electrical cables from the lampholder.
- (4) Withdraw the cover clear of the baseplate.
- (5) Remove the bolts and washers securing the baseplate to the bulkhead and remove the baseplate.

R

EFFECTIVITY: ALL

BA

C812672

# 33-31-00

Page 405  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Secure the baseplate to the bulkhead with the bolts and washers, friction-tight.
- (3) Adjust the position of the baseplate to enable the lamp to illuminate the door area. Tighten the securing bolts.
- (4) Insert the electrical cable through the grommet at the rear of the lamp cover and connect the cable to the lampholder, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (5) Fit the lampholder to the retainer clip.
- (6) Fit the cover to its mounting on the baseplate and secure it with the screws and washers.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clip and reset the circuit breaker tripped before removal.
- (3) With the rear baggage compartment door open, switch on the light control switch and check that the floodlamp is lit.
- (4) Adjust the cowl on the lamp cover so that the baggage compartment door area is illuminated.
- (5) Refit the protective cage to the furnishing panel and secure it with the bolts and washers.
- (6) Switch off and disconnect electrical ground power as detailed in 24-41-00.

## 6. Forward Baggage Compartment Light Control Relay

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clip	-

R

EFFECTIVITY: ALL

BA

C812673

# 33-31-00

Page 406  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### B. Prepare

- (1) Trip the circuit breakers listed below and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH LDG/TAXI LT CONT	13-216	L42	B9
RH LDG/TAXI LT SUP	13-216	L46	B8
LH LDG/TAXI LT CONT	14-215	L41	E11
GRND POWER LTS SUP	25-216	X369	B9
GRND POWER SERVICES SUP	25-216	X368	B5
FWD BAGGAGE LTS SUP	25-216	L763	C2
FWD BAGGAGE DOOR FLOOD LT SUP	25-216	L762	C3

- (2) Open service compartment door 123 AB (Ref. 52-41-11) to gain access to the light control relay in panel 10-123, mounted in the forward underfloor racking.

### C. Remove

- (1) Release the two hold-down fasteners from the panel hold-down hooks.
- (2) Withdraw the panel from its mounting rack and remove the quick-release cable clamps to detach the cables from the top of the panel. When the panel is clear of the rack, lower the panel on to a suitable support.
- (3) Remove the screws securing the top cover to the panel and remove the cover.
- (4) Release the relay retaining clamp and withdraw the relay from its socket.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the relay into its socket and secure it with the retaining clamp.

R

EFFECTIVITY: ALL

BA

C812674

# 33-31-00

Page 407  
Mar 29/96



# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

- (3) Fit the top cover to the panel and secure it with the screws.
- (4) Place the panel on the end of the rack support rails and secure the cables to the top of the panel with the cable clamps.
- (5) Slide the panel into the racking and secure it with the hold-down fasteners.
- (6) Check that the panel is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Reset the circuit breakers tripped before removal.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Open the forward baggage compartment door and switch on the light control switch. Check that the forward baggage compartment lamps and the door floodlamp are lit.
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.
- (5) Close and secure service compartment door 123 AB (Ref. 52-41-11).

## 7. Rear Baggage Compartment Light Control Relay

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

### B. Prepare

- (1) Ensure that the rear baggage compartment door is closed.
- (2) Trip the circuit breakers listed below and fit safety clips.

R

EFFECTIVITY: ALL

BA

C812675

# 33-31-00

Page 408  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
AFT BAGGAGE LTS SUP	25-216	L764	C5
AFT BAGGAGE DOOR FLOOD LT SUP	25-216	L765	C4
GRND POWER SERVICES SUP	25-216	X368	B4

### C. Remove

- (1) Remove the lower furnishing panel from the rear right-hand electronic racking to gain access to the light control relay at the bottom of the outboard sidewall.
- (2) Remove the securing screws and withdraw the relay from its socket.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Fit the relay into its socket and secure it with the retaining screws.
- (3) Refit the furnishing panel to the racking.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- (3) Open the rear baggage compartment door and switch the light control switch on. Check that the rear baggage compartment lamps and the door floodlamp are lit.
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.

R EFFECTIVITY: ALL

BA

C812676

# 33-31-00

Page 409  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### 8. Baggage Compartment Light Control Switches

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Trip the associated circuit breakers listed below and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
FWD BAGGAGE LTS SUP	25-216	L763	C2
FWD BAGGAGE DOOR FLOOD LT SUP	25-216	L762	C3
AFT BAGGAGE LTS SUP	25-216	L764	C5
AFT BAGGAGE DOOR FLOOD LT SUP	25-216	L765	C4

- (2) Open the appropriate baggage compartment door to gain access to the light control switch.

NOTE: There is direct access to the light control switch.

#### C. Remove

- (1) Disconnect the electrical cables from the switch terminals.
- (2) Using a tubular spanner, remove the nut and washer from the front of the switch, and withdraw the switch complete with tabwasher from the rear of its mounting panel.

R

EFFECTIVITY: ALL

BA

C812730

# 33-31-00

Page 410  
Mar 29/96

PRINTED IN ENGLAND

# *Concorde*

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Position the tabwasher on the switch and insert the switch through the aperture from the rear of the mounting panel, ensuring that the tab on the washer engages the locating hole in the panel.
- (3) Secure the switch with the nut and washer.
- (4) Connect the electrical cables to the switch terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- (3) With the appropriate baggage compartment door open, switch on the light control switch and check that the baggage compartment lamps and the door floodlamp are lit.
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.

R

EFFECTIVITY: ALL

BA

C812731

# 33-31-00

Page 411  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

### BAGGAGE COMPARTMENT LIGHTING - ADJUSTMENT/TEST

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Baggage compartment lighting tests are contained under two headings: Operational Test, and Functional Test. A System Test is not considered necessary in this application. The Operational Test details the procedure for checking the operation of the baggage compartment lights. The Functional Test checks the baggage compartment lighting in more detail to prove that it is electrically and functionally correct.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test Forward Baggage Compartment Lighting

- (1) With the forward baggage compartment door open and the baggage compartment lights control switch at OFF, check that the baggage compartment lights and the door floodlight are extinguished.
- (2) Set the forward baggage compartment lights control switch to "ON" and check that the filament lamps and the door floodlamp are lit.
- (3) Depress the baggage compartment door microswitch manually and check that the baggage compartment lights and the door floodlight are extinguished.
- (4) Set the lights control switch to "OFF".

##### C. Test Rear Baggage Compartment Lighting

- (1) With the rear baggage compartment door open and the rear baggage compartment lights control switch at OFF, check that the baggage compartment lights and the door floodlight are extinguished.
- (2) Set the rear baggage compartment lights control switch to "ON" and check that the filament lamps and the door floodlamp are lit.

EFFECTIVITY: ALL

BA

Printed in England

**33-31-00**

Page 501  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

(3) Depress the rear baggage compartment door microswitch manually and check that the baggage compartment lights and the door floodlight are extinguished.

(4) Set the lights control switch to "OFF".

### D. Conclusion

(1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

## 3. Functional Test

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

### B. Prepare

(1) Make available electrical ground power as detailed in 24-41-00.

### C. Test Forward Baggage Compartment Lighting

(1) Electrically isolate the supplies to the forward baggage compartment lights, the baggage door floodlight, and baggage compartment lights control relay, by tripping the associated circuit breakers listed below, and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
FWD BAGGAGE LTS SUP	25-216	L763	C2
FWD BAGGAGE DOOR FLOODLT SUP	25-216	L762	C3
GRND POWER SERVICES SUP	25-216	X368	B4

EFFECTIVITY: ALL

# 33-31-00

Page 502  
Feb 29/76

Printed in England

# Concorde

## MAINTENANCE MANUAL

(2) With the forward baggage compartment door open and the lights control switch at OFF, check that baggage compartment lights and the door floodlight are extinguished.

R (3) Remove the safety clip and reset the FWD  
R BAGGAGE LTS SUP circuit breaker.

(4) Set the baggage compartment lights control switch to "ON" and check that the baggage compartment lights are extinguished.

R (5) Remove the safety clip and reset the FWD BAGGAGE  
R DOOR FLOODLT SUP circuit breaker. Check that the door floodlight is extinguished.

R (6) Remove the safety clip and reset the GRND POWER  
R SERVICES SUP circuit breaker. Check that the  
R compartment lamps and door flood-lamp are lit.

(7) Depress the baggage door microswitch manually and check that the compartment lights and door floodlight are extinguished.

(8) Set the baggage compartment lights control switch to "OFF".

### D. Test Rear Baggage Compartment Lighting

(1) Electrically isolate the supplies to the rear baggage compartment lights, the baggage door floodlight, and baggage compartment lights control relay, by tripping the associated circuit breakers listed below, and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
---------	-------	--------------------	-------------

R AFT BAGGAGE	25-216	L764	C5
R LTS SUP			

R AFT BAGGAGE	25-216	L765	C4
R DOOR FLOODLT SUP			

R GRND POWER	25-216	X368	B4
R SERVICES SUP			

(2) With the rear baggage compartment door open and

EFFECTIVITY: ALL

BA

# 33-31-00

Page 503  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

the lights control switch at OFF, check that baggage compartment lights and the door floodlight are extinguished.

- R (3) Remove the safety clip and reset the AFT BAGGAGE  
R LTS SUP circuit breaker.
- (4) Set the baggage compartment lights control switch to "ON" and check that the baggage compartment lights are extinguished.
- R (5) Remove the safety clip and reset the AFT BAGGAGE  
R DOOR FLOODLT SUP circuit breaker. Check that the door floodlight is extinguished.
- R (6) Remove the safety clip and reset the GRND POWER  
R SERVICES SUP circuit breaker. Check that the  
R compartment lamps and door flood-lamp are lit.
- (7) Depress the baggage door microswitch manually and check that the compartment lights and door floodlight are extinguished.
- (8) Set the baggage compartment lights control switch to "OFF".

### E. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-31-00**

Page 504  
Aug 30/75



# *Concorde*

## MAINTENANCE MANUAL

### SERVICE LIGHTING - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig.001 and 002)

General illumination of the nose, equipment bays, landing gear bays, toilet servicing compartments and ground refuelling panel is provided by service lamps which light whenever the aircraft is connected to an electrical ground power supply, provided that a ground lighting control switch on the oxygen panel in the flight compartment is switched on.

The instruments on the refuelling panel are integrally lit from a 115 V ground power supply through a 115/5.9 V control transformer, with the ground lighting control switch either on or off.

#### 2. Service Lamp (Ref. Fig. 001 )

Each lamp comprises a base, containing a lampholder fitted with a filament, and a lens protected with a wire guard and secured to the base with screws. Electrical cables are connected to terminals in the base, which is bolted to the aircraft structure.

#### 3. Control Transformer

The control transformer, which is mounted in the forward baggage compartment, has a stepped primary supplied from a 115 V a.c., and controls the output voltage in five steps up to 5.9 V. The secondary output voltages are protected by fuses within the transformer case, and electrical connections are made at terminals on top of the transformer.

#### 4. Operation (Ref. Fig. 003 )

All the lamps, except the refuelling panel floodlamp and integral lamps, light whenever there is a supply at the ground power 115 V a.c. busbar, provided that the ground lighting control switch on the oxygen panel in the flight compartment is switched on (Ref. 24-41-00).

A microswitch, operated by opening the refuelling panel access door, energizes a panel door relay which has two pairs of contacts. One pair of these contacts connects the supply from the ground service lights 28 V a.c. busbar to light the refuelling panel floodlamp. The other pair of contacts connects the supply from the ground power 115 V a.c. busbar via the 115/5.9 V control transformer, to supply the refuelling panel integral lighting, which is thus independent of the position of the ground lighting control switch.

EFFECTIVITY: ALL

BA


Printed in England

# 33-32-00

Page 1  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL



- Service Lights - Nose and Equipment Bays  
Figure 001

EFFECTIVITY: ALL

BA


Printed in England

**33-32-00**

Page 2  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL



- Service Lights - Landing Gear Bays, Toilet Servicing Compartments and Refuelling Panel  
Figure 002

EFFECTIVITY: ALL

BA


Printed in England

**33-32-00**

Page 3  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL



- Service Lights - Simplified Schematic  
Figure 003

EFFECTIVITY: ALL

**33-32-00**

R

BA

Page 4  
Nov 30/75

Printed in England

# Concorde

## MAINTENANCE MANUAL

R

### SERVICE LIGHTING - TROUBLE SHOOTING

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

The lighting circuits for each service area are similar, therefore one chart is provided, applicable to each circuit. Where identical components are involved, i.e., one in each circuit, the references to the associated components listed in Table 101 are given, e.g., 'Renew appropriate CB (2) to (7)'. Separate charts are provided for the refuelling panel floodlamp and the refuelling panel instrument lighting.

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

R

EFFECTIVITY: ALL

BA

C812835

**33-32-00**

Page 101  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting

- A. Prepare to trouble shoot (Ref. para.2.).  
Set the GROUND LIGHTING switch to "ON".  
Check that the service lamps in the following compartments are lit:

- (a) Nose shell.
  - (b) Forward equipment bay.
  - (c) Nose landing gear bay.
  - (d) Equipment bay above nose landing gear bay.
  - (e) LH and RH sanitation points.
  - (f) LH and RH main landing gear bays.
  - (g) Rear equipment bay.
- IF -

OK

NOT OK

1. One service lamp fails to light - change filament.
2. Service lamps in associated compartments not lit - Chart 101.

B.

Open the refuelling panel access door and check that floodlamp is lit, and that instruments on panel are integrally lit.

NOT OK

1. Flood lamp not lit - Chart 102.
2. One group of instruments not lit - renew Transformer (11).
3. No instruments lit - Chart 103.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812858

**33-32-00**

Page 102  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

SERVICE LAMPS IN  
ASSOCIATED COMPARTMENTS  
NOT LIT WHEN SWITCHED  
ON.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	
MULTIMETER -	

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 101

R EFFECTIVITY: ALL

BA

C812859

# 33-32-00

Page 103  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

REFUELLING PANEL FLOODLAMP NOT  
LIT WHEN SWITCHED ON AND  
REFUELLING PANEL ACCESS DOOR  
OPEN.

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

NOTE: Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 102

 $\mathbb{R}$ 

EFFECTIVITY: ALL

BA

C812860

**33-32-00**

Page 104  
Mar 29/96



# Concorde

## MAINTENANCE MANUAL

NO INSTRUMENTS ON THE  
REFUELLING PANEL  
LIT WHEN PANEL ACCESS  
DOOR OPEN.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 103

R

EFFECTIVITY: ALL

BA

C812861

# 33-32-00

Page 105  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL/ PANEL ZONE		EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 115 V	-	25-216	X369	Map ref.B5	24-50-00 R/I	
(2) Circuit breaker 28 V	123 AB	10-123	L633	Forward underfloor racking	24-41-00 24-50-00 R/I	
(3) Circuit breaker 28 V	123 AB	10-123	L634	Forward underfloor racking	24-41-00 24-50-00 R/I	
(4) Circuit breaker 28 V	123 AB	10-123	L635	Forward underfloor racking	24-41-00 24-50-00 R/I	
(5) Circuit breaker 28 V	123 AB	10-123	L636	Forward underfloor racking	24-41-00 24-50-00 R/I	
(6) Circuit breaker 28 V	123 AB	10-123	L637	Forward underfloor racking	24-41-00 24-50-00 R/I	
(7) Circuit breaker 28 V	123 AB	10-123	L638	Forward underfloor racking	24-41-00 24-50-00 R/I	
(8) Circuit breaker 115 V	-	25-216	Q635	Map ref.B8	24-50-00 R/I	
(9) GROUND LIGHTING switch	-	20-215	X371	Flight compartment racking	24-41-00 R/I	
(10) Service lights 115/28 V transformer	123 AB	10-123	X372	Forward underfloor racking	24-41-12 R/I	
(11) Refuel panel integral lights transformer	-	132	L752	Forward baggage compartment	33-32-32 R/I	

PRINTED IN ENGLAND

R EFFECTIVITY: ALL

BA

C812862

# 33-32-00

Page 106  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL/ PANEL ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
				MAINT. TOPIC	WIRING DIAGRAM
(12) Refuel panel light supply relay	123 AB 10-123	Q578	Forward underfloor racking		
(13) Ground service lights 28 V a.c. busbar	123 AB 10-123	31X	Forward underfloor racking	24-41-00 DO	
(14) Refuel panel door microswitch	- 194	Q548	Refuel panel access door	28-24-00 R/I	

Component Identification  
Table 101

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812863

**33-32-00**

Page 107  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

R

### SERVICE LIGHTING - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic details the operations necessary for the replacement of service lamp filaments and for the removal and installation of service lamp assemblies.

Service lamps are located in the nose shell, forward and rear equipment bays, nose landing gear bay and refuelling panel, left and right landing gear bays, left and right sanitation points and the equipment bay above the nose landing gear bay. All service lamps are identical, and electrical connections are made at terminals on the base of the lamp which is bolted to the aircraft structure.

#### 2. Service Lamp Filament

##### A. Prepare

- (1) Ensure that the GROUND LIGHTING control switch on the oxygen panel 20-215 is at OFF.

##### B. Replace Filament

- (1) Release the screws securing the lens protective cover to the base and remove both lens and cover.
- (2) Remove the filament and fit a replacement.
- (3) Position the lens and protective cover on the base and secure them with the screws.

##### C. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Select "ON" at the GROUND LIGHTING switch on the oxygen panel 20-215 and check that the lamp lights.
- (3) Switch off and disconnect electrical ground power as detailed in 24-41-00.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812587

# 33-32-00

Page 401  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### 3. Service Lamp

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Set the GROUND LIGHTING control switch on the oxygen panel 20-215 to "OFF".
- (2) Gain access to the service lighting circuit breakers on panel 10-123 by opening service compartment door 123 AB (Ref. 52-41-11).
- (3) Trip the associated circuit breaker listed below and fit a safety clip.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF
Equipment bay (above nose well) and nose shell	10-123	L633	-
RH sanitation point RH landing gear bay	10-123	L634	-
Rear equipment bay	10-123	L635	-
Nose landing gear bay refuelling panel	10-123	L636	-
LH sanitation point LH landing gear bay	10-123	L637	-
Forward equipment bay	10-123	L638	-

#### C. Remove

- (1) Release the two screws securing the lamp to the aircraft structure.
- (2) Support the lamp and disconnect the electrical cables.
- (3) Remove the lamp clear of the aircraft structure.

R

EFFECTIVITY: ALL

BA

C812588

# 33-32-00

Page 402  
Mar 29/96

PRINTED IN ENGLAND

# *Concorde*

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the lamp and connect the electrical cables to the terminals, ensuring that the connections are made in accordance with the cable identification and the applicable wiring diagram.
- (3) Secure the lamp to the aircraft structure with the screws.
- (4) Check that the lamp is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Remove the safety clip and reset the associated circuit breaker tripped before removal.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Set the GROUND LIGHTING control switch to "ON" and check that the service lamp lights. Set the control switch to "OFF".
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.
- (5) Close the service compartment door 123 AB (Ref. 52-41-11).

R

EFFECTIVITY: ALL

BA

C812589

# 33-32-00

Page 403  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

R

### SERVICE LIGHTING - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic details the procedure for an Operational Test only. Functional and System Tests are not considered necessary in this application.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

NOTE: Ensure that the GROUND LIGHTING switch on the oxygen panel 20-215 is at ON.

##### B. Test

- (1) Check that the service lamps in each compartment listed below are lit:
  - (a) Nose shell.
  - (b) Forward equipment bay.
  - (c) Nose landing gear bay.
  - (d) Equipment bay above nose landing gear bay.
  - (e) LH and RH sanitation points.
  - (f) LH and RH main landing gear bays.
  - (g) Rear equipment bay.
- (2) Open the refuelling panel access door and check that the floodlamp is lit and that the instruments on the panel are integrally lit.
- (3) Close the refuelling panel access door.

##### C. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812572

# 33-32-00

Page 501  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

### 115/5.9 V TRANSFORMER - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

The 115/5.9 V transformer is supplied from the ground power 115 V a.c. busbar, when the refuel control panel access doors are open (Ref. 28-24-00), and provides a 5.9 V output to light the refuelling panel integral filaments.

The transformer is secured to a mounting bracket fitted on a vertical floor strut located behind the sidewall panels on the right side of the forward baggage compartment, close to the baggage compartment door. Four bolts and washers secure the transformer to its mounting bracket. Electrical connections are made at terminals fitted with nuts and washers, on top of the transformer case. The terminals are protected by a terminal cover attached to the transformer case by two screws.

#### 2. 115/5.9 V Transformer

##### A. Equipment and Materials

---

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

---

##### B. Prepare

- (1) Ensure that the refuel control panel access door is closed.
- (2) Trip the GROUND POWER REFUEL CONT & IND circuit breaker, Q635 on panel 25-216, map ref.B8, and fit a safety clip.
- (3) Open the forward baggage compartment door.
- (4) Gain access to the transformer by removing the baggage compartment sidewall panel VS (Ref. 25-52-00).

##### C. Remove

- (1) Remove the transformer terminal cover and disconnect

EFFECTIVITY: ALL

BA

# 33-32-32

Page 401  
Jun 30/75



# *Concorde*

## MAINTENANCE MANUAL

the cables from the terminals.

- (2) Refit the terminal cover.
- (3) Support the transformer, remove the four securing bolts and washers at the base of the transformer and lift the transformer from its mounting.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the transformer on its mounting bracket and secure it with the four bolts and washers.
- (3) Remove the terminal cover from the transformer.
- (4) Connect the electrical cables to the transformer terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (5) Refit the terminal cover.
- (6) Check that the transformer is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Remove the safety clip and reset the GROUND POWER REFUEL CONT & IND circuit breaker.
- (2) Make available electrical ground power as detailed in 24-41-00.
- (3) Open the refuel control panel access door and check that the instruments on the panel are integrally lit.
- (4) Close the refuel control panel access door.
- (5) Refit the baggage compartment sidewall panel VS (Ref. 25-52-00).
- (6) Close the forward baggage compartment door.
- (7) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

# 33-32-32

Page 402  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

### NAVIGATION LIGHTS - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig. 001 )

The navigation lights show the position of the aircraft in flight and on the ground by means of lamp units, mounted one in the outer leading edge of each wing and one in the tail cone. The colour of each light identifies the left, right or rear part of the aircraft, and all three lights are controlled by a switch mounted on the flight compartment roof panel.

#### 2. Wing Lamp Unit

Each wing lamp unit comprises a parallel beam light generator mounted inside the wings and perpendicular to the wing leading edge, a leading edge lens assembly and a 115/12 V step-down transformer, mounted close to the parallel beam light generator.

The parallel beam light generator comprises a 12 V 100 W quartz halogen filament in a sealed beam unit, mounted on a light-alloy optical guide that is polished internally and protected by a dust seal.

The leading edge lens assembly consists of a stainless steel receptacle containing a coloured glass optical system, red for the left wing and green for the right, elliptically shaped at one end and shaped to the wing leading edge profile at the other. The receptacle is secured to the wing leading edge upper and lower surfaces.

#### 3. Tail Lamp Unit

The tail lamp unit is a part of a navigation/anti-collision lamp assembly mounted in the tail cone. The navigation lamp comprises two 8.5 V 7.3 A filaments behind clear lenses and a 115/6.2 V step-down transformer.

#### 4. Operation

##### A. Control (Ref. Fig. 002 )

The navigation lights are supplied from one phase of No.1 ground/flight 115 V a.c. busbar, and are controlled by the operation of a single-pole two-position toggle switch engraved NAV, ON - OFF, mounted on the rear of the flight compartment roof panel (panel 4-211).

##### B. Functional Description

EFFECTIVITY: ALL


BA

**33-41-00**

Page 1  
Aug 30/77

# Concorde

## MAINTENANCE MANUAL



Navigation Lamps  
Figure 001

EFFECTIVITY: ALL

BA


Printed in England

# 33-41-00

Page 2  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL



CMB 3341 000BAM0

### - Navigation Lights - Control Figure 002

When electrical supplies are available and ON is selected at the NAV lights control switch, the 115 V single-phase supply is connected to each wing lamp transformer, which provides a 12 V a.c. output to light the associated 100 W quartz halogen filament, and to the tail lamp transformer, which provides a 6.2 V a.c. output to light the two 7.3 A filaments in parallel. When OFF is selected at the NAV lights switch the 115 V supply is interrupted and all navigation lights are extinguished.

EFFECTIVITY: ALL

**33-41-00**

R

BA

Page 3  
Aug 30/77

Printed in England

# Concorde

## MAINTENANCE MANUAL

R

### NAVIGATION LIGHTS - TROUBLE SHOOTING

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the specified rectification action.

If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, and that electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

#### 2. Preparation

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Ground power supply	-
Multimeter	-

B. Ensure that the associated circuit breaker is set (Ref. Table 101).

C. Make available electrical ground power as detailed in 24-41-00.

R

EFFECTIVITY: ALL

BA

C812249

# 33-41-00

Page 101  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting

- A. Prepare to trouble shoot (Ref. para.2.). Set the NAV lights control switch on the flight compartment roof panel to "ON" and check that both wing navigation lamps and the twin navigation filaments in the tail navigation/anti-collision lamp are lit. IF -

NOT OK

1. Wing and tail navigation lamps not lit - check for 115 V a.c. output from CB (1). IF OK - renew Switch (2). IF NOT OK - renew CB (1).
2. One wing navigation lamp not lit - check for 115 V a.c. at the output terminals of Transformer (3) or (4). IF OK - renew sealed beam unit of associated Navigation Lamp (5) or (6). IF NOT OK - renew associated Transformer (3) or (4).
3. Wing lamps lit but both tail navigation lamp filaments not lit - check earth on pin B of tail navigation lamp free connector. IF NOT OK - check earth fault in wiring between pin B and earth point UN-313-9 on structure in zone 313. IF OK - check for 115 V a.c. at pin A of connector. If no voltage - locate and rectify open circuit in wiring between pin A and terminal block UG1310 in equipment bay, zone 151. If voltage present - renew Tail Navigation/Anti-collision Lamp (7).
4. If one filament in tail navigation lamp not lit - renew Tail Navigation/Anti-collision Lamp (7).

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812250

# 33-41-00

Page 102  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 115 V	-	14-215	L1	Map ref.D11	24-50-00 R/I	33-41-11
(2) Navigation lights control switch	-	4-211	L2	Flight compartment roof panel	33-00-00 R/I	33-41-11
(3) Navigation lamp (RH wing) transformer	-	614	L6	RH wing outer leading edge	33-41-21 R/I	33-41-11
(4) Navigation lamp (LH wing) transformer	-	514	L7	LH wing outer leading edge	33-41-21 R/I	33-41-11
(5) RH wing navigation lamp	-	614	L3	RH wing outer leading edge	33-41-21 R/I	33-41-11
(6) LH wing navigation lamp	-	514	L4	LH wing outer leading edge	33-41-21 R/I	33-41-11
(7) Tail navigation/ anti- collision lamp	-	313	L5	Tail cone	33-41-41 R/I	33-41-11

Component Identification  
Table 101

R

EFFECTIVITY: ALL

BA

C812251

# 33-41-00

Page 103  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

R

### NAVIGATION LIGHTS - REMOVAL/INSTALLATION

#### 1. General

Instructions for the removal and installation of the navigation lights control switch, mounted on the rear switch panel of the flight compartment roof panel, are contained in 33-00-00.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812252

# 33-41-00

Page 401  
Mar 29/96



# Concorde

## MAINTENANCE MANUAL

R

### NAVIGATION LIGHTS - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic contains an Operational Test which details the procedure for checking the operation of the navigation lights. Functional and System Tests are not considered necessary in this application.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test

- (1) Set the NAV lights control switch on the flight compartment roof panel (panel 4-211) to "ON".
- (2) Check that the three navigation lamps are lit as follows:
  - (a) Right wing outer leading edge, sealed beam unit - green.
  - (b) Left wing outer leading edge, sealed beam unit - red.
  - (c) Tail cone, twin filaments - white.
- (3) Return the switch to "OFF" and check that the three navigation lights are extinguished.

##### C. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812253

# 33-41-00

Page 501  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

R

### NAVIGATION LIGHT ASSEMBLY (WINGS) - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General (Ref. Fig. 401)

This topic contains instructions for the renewal of the sealed beam unit in a wing navigation lamp assembly, and for the removal and installation of the various navigation lamp assembly components.

The sealed beam unit forms an integral part of the lamp assembly and consists of a light generator, heat sink and mounting plate. The complete lamp assembly comprises the sealed beam unit, a 115/12 V step-down transformer, sealed beam unit support and optical guide, and a leading edge lens assembly.

The wing navigation lamp assemblies are mounted one in the outer leading edge of each wing. Access to the transformer, sealed beam unit, sealed beam unit support and optical guide is gained through a wing upper access panel. The lens assembly is secured to the wing by screws and forms part of the outer wing leading edge.

#### 2. Sealed Beam Unit - Renewal

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

##### B. Prepare

- (1) Ensure that the NAV lights control switch on the flight compartment roof panel is at "OFF".
- (2) Trip the NAV LTS SUP circuit breaker Li, on panel 14-215, map ref.D11, and fit a safety clip.
- (3) Remove the screws securing the access panel to the top of the wing above the navigation lamp and remove the panel to gain access to the sealed beam unit.

R

EFFECTIVITY: ALL

BA

C812778


# 33-41-21

Page 401  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



Wing Navigation Lamp Assembly - Installation  
Figure 401

**33-41-21**



Page 402  
Mar 29/96

EFFECTIVITY: ALL

BA

# Concorde

## MAINTENANCE MANUAL



Wing Navigation Lamp Assembly  
Figure 402

CMB 33 41 21 4 ACM0 00

**33-41-21**

Page 403  
Mar 29/96

EFFECTIVITY: ALL

BA

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

### C. Renew

- (1) Disconnect the electrical cables from the terminals on the transformer and release the cables from the cable clip.
- (2) Release the fasteners securing the sealed beam unit mounting plate to its support, manipulate the unit to disengage the locating spigots from the mounting plate and withdraw the unit through the wing access opening.
- (3) Fit a replacement sealed beam unit to its support inside the wing, ensuring that the locating spigots on the support engage the locating holes in the mounting plate. Secure the mounting plate to the support with the fasteners.

NOTE: Modification 33D005 introduces a modified navigation lamp, ceramic gaskets and tubular spacers to produce a "sandwich" antivibration mounting. The modified lamp has enlarged bolt holes through which a spacer passes providing the load path upon which the bolts tighten. Two ceramic gaskets sandwiched around the navigation lamp provide the antivibration mounting whilst still providing a heat path.

The preparation, renewal and conclusion tasks for the sealed beam unit are identical for the modified navigation lamp, except that the ceramic gaskets and spacers should be assembled in accordance with Fig. 402.

- (4) Connect the electrical cables to the transformer terminals and secure the cables with the cable clip.

### D. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clip and reset the circuit breaker tripped before renewal.
- (3) Set the NAV lights control switch to "ON" and check that the navigation lamp is lit. Return the switch to "OFF".
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

C812779

# 33-41-21

Page 404  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

### 3. Navigation Light Transformer - Removal/Installation

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Ensure that the NAV lights control switch on the flight compartment roof panel is at "OFF".
- (2) Trip the NAV LTS SUP circuit breaker L1, on panel 14-215, map ref.D11, and fit a safety clip.
- (3) Remove the screws securing the access panel to the top of the wing above the navigation lamp and remove the panel to gain access to the transformer.

#### C. Remove

- (1) Disconnect the electrical cables from the transformer terminals.
- (2) Disconnect the transformer electrical connector.
- (3) Disconnect the earth connector from its fixing point on the wing structure.
- (4) From the bottom side of the wing, remove the screws securing the transformer to its mounting inside the wing and withdraw the transformer through the access opening.

#### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Position the transformer on its mounting inside the wing and, from the bottom side of the wing, secure the transformer to the mounting with the screws.
- (3) Connect the electrical cables to the transformer terminals.
- (4) Connect the transformer electrical connector, ensuring that the mating surfaces are clean and undamaged.

R

EFFECTIVITY: ALL

BA

C812780

# 33-41-21

Page 405  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

- (5) Connect the earth connector to its fixing point on the wing structure.
- (6) Check that the transformer is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clip and reset the circuit breaker tripped before removal.
- (3) Set the NAV lights control switch to "ON" and check that the navigation lamp is lit. Return the switch to "OFF".
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.
- (5) Refit the access panel to the wing and secure it with the screws.

## 4. Sealed Beam Unit Support and Optical Guide - Removal/Installation

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

### B. Prepare

- (1) Ensure that the NAV lights control switch on the flight compartment roof panel is at "OFF".
- (2) Trip the NAV LTS SUP circuit breaker L1, on panel 4-215, map ref.D11, and fit a safety clip.
- (3) Remove the screws securing the access panel to the top of the wing above the navigation lamp and remove the panel to gain access to the sealed beam unit support and optical guide.
- (4) Remove the sealed beam unit (Ref. para.2.).

R

EFFECTIVITY: ALL

BA

C812781

# 33-41-21

Page 406  
Mar 29/96

PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

### C. Remove

- (1) From the bottom side of the wing, remove the screws securing the sealed beam unit support and optical guide to its mounting inside the wing.
- (2) Lift the unit from its mounting and manipulate it to withdraw it through the wing access opening.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Position the sealed beam unit support and optical guide on its mounting inside the wing and, from the bottom side of the wing, secure the unit to its mounting with the screws.

### E. Conclusion

- (1) Refit the sealed beam unit to the lamp assembly (Ref. para.2.).

## 5. Leading Edge Lens Assembly - Removal/Installation

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

### B. Prepare

- (1) Ensure that the NAV lights control switch on the flight compartment roof panel is at "OFF".
- (2) Trip the NAV LTS SUP circuit breaker L1, on panel 14-215, map ref.D11, and fit a safety clip.

### C. Remove

- (1) Remove the screws securing the lens assembly to the upper and lower surfaces of the outer wing leading edge.
- (2) Withdraw the complete lens assembly from the wing.

R

EFFECTIVITY: ALL

BA

C812782

# 33-41-21

Page 407  
Mar 29/96



# *Concorde*

## MAINTENANCE MANUAL

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Orientate the lens assembly so that the face marked LOWER SKIN is facing downward.
- (3) Fit the lens assembly to its mounting on the outer wing leading edge and secure it to the wing upper and lower surfaces with the screws.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clip and reset the circuit breaker tripped before removal.
- (3) Set the NAV lights control switch to "ON" and check that the navigation lamp is lit, right wing lamp - green, or left wing lamp - red, as appropriate. Return the switch to "OFF".
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812783

**33-41-21**

Page 408  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### NAVIGATION/ANTI-COLLISION LIGHT ASSEMBLY (TAIL) - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED  
IN 24-00-00.

ENSURE THAT POWER TO THE ANTI-COLLISION LAMP UNIT  
IS SWITCHED OFF 5 min BEFORE REMOVING THE ELECTRICAL  
CONNECTOR. 650 V IS PRESENT AT THE CONNECTOR  
DURING OPERATION AND THE POWER SUPPLY RETAINS THIS  
CHARGE FOR APPROXIMATELY 5 min AFTER OPERATION IS  
DISCONTINUED.

#### 1. General (Ref. Fig. 401 )

This topic contains instructions for the removal and  
installation of the tail navigation/anti-collision lamp  
assembly, which comprises a navigation lamp unit and an  
anti-collision lamp unit, both mounted on a lamp support  
located in the tail cone behind a clear domed lens.

The navigation lamp unit incorporates two 6 V quartz  
lamps, and a step-down transformer which is mounted  
on the reverse side of the lamp support. A flashtube,  
trigger coil and reflector form the anti-collision lamp  
unit, which is contained in a lamp housing fitted with a  
red lens mounted on the lamp support between the two  
navigation lamps.

A fault in any one of the navigation lamp or anti-  
collision lamp unit parts necessitates the complete  
renewal of the tail navigation/anti-collision lamp  
assembly.

Electrical connection to both lamp units is made through  
electrical connectors on the reverse side of the lamp  
support.

#### 2. Navigation/Anti-collision Lamp Assembly (Tail)

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-
Torque spanner, 40 to 45 lbf in (0.452 to 0.508 mdaN)	-
Sealant (Ref. 20-30-00,	RTV 730

EFFECTIVITY: ALL

# 33-41-41

Page 401  
Nov 30/80

# Concorde

## MAINTENANCE MANUAL

---

### DESCRIPTION

### PART NO.

---

No.360)

R B

Primer (Ref. 20-30-00,  
No.367), for RTV 730 sealant

Dow Corning  
1200 Clear

R B

Gasket

Grimes 31-4120-1

Solvent (Ref. 20-30-00,  
No.473)

BAC M302

---

### B. Prepare

- (1) Ensure that the NAV and ANTI COLN light control switches on the flight compartment roof panel are at OFF.
- (2) Trip the NAV LTS SUP circuit breaker L1, on panel 14-215, map ref.D11, and the ANTI COLLISION LTS SUP circuit breaker L8, on panel 14-216, map ref.A10, and fit safety clips.

### C. Remove

- (1) Remove the bolts securing the collar of the domed lens assembly to the end of the tail cone and withdraw the domed lens assembly from the mounting.
- (2) Remove the bolts securing the lamp support to the aircraft structure, and withdraw the lamp assembly from the tail cone sufficiently to gain access to the electrical connectors and bonding lead.
- (3) Disconnect the electrical connectors and bonding lead from the lamp assembly and remove the lamp.
- (4) If the domed lens assembly is to be refitted, proceed as follows:-
  - (a) Remove and discard the gasket from the domed lens assembly.
  - (b) Using solvent BAC M302, clean old sealant from the domed lens and lamp assembly/tail cone joint; allow solvent to dry.

EFFECTIVITY: ALL

BA


# 33-41-41

Page 402  
Nov 30/80

# Concorde

## MAINTENANCE MANUAL

CB13280/00B



CMB 33 41 41 4 AAWO

Tail Navigation/Anti-collision  
Lamp Assembly - Installation  
Figure 401

R EFFECTIVITY: ALL

BA

**33-41-41**

Page 403  
Aug 30/80

Printed in England

# Concorde

## MAINTENANCE MANUAL

### D. Prepare to Install

**CAUTION:** A NEW GASKET MUST BE FITTED TO THE DOMED LENS ASSEMBLY BEFORE INSTALLATION.

**NOTE:** Primer and sealant manufacturer's instructions must be followed.

- (1) If the domed lens assembly, previously removed, is being refitted, seal a new gasket to the lens, as follows:

(a) Prime mating surfaces with primer.

(b) Seal the gasket to the lens, with the gasket ridges facing away from the lens, using sealant RTV 730.

- (2) Ensure that the mating surfaces of the lamp support and tail cone are clean and free from grease, in order to provide a good electrical bonding contact.

- (3) Check the anchor stiff nuts and bolts used to secure the lamp assembly and the domed lens to the tail cone. Anchor nuts with inadequate friction and worn bolts must be replaced.

### E. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the tail navigation/anti-collision lamp assembly and connect the electrical connectors, ensuring that the mating surfaces are clean and undamaged.
- (3) Connect the bonding lead to the stud on the lamp assembly with the washer and nut; torque-tighten the nut to between 29 and 32 lbf in (0.328 and 0.362 mdaN).
- (4) Fit the lamp support to its mounting on the rear of the tail cone and secure it with the bolts. Torque-tighten the bolts to between 40 and 45 lbf in (0.452 and 0.508 mdaN).
- (5) Check that the lamp assembly is electrically bonded in accordance with 20-27-11.
- (6) Place the domed lens assembly on its mounting at the rear of the tail cone and secure it with the bolts.

EFFECTIVITY: ALL

BA

C798222

**33-41-41**

Page 404  
Sep 30/92

PRINTED IN ENGLAND

# *Concorde*

## MAINTENANCE MANUAL

Torque-tighten the bolts to between 40 and 45 lbf in (0.452 and 0.508 mdaN).

- (7) Prime the lamp support/tail cone joint with primer Dow Corning 1200 Clear.
- (8) Seal the lamp support/tail cone joint with sealant RTV 730. Apply and cure as defined in 20-22-13.

B

R

### F. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00, Servicing.
- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- (3) Set the NAV lights control switch to "ON" and check that the navigation lights are lit. Return the switch to "OFF".
- (4) Set the ANTI COLN light control switch to "ON" and check that the anti-collision lamp shows a red light flashing at a rate of 40 to 100 flashes per minute. Return the switch to "OFF".
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00, Servicing.

R

PRINTED IN ENGLAND

EFFECTIVITY: ALL

BA

C822403

# 33-41-41

Page 405  
Mar 31/98

***Concorde***  
**British airways**  
**MAINTENANCE MANUAL**

NAVIGATION/ANTI-COLLISION LIGHT ASSEMBLY (TAIL)  
INSPECTION/CHECK

1. INSPECTION/CHECK

- A. Inspect the glass dome for security, cracks and cleanliness.
- B. Check that the torque - loading on the 12 lens collar securing bolts, is between 40 and 45 lbf in (0.452 and 0.508 mdaN).
- C. If any of the lens securing bolts is found to be loose, check all the bolts and anchor nuts used to secure the lens and lamp assemblies. Anchor nuts with inadequate friction and worn bolts must be replaced.

EFFECTIVITY: ALL

BA

C798223

**33-41-41**

Page 601  
Sep 30/92

# *Concorde*

## MAINTENANCE MANUAL

### ANTI-COLLISION LIGHTS - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig. 001 )

Anti-collision lights show the position of the aircraft by means of a flashtube mounted in the leading edge of each wing and in the tail cone. The lights flash simultaneously at a rate between 40 and 100 flashes per minute.

The three flashtubes, each with an associated power unit, are governed by a flasher unit which is controlled by a switch mounted on the flight compartment roof panel. The flasher unit is located in the forward underfloor racking, and each flashtube power unit is mounted close to its associated flashtube in the wings and in the tail cone.

#### 2. Flasher Unit

The flasher unit is housed in a case mounted in the forward underfloor racking (panel 5-123). Electrical connections are made at a connector on the rear of the case.

The flasher unit comprises a timing circuit which supplies 115 V 400 Hz a.c. pulsed outputs of approximately 60 pulses per minute to each of the flashtube power units.

R

#### 3. Power Unit

Each flashtube power unit is enclosed in a cover assembly and located close to its associated flashtube. Electrical connections are made at two connectors on the rear of the cover.

The power unit comprises three sections: a converter, a timer and an energy storage and firing circuit.

The converter section changes the 115 V a.c. pulsed input into 650 V d.c. which charges a capacitor bank in the energy storage and firing circuit.

The timer generates a trigger pulse which is adjustable to provide 60( $\pm 10$ ) pulses per minute. These pulses are fed to the energy storage and firing circuit to provide the power surges that fire the flashtube.

#### 4. Flashtube Lamp Assembly

Each flashtube is contained within an anti-collision lamp assembly mounted in the leading edge of each wing, and in the tail navigation lamp assembly. Electrical connections are made at a connector in the rear of each lamp housing.

EFFECTIVITY: ALL

BA


# 33-42-00

Page 1  
Aug 30/77



# Concorde

## MAINTENANCE MANUAL



- Anti-collision Lights and Equipment  
Figure 001

R EFFECTIVITY: ALL

BA

Printed in England

**33-42-00**

Page 2  
May 30/77

# Concorde


## MAINTENANCE MANUAL

The anti-collision lamp assembly comprises a flashtube, a trigger coil and a reflector, contained within a lamp housing fitted with a red, heat-resistant glass lens. There are no moving parts in the assembly, and the lamp operates only in conjunction with the flasher unit and the flashtube power unit.

### 5. Operation

#### A. Control (Ref. Fig. 002 )

The anti-collision lights are supplied from one phase of No.2 ground/flight 115 V a.c. busbar through the common flasher unit. The lights are manually controlled by a single-pole two-position (ON-OFF) toggle switch engraved ANTI COLN, mounted on the rear of the flight compartment roof panel (panel 4-211).



- Anti-collision Lights - Control  
Figure 002

#### B. Functional Description (Ref. Fig. 003 )

When electrical supplies are available and ON is

EFFECTIVITY: ALL

BA

Printed in England

**33-42-00**


Page 3  
Aug 30/77

# Concorde

## MAINTENANCE MANUAL

CB12525/00A

CMB 33 42 00 0 CAMO



Anti-collision Lights -  
Simplified Schematic  
Figure 003

R

selected at the ANTI COLN control switch, the 115 V a.c. single-phase supply is connected directly to the flasher unit.

The flasher unit provides a pulsed output of 115 V 400 Hz a.c. to each flashtube power unit.

The converter section of the power unit transforms and rectifies the 115 V a.c. input and provides a 650 V d.c. output which charges the capacitors in the energy storage and firing circuit. The 650 V d.c. supply is also applied directly across the flashtube and retains the gas in the tube near ionization.

R

The power unit timer receives a sample of the a.c. input, before conversion, and generates a signal pulse, approximately once per second, which triggers the firing circuit. The firing circuit then applies a charge across the trigger coil, which ionizes the gas in the flashtube, permitting the capacitors in the energy storage unit to discharge through the tube, causing a

EFFECTIVITY: ALL

BA

**33-42-00**

Page 4  
Aug 30/77

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

bright flash.

When the gas in the tube de-ionizes and the firing circuit shuts off, the capacitor bank starts to recharge.

EFFECTIVITY: ALL

R

BA

Printed in England

**33-42-00**

Page 5  
Aug 30/77

# *Concorde*

## MAINTENANCE MANUAL

### ANTI-COLLISION LIGHTS - TROUBLE SHOOTING

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-42-00**

Page 101  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting

A.\*\*\*\*\*  
\*Prepare to trouble shoot (Ref. para.2.).\*  
\*Set the ANTI COLN light control switch \*  
\*on the flight compartment roof panel \*  
\*to "ON". Check that the anti-collision \*  
\*lamps flash in unison at a rate of \*  
\*between 40 and 100 flashes per minute. \*  
\*\*\*\*\*

NOT OK-----

- 1. No anti-collision lights - Chart 101.
- 2. One anti-collision lamp not flashing - Chart 102.
- 3. All anti-collision lamps flashing outside the rate of 40 to 100 flashes per minute - renew Flasher Unit (3).

EFFECTIVITY: ALL

**33-42-00**

Page 102  
Aug 30/78

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*NO ANTI-COLLISION LIGHTS WHEN\*  
 \*'ANTI COLN' LIGHT SWITCH AT \*  
 \*'ON'\*.  
 \*\*\*\*\*

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 101

EFFECTIVITY: ALL

**33-42-00**

R

BA

Page 103  
Aug 30/78

# Concorde

## MAINTENANCE MANUAL

\*\*\*\*\*  
 \*ONE ANTI-COLLISION LIGHT NOT \*  
 \*FLASHING WHEN 'ANTI COLN' \*  
 \*LIGHT SWITCH AT 'ON'. \*  
 \*\*\*\*\*

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

**NOTE:** Before renewal of components (\*), check the preceding run of wiring for continuity.




Chart 102

EFFECTIVITY: ALL

BA

Printed in England

**33-42-00**

Page 104  
 Nov 30/76



# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 115 V	-	14-216	L8	Map ref.A10	24-50-00 R/I	33-42-11
(2) Anti- collision light control switch	-	4-211	L9	Roof panel	33-00-00 R/I	33-42-11
(3) Flasher unit	123AB	5-123	L10	Fwd. underfloor racking	33-42-13 R/I	33-42-11
(4) RH wing lamp power unit	-	611	L11	RH wing	33-42-12 R/I	33-42-11
(5) LH wing lamp power unit	-	511	L13	LH wing	33-42-12 R/I	33-42-11
(6) Tail lamp power unit	-	313	L12	Tail	33-42-12 R/I	33-42-11
(7) RH wing anti-collision lamp	-	611	L14	RH wing	33-42-11 R/I	33-42-11
(8) LH wing anti-collision lamp	-	511	L15	LH wing	33-42-11 R/I	33-42-11
(9) Tail anti- collision lamp	-	313	L5	Tail cone	33-41-41 R/I	33-42-11

Component Identification  
Table 101

EFFECTIVITY: ALL

BA

# 33-42-00

Page 105  
Nov 30/79

# *Concorde*

## MAINTENANCE MANUAL

### ANTI-COLLISION LIGHTS - REMOVAL/INSTALLATION

#### 1. General

Instructions for the removal and installation of the anti-collision lights control switch, mounted on the rear switch panel of the flight compartment roof panel, are contained in 33-00-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-42-00**

Page 401  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

### ANTI-COLLISION LIGHTS - ADJUSTMENT/TEST

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Anti-collision lights tests are contained under two headings: Operational Test and Functional Test. A System Test is not considered necessary in this application. The Operational Test details the procedure for checking the operation of the anti-collision lights. The Functional Test checks the anti-collision lights in more detail to prove that the flasher unit is electrically and functionally correct.

#### 2. Operational Test

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test

- (1) Set the ANTI COLN light control switch on the flight compartment roof panel (panel 4-211) to "ON".
- (2) Check that the anti-collision lamps at the right and left wing forward leading edge, and at the tail cone, show a flashing red light.
- (3) Return the switch to "OFF" and check that the anti-collision lights are extinguished.

##### C. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

#### 3. Functional Test

##### A. Equipment and Materials

EFFECTIVITY: ALL

BA

Printed in England

**33-42-00**

Page 501  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

---

DESCRIPTION	PART NO.
Stop watch	-

---

### B. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

### C. Test

- (1) Set the ANTI COLN light control switch on the flight compartment roof panel (panel 4-211) to "ON".
- (2) Check that the anti-collision lamps at the right and left wing forward leading edge, and at the tail cone, show a flashing red light.
- (3) Check that the lights flash in unison at a rate of between 40 and 100 flashes per minute.
- (4) Return the switch to "OFF" and check that the anti-collision lights are extinguished.

### D. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

# 33-42-00

Page 502  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

### ANTI-COLLISION LIGHT ASSEMBLY (WINGS) - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

ENSURE THAT POWER TO THE ANTI-COLLISION LAMPS IS SWITCHED OFF 5 min BEFORE A LAMP IS REMOVED FROM ITS MOUNTING. 650 V IS PRESENT AT THE LAMP TERMINALS DURING OPERATION AND THE POWER SUPPLY RETAINS THIS CHARGE FOR APPROXIMATELY 5 min AFTER OPERATION IS DISCONTINUED.

#### 1. General

Two anti-collision lamps are mounted in the wings, one in the forward section of the left wing leading edge, and the other in the forward section of the right wing leading edge. Each lamp unit is secured in a leading edge fairing by countersunk bolts through the lens assembly. Electrical connections are made at a connector at the back of each lamp housing.

The removal and installation procedures apply to both the left and right wing anti-collision lamp installations.

#### 2. Anti-collision Lamp

##### A. Equipment and Materials

---

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

---

##### B. Prepare

- (1) Ensure that the ANTI COLN light control switch on the flight compartment roof panel is at OFF.
- (2) Trip the ANTI-COLLISION LTS SUP circuit breaker L8, on panel 14-216, map ref.A10, and fit a safety clip.

##### C. Remove

- (1) Allow a time delay of 5 min from the time that power is switched off at the anti-collision light control switch.

EFFECTIVITY: ALL

**33-42-11**

Page 401  
Feb 29/76

# *Concorde*

## MAINTENANCE MANUAL

- (2) Remove the bolts securing the anti-collision lamp to the wing leading edge fairing.
- (3) Withdraw the lamp from the fairing sufficiently to gain access to the electrical connector at the back of the lamp housing.
- (4) Disconnect the electrical connector from the lamp and remove the lamp clear of the wing.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the anti-collision lamp close to its mounting position in the wing leading edge fairing. Connect the electrical connector to the lamp, ensuring that the mating surfaces are clean and undamaged.
- (3) Insert the lamp into its aperture in the wing leading edge fairing and secure it with the bolts.

### E. Conclusion

R  
R

- (1) Remove the safety clip and reset the ANTI-COLLISION LTS SUP circuit breaker.
- (2) Carry out an Operational Test of the anti-collision lights (Ref. 33-42-00).

EFFECTIVITY: ALL

BA

Printed in England

**33-42-11**

Page 402  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL

### ANTI-COLLISION LIGHT POWER UNIT - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

ENSURE THAT POWER TO THE POWER UNITS IS SWITCHED OFF 5 min BEFORE REMOVING THE ELECTRICAL CONNECTORS. 650 V IS PRESENT AT THE POWER UNIT ENERGY STORAGE CIRCUIT WHICH IS RETAINED FOR 5 min, APPROXIMATELY, AFTER OPERATION IS DISCONTINUED.

#### 1. General

This topic contains instructions for the removal and installation of three anti-collision light power units, each power unit being mounted close to its associated anti-collision lamp in the forward section of each wing leading edge and in the tail cone.

Electrical connections are made at two connectors on the side of each power unit, and an earth connection is made to a power unit mounting bolt.

#### 2. Anti-collision Light Power Unit

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-
Torque spanner, 32 lbf in (0.362 mdaN)	-

##### B. Prepare

- R (1) To remove a wing power unit, proceed as follows:-
- R (a) Ensure that the ANTI COLN light control switch
- R on the flight compartment roof panel is at OFF.
- R (b) Trip the ANTI-COLLISION LTS SUP circuit breaker
- R L8 on panel 14-216, map ref.A10, and fit a
- R safety clip.
- R (2) To remove a tail cone power unit, proceed as follows:-
- R (a) Ensure that the tail gear is lowered.

EFFECTIVITY: ALL

BA

# 33-42-12

Page 401  
Aug 30/79

# Concorde

## MAINTENANCE MANUAL

R (b) Ensure that the ANTI COLN light control switch  
R on the flight compartment roof panel is at OFF.

R (c) Trip the following circuit breakers and fit  
R safety clips.

R

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
---------	-------	--------------------	-------------

ANTI-COLLISION LTS SUP	14-216	L8	A10
------------------------	--------	----	-----

UC LOWER DOORS OPEN SUP	15-215	G3	A8
----------------------------	--------	----	----

UC RAISE DOORS CLOSE SUP	15-215	G1	A6
-----------------------------	--------	----	----

UC POSN IND	1-213	G51	N16
-------------	-------	-----	-----

R (d) Fit a locking sleeve to the tail gear jack  
R (Ref. 12-37-00, Tail Gear Wheel).

### C. Remove Wing Anti-collision Light Power Unit

(1) Allow a time delay of 5 min from the time that power is switched off at the ANTI COLN light control switch.

(2) Remove the bolts securing the forward section of the wing leading edge detachable fairing. Withdraw and support the fairing at the extent of the electrical cables.

(3) Remove the nuts and washers securing the power unit mounting plate to the mounting brackets, and withdraw the power unit sufficiently to gain access to the electrical connectors.

(4) Disconnect the electrical connectors from the power unit. Disconnect the metal braid from the bonding stud on the power unit.

(5) Remove the power unit from the wing.

### D. Install Wing Anti-collision Light Power Unit

(1) Comply with the electrical safety precautions.

EFFECTIVITY: ALL

BA

Printed in England

# 33-42-12

Page 402  
Aug 30/79



# *Concorde*

## MAINTENANCE MANUAL

- (2) Place the power unit on its mounting and connect the two electrical connectors to the power unit, ensuring that the mating surfaces are clean and undamaged.
- (3) Connect the metal braid to the bonding stud on the power unit with the nut and washers. Torque-tighten the nut to 32 lbf in (0.362 mdaN).
- (4) Secure the power unit to its mounting brackets with the nuts and washers.
- (4) Check that the power unit is bonded in accordance with 20-27-11.
- (5) Refit the fairing to the wing.

### E. Remove Tail Cone Anti-collision Light Power Unit

- (1) Allow a time delay of 5 min from the time that power is switched off at the ANTI COLN light control switch.
- R  
R (2) Gain access to the anti-collision light power unit via the tail gear doors.
- R (3) Disconnect the electrical connectors from the power unit. Disconnect the metal braid and the bonding lead (if fitted) from the bonding stud on the power unit.
- (4) Remove the nuts and washers securing the power unit mounting plate to the mounting brackets and lift the power unit from the tail cone.

### F. Install Tail Cone Anti-collision Light Power Unit

- (1) Comply with the electrical safety precautions.
- (2) Place the power unit on its mounting and connect the two electrical connectors to the power unit, ensuring that the mating surfaces are clean and undamaged.
- R (3) Secure the power unit to its mounting with the nuts and washers, connecting the metal braid and the bonding lead (if fitted) to the bonding stud on the power unit with the nut and washer. Torque-tighten the nut to 32 lbf in (0.362 mdaN).
- (4) Check that the power unit is bonded in accordance with 20-27-11.

R EFFECTIVITY: ALL

BA

# 33-42-12

Page 403  
Aug 30/79

# *Concorde*

## MAINTENANCE MANUAL

### G. Conclusion

R  
R

- (1) If applicable, remove the locking sleeve from the tail gear jack.
- (2) Remove the safety clip(s) and reset the circuit breaker(s) previously tripped.
- (3) Make available electrical ground power as detailed in 24-41-00.
- (4) Set the ANTI COLN light control switch to "ON" and check that the anti-collision lamp shows a flashing red light, operating in unison with other anti-collision lights, at a rate of between 40 and 100 flashes per minute.
- (5) Set the ANTI COLN light control switch to "OFF".
- (6) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-42-12**

Page 404  
Aug 30/79

# *Concorde*

## MAINTENANCE MANUAL

### FLASHER UNIT - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

R The anti-collision lights flasher unit is secured within a case (panel 5-123) mounted in the forward underfloor racking. The case is clamped to its mounting rack by two hold-down fasteners at the front and two hold-down pins and three index pins at the rear. A handle on the front of the case facilitates the removal and installation of the unit. Electrical connections are made through connectors at the case rear end plate.

#### 2. Flasher Unit

##### A. Prepare

- (1) Ensure that the ANTI COLN light control switch on the flight compartment roof panel is at OFF.
- (2) Isolate the electrical generation and external power supplies as detailed in 24-00-00, Servicing.
- (3) Open service compartment door 123 AB (Ref. 52-41-11) to gain access to the forward underfloor racking.

##### B. Remove

- (1) Release the two hold-down fasteners from the lugs on the case front end plate.
- (2) Withdraw the case from its mounting rack and remove the quick-release cable clamps to detach the cables from the top of the case. When the case is clear of the rack, lower the case on to a suitable support.
- (3) Disconnect the cable loom from the flasher unit connector, L10A, at the case rear end plate.
- (4) Loosen the screws securing the top cover to the case assembly and remove the cover from the chassis.
- (5) Tilt the chassis to gain access to the flasher unit securing screws. Support the flasher unit,

R EFFECTIVITY: ALL

BA

# 33-42-13

Page 401  
May 30/83



## MAINTENANCE MANUAL

remove the four securing screws and washers and lift the flasher unit from its mounting.

### C. Install

- (1) Comply with the electrical safety precautions.
- (2) Tilt the chassis, support the flasher unit on its mounting and secure it with the four screws and washers.
- (3) Refit the top cover and secure it to the case assembly with the four screws.
- (4) Connect the cable loom to the flasher unit connector, L10A, at the case rear end plate.
- (5) Position the case on the end of the mounting rack support rail and secure the cables to the top of the case with the quick-release cable clamps.
- (6) Slide the case back onto its mounting rack, ensuring that the two hold-down pins and the three index pins enter their respective holes in the case rear end plate.
- (7) Secure the front of the case with the two hold-down fasteners.
- (8) Ensure that the case is bonded in accordance with 20-27-11.

### D. Conclusion

- (1) Close and secure service compartment door 123 AB (Ref. 52-41-11).
- (2) Cancel the electrical safety precautions taken before removal.
- (3) Carry out an Operational Test of the anti-collision lights (Ref. 33-42-00).

R EFFECTIVITY: ALL

BA

Printed in England

# 33-42-13

Page 402  
May 30/83



# *Concorde*

## MAINTENANCE MANUAL

### MAIN LANDING LIGHTS - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig. 001 )

Two main landing lamps, one mounted in each wing root, illuminate the area in front of the aircraft during landing. The landing lamps have retractable/extensible mountings, and when not in use are retracted into housings in the aircraft structure.

R Each lamp assembly is fitted with an automatic blowback device which allows the lamp to be blown back automatically into its housing, during flight, at air speeds greater than 300 kt, approximately, if the control switch has not been operated, or if the power supply to the lamp fails at the time of retraction.

Control of the landing lights is by switches on the flight compartment roof panel, and an adjacent caption indicates the extended condition of one or both landing lamps.

#### 2. Main Landing Lamps

A landing lamp assembly is mounted in each wing root, close to the wing leading edge and fuselage intersection.

R Each lamp comprises a 600 W quartz halogen filament in a sealed beam unit that can be extended from, or retracted into, its housing by an actuator driven by an integral electric motor. A motor control relay, and extend and retract limit switches in the motor circuit, terminate lamp movement at the required lights. A light control relay and a step-down transformer in the light circuit, connected to the 115 V a.c. input supply, provide a 28 V operating voltage for the 600 W filament.

A blowback device comprising spring, ratchet roller and sun gear is fitted to the motor case, and allows air pressure on the lamp lens, above the predetermined value, to force the lamp back into its housing.

#### 3. Operation

##### A. Control and Indication (Ref. Fig. 002 )

Each landing lamp is controlled primarily by a MAIN LANDING, two-position (ON - OFF) light control switch, and a two-position (EXTEND - RETRACT) position control switch mounted on sub-panel 1 of the flight compartment roof panel (panel 4-211). Secondary control of the landing lamp light

EFFECTIVITY: ALL

BA


**33-43-00**

Page 1  
Aug 30/77

Printed in England

# Concorde

## MAINTENANCE MANUAL



- Main Landing Lamps  
Figure 001

is through the contacts of the light control relay in the lamp assembly, and the contacts of the retract limit switch which connects the 115 V supply to the step-down transformer.

Secondary control of the landing lamp position is through the contacts of the extend/retract limit switches and the contacts of the motor control relay in the lamp assembly.

Normally the four landing light switches are operated simultaneously by a common switch bar, but each switch can be controlled independently if required. A blue EXTENDED caption, mounted close to the landing lamp control switches on the flight compartment roof panel, is operated by a contact of the light control relay, and is illuminated when either lamp position control switch is set to EXTEND and the lamp starts to move from its housing.

### B. Functional Description (Ref. Fig. 003 )

EFFECTIVITY: ALL

# 33-43-00


R

BA

Page 2  
Nov 30/75

# Concorde

## MAINTENANCE MANUAL



CMB3343000 BAMO

Controls and Indicators  
Figure 002

When the aircraft electrical supplies are available and EXTEND is selected at a position control switch, a supply is connected through the extend limit switch and via the motor control relay to the 'extend' windings of the lamp motor which operates to extend the lamp from its housing.

As the lamp starts to extend the retract limit switch closes and connects a supply from the EXTEND position of the position control switch to energize the light control relay, the contacts of which change over to connect the ON position of the light control switch to the step-down transformer, and to provide an earth return to light the EXTENDED caption. Subsequent operation of the light control switch to ON connects a 115 V a.c. supply to the step-down transformer to give a 28 V operating voltage to light the 600 W filament. When the lamp is fully extended the supply to the lamp motor is interrupted by the operation of the extend limit switch which changes over and connects the supply to energize the motor control relay. When the relay is operated, one contact open-circuits the connection to the lamp motor, and a second contact connects a 'hold-on' supply to the

EFFECTIVITY: ALL

**33-43-00**

R

BA

Page 3  
Nov 30/75

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

relay coil from the EXTEND position of the control switch.

When the position control switch is moved to RETRACT, the supply to the light control relay is interrupted, the relay is de-energized and the contacts open to isolate the step-down transformer, and to open-circuit the earth connection of the EXTENDED caption. The caption and the landing light are thus extinguished. A supply is also fed from the RETRACT position of the switch, through the retract limit switch to the 'retract' windings of the lamp motor which operates to retract the lamp into its housing. The 'hold-on' supply to the motor control relay is also disconnected and the relay is de-energized in preparation for a subsequent 'extend' operation.

When the lamp is fully retracted the retract limit switch is operated and the contacts open to disconnect the supply from the lamp motor and to isolate the light control relay.

R If the landing lamp remains extended after take-off, due to a power supply failure, or by the position control switch being left at EXTEND, the automatic blowback device allows air pressure to force the lamp back into the retracted position when the airspeed exceeds 300 kt, approximately.

If the position control switch is at EXTEND when blowback occurs, the hold-on circuit of the motor control relay ensures that the relay remains energized, and therefore the supply to the extend windings of the motor stay isolated. This prevents the lamp from extending and retracting in a 'pumping' action.

To extend the lamp after blowback, it is therefore necessary to move the position control switch to RETRACT to release the hold-on circuit, and then reset the switch to EXTEND.

#### 4. Electrical Power Supplies

Each landing lamp has two separate electrical power supplies. The supplies for the RH landing lamp are obtained from No.2 main 115 V a.c. busbar, each supply being fed through separate circuit breakers on panel 13-215. The supplies for the LH landing lamp are obtained from No.4 main 115 V a.c. busbar, each supply being fed through separate circuit breakers on panel 14-216. The EXTENDED caption is supplied from 'B' main 28 V d.c. busbar through a circuit breaker on panel 15-216.

EFFECTIVITY: ALL

BA


**33-43-00**

Page 4  
Aug 30/77



# Concorde

## MAINTENANCE MANUAL



- Main Landing Lights - Simplified Schematic  
Figure 003

EFFECTIVITY: ALL

BA

Printed in England

**33-43-00**

Page 5  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

R

### MAIN LANDING LIGHTS - TROUBLE SHOOTING

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

The LH and RH main landing lights circuits are similar, therefore the procedures and charts are applicable to either. Where two identical components are involved, i.e., one in each circuit, both references to the associated components listed in Table 101 are given, e.g., 'Replace Switch (7) or (9)'.

#### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812828


**33-43-00**

Page 101  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting



PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812829

**33-43-00**

Page 102  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

LANDING LAMP FAILS TO EXTEND  
WHEN POSITION CONTROL SWITCH  
IS AT "EXTEND".

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

Set  
appropriate  
position  
control  
switch to  
"EXTEND".

Check for  
115 V a.c. at  
terminal B of  
Lamp (11) or  
(12).

YES

Renew Lamp  
(11) or (12)  
and retest.

NO

Check for  
115 V a.c. at  
terminal 1 of  
Switch (7) or  
(9).

YES

Locate and  
rectify open  
circuit between  
terminal 1 of  
Switch (7) and  
terminal B of  
Lamp (11) or  
(12).

NO

Check for  
115 V a.c. at  
terminal 2 of  
Switch (7) or  
(9).

YES

Renew Switch  
(7) or (9)  
and retest.

NO

Locate and  
rectify open  
circuit  
between  
terminal 2 of  
Switch (7) or  
(9) and CB  
(2) or (4).

Chart 101

R

EFFECTIVITY: ALL

BA

C812830

# 33-43-00

Page 103  
Mar 29/96


# Concorde

## MAINTENANCE MANUAL

INDICATOR FILAMENTS FAIL TO LIGHT  
WHEN THE APPROPRIATE LH OR RH LAMP  
POSITION CONTROL SWITCH IS AT  
"EXTEND".

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-



PRINTED IN ENGLAND

Chart 102

R

EFFECTIVITY: ALL

BA

C812831

# 33-43-00

Page 104  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

LANDING LAMP FILAMENT FAILS TO LIGHT WHEN THE LIGHT CONTROL SWITCH IS AT "ON" AND THE LAMP IS EXTENDED.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

Set appropriate light control switch to "ON" and the position control switch to "EXTEND".

Check for 115 V a.c. at terminal M of Lamp (11) or (12).

YES

Renew sealed unit filament and retest.

NO

Renew Lamp (11) or (12) and retest.

NO

Check for 115 V a.c. at terminal 1 of Switch (6) or (10).

YES

Check wiring for open circuit between terminal 1 of Switch (6) or (10) and terminal M of Lamp (11) or (12).

NO

Check for 115 V a.c. at terminal 2 of Switch (6) or (10).

YES

Renew Switch (6) or (10) and retest.

NO

Locate and rectify open circuit between terminal 2 of Switch (6) or (10) and CB (1) or (5).

Chart 103

R

EFFECTIVITY: ALL

BA

C812832

# 33-43-00

Page 105  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

LANDING LAMP FAILS TO RETRACT  
WHEN THE POSITION CONTROL SWITCH  
IS SET TO "RETRACT".

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

Set  
appropriate  
position  
control  
switch to  
"RETRACT".

Check for  
115 V a.c.  
at terminal  
A of Lamp  
(11) or  
(12).

YES Renew Lamp  
(11) or (12).

NO

Check for  
115 V a.c.  
at terminal  
(3) of  
Switch (7)  
or (9).

YES Locate and  
rectify open  
circuit between  
terminal A of Lamp  
(11) or (12) and  
terminal 3 of  
Switch (7) or (9).

NO

Check for  
115 V a.c.  
at terminal  
(4) of  
Switch (7)  
or (9).

YES Renew Switch (7)  
or (9) and retest.

NO

Locate and  
rectify  
open  
circuit  
between  
terminal 4  
of Switch  
(7) or (9)  
and CB (2)  
or (4).

Chart 104

EFFECTIVITY: ALL

BA

C812833

# 33-43-00

Page 106  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 115 V	-	13-215	L24	Map ref. C12	24-50-00 R/I	
(2) Circuit breaker 115 V	-	13-215	L21	Map ref. B11	24-50-00 R/I	
(3) Circuit breaker 28 V	-	15-216	L23	Map ref. A12	24-50-00 R/I	
(4) Circuit breaker 115 V	-	14-216	L22	Map ref. D8	24-50-00 R/I	
(5) Circuit breaker 115 V	-	14-216	L25	Map ref. C8	24-50-00 R/I	
(6) RH landing lamp light control switch	-	4-211	L26	Pilots' roof panel	33-43-00 R/I	
(7) RH landing lamp position control switch	-	4-211	L28	Pilots' roof panel	33-43-00 R/I	
(8) Position indicator	-	4-211	L30	Pilots' roof panel	33-14-00 R/I	
(9) LH landing lamp position control switch	-	4-211	L29	Pilots' roof panel	33-43-00 R/I	
(10) LH lamp light control switch	-	4-211	L27	Pilots' roof panel	33-43-00 R/I	
(11) LH landing lamp	-	511	L32	LH wing root	33-43-00 R/I	
(12) RH landing lamp	-	611	L31	RH wing root	33-43-00 R/I	

Component Identification  
Table 101

R

EFFECTIVITY: ALL

BA

C812834

# 33-43-00

Page 107  
Mar 29/96



# *Concorde*

## MAINTENANCE MANUAL

R

### MAIN LANDING LIGHTS - REMOVAL/INSTALLATION

#### 1. General

Instructions for the removal and installation of associated control switches and an associated caption light module, mounted on the flight compartment roof panel, are contained in 33-00-00.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812254

# 33-43-00

Page 401  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

### MAIN LANDING LIGHTS - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic contains an Operational Test only, which details the procedure to prove the correct operation of the main landing lights. Functional and System Tests are not considered necessary in this application.

#### 2. Operational Test

CAUTION: DO NOT LEAVE THE LANDING LAMP LIT FOR MORE THAN 5 min IN ANY 10 min PERIOD.

##### A. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Test

- (1) On the flight compartment roof panel, depress the LIGHTS TEST button and check that the main landing lights EXTENDED caption is illuminated.
- (2) Release the button and check that the caption is extinguished.
- (3) Set the left MAIN LANDING LIGHTS control switch, on the flight compartment roof panel, to "ON". Check that the left landing lamp is not lit.
- (4) Set the left MAIN LANDING LIGHTS - RETRACT - EXTEND switch to "EXTEND". As the lamp starts to extend from its housing, check that the filament is lit and the EXTENDED caption illuminated.
- (5) Ensure that the lamp travels to its fully extended position and that the motor cuts out.
- (6) Set the left MAIN LANDING LIGHTS control switch to "OFF" and check that the light is extinguished.
- (7) Return the switch to "ON" and check that the lamp is lit.
- (8) Set the left MAIN LANDING LIGHTS - RETRACT - EXTEND switch to "RETRACT". Check that the lamp

EFFECTIVITY: ALL

BA

Printed in England

**33-43-00**

Page 501  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

travels to its fully retracted position in its housing, and that during the initial retraction sequence the landing light and the EXTENDED caption are extinguished, and when the lamp reaches its fully retracted position in its housing the motor cuts out.

- (9) Set the left MAIN LANDING LIGHTS control switch to "OFF".
- (10) Repeat operations (3) to (9) with respect to the right switches and lamp.

### C. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-43-00**

Page 502  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

### LANDING LIGHT ASSEMBLY - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General (Ref. Fig. 401 )

This topic contains instructions for the renewal of a landing lamp glass cover (lens) and the renewal of a sealed beam unit, and for the removal and installation of a landing lamp assembly.

Each landing lamp is secured to a lamp door which forms part of the bottom surface of the wing close to the leading edge and fuselage intersection. The lamp door hinges downward to facilitate easy removal and installation of the lamp assembly.

Renewal of a glass cover and a sealed beam unit can be carried out with the lamp extended or retracted, or with the lamp door open or closed, as convenient.

#### 2. Glass Cover (Ref. Fig. 401 )

##### A. Renew

- (1) Support the glass cover and remove the three screws securing the glass cover to the lamp inner assembly. Remove the glass cover and the retaining ring from the lamp, taking care that the sealed beam unit does not fall from its housing.

CAUTION: ENSURE THAT THE SEALED BEAM UNIT IS CORRECTLY ORIENTATED AND POSITIONED IN ITS HOUSING BEFORE FITTING THE RETAINING RING AND GLASS COVER TO THE LAMP, OTHERWISE DAMAGE MAY BE CAUSED TO THE LAMP INNER ASSEMBLY AND THE SEALED BEAM UNIT.

- (2) Ensure that the sealed beam unit is correctly positioned in its housing, with the word TOP, stencilled on the glass cover, located toward the the drive assembly, i.e., toward the front of the aircraft when the lamp is installed, and the locating lug, on the side of the sealed beam unit, correctly seated in the adjustment bracket within the lamp housing.
- (3) Press the sealed beam unit inward against the pressure springs, maintain the pressure and refit the retaining ring and glass cover to the lamp and secure the glass cover with the screws.

EFFECTIVITY: ALL

BA

Printed in England

**33-43-11**

Page 401  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

### 3. Sealed Beam Unit (Ref. Fig. 401 )

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Ensure that the MAIN LANDING LIGHTS light control switch is at OFF.
- (2) Trip the associated circuit breakers listed below and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH LDG LT SUP	13-215	L24	C12
RH LDG LT CONT	13-215	L21	B11
LH LDG LT SUP	14-216	L25	C8
LH LDG LT CONT	14-216	L22	D8

#### C. Renew

- (1) Support the glass cover and remove the screws securing the glass cover to the lamp inner assembly. Remove the glass cover and the retaining ring from the lamp.
- (2) Withdraw the sealed beam unit from the inner assembly sufficiently to gain access to the screw terminals.
- (3) Disconnect the electrical cables from the terminals on the sealed beam unit. Label the cables to assist identification for reconnection.
- (4) Remove the sealed beam unit.

R

CAUTION: ENSURE THAT THE SEALED BEAM UNIT IS

EFFECTIVITY: ALL

BA


**33-43-11**

Page 402  
Feb 28/77

Printed in England

# Concorde

## MAINTENANCE MANUAL



- Landing Lamp Assembly - Installation  
Figure 401

R

EFFECTIVITY: ALL

BA

Printed in England

**33-43-11**

Page 403  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

R  
R  
R  
R  
R

CORRECTLY ORIENTATED AND POSITIONED IN ITS HOUSING BEFORE FITTING THE RETAINING RING AND GLASS COVER TO THE LAMP, OTHERWISE DAMAGE MAY BE CAUSED TO THE LAMP INNER ASSEMBLY AND THE SEALED BEAM UNIT.

- (5) Support the replacement unit and connect the electrical cables to the terminals, ensuring that the connections are made in accordance with the cable identifications.
- (6) Orientate the sealed beam unit until the word TOP, stencilled on the glass cover, is located toward the drive assembly, i.e., toward the front of the aircraft when the lamp is installed.
- (7) Insert the sealed beam unit into its housing in the lamp inner assembly and manipulate the unit until the locating lug is seated in the adjustment bracket within the housing.
- (8) Press the sealed beam unit inward against the pressure springs, maintain the pressure and refit the retaining ring and lens to the lamp and secure the glass cover with the screws.

### D. Conclusion

- (1) Remove the safety clips and reset the circuit breakers tripped before renewal.
- (2) Carry out an Operational Test of the main landing lights as detailed in 33-43-00, Adjustment/Test, followed by a Beam Alignment Test as detailed in 33-43-11, Adjustment/Test.

## 4. Landing Lamp (Ref. Fig. 401 )

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-
Torque spanner, 30 lbf in (0.339 mdaN)	-

### B. Prepare

EFFECTIVITY: ALL

BA

# 33-43-11

Page 404  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

- (1) Ensure that the MAIN LANDING LIGHTS position control and light control switches are at RETRACT and OFF, respectively.
- (2) Trip the LDG LTS POSN IND circuit breaker L23, on panel 15-216, map ref.A12, and fit a safety clip.
- (3) Trip the associated circuit breakers listed below and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH LDG LT SUP	13-215	L24	C12
RH LDG LT CONT	13-215	L21	B11
LH LDG LT SUP	14-216	L25	C8
LH LDG LT CONT	14-216	L22	D8

- (4) Support the lamp door and unscrew the fasteners securing the door to the bottom surface of the wing.
- (5) Lower the door, complete with lamp, on its hinges.

### C. Remove

- (1) Disconnect the lamp assembly electrical connectors.
- (2) Support the lamp assembly. Remove the screws around the periphery of the lamp outer canopy and lift the lamp, together with the gasket, from the door.

R

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Orientate the lamp assembly so that the drive assembly is located toward the front of the aircraft.
- (3) Fit the lamp assembly, together with the gasket, to its mounting on the lamp door and secure the outer canopy to the door with the eight mounting screws, ensuring that the three horizontal adjusting nuts and bolts are in position and tight.

R

EFFECTIVITY: ALL

BA

**33-43-11**

Page 405  
Feb 28/77



# *Concorde*

## MAINTENANCE MANUAL

- (4) Connect the lamp assembly electrical connectors, ensuring that the mating surfaces are clean and undamaged.
- (5) Check that the lamp is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Close the lamp door and secure it by screwing in the fasteners. Torque-load the fasteners to 30 lbf in (0.339 mdaN).
- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- (3) Carry out an Operational Test of the main landing lights as detailed in 33-43-00, Adjustment/Test, followed by a Beam Alignment Test as detailed in 33-43-11, Adjustment/Test.

EFFECTIVITY: ALL

R

BA

Printed in England

# 33-43-11

Page 406  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

### LANDING LIGHT ASSEMBLY - ADJUSTMENT/TEST

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

**CAUTION:** THE MAIN LANDING LAMPS MUST NOT REMAIN ON FOR PERIODS GREATER THAN 20 min. EACH SUCH PERIOD MUST BE FOLLOWED BY A 45 min REST PERIOD.

IF LAMPS ARE ON FOR PERIODS NOT EXCEEDING 5 min, EACH SUCH PERIOD MUST BE FOLLOWED BY A 5 min REST PERIOD.

#### 1. General

This topic contains instructions for a Beam Alignment Test to ensure that the adjustable main landing lamps are correctly positioned with respect to the aircraft axis. The test includes lamp retraction adjustments to ensure full retraction of the lamp after beam alignment adjustments have been completed.

Operational, Functional and System Tests are not applicable to this topic, but an Operational Test of the main landing lights is detailed in 33-43-00, Adjustment/Test.

#### 2. Beam Alignment Test

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-
Torque spanner, 30 lbf in (0.339 mdaN)	-
Clinometer	-

##### B. Prepare (Ref. Fig. 501 )

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Ensure that the aircraft is standing on its wheels on a level surface with the nose landing gear bay doors closed. Ensure that a clear space extending at least 60 ft (18.3 m) is available in front of the main landing lamps.

EFFECTIVITY: ALL

BA

# 33-43-11

Page 501  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

- R (3) At the seat rails above the main landing gear,  
R at frame 58, check the aircraft attitude, using  
R the clinometer. The roll attitude must be 0 deg.  
R The pitch attitude may be 0 deg, 1 deg or 2 deg  
R nose-up.
- R (4) From the point on the ground immediately below  
R the centre of each main landing lamp, mark a line  
R (using chalked string or other suitable method)  
R extending forward for approximately 60 ft (18.3 m)  
R parallel to the aircraft centre line.
- R (5) Ensure that the MAIN LANDING LIGHTS (ON - OFF)  
light control switches on the flight compartment roof  
panel are at OFF, and the RETRACT - EXTEND position  
control switches are at RETRACT.

### C. Test

- (1) Set the appropriate left or right MAIN LANDING LIGHTS  
(RETRACT - EXTEND) position control switch to "EXTEND"  
and check that the associated landing lamp travels to  
its fully extended position.
- (2) Set the associated MAIN LANDING LIGHTS light control  
switch to "ON" and check that the landing lamp is  
lit.
- R (3) Check that the ellipse of light formed by the beam is  
R bisected by the associated line drawn in operation  
R B.(4). If not, adjust the lamp horizontal setting as  
R detailed in paragraph D.
- R (4) Check the vertical alignment as detailed in paragraph  
R E. Vertical Adjustment. If necessary, adjust the  
R vertical setting as detailed.

### D. Horizontal Adjustment (Ref. Fig. 502 )

- (1) Set the associated light control switch to "OFF".
- (2) Trip the associated circuit breakers listed below  
and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH LDG LT SUP	13-215	L24	C12

EFFECTIVITY: ALL

BA

Printed in England

# 33-43-11

Page 502  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH LDG LT CONT	13-215	L21	B11
LH LDG LT SUP	14-216	L25	C8
LH LDG LT CONT	14-216	L22	D8

- (3) Loosen the screws securing the lamp outer canopy to the lamp door.
  - (4) Support the lamp door and unscrew the fasteners securing the door to the bottom surface of the wing. Lower the door, complete with lamp, on its hinges.
  - (5) Loosen the three horizontal adjusting nuts disposed at 120 deg intervals around the periphery of the lamp outer canopy. Ensure that the white lines painted on the outer canopy coincide with those painted on the canopy retaining collar.
- NOTE: A new lamp will not have painted lines.
- (6) Close the lamp door and secure it temporarily with the fasteners.
  - (7) Remove the safety clips and reset the circuit breakers tripped in operation (2).
  - (8) Set the associated MAIN LANDING LIGHTS light control switch to "ON".
  - (9) Rotate the lamp until the correct horizontal setting is obtained (an adjustment of  $\pm 8$  deg is provided).
  - (10) Tighten the screws securing the lamp outer canopy to the lamp door.
  - (11) Set the associated MAIN LANDING LIGHTS position control switch to "RETRACT". Check that the lamp travels to its fully retracted position and that it fits flush in its housing.
  - (12) Set the position control switch to "EXTEND" and, when the lamp is fully extended, check that the correct horizontal setting is still obtained.

EFFECTIVITY: ALL

R

BA

# 33-43-11

Page 503  
Feb 28/77



Printed in England

# Concorde

## MAINTENANCE MANUAL

CMB 33 43 11 5 AAMO

CB15406/00A



Main Landing Lamps  
Figure 501

R

EFFECTIVITY: ALL

BA

Printed in England

**33-43-11**

Page 504  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

- (13) Set the associated light control switch to "OFF".
- (14) Trip the associated circuit breakers listed in paragraph (2) and fit safety clips.
- (15) Release the lamp door fasteners and lower the door on its hinges.
- (16) Tighten the three horizontal adjusting nuts around the periphery of the lamp outer canopy.

NOTE: If a new lamp assembly is installed, ensure that white lines are painted on the outer canopy and on the canopy retaining collar, for future horizontal alignment.

- (17) Close the lamp door and secure it with the fasteners. Torque-tighten the fasteners to 30 lbf in (0.339 mdaN).
- (18) Remove the safety clips and reset the circuit breakers tripped in operation (14).

### R E. Vertical Adjustment (Ref. Fig.501 and 502)

- (1) Ensure that the associated MAIN LANDING LIGHTS light control switch is at OFF and that the lamp is extended.
- (2) Ensure that the glass cover of the lamp is clean and dry. Support the clinometer on the cover face and check that the angle of the lamp with respect to the horizontal plane is as follows:-

R  
R

R  
R

Aircraft nose-up attitude 0 deg: clinometer reading 106 deg

R  
R

Aircraft nose-up attitude 1 deg: clinometer reading 105 deg

R  
R

Aircraft nose-up attitude 2 deg: clinometer reading 104 deg

- (3) If necessary, adjust the 'extend' limit micro-switch adjusting screw, painted red, inside the lamp outer canopy, until the correct angle is obtained.

R  
R

R  
R  
R

NOTE: Counter-clockwise rotation of the screw will increase the extension angle. One full turn is equal to 2 deg, approximately.

EFFECTIVITY: ALL

BA

# 33-43-11

Page 505  
Feb 28/77

# *Concorde*

## MAINTENANCE MANUAL

R  
R  
R  
R  
R

- (4) Set the associated MAIN LANDING LIGHTS position control switch to "RETRACT". Check that the lamp travels to its fully retracted position and that it fits flush in its housing.
- (5) Set the position control switch to "EXTEND" and, when the lamp is fully extended, using the clinometer, check that the correct vertical angle with respect to the horizontal plane is still obtained. Adjust as necessary and after each adjustment carry out a retract/extend cycle and recheck the lamp angle.

### F. Beam Elliptical Axis Adjustment (Ref. Fig. 502 )

- (1) If the major elliptical axis of the beam is not parallel to the aircraft vertical axis, loosen the screws securing the glass cover to the lamp. Adjust the screw on the worm drive on the side of the lamp inner assembly to rotate the sealed beam unit until the correct setting is obtained (an adjustment of  $\pm 8$  deg is provided).
- (2) Set the associated MAIN LANDING LIGHTS light control switch to "OFF".
- (3) Tighten the glass cover securing screws.

### G. Lamp Retraction Adjustment (Ref. Fig. 502 )

- (1) If the lamp does not fit flush in its housing after retraction, trip the associated circuit breakers listed in paragraph D.(2) and fit safety clips.
- (2) Support the lamp door and unscrew the fasteners securing the door to the bottom surface of the wing. Lower the door, complete with lamp, on its hinges.
- (3) Remove the cylindrical cap covering the micro-switches on the lamp drive assembly.
- (4) Adjust the microswitch camshaft by turning the adjusting screw (1/2 turn of the screw is approximately 0.05 in (1.27 mm) adjustment, measured between the rear edge of the glass cover and the outer canopy retaining collar).
- (5) Close the lamp door and secure it temporarily with

EFFECTIVITY: ALL

BA


# 33-43-11

Page 506  
Feb 28/77

Printed in England

# Concorde

## MAINTENANCE MANUAL



CMB 33-43-11-5 BAMO

Landing Lamp Adjustment Controls  
Figure 502

EFFECTIVITY: ALL

**33-43-11**

Page 507  
Feb 28/77

Printed in England



# *Concorde*

## MAINTENANCE MANUAL

the fasteners.

- (6) Remove the safety clips and reset the circuit breakers tripped in operation (1).
- (7) Set the associated main landing lights position control switch to "RETRACT". After retraction check that the lamp is flush in its housing.
- (8) Repeat operations (1) and (2), and (4) to (7), until the correct setting is obtained.
- (9) After final adjustment, trip the associated circuit breakers listed in paragraph D.(2), and fit safety clips.
- (10) Release the fasteners securing the lamp door and lower the door on its hinges.
- (11) Refit the cylindrical cap to the lamp drive assembly.
- (12) Close the lamp door and secure it with the fasteners. Torque-tighten the fasteners to 30 lbf in (0.339 mdaN).
- (13) Remove the safety clips and reset the circuit breakers tripped in operation (9).

### H. Conclusion

- R      (1) Carry out an Operational Test of the main landing lights as detailed in 33-43-00, Adjustment/Test.

EFFECTIVITY: ALL

BA

Printed in England

**33-43-11**

Page 508  
Feb 28/77

# *Concorde*

## MAINTENANCE MANUAL

### LAND/TAXI AND TURN-OFF LIGHTS - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig. 001 )

Two land/taxi lamps, mounted on the nose landing gear doors, supplement the illumination provided by the main landing lamps during landing (Ref. 33-43-00), and illuminate the area in front of the aircraft when taxiing.

Two taxi/turn-off lamps, one mounted on each side of the forward fuselage, provide ground illumination for identifying turn-off points.

The land/taxi and taxi/turn-off lamps, together, give ground illumination during taxiing of approximately 60 deg each side of the aircraft centre line.

The land/taxi lamps have retractable/extensible mountings and, when not in use, are retracted into housings in the aircraft structure. The lamps are extended to an intermediate position before landing and automatically extended on landing to the full position for taxiing, thereby changing the angle of the beam to compensate for the attitude change. Each lamp assembly is fitted with an automatic blowback device which allows the lamp to be blown back automatically into its housing during flight, at airspeeds greater than 300 kt, approximately, if the control switch has not been operated, or if the power supply to the lamp fails at the time of retraction.

Control of the land/taxi and turn-off lights is effected by switches on the flight compartment roof panel, operating in conjunction with supply control contactors mounted in the forward underfloor racking. A caption mounted close to the switches on the roof panel indicates the extended condition of one or both land/taxi lamps.

#### 2. Land/Taxi Lamps

A land/taxi lamp assembly is mounted in each door of the nose landing gear. Each lamp comprises a 600 W quartz halogen filament used during landing, and a 400 W quartz halogen filament used during taxiing, both contained in a sealed beam unit that can be extended from, or retracted into, its housing by an actuator driven by an integral electric motor. A motor control relay, 'land' and 'taxi' extend limit switches and a retract limit switch in the motor circuit, terminate lamp movement at the required limits. A light control relay and a step-down transformer in the light circuit, connected to the 115 V a.c. supply, provide a 28 V

EFFECTIVITY: ALL

BA


Printed in England

**33-44-00**

Page 1  
Aug 30/77

# Concorde

## MAINTENANCE MANUAL



- Land/Taxi and Turn-off Lamps  
Figure 001

operating voltage for the 600 W and 400 W filaments.

R A blowback device comprising spring, ratchet roller and  
R sun gear is fitted to the motor case, and allows air  
R pressure on the lamp lens, above the predetermined value,  
R to force the lamp back into its housing.

### 3. Taxi/Turn-off Lamps

A taxi/turn-off lamp is fitted to each side of the nose fairing below the forward facing windshields.

Each lamp consists of a 28 V 450 W sealed beam filament unit secured in a housing in the aircraft structure.

### 4. Land/Taxi Contactors

Two contactors, associated with the land/taxi lamps, are housed in the ground power panel (panel 10-123) in the forward underfloor racking.

### 5. Taxi/Turn-off Contactors

EFFECTIVITY: ALL

BA

Printed in England

**33-44-00**

Page 2  
Nov 30/75

# *Concorde*

## MAINTENANCE MANUAL

Two contactors, associated with the taxi/turn-off lamps, are mounted on the front structure of the forward underfloor racking (1-123).

### 6. Operation

#### A. Control and Indication (Ref. Fig. 002 )

Each land/taxi lamp is controlled primarily by a LANDING TAXI, two-position (ON - OFF) light control switch, and a two-position (EXTEND - RETRACT) position control switch mounted on sub-panel 1 of the flight compartment roof panel (panel 4-211).

A blue EXTENDED caption, mounted close to the land/taxi position control switches on the flight compartment roof panel, is illuminated when either lamp position control switch is set to EXTEND.

Normally the four land/taxi control switches are operated by a common switch bar, but each switch can be operated independently if required.

Each taxi-turn-off light is controlled by a TAXI/TURN two-position (ON - OFF) light control switch on sub-panel 1 of the flight compartment roof panel.

#### B. Functional Description (Ref. Fig.003 and 004)

During flight, when EXTEND is selected at a LANDING TAXI position control switch, a supply is connected through the 'land' limit switch to the 'extend' windings of the lamp motor which operates to extend the lamp from its housing.

As the lamp starts to extend, the retract limit switch closes and connects a supply from the EXTEND position of the switch to energize the light control relay, the contacts of which change over and connect the ON position of the light control switch to the step-down transformer, and to complete an earth return to light the EXTENDED caption. Subsequent operation of the light control switch to ON connects a 115 V a.c. supply to the step-down transformer to give a 28 V operating voltage to light the 600 W 'land' filament, through a contact of the land/taxi supply control contactor.

When the lamp is extended to the intermediate 'land' position, the supply to the lamp motor is interrupted by the operation of the 'land' limit switch which

EFFECTIVITY: ALL

**33-44-00**

R


BA

Page 3  
Nov 30/75

Printed in England

# Concorde

## MAINTENANCE MANUAL



CMB3344000 BANO

Controls and Indicators  
Figure 002

changes over to connect the supply to energize the motor control relay. When the relay is operated, one contact open-circuits the connection to the lamp motor, and a second contact connects a 'hold-on' supply to the relay coil from the EXTEND position of the control switch.

When the aircraft lands, the external supply control contactors are energized by the operation of the landing gear weight switch control relays, and the contacts change over. One contact completes an alternative supply from the EXTEND position of the control switch, through the internal 'taxi' limit switch to the extend windings of the lamp motor which operates to extend the lamp from the intermediate position to the fully extended 'taxi' position. A second contact open-circuits the 600 W land filament supply, and a third contact completes the supply to light the 400 W taxi filament.

When the lamp is fully extended, the supply to the lamp motor is interrupted by the operation of the 'taxi' limit switch which opens to isolate the lamp motor

EFFECTIVITY: ALL

33-44-00

Page 4  
Nov 30/75

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

'extend' windings.

Setting the LANDING TAXI position control switch to RETRACT interrupts the supply to the integral light control relay, the relay is de-energized and the contacts open to isolate the step-down transformer, and to open-circuit the earth connection of the EXTENDED caption. The caption and the taxi light are thus extinguished. A supply is also fed from the RETRACT position of the switch, through the retract limit switch, to the retract windings of the lamp motor which operates to retract the lamp into its housing. The 'hold-on' supply to the motor control relay is also disconnected and the relay is de-energized in preparation for a subsequent 'extend' operation.

In the fully retracted position the retract limit switch is operated and the contacts open to disconnect the supply from the lamp motor and to isolate the light control relay.

If the land/taxi lamp remains extended after take-off, due to a power supply failure, or by the position control switch being left at EXTEND, the automatic blowback device allows air pressure to force the lamp back into the retracted position when the airspeed exceeds 300 kt, approximately.

R

If the position control switch is at EXTEND when blowback occurs, the hold-on circuit of the motor control relay ensures that the relay remains energized, and therefore the extend windings of the motor remain isolated from the supply. This prevents the lamp from extending and retracting in a 'pumping' action.

To extend the lamp after blowback, it is therefore necessary to move the position control switch to RETRACT to release the hold-on circuit, and then reset the switch to EXTEND.

When the taxi/turn-off light control switch is set to ON, a supply is connected to the associated taxi/turn-off light control contactor. The contactor is energized and a supply is connected through a contact to light the taxi/turn-off lamp filament.

### 7. Electrical Power Supplies

The RH land/taxi lamp is supplied by two separate outputs from No.3 main 115 V a.c. busbar, each supply being fed through separate circuit breakers on panel 13-216. One of

EFFECTIVITY: ALL

BA


**33-44-00**

Page 5  
Aug 30/77

Printed in England

# Concorde

## MAINTENANCE MANUAL



- Land/Taxi Lights - Simplified Schematic  
Figure 003

EFFECTIVITY: ALL

BA


Printed in England

**33-44-00**

Page 6  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL



- Taxi/Turn-off Lights - Simplified Schematic  
Figure 004

these outputs also supplies the RH land/taxi supply control contactor.

The LH land/taxi lamp is supplied by two separate outputs from No.1 main 115 V a.c. busbar, each supply being fed through separate circuit breakers on panel 14-215. One of these outputs also supplies the LH land/taxi supply control contactor.

The EXTENDED caption is supplied from 'A' main 28 V d.c. busbar through a circuit breaker on panel 15-215.

The RH taxi/turn-off lamp is supplied from 'B' main 28 V d.c. busbar through a circuit breaker on panel 15-216. The LH taxi/turn-off lamp is supplied from 'A' main 28 V d.c. busbar through a circuit breaker on panel 15-215.

Both taxi/turn-off light control contactors are supplied from 'B' main 28 V d.c. busbar, through a common circuit breaker on panel 15-216.

EFFECTIVITY: ALL

**33-44-00**

R

BA

Page 7  
Aug 30/76

Printed in England



# Concorde

## MAINTENANCE MANUAL

R

### LAND/TAXI AND TURN-OFF LIGHTS - TROUBLE SHOOTING

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

**CAUTION:** DO NOT LEAVE A LAND/TAXI LAMP LIT FOR MORE THAN 5 min IN ANY 10 min PERIOD.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through IF OK and IF NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is OK.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

The LH and RH land/taxi and turn-off lights circuits are similar, therefore the procedures and charts are applicable to either. Where two identical components are involved, i.e., one in each circuit, both references to the associated components listed in Table 101 are given, e.g., 'Replace Contactor (11) or (12)'.

#### Preparation

A. Ensure that the associated circuit breakers are set (Ref. Table 101).

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812714

**33-44-00**

Page 101  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

- B. Make available electrical ground power as detailed in 24-41-00.

NOTE: During trouble shooting, the aircraft must be on its wheels with the landing gear weight switches depressed.

PRINTED IN ENGLAND

R

EFFECTIVITY: ALL

BA

C812715

**33-44-00**

Page 102  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting

- A. Prepare to trouble shoot (Ref. para.2). Trip CB (6) or (7) and fit a safety clip. As appropriate, set the LH or RH land/taxi lamp light control switch to "ON" and the position control switch to "EXTEND". Check that the associated 600 W lamp filament and the position indicator filaments light when the lamp begins to extend and that the motor cuts out when the lamp is extended to the 'land' position. IF -

OK

NOT OK

1. Lamp fails to extend to 'land' position - Chart 101.
2. Indicator filaments fail to light - Chart 102.
3. 600 W lamp filament fails to light - Chart 103.

- B. Remove safety clip and reset CB (6) or (7) and check that the 600 W filament goes out, the 400 W filament lights and the motor cuts out when the lamp is extended to the 'taxi' position. IF -

NOT OK

1. 600 W filament fails to go out. Replace lamp assembly.
2. 400 W filament fails to light - Chart 105.
3. Lamp fails to extend to 'taxi' position - Chart 104.

OK

R EFFECTIVITY: ALL

R BA

C812716

# 33-44-00

Page 103  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

C. As appropriate, set the RH or LH land/taxi position control switch to "RETRACT" and check that the indicator filaments and the lamp filament goes out when the lamp is fully retracted, then set the control switch to "OFF". IF -

OK

NOT OK

1. Indicator filaments fail to go out - renew lamp assembly.
2. Lamp filament fails to go out - renew lamp assembly.
3. Lamp fails to retract fully - Chart 106.

D. As appropriate, set the RH or LH taxi turn-off light control switch to "ON". Check that the associated turn-off lamp lights. IF -

NOT OK

1. Lamp fails to light - Chart 107.

R  
R

EFFECTIVITY: ALL

BA

C812717

# 33-44-00

Page 104  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

LAND/TAXI LAMP FAILS TO EXTEND TO 'LAND' POSITION WHEN POSITION CONTROL SWITCH IS AT 'EXTEND'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

Set the appropriate position control switch to "EXTEND".

Check for 115 V a.c. at terminal B of Lamp (15) or (16)

YES Renew Lamp (15) or (16)

NO

Check for 115 V a.c. at terminal 1 of Switch (9) or (13).

YES Locate and rectify open circuit between terminal 1 of Switch (9) or (13) and terminal B of Lamp (15) or (16).

NO

Check for 115 V a.c. at terminal 2 of Switch (9) or (13).

YES Renew Switch (9) or (13).

NO

Check for 115 V a.c. at output of CB (1) or (5).

YES Locate and rectify open circuit between terminal 2 of Switch (9) or (13) and CB (1) or (5).

NO

Renew CB (1) or (5).

Chart 101

# 33-44-00

Page 105  
Mar 29/96

EFFECTIVITY: ALL

BA

C812718


# Concorde

## MAINTENANCE MANUAL

INDICATOR FILAMENTS FAIL TO LIGHT WHEN THE APPROPRIATE LH OR RH LAMP POSITION CONTROL SWITCH IS AT 'EXTEND'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-



PRINTED IN ENGLAND

Chart 102 (Sheet 1 of 2)

EFFECTIVITY: ALL

BA

C812719

# 33-44-00

Page 106  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND




Chart 102 (Sheet 2 of 2)

R EFFECTIVITY: ALL

R

BA

C812836

# 33-44-00

Page 107  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

LAND/TAXI 600 W LAMP FILAMENT FAILS TO LIGHT WHEN THE LIGHT CONTROL SWITCH IS AT 'ON' AND THE LAMP IS EXTENDED.

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	
MULTIMETER -	

Set the appropriate light control switch to "ON" and position control switch to "EXTEND".

Check for 115 V a.c. at terminal M of Lamp (15) or (16).

YES

Check for 28 V a.c. at terminal 3 of Lamp (15) or (16).

YES

Check for open circuit between terminal 3 of Lamp (15) or (16) and terminal 6 of Contactor (11) or (12).

NO

NO

NO

Renew sealed beam unit.

Check for open circuit between terminal 5 of Contactor (11) or (12) and earth.

NO

NO

Renew Lamp (15) or (16).

Renew Contactor (11) or (12).

Chart 103 (Sheet 1 of 2)

EFFECTIVITY: ALL

BA

C812837

# 33-44-00

Page 108  
Mar 29/96

PRINTED IN ENGLAND



# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND




Chart 103 (Sheet 2 of 2)

R  
R

EFFECTIVITY: ALL

BA

C812838

# 33-44-00

Page 109  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

LAND/TAXI LAMP FAILS TO EXTEND TO 'TAXI' POSITION WHEN POSITION CONTROL SWITCH IS AT 'EXTEND' AND CIRCUIT BREAKERS (6) AND (7) ARE RESET.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY =	-
MULTIMETER	-

Remove safety clips and reset CB (6) and (7) then set position control switch to "EXTEND".

Check for 115 V a.c. at terminal D of Lamp (15) or (16).

YES Renew Lamp (15) or (16).

NO

Check for 115 V a.c. at terminal 8 of Contactor (11) or (12).

YES Locate and rectify open circuit between terminal 8 of Contactor (11) or (12) and terminal D of Lamp (15) or (16).

NO

Check for 115 V a.c. at terminal 7 of Contactor (11) or (12).

YES Renew Contactor (11) or (12).

NO

Check for 115 V a.c. at terminal 1 of Switch (9) or (13).

YES Locate and rectify open circuit between terminal 7 of Contactor (11) or (12) and terminal 1 of Switch (9) or (13).

NO

Chart 104 (Sheet 1 of 2)

EFFECTIVITY: ALL

# 33-44-00

BA

C812839

Page 110  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND




Chart 104 (Sheet 2 of 2)

R

EFFECTIVITY: ALL

R

BA

C812840

# 33-44-00

Page 111  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

LAND/TAXI 400 W LAMP FILAMENT FAILS TO LIGHT WHEN THE LIGHT CONTROL SWITCH IS AT 'ON' AND THE LAMP IS EXTENDED.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-

Set the appropriate light control switch to "ON" and position control switch to "EXTEND".

Check for 115 V a.c. at terminal M of Lamp (15) or (16).

YES

Check for 28 V a.c. at terminal 2 of Lamp (15) or (16).

YES

Check for open circuit between terminal 2 of Lamp (15) or (16) and terminal 4 of Contactor (11) or (12).

NO

Renew sealed beam unit.

NO

Renew Lamp (15) or (16) and re-test.

NO

Check for open circuit between terminal 3 of Contactor (11) or (12) and earth.

NO

Renew Contactor (11) or (12).

NO

PRINTED IN ENGLAND

Chart 105 (Sheet 1 of 2)

# 33-44-00

EFFECTIVITY: ALL

BA

C812841

Page 112  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND




Chart 105 (Sheet 2 of 2)

R EFFECTIVITY: ALL

R BA

C812842

# 33-44-00

Page 113  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

LAND/TAXI LAMP FAILS TO RETRACT  
WHEN THE POSITION CONTROL SWITCH  
IS SET AT 'RETRACT'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY -	-
MULTIMETER	-

Set the  
appropriate  
position  
control switch  
to "RETRACT".

Check for 115 V  
a.c. at terminal  
A of Lamp (15)  
or (16).

YES Renew Lamp (15) or  
(16).

NO

Check for 115 V  
a.c. at terminal  
3 of Switch (9)  
or (13).

YES Locate and rectify  
open circuit  
between terminal A  
of Lamp (15) or (16)  
and terminal 3 of  
Switch (9) or (13).

NO

Check for 115 V  
a.c. at terminal  
2/4 of Switch  
(9) or (13).

YES Renew Switch (9) or  
(13).

NO

Check for 115 V  
a.c. at output  
of CB (1) or  
(5).

YES Locate and rectify  
open circuit between  
terminal 2/4 of  
Switch (9) or (13)  
and CB (1) or (5).

NO

Renew CB (1) or  
(5).

Chart 106

EFFECTIVITY: ALL

BA

C812843

# 33-44-00

Page 114  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

TURN-OFF LAMP FAILS TO LIGHT WHEN  
CONTROL SWITCH IS SET AT 'ON'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

Set the appropriate turn-off lamp control switch to "ON".

Check for 28 V d.c. at terminal 1 of Lamp (24) or (25).

YES

Renew filament in Lamp (24) or (25).

NO

Check for 28 V d.c. at terminal L1 of Contactor (22) or (23).

YES

Locate and rectify open circuit between terminal 1 of Lamp (24) or (25) and L1 of Contactor (22) or (23).

NO

Check for 28 V d.c. at terminal A of Contactor (22) or (23).

YES

Check for 28 V d.c. at terminal X1 of Contactor (22) or (23).

YES

Renew Contactor (22) or (23).

NO

NO

Chart 107 (Sheet 1 of 2)

EFFECTIVITY: ALL

BA


C812844

# 33-44-00

Page 115  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL



PRINTED IN ENGLAND

Chart 107 (Sheet 2 of 2)

EFFECTIVITY: ALL

BA

C812845

# 33-44-00

Page 116  
Mar 29/96



# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL/ PANEL	ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 115 V	-	13-216	L42	Map ref.B9	24-50-00 R/I	
(2) Circuit breaker 115 V	-	13-216	L46	Map ref.B8	24-50-00 R/I	
(3) Circuit breaker 28 V	-	15-215	L43	Map ref.A13	24-50-00 R/I	
(4) Circuit breaker 115 V	-	14-215	L45	Map ref.E10	24-50-00 R/I	
(5) Circuit breaker 115 V	-	14-215	L41	Map ref.E11	24-50-00 R/I	
(6) Circuit breaker 28 V	-	3-213	G293	Map ref.B8	24-50-00 R/I	
(7) Circuit breaker 28 V	-	3-213	G294	Map ref.B9	24-50-00 R/I	
(8) RH land/ taxi light control switch	-	4-211	L52	Pilots' roof panel	33-44-00 R/I	
(9) RH land/ taxi position control switch	-	4-211	L53	Pilots' roof panel	33-44-00 R/I	
(10) Position indicator	-	4-211	L49	Pilots' roof panel	33-44-00 R/I	
(11) RH supply control contactor	-	10-123	L57	Underfloor racking	33-44-00 R/I	
(12) LH supply control contactor	-	10-123	L56	Underfloor racking	33-44-00 R/I	
(13) LH land/ taxi position control switch	-	4-211	L50	Pilots' roof panel	33-44-00 R/I	

EFFECTIVITY: ALL

BA

C812846

# 33-44-00

Page 117  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(14) LH land/taxi light control switch	-	4-211	L51	Pilots' roof panel	33-44-00 R/I	
(15) RH land/taxi lamp	-	128	L61	RH nosewheel door	33-44-00 R/I	
(16) LH land/taxi lamp	-	127	L60	LH nosewheel door	33-44-00 R/I	
(17) Circuit breaker 28 V	-	15-216	L48	Map ref.B12	24-50-00 R/I	
(18) Circuit breaker 28 V	-	15-216	L44	Map ref.B13	24-50-00 R/I	
(19) Circuit breaker 28 V	-	15-215	L47	Map ref.A14	24-50-00 R/I	
(20) RH taxi turn-off light control switch	-	4-211	L55	Pilots' roof panel	33-44-00 R/I	
(21) LH taxi turn-off light control switch	-	4-211	L54	Pilots' roof panel	33-44-00 R/I	
(22) RH light control contactor	-	1-123	L59	Underfloor racking	33-44-00 R/I	
(23) LH light control contactor	-	1-123	L58	Underfloor racking	33-44-00 R/I	
(24) RH turn-off lamp	-	122	L63		33-44-00 R/I	
(25) LH turn-off lamp	-	121	L62		33-44-00 R/I	

Component Identification  
Table 101

EFFECTIVITY: ALL

BA

C812876

# 33-44-00

Page 118  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

### LAND/TAXI AND TURN-OFF LIGHTS - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic contains instructions for the removal and installation of the light control contactors associated with the land/taxi and turn-off lights. These contactors are located in the forward underfloor racking.

Instructions for the removal and installation of associated control switches and the EXTENDED caption light module, mounted on the flight compartment roof panel, are contained in 33-00-00.

#### 2. Land/Taxi Light Control Contactor (Ref. Fig. 401 )

##### A. Equipment and Materials

R  
R  
R  
R

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

##### B. Prepare

- (1) Ensure that the LANDING/TAXI light control switches and the EXTEND - RETRACT position control switches, on the flight compartment roof panel, are at OFF and RETRACT respectively.
- (2) Trip the circuit breakers listed below and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH LDG/TAXI LT CONT	13-216	L42	B9
RH LDG/TAXI LT SUP	13-216	L46	B8
RH LDG/TAXI CONT	14-215	L41	E11
GRND POWER LTS SUP	25-216	X369	B9

EFFECTIVITY: ALL


BA

**33-44-00**

Page 401  
May 30/76

# Concorde

## MAINTENANCE MANUAL



- Control Contactors - Installation  
Figure 401

R

EFFECTIVITY: ALL

BA

Printed in England

**33-44-00**

Page 402  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

- (3) Open service compartment door 123 AB (Ref. 52-41-11) to gain access to the land/taxi light control contactor in the ground power panel, 10-123, mounted in the forward underfloor racking.

### C. Remove

- (1) Release the hold-down fasteners from the ground power panel hold-down hooks.
- (2) Withdraw the panel from the rack sufficiently to gain access to the quick-release cable clamps on top of the panel.
- (3) Release the cable clamps and remove the cables from the top of the panel.
- (4) Withdraw the panel clear of the rack and lower the panel on to a suitable support.
- (5) Remove the screws securing the top cover to the panel and remove the cover.
- (6) Remove the terminal covers from the contactor.
- (7) Disconnect the electrical cables from the contactor terminals.
- (8) Refit the terminal covers to the contactor.
- (9) Remove the screws and washers securing the contactor to its mounting and lift the contactor from the panel.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Place the contactor on its mounting in the ground power panel and secure it with the screws and washers.
- (3) Remove the contactor terminal covers.
- (4) Connect the electrical cables to the terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (5) Refit the terminal covers to the contactor.

EFFECTIVITY: ALL

**33-44-00**

Page 403  
May 30/76

Printed in England

# Concorde

## MAINTENANCE MANUAL

- (6) Fit the top cover to the panel and secure it with the screws.
- (7) Mount the panel on the end of the rack support rails and secure the cables to the top of the panel with the quick-release cable clamps.
- (8) Slide the panel into the racking and secure it with the hold-down fasteners.
- (9) Check that the panel is bonded in accordance with 20-27-11.

### E. Conclusion

- (1) Remove the safety clips and reset the circuit breakers tripped before removal.
- (2) Carry out an Operational Test of the land/taxi lights as detailed in Adjustment/Test.
- (3) Close and secure service compartment door 123 AB (Ref. 52-41-11).

### 3. Taxi/Turn-off Lights Control Contactor (Ref. Fig. 401 )

#### A. Equipment and Materials

R  
R  
R  
R

DESCRIPTION

PART NO.

Circuit breaker safety clips

-

#### B. Prepare

- (1) Ensure that the TAXI TURN light control switches on the flight compartment roof panel are at OFF.
- (2) Trip the circuit breakers listed below and fit safety clips.

SERVICE

PANEL

CIRCUIT  
BREAKER

MAP  
REF.

TAXI/TURN OFF LTS CONT

15-216

L44

B13

RH TAXI/TURN OFF LT SUP

15-216

L48

B12

EFFECTIVITY: ALL

BA

**33-44-00**

Page 404  
May 30/76

Printed in England

# Concorde

## MAINTENANCE MANUAL

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
LH TAXI/TURN OFF LT SUP	15-215	L47	A14

- (3) Open service compartment door 123 AB (Ref. 52-41-11) to gain access to the taxi/turn-off light control contactor mounted on the forward underfloor rack-ing structure.

### C. Remove

- (1) Remove the terminal cover from the contactor.
- (2) Disconnect the electrical cables from the contactor terminals.
- (3) Remove the bolts securing the contactor to the mounting tray and lift the contactor clear of the structure.
- (4) Refit the terminal cover to the contactor.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Remove the contactor terminal cover.
- (3) Fit the contactor on the mounting tray and secure it with the bolts.
- (4) Check that the contactor is bonded to the tray in accordance with 20-27-11.
- (5) Connect the electrical cables to the contactor terminals, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (6) Refit the terminal cover to the contactor.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

# 33-44-00

Page 405  
May 30/76

# *Concorde*

## MAINTENANCE MANUAL

- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- (3) Set the appropriate left or right TAXI TURN light control switch to "ON" and check that the associated taxi/turn-off lamp is lit. Return the switch to "OFF".
- (4) Close and secure service compartment door 123 AB (Ref. 52-41-00).
- (5) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

**33-44-00**

R

BA

Page 406  
May 30/76

Printed in England



# Concorde

## MAINTENANCE MANUAL

### LAND/TAXI AND TURN-OFF LIGHTS - ADJUSTMENT/TEST

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General

This topic contains an Operational Test only, which details the procedure to prove the correct operation of the land/taxi and turn-off lights. Functional and System Tests are not considered necessary in this application.

#### 2. Operational Test

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

##### B. Prepare

- (1) Make available electrical ground power as detailed in 24-41-00.

##### C. Test Land/Taxi Lights

**NOTE:** For this test the aircraft must be on its wheels with the landing gear weight switches depressed.

- (1) Depress the LIGHTS TEST switch on the pilots' roof panel and check that the land/taxi lights EXTENDED caption is illuminated.
- (2) Release the switch and check that the caption is extinguished.

**CAUTION:** SUBSEQUENT TEST PROCEDURES REQUIRE THE TRIPPING OF CIRCUIT BREAKERS, TO ESTABLISH LEFT-HAND AND RIGHT-HAND WEIGHT SWITCH OPERATED RELAYS IN THE 'IN-FLIGHT' POSITION. CARE MUST BE TAKEN TO ENSURE THAT ALL SERVICES ADVERSELY AFFECTED BY THIS CONDITION ARE PREVIOUSLY ISOLATED. (REF. 7-11-00).

DO NOT LEAVE THE LAND/TAXI LAMP LIT FOR MORE THAN 5 min IN ANY 10 min PERIOD.

EFFECTIVITY: ALL

BA

Printed in England

**33-44-00**

Page 501  
Feb 29/76

# Concorde

## MAINTENANCE MANUAL

- R (3) Trip the LH UC WEIGHT SW 'A' SYS SUP circuit breaker  
R G292, on panel 1-213, map ref.M17, and the RH UC  
R WEIGHT SW 'B' SYS SUP circuit breaker G294, on panel  
R 3-213, map ref.B9, and fit safety clips. This de-  
R energizes the associated weight switch relays thus  
R simulating flight conditions. Ensure that all  
R services adversely affected by this condition are  
R isolated.
- (4) Set the LH LANDING TAXI LIGHTS switch to "ON"  
and check that the land/taxi lamp is not lit.
- (5) Set the LH LANDING TAXI LIGHTS - RETRACT - EXTEND  
switch to "EXTEND".
- (6) Check that, as the LH land/taxi lamp commences to  
extend, the 600 W filament is lit and the  
EXTENDED caption is illuminated.
- (7) Check that the lamp travels to the landing  
position and that the motor cuts out.
- (8) Set the LH LANDING TAXI LIGHTS switch to "OFF"  
and check that the lamp is not lit.
- (9) Return the switch to ON and check that the 600 W  
filament is again lit.
- R (10) Remove the circuit breaker safety clip and reset  
circuit breaker G292. Check that -
- (a) the 600 W filament is extinguished,
- (b) the 400 W filament is lit,
- (c) the lamp extends to the taxi position,
- (d) the motor then cuts out and
- (e) the EXTENDED caption remains illuminated.
- (11) Set the LH LANDING TAXI LIGHTS switch to "OFF"  
and check that the LH land/taxi lamp is not lit.
- (12) Return the switch to "ON" and check that the  
400 W filament is again lit.
- (13) Set the LH LANDING TAXI LIGHTS - RETRACT - EXTEND  
switch to "RETRACT".
- (14) Check that the LH lamp travels to its fully

EFFECTIVITY: ALL

BA

Printed in England

**33-44-00**

Page 502  
Aug 30/75

# *Concorde*

## MAINTENANCE MANUAL

- R retracted position and that during the initial  
R retract sequence -
- (a) the light goes out,
- R (b) the EXTENDED caption is extinguished and
- R (c) in the fully retracted position the motor cuts  
R out.

(15) Set the LH LANDING TAXI LIGHTS switch to "OFF".

(16) Repeat operations (4) to (15) inclusive,  
substituting the RH switches and lamp and,  
in operation (10), resetting circuit breaker  
R G294 in place of G292.

(17) Ensure that the weight switch relay controlled  
services, isolated in accordance with the  
requirements of operation (3), are reinstated as  
required.

### D. Test Turn-off Lights

- (1) On the pilots' roof panel, operate the left-hand  
TAXI TURN LIGHTS switch to "ON" and check that  
the left taxi turn-off lamp is lit.
- (2) Return the switch to "OFF" and check that the  
light is extinguished.
- (3) Operate the right-hand TAXI TURN LIGHTS switch  
to "ON" and check that the right taxi turn-off  
lamp is lit.
- (4) Return the switch to "OFF" and check that the  
light is extinguished.

### E. Conclusion

- (1) Switch off and disconnect electrical ground power  
as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

**33-44-00**

Page 503  
Aug 30/75

# Concorde

## MAINTENANCE MANUAL

### LAND/TAXI LIGHT - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General (Ref. Fig. 401 )

This topic contains instructions for the renewal of a land/taxi lamp glass cover (lens) and the renewal of a sealed beam unit, and for the removal and installation of a land/taxi lamp assembly.

Two land/taxi lamps are fitted, one in each of the main door assemblies of the nose landing gear bay. The back of each lamp is protected by a cover which, in turn, is fitted with a plug access cover.

Renewal of a glass cover and a sealed beam unit is normally carried out with the lamp retracted, but can be carried out with the lamp in the extended position if necessary. Removal and installation of the lamp assembly can be conducted only with the nose landing gear bay doors open.

#### 2. Lens (Ref. Fig. 401 )

##### A. Renew

- (1) Support the glass cover and remove the three screws securing the glass cover to the lamp inner assembly. Remove the glass cover and the retaining ring from the lamp, taking care that the sealed beam unit does not fall from its housing.

**CAUTION:** ENSURE THAT THE SEALED BEAM UNIT IS CORRECTLY ORIENTATED AND POSITIONED IN ITS HOUSING BEFORE FITTING THE RETAINING RING AND GLASS COVER TO THE LAMP, OTHERWISE DAMAGE MAY BE CAUSED TO THE LAMP INNER ASSEMBLY AND THE SEALED BEAM UNIT.

- (2) Ensure that the sealed beam unit is correctly positioned in its housing, with the word TOP, stencilled on the glass face, located toward the drive assembly, i.e., toward the front of the aircraft when the lamp is installed, and the locating lug, on the side of the sealed beam unit, correctly seated in the adjustment bracket within the lamp housing.
- (3) Press the sealed beam unit inward against the pressure springs, maintain the pressure and refit

EFFECTIVITY: ALL

BA

Printed in England

# 33-44-11

Page 401  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

the retaining ring and glass cover to the lamp and secure the glass cover with the screws.

### 3. Sealed Beam Unit - Renewal (Ref. Fig. 401 )

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Ensure that the LANDING TAXI light control switch is at OFF.
- (2) Trip the associated circuit breakers listed below and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH LDG/TAXI LT SUP	13-216	L46	B8
RH LDG/TAXI LT CONT	13-216	L42	B9
LH LDG/TAXI LT SUP	14-215	L45	E10
LH LDG/TAXI LT CONT	14-215	L41	E11

#### C. Renew

- (1) Support the lamp glass cover and remove the screws securing the glass cover to the lamp inner assembly. Remove the glass cover and the retaining ring from the lamp.
- (2) Withdraw the sealed beam unit from the lamp inner assembly sufficiently to gain access to the electrical cables.
- (3) Label the electrical cables to assist identification for reconnection. Disconnect the electrical cables from the terminals on the sealed beam unit.

EFFECTIVITY: ALL


**33-44-11**

Page 402  
Feb 28/77

Printed in England

# Concorde

## MAINTENANCE MANUAL



- Land/Taxi Lamp Assembly - Installation  
Figure 401

R

EFFECTIVITY: ALL

BA

Printed in England

**33-44-11**

Page 403  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

- (4) Remove the sealed beam unit.

CAUTION: ENSURE THAT THE SEALED BEAM UNIT IS CORRECTLY ORIENTATED AND POSITIONED IN ITS HOUSING BEFORE FITTING THE RETAINING RING AND GLASS COVER TO THE LAMP, OTHERWISE DAMAGE MAY BE CAUSED TO THE LAMP INNER ASSEMBLY AND THE SEALED BEAM UNIT.

- (5) Support the replacement unit and connect the electrical cables to the terminals, ensuring that the connections are made in accordance with the cable identifications.
- (6) Orientate the sealed beam unit until the word TOP, stencilled on the glass face, is located toward the lamp drive assembly, i.e., toward the front of the aircraft when the lamp is installed.
- (7) Insert the sealed beam unit into its housing in the lamp inner assembly and manipulate the unit until the locating lug is seated in the adjustment bracket within the housing.
- (8) Press the sealed beam unit inward against the pressure springs, sustain pressure and refit the retaining ring and glass cover to the lamp and secure the glass cover with the screws.

### D. Conclusion

- (1) Remove the safety clips and reset the circuit breakers tripped before renewal.
- (2) Carry out an Operational Test of the land/taxi lights as detailed in 33-44-00, Adjustment/Test, followed by a Beam Alignment Test as detailed in 33-44-11, Adjustment/Test.

### 3. Land/Taxi Lamp - Removal/Installation (Ref. Fig. 401 )

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

EFFECTIVITY: ALL

BA

**33-44-11**

Page 404  
Feb 28/77

Printed in England

# Concorde

## MAINTENANCE MANUAL

- (1) Open the nose landing gear bay doors (Ref. Chap.32).
- (2) Ensure that the LANDING TAXI light control and position control switches are at OFF and RETRACT respectively.
- (3) Trip the LDG/TAXI LTS POSN IND circuit breaker L43 on panel 15-215, map ref.A13, and fit a safety clip.
- (4) Trip the associated circuit breakers listed below and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH LDG/TAXI LT SUP	13-216	L46	B8
RH LDG/TAXI LT CONT	13-216	L42	B9
LH LDG/TAXI LT SUP	14-215	L45	E10
LH LDG/TAXI LT CONT	14-215	L41	E11

### C. Remove

- (1) Remove the bolts securing the plug access cover and slide it back on the electrical cable to gain access to the electrical connectors.
- (2) Disconnect the lamp assembly electrical connectors.
- (3) Remove the bolts securing the lamp cover to the door and remove the cover from the lamp.
- (4) Support the lamp assembly. Remove the screws around the periphery of the lamp outer canopy and lift the lamp, together with the gasket, from the door.

R

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Orientate the lamp assembly so that the drive mechanism is located toward the front of the aircraft.
- (3) Fit the lamp assembly, together with the gasket,

R

EFFECTIVITY: ALL

BA

Printed in England

# 33-44-11

Page 405  
Feb 28/77



# *Concorde*

## MAINTENANCE MANUAL

to its mounting on the nose landing gear bay door and secure the outer canopy to the door with the eight mounting screws, ensuring that the three horizontal adjusting nuts and bolts are in position and tight.

- (4) Check that the lamp is bonded in accordance with 20-27-11.
- (5) Place the lamp cover over the lamp and secure the cover to the door with the bolts.
- (6) Connect the electrical connectors to the lamp assembly, ensuring that the mating surfaces are clean and undamaged.
- (7) Fit the plug access cover to the lamp cover and secure it with the bolts.

### E. Conclusion

- (1) Close the nose landing gear bay doors (Ref. Chap.32).
- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- (3) Carry out an Operational Test of the land/taxi lights as detailed in 33-44-00, Adjustment/Test, followed by a Beam Alignment Test as detailed in 33-44-11, Adjustment/Test.

EFFECTIVITY: ALL

R

BA

# 33-44-11

Page 406  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

### LAND/TAXI LIGHT - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS  
DETAILED IN 24-00-00.

CAUTION: THE LAND/TAXI LAMPS MUST NOT REMAIN ON FOR  
PERIODS GREATER THAN 20 min. EACH SUCH PERIOD  
MUST BE FOLLOWED BY A 45 min REST PERIOD.

IF LAMPS ARE ON FOR PERIODS NOT EXCEEDING 5 min,  
EACH SUCH PERIOD MUST BE FOLLOWED BY A 5 min  
REST PERIOD.

SUBSEQUENT TEST PROCEDURES REQUIRE THE TRIPPING  
OF CIRCUIT BREAKERS, TO ESTABLISH LEFT-HAND AND  
RIGHT-HAND WEIGHT SWITCH OPERATED RELAYS IN THE  
'IN-FLIGHT' POSITION. CARE MUST BE TAKEN TO  
ENSURE THAT ALL SERVICES ADVERSELY AFFECTED BY  
THIS CONDITION ARE PREVIOUSLY ISOLATED  
(REF. 7-11-00).

#### 1. General

This topic contains instructions for a Beam Alignment Test  
to ensure that the adjustable land/taxi lamps are correctly  
positioned with respect to the aircraft axis, and for  
lamp retraction adjustments to ensure full retraction of  
the lamp after beam alignment adjustments have been  
completed.

Operational, Functional and System Tests are not applicable  
to this topic, but an Operational Test of the land/taxi  
lights is detailed in 33-44-00, Adjustment/Test.

#### 2. Beam Alignment Test

##### A. Equipment and Materials

---

DESCRIPTION	PART NO.
Circuit breaker safety clips	-
Clinometer	-

---

##### B. Prepare (Ref. Fig. 501 )

(1) Make available electrical ground power as detailed

EFFECTIVITY: ALL

BA

Printed in England

# 33-44-11

Page 501  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

in 24-41-00.

- R  
R  
R
- (2) Ensure that the aircraft is standing on its wheels on a level surface with the nose landing gear bay doors closed. Ensure that a clear space extending at least 30 ft (9.15 m) is available in front of the land/taxi lamps.
- R  
R  
R  
R  
R
- (3) At the seat rails above the main landing gear, at frame 58, check the aircraft attitude, using the clinometer. The roll attitude must be 0 deg. The pitch attitude may be 0 deg, 1 deg or 2 deg nose-up.
- R  
R  
R  
R  
R  
R
- (4) From the point on the ground immediately below the centre of each land/taxi lamp, mark a line (using chalked string or other suitable method) extending forward and passing through a point 30 ft (9.15 m) forward of the lamp and 21 in (533.4 mm) from the aircraft centre line.
- R
- (5) Ensure that the LANDING TAXI LIGHTS - ON - OFF control switches on the flight compartment roof panel are at OFF, and the RETRACT - EXTEND position control switches are at RETRACT.
- (6) Trip circuit breakers LH UC WEIGHT SW 'A' SYS SUP, G292, on panel 1-213, map ref.M17, and RH UC WEIGHT 'B' SYS SUP, G294, on panel 3-213, map ref.B9, and fit safety clips. This will de-energize the weight switch relays, thus simulating flight conditions. Ensure that all services adversely affected by this condition are isolated (Ref. 7-11-00).

### C. Test

- (1) Set the appropriate left or right LANDING TAXI LIGHTS - RETRACT - EXTEND position control switch to "EXTEND" and check that the associated land/taxi lamp travels to its landing position.
- (2) Set the associated LANDING TAXI LIGHTS light control switch to "ON" and check that the land/taxi lamp is lit.
- R  
R  
R  
R
- (3) Check that the ellipse of light formed by the beam is bisected by the associated line drawn in operation B.(4). If not, adjust the horizontal setting as detailed in paragraph D.

EFFECTIVITY: ALL

BA

# 33-44-11


Page 502  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

CMB 33 44 11 5 AAM0

CB15407/00A



R

Land/Taxi Lamps  
Figure 501

EFFECTIVITY: ALL

BA

Printed in England

# 33-44-11

Page 503  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

- R (4) Check the vertical alignment as detailed in  
R paragraph E. Landing Position Vertical Adjustment.  
R If necessary, adjust the vertical setting as  
R detailed.

### D. Horizontal Adjustment (Ref. Fig. 502 )

- (1) Set the associated light control switch to "OFF".  
(2) Trip the associated circuit breakers listed below  
and fit safety clips.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
RH LDG/TAXI LT SUP	13-216	L46	B8
RH LDG/TAXI LT CONT	13-216	L42	B9
LH LDG/TAXI LT SUP	14-215	L45	E10
LH LDG/TAXI LT CONT	14-215	L41	E11

- (3) Loosen the screws securing the lamp outer canopy  
to the nose landing gear bay door.  
(4) Open the nose landing gear bay doors (Ref. Chap.32).  
(5) Remove the plug access cover and the lamp cover  
from the lamp (Ref. Removal/Installation).  
(6) Loosen the three horizontal adjusting nuts disposed  
at 120 deg intervals around the periphery of  
the lamp outer canopy. Ensure that the white  
lines painted on the outer canopy coincide with  
those painted on the canopy retaining collar.  
**NOTE:** A new lamp will not have painted lines.  
(7) Refit the lamp cover and plug access cover over  
the lamp and temporarily secure the covers.  
(8) Close the nose landing gear bay doors (Ref. Chap.32).  
(9) Remove the safety clips and reset the circuit  
breakers tripped in operation (2).

EFFECTIVITY: ALL

BA

**33-44-11**

Page 504  
Feb 28/77

# *Concorde*

## MAINTENANCE MANUAL

- (10) Set the associated LANDING TAXI LIGHTS light control switch to "ON".
- (11) Rotate the lamp until the correct horizontal setting is obtained (an adjustment of  $\pm 8$  deg is provided).
- (12) Tighten the screws securing the lamp outer canopy to the nose landing gear bay door.
- (13) Set the associated LANDING TAXI LIGHTS position control switch to "RETRACT". Check that the lamp travels to its fully retracted position and that it fits flush in its housing.
- (14) Set the position control switch to "EXTEND" and, when the lamp is extended to the landing position, check that the correct horizontal setting is still obtained.
- (15) Set the associated light control switch to "OFF".
- (16) Trip the associated circuit breakers listed in operation (2) and fit safety clips.
- (17) Open the nose landing gear bay doors (Ref. Chap.32), and remove the plug access cover and lamp cover.
- (18) Tighten the three horizontal adjusting nuts around the periphery of the lamp outer canopy.

NOTE: If a new lamp assembly is installed, ensure that white lines are painted on the outer canopy and on the canopy retaining collar, for future horizontal alignment.

- (19) Refit the lamp cover and plug access cover to the lamp and secure them with the bolts.
- (20) Close the nose landing gear bay doors.
- (21) Remove the safety clips and reset the circuit breakers tripped in operation (16).

### R E. Landing Position Vertical Adjustment (Ref. Fig.501 and 502)

- (1) Ensure that the associated LANDING TAXI LIGHTS light control is at OFF and that the lamp is extended to the landing position.

EFFECTIVITY: ALL

BA

Printed in England

# 33-44-11

Page 505  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

- (2) Ensure that the glass face of the lamp is clean and dry. Support the clinometer on the lamp face and check that the angle of the lamp with respect to the horizontal plane is as follows:-

R  
R

Aircraft nose-up attitude 0 deg: clinometer reading 106 deg

R  
R

Aircraft nose-up attitude 1 deg: clinometer reading 105 deg

R  
R

Aircraft nose-up attitude 2 deg: clinometer reading 104 deg

R  
R

- (3) If necessary, adjust the landing position 'extend' limit microswitch adjusting screw, inside the lamp outer canopy, until the correct vertical setting is obtained.

R

NOTE: The landing position 'extend' limit microswitch adjusting screw is painted red. Counter-clockwise rotation of the screw will increase the extension angle. One full turn is equal to 2 deg, approximately.

R  
R  
R

- (4) Set the associated LANDING TAXI LIGHTS position control switch to "RETRACT". Check that the lamp travels to its fully retracted position and that it fits flush in its housing.

- (5) Set the position control switch to "EXTEND" and, when the lamp is extended to its landing position, using the clinometer, check that the correct vertical angle with respect to the horizontal plane is still obtained. Adjust as necessary and after each adjustment carry out a retract/extend cycle and recheck the lamp angle.

R  
R  
R  
R  
R

### F. Beam Elliptical Axis Adjustment (Ref. Fig. 502 )

- (1) If the major elliptical axis of the beam is not parallel to the aircraft vertical axis, loosen the screws securing the glass face to the lamp. Adjust the screw on the worm drive on the side of the lamp inner assembly to rotate the sealed beam unit until the correct setting is obtained (an adjustment of  $\pm 8$  deg is provided).
- (2) Set the associated LANDING TAXI LIGHTS light control switch to "OFF".

EFFECTIVITY: ALL

BA

# 33-44-11

Page 506  
Feb 28/77

# *Concorde*

## MAINTENANCE MANUAL

(3) Tighten the glass face securing screws.

### G. Lamp Retraction Adjustment (Ref. Fig. 502 )

- (1) If the lamp does not fit flush in its housing after retraction, fully extend the lamp, then trip the associated circuit breakers listed in paragraph D.(2) and fit safety clips.
- (2) Open the nose landing gear bay doors and remove the plug access cover and lamp cover.
- (3) Remove the cylindrical cap covering the micro-switches on the lamp drive assembly.
- (4) Adjust the microswitch camshaft by turning the adjusting screw (1/2 turn of the screw gives approximately 0.05 in (1.27 mm) adjustment, measured between the rear edge of the lens and the outer canopy retaining collar).
- (5) Refit the covers over the lamp and secure them temporarily.
- (6) Remove the safety clips and reset the circuit breakers tripped in operation (1).
- (7) Set the associated LANDING TAXI LIGHTS position control switch to "RETRACT". After retraction check that the lamp is flush in its housing.
- (8) Repeat operations (1) and (2) and (4) to (7), until the correct setting is obtained.
- (9) After final adjustment, trip the associated circuit breakers listed in operation D.(2), and fit safety clips.
- (10) Open the nose landing gear bay doors and remove the plug access cover and lamp cover.
- (11) Refit the cylindrical cap to the lamp drive assembly.
- (12) Refit the lamp cover and plug access cover to the lamp and secure them with the bolts.
- (13) Close the nose landing gear bay doors.
- (14) Remove the safety clips and reset the circuit breakers tripped in operation (9).

EFFECTIVITY: ALL

R

BA


# 33-44-11

Page 507  
Feb 28/77



# Concorde

## MAINTENANCE MANUAL



CMB 33-44-11-5 BAMO

- Land/Taxi Lamp Adjustment Controls  
Figure 502

EFFECTIVITY: ALL

**33-44-11**

R

BA

Page 508  
Feb 28/77

Printed in England

# Concorde

## MAINTENANCE MANUAL

### H. Taxi Position Vertical Adjustment (Ref. Fig.501 and 502)

- R  
R
- (1) Reset circuit breakers LH UC WEIGHT SW 'A' SYS SUP, G292, on panel 1-213, map ref.M17, and RH UC WEIGHT SW 'B' SYS SUP, G294, on panel 3-213, map ref.B9, to establish aircraft taxiing conditions.
- R
- (2) Ensure that the weight switch relay controlled services, isolated with the requirements of operation B.(6), are reinstated as required.
- R
- (3) Set the associated LANDING TAXI LIGHTS light control and position control switches to "ON" and "EXTEND" respectively. Check that the lamp extends to the 'taxi' position and that the lamp is lit.
- R  
R
- (4) Set the associated LANDING TAXI LIGHTS light control switch to 'off'.
- R  
R  
R  
R
- (5) Ensure that the glass cover of the lamp is clean and dry. Support the clinometer on the glass face and check that the angle of the lamp with respect to the horizontal plane is as follows:-
- R
- Aircraft nose-up attitude 0 deg: clinometer reading 95 deg
- R
- Aircraft nose-up attitude 1 deg: clinometer reading 94 deg
- R
- Aircraft nose-up attitude 2 deg: clinometer reading 93 deg
- R
- (6) If adjustment is required, correct the setting of the taxi position 'extend' limit microswitch by adjusting the black screw inside the lamp outer canopy until the correct vertical setting is obtained.

NOTE: The taxi position 'extend' limit microswitch adjusting screw is black. Counter-clockwise rotation of the screw will increase the extension angle. One full turn is equal to 2 deg, approximately.

Only vertical settings are required at this stage.

- (7) Complete a full retract, extend and retract cycle

EFFECTIVITY: ALL

BA

Printed in England

# 33-44-11

Page 509  
Feb 28/77

# *Concorde*

## MAINTENANCE MANUAL

to ensure that the vertical setting is still obtained.

R  
R

### I. Conclusion

R

- (1) Carry out an Operational Test of the land/taxi lights as detailed in 33-44-00, Adjustment/Test.

EFFECTIVITY: ALL

BA

Printed in England

# 33-44-11

Page 510  
Feb 28/77

# Concorde

## MAINTENANCE MANUAL

R

### TURN-OFF LIGHT - REMOVAL/INSTALLATION

**WARNING:** OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

#### 1. General (Ref. Fig. 401)

This topic contains instructions for the renewal of a turn-off lamp sealed beam unit, and for the removal and installation of a turn-off lamp assembly.

Two turn-off lamps are fitted, one on each side of the forward fuselage, below the forward-facing windshield.

#### 2. Sealed Beam Unit - Renewal (Ref. Fig. 401)

##### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

##### B. Prepare

- (1) Ensure that the left or right TAXI TURN LIGHTS switch, as appropriate, is at "OFF".
- (2) Trip the associated RH TAXI/TURN OFF LT SUP circuit breaker L48, on panel 15-216, map ref.B12, or the LH TAXI/TURN OFF LT SUP circuit breaker L47, on panel 15-215, map ref.A14, and fit a safety clip.

##### C. Renew

- (1) Remove the screws securing the lamp cover to the lamp housing and withdraw the cover, complete with lens, from the lamp.
- (2) Release the captive screws securing the sealed beam unit retainer in the lamp housing, remove the retainer and withdraw the sealed beam unit from its mounting sufficiently to gain access to the screw terminals.
- (3) Label the electrical cables to assist identification for reconnection. Disconnect the electrical cables from the terminals and remove the sealed beam unit.

R

EFFECTIVITY: ALL

BA

C812255


# 33-44-12

Page 401  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



Turn-off Lamp Assembly - Installation  
Figure 401

CMB 33 44 12 4 AAMD 00

R

EFFECTIVITY: ALL

BA

# 33-44-12

Page 402  
Mar 29/96

# Concorde

## MAINTENANCE MANUAL

- (4) Support the replacement sealed beam unit and connect the electrical cables to the screw terminals, ensuring that the connections are made in accordance with the cable identifications.
- (5) Fit the sealed beam unit to its mounting in the lamp housing, support the unit, refit the retainer and secure it with the captive screws.
- (6) Fit the lamp cover, complete with lens, to the lamp housing, support the cover and secure it with the screws.

### D. Conclusion

- (1) Remove the safety clip and reset the circuit breaker tripped before removal.
- (2) Make available electrical ground power as detailed in 24-41-00.

**CAUTION:** DO NOT LEAVE THE TURN-OFF LAMP LIT FOR MORE THAN 5 min IN ANY 10 min PERIOD.

- (3) Set the appropriate left or right TAXI TURN LIGHTS switch to "ON" and check that the associated turn-off lamp is lit. Return the switch to "OFF".
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### 3. Turn-off Lamp - Removal/Installation (Ref. Fig. 401)

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Ensure that the left or right TAXI TURN LIGHTS switch, as appropriate, is at "OFF".
- (2) Trip the associated RH TAXI/TURN OFF LT SUP circuit breaker L48, on panel 15-216, map ref.B12, or the LH TAXI/TURN OFF LT SUP circuit breaker L47, on panel 15-215, map ref.A14, and fit a safety clip.

R

EFFECTIVITY: ALL

BA

C812256

**33-44-12**

Page 403  
Mar 29/96

# *Concorde*

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

### C. Remove

- (1) Remove the screws securing the lamp cover to the lamp housing and withdraw the cover, complete with lens, from the lamp.
- (2) Remove the screws securing the lamp housing to the aircraft structure and withdraw the lamp housing, together with the gasket, from the aircraft fuselage to the extent of the electrical cable.
- (3) Disconnect the electrical connector and remove the turn-off lamp.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the turn-off lamp and connect the electrical connector, ensuring that the mating surfaces are clean and undamaged.
- (3) Position the lamp on its mounting on the aircraft structure. Support the lamp, fit the gasket around the periphery of the lamp and secure the assembly to the mounting with the screws.
- (4) Fit the lamp cover, complete with lens, to the lamp housing, support the cover and secure it with the screws.

### E. Conclusion

- (1) Remove the safety clip and reset the circuit breaker tripped before removal.
- (2) Make available electrical ground power as detailed in 24-41-00.

**CAUTION:** DO NOT LEAVE THE TURN-OFF LAMP LIT FOR MORE THAN 5 min IN ANY 10 min PERIOD.

- (3) Set the appropriate left or right TAXI TURN LIGHTS switch to "ON" and check that the associated turn-off lamp is lit. Return the switch to "OFF".
- (4) Switch off and disconnect electrical ground power as detailed in 24-41-00.

R

EFFECTIVITY: ALL

BA

C812257

# 33-44-12

Page 404  
Mar 29/96

**END OF THIS  
SECTION**

**NEXT**



# *Concorde*

## MAINTENANCE MANUAL

### EMERGENCY LIGHTING - DESCRIPTION AND OPERATION

#### 1. General (Ref. Fig.001 and 002)

- A. The emergency lighting system consists of two separate and independent lighting circuits (System A and System B).

System A operates if the aircraft d.c. essential supplies fail. The system comprises a lighting circuit consisting of rechargeable 6 V batteries which light filaments in the flight compartment roof lamps (Ref. 33-12-00), the forward and rear passenger cabin emergency lanterns, the threshold lamps in each door and in the exit signs and exit direction signs. These filaments are connected in groups (Ref. Table 1) and each group is supplied by its own electronically switched battery pack.

System B operates if the aircraft a.c. supply feeding the main lighting system fails or whenever the NO SMKG switch is at ON (Ref. 33-25-00). System B comprises a 'standby' lighting circuit which consists of the 28 V filaments in the exit signs and exit direction signs, the cabin 'dim' lighting (Ref. 33-23-00), the vestibule 'dim' lighting (Ref. 33-23-00) and toilet standby lighting (Ref. 33-22-00).

- B. When testing the Emergency Lighting System of aircraft with Floor Proximity Lighting Systems installed (Mod 33D022), it is important to note that the Pilots Emergency Light Switch will operate both the Overhead Emergency Lighting System and the Floor Proximity Lighting System. Extreme care must be exercised, whenever testing of the Emergency Lighting System is carried out to avoid depletion of the Floor Proximity Lighting System NON-RECHARGEABLE battery packs.

CAUTION: "ON TEST" MUST BE USED WHENEVER IT IS NECESSARY TO TEST THE OVERHEAD EMERGENCY LIGHTING, "OFF TEST" MUST BE USED WHENEVER IT IS NECESSARY TO TEST THE FLOOR PROXIMITY LIGHTING.

- C. The Attendant's Emergency Light Switch will cause the Floor Proximity Lights to be energised and deplete the batteries and must therefore not be used to turn the Emergency Lights ON unless absolutely necessary.

- (1) Use of the Emergency Light Test position of the Attendants panel Emergency Light Switch installed on Concorde will cause the Floor Proximity Lights to come ON. This switch is not to be used for testing the existing Overhead Emergency Lights or Floor Proximity Lights.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737398

**33-51-00**

Page 1  
Sep 29/89

*Concorde*  
MAINTENANCE MANUAL

Left Blank Intentionally

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

748024

**33-51-00**

Page 1A  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

RB D. Whenever it is necessary to test the existing Overhead  
RB Emergency Lighting, use must be made of the "ON TEST" Mode  
RB of the Floor Proximity Light System. This test is described  
RB in 33-51-00 page 201.

### 2. Flight Compartment Roof Lamps

Three 6 V filaments are fitted in each roof lamp in the flight compartment (Ref. 33-12-00).

### 3. Emergency Lanterns (Ref. Fig.003)

Each emergency lantern comprises a reflector assembly, four 6 V filaments and a clear lens which fits flush with the aircraft furnishing line. The reflector is hinged to its mounting bracket and held in the closed position by a securing bolt. The clear lens is secured to the reflector by spring clips and is removable for the replacement of filaments.

GROUP NO.	BATTERY PACK LOCATION	SIGNS AND LAMPS SUPPLIED
1	Fwd. vestibule roof	Fwd. service door EXIT sign  Fwd. service door threshold lamp

Continued on Page 2

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737399

**33-51-00**

Page 1B  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

GROUP NO.	BATTERY PACK LOCATION	SIGNS AND LAMPS SUPPLIED
2	Fwd. vestibule roof	Fwd. passenger door EXIT sign  Fwd. passenger door threshold lamp  Fwd. vestibule exit direction sign
3	Between luggage bins on left side of fwd. cabin, level with centre roof lantern	Three roof lanterns spaced at intervals in the fwd. cabin roof
4	Centre vestibule roof	Centre service door EXIT sign  Centre service door threshold lamp  Centre vestibule exit direction sign (forward)
5	Centre vestibule roof	Centre passenger door EXIT sign  Centre passenger door threshold lamp  Centre vestibule exit direction sign (rear)
6	Between luggage bins on left side of rear cabin, level with second roof lantern	Three roof lanterns spaced at intervals in the rear cabin roof
7	Rear vestibule roof	Rear right door EXIT sign

EFFECTIVITY: ALL

BA

**33-51-00**

Page 2  
Jun 30/75

Printed in England

# Concorde

## MAINTENANCE MANUAL

GROUP NO.	BATTERY PACK LOCATION	SIGNS AND LAMPS SUPPLIED
		Rear right door threshold lamp
		Rear vestibule exit direction sign
8	Above rear steward's control panel	Rear left door EXIT sign
		Rear left door threshold lamp
		Roof lantern in rear cabin
-	Flight compartment roof	6 V filaments in flight compartment roof lamps

System A Emergency Light Grouping  
Table 1

#### 4. Above-door Exit Signs (Ref. Fig.003 and 004)

The EXIT sign above each passenger and service door consists of a case in which are fitted five 6 V filaments and four 28 V filaments covered by a translucent sign engraved EXIT, and two 6 V and two 28 V filaments fitted along the bottom exterior surface of the case and covered by a clear lens. Light through the clear lens illuminates the door exit area.

The translucent sign is secured to the case by spring clips and is easily removable for replacement of filaments.

The clear lens on the bottom of the case is removed by releasing two captive screws securing the lens to the case.

#### 5. Exit Direction Signs (Ref. Fig.003 and 004)

The exit direction signs above the centre aisles each

EFFECTIVITY: ALL

BA


**33-51-00**






Page 3  
Jun 30/75



# Concorde

## MAINTENANCE MANUAL

CMB3351000HAMO



-  EMERGENCY LANTERNS
-  EXIT DIRECTION SIGNS
-  DOOR EXIT SIGNS
-  THRESHOLD LAMPS
-  BATTERY PACK  
(WITH GROUP NUMBER OF LAMPS SUPPLIED)



Emergency Lighting - System A  
Figure 001

EFFECTIVITY: ALL

BA

Printed in England


**33-51-00**

Page 4  
Jun 30/75



# Concorde

## MAINTENANCE MANUAL

CMB3351000JAMO



- CABIN 'DIM' LIGHTING
- VESTIBULE 'DIM' LIGHTING
- ▲ TOILET FLAMENT LIGHTING
- DOOR EXIT SIGNS
- EXIT DIRECTION SIGNS



Emergency Lighting - System B  
Figure 002

EFFECTIVITY: ALL

BA

Printed in England

**33-51-00**

Page 5  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

comprise five 6 V filaments and six 28 V filaments fitted behind a translucent sign panel engraved EXIT.

The translucent sign panel is fitted to the lamp case by means of a groove along the lower edge of the panel and secured at the upper edge by a retaining strip. Finger recesses in the panel facilitate removal of the panel from the lamp case.

### 6. Threshold Lamps (Ref. Fig. 003 )

The threshold lamp in each door comprises four 6 V filaments enclosed by a front and rear cover secured together by two captive screws. The front cover incorporates a clear lens which directs the light downward towards the door threshold. The assembly is secured in the door structure by a retaining ring which is screwed to the door panel. On the rear doors the threshold lamp is mounted on the escape pack.

### 7. Battery Pack (Ref. Fig. 003 )

Each battery pack comprises a case containing a rechargeable 6 V cadmium nickel battery, a solid state battery control circuit, a charging circuit and a terminal block. A cover is secured to the case by six captive screws and is removable to gain access to the components.

The battery is secured in the case by a retainer fitted with felt anti-vibration pads and held in position by two captive screws.

### 8. Operation (Ref. Fig. 005 )

#### A. Control and Indication

System A emergency lighting is controlled by a pilots' OFF - ARM - ON emergency (EMERG) lighting control switch on the lights section of the flight compartment roof panel, and by a steward's TEST - NORMAL - ON emergency (EMERG) lighting control switch on the forward steward's control panel.

The pilots' EMERG switch includes a filament in the toggle which lights when the switch is in the OFF position, and at the other two positions when the associated LIGHT TEST switch is pressed (Ref. 33-14-00). The switch is mechanically locked (pull-to-unlock) in each position and is effective as follows:-

EFFECTIVITY: ALL

BA

**33-51-00**


Page 6  
Jun 30/75

Printed in England



# Concorde

## MAINTENANCE MANUAL



System A - Location of Equipment  
Figure 003

EFFECTIVITY: ALL

BA


Printed in England

**33-51-00**

Page 7  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL



- System B - Location of Equipment  
Figure 004

EFFECTIVITY: ALL

BA

Printed in England

**33-51-00**

Page 8  
Jun 30/75

# Concorde

## MAINTENANCE MANUAL

RB	SWITCH	28V DC	CONNECTED TO
RB	POSITION	SUPPLY	BATTERY PACK TERMINALS
RB	"OFF"	'A' ESSENTIAL	OFF (and toggle switch filament)
RB		'A' MAIN	ARM
RB		'A' MAIN	ARM
RB	"ARM"	'A' MAIN	ARM
RB	"ON"	'A' ESSENTIAL	ON

The steward's panel EMERG switch is mechanically locked (pull-to-unlock for NORMAL-to-ON operation) and spring-loaded to return the toggle to NORMAL from the TEST position, and is effective as follows:

RB CAUTION: DO NOT OPERATE CABIN SWITCH TO 'ON' OR 'TEST' (WHEN  
RB PILOTS SWITCH TO 'ARM') DURING AIRCRAFT MAINTENANCE  
RB UNLESS THE FLOOR PROXIMITY LIGHTING IS DE-ACTIVATED  
RB REF 33-52-00 PAGE 201.

RB	Pilots EMERG	Cabin EMERG	Battery pack inputs/
RB	Switch Position	Switch Position	System Operation
RB	OFF	TEST	28 V d.c. ESS removed from OFF terminals, 28 V d.c. MAIN removed from ARM terminals; lights remain extinguished
RB		NORM	As per pilots switch
RB		ON	28 V d.c. ESS connected to ON terminals, 28 V d.c. ESS removed from OFF terminals, 28 V d.c. MAIN removed from ARM terminals; lights illuminate
RB	ARM	TEST	28 V d.c. MAIN removed from ARM terminal, lights illuminate
RB		NORM	As per pilots switch
RB		ON	28 V d.c. MAIN removed from ARM terminal, 28 V d.c. ESS. connected to ON TERMINAL; lights illuminate
RB	ON	TEST	As per pilots switch
RB		NORM	As per pilots switch
RB		ON	Cabin switch provides a second connection from 28 V d.c. ESS to ON terminal

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND


737401

# 33-51-00

Page 9  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL



Systems A and B - Controls and Indicators  
Figure 005

System 'B' stand-by lighting, for illuminating the over-door exit signs and exit direction signs, is controlled by one contact of the NO SMKG ON/OFF switch (Ref.33-25-00) on the flight compartment roof panel, or by the emergency oxygen system services relay (Ref.35-21-00). If the NO SMKG switch is at ON or the relay is energized, the 'A' essential 28 V d.c. busbar is connected to the standby filaments in each exit sign.

### B. Functional Description (Ref. Fig.006)

Under normal operating conditions the pilots' EMERG lighting switch on the flight compartment roof panel is set at ARM and the steward's EMERG lighting switch on the forward steward's panel at NORMAL. With 'A' main 28 V d.c. supplies available, power is applied to each battery electronic switching circuit which is activated to trickle-charge the battery and to arm the battery for automatic operation if the 28 V d.c. supply fails. All 6 V emergency lights are extinguished.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737402

33-51-00

Page 10  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

A subsequent loss of the 28 V d.c. supply will initiate electronic switching in the battery pack to complete the circuit from each battery to the associated filaments and simultaneously terminate the trickle-charge supply. All 6 V emergency filaments will be lit.

RB Setting the pilots' EMERG switch to ON connects 'A' essential  
RB 28 V d.c. to the ON terminals of all the emergency light  
RB battery packs. The system is now selected hard on, and will  
RB remain ON until the switch is deselected from ON, or the  
RB system batteries are depleted.

RB When the pilots EMERG switch is at OFF, 'A' essential 28 V d.c.  
RB is connected to the OFF terminal and 'A' main 28 V d.c. is  
RB connected to the ARM/CHARGE terminal of each battery unit. The  
RB OFF supply ensures the system is off when selected and allows  
RB the subsequent removal of A.C. power without activating the  
RB emergency light system.

When the aircraft is on the ground, to avoid automatically switching on the emergency lighting system with consequent draining of the batteries, it is essential that the EMERG switch on the flight compartment roof panel is set at OFF before the aircraft electrical supplies are switched off.

The steward's EMERG switch operates in the same way as the pilots' EMERG switch when at ON, and lights the 6 V filaments. When the pilots' EMERG switch is at ARM and the steward's EMERG switch is pressed to TEST, the 28 V d.c. supply to the battery pack is disconnected, thus simulating loss of power, and all 6 V emergency filaments are switched on by the battery pack electronic switching.

When the NO SMKG switch (Ref. 33-25-00) on the flight compartment roof panel is set to ON or the emergency oxygen services relay (Ref.35-21-00) is energized, a 28 V d.c. supply is connected to light the 'standby' filaments in the exit signs over the doors and the exit direction signs over the centre aisles.

Failure of the aircraft a.c. power supplies to the main cabin lighting will automatically switch on the associated system B 'standby' filament lighting in the passenger cabins (Ref.33-21-00), vestibules (Ref. 33-23-00) and toilets (Ref. 33-22-00).

### 9. Electrical Power Supplies

System A is powered from rechargeable batteries within power packs located close to the groups of emergency light units they control.

RB The batteries are trickle-charged from 'A' main 28 V d.c. busbar,  
RB through a circuit breaker on circuit breaker panel 15-215.

RB System B is supplied from the 'A' essential 28 V d.c. busbar  
RB through a circuit breaker on circuit breaker panel 1-213.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND


737403

# 33-51-00

Page 11  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL



Emergency Lighting - Simplified Schematic  
Figure 006

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737405

**33-51-00**

Page 12  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

### EMERGENCY LIGHTING - TROUBLE SHOOTING

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

CAUTION: ALL CHECKS WITH 6 V EMERGENCY LIGHTS ON MUST BE COMPLETED AS QUICKLY AS POSSIBLE TO CONSERVE THE LIFE OF THE BATTERIES.

RB CAUTION: WHEN TROUBLESHOOTING SYSTEM A EMERGENCY LIGHTING, THE FLOOR  
RB PROXIMITY LIGHTING SYSTEM MUST FIRST BE DE-ACTIVATED  
RB I.A.W. 33-52-00 PAGE 201.

#### 1. General

Faults are dealt with on a probability basis and identified as a result of testing.

The defect can be isolated with the aid of trouble shooting procedures (Ref. para.3.), and traced through if OK and if NOT OK paths to the appropriate charts or other specified rectification action as may be necessary. If a defect occurs, perform the appropriate rectification action, then repeat the operation at which the defect was encountered to ensure that the operation is O.K.

Bracketed numbers in the procedures and charts indicate items on the component identification table (Ref. Table 101). The table provides information, including component location, required for rectification. Component location also indicates the possible necessity of repositioning certain items of ground service equipment. Each chart also specifies the ground equipment required for that particular task.

All procedures dealing with trouble shooting are based on the assumption that electrical wiring is serviceable, all associated circuit breakers are set and electrical power is available, unless otherwise stated. If the fault is not rectified, check the wiring in accordance with the Wiring Diagram Manual (Ref. Table 101).

This topic contains trouble shooting procedures and charts for System A emergency Lighting, and for the 28 V lighting in the exit signs associated with System B. Trouble shooting procedures and charts for the remainder of System B emergency lighting are contained in cabin lighting, boarding and vestibule lighting, and toilet lighting trouble shooting (Ref. 33-21-00, 33-23-00 and 33-22-00, respectively).

Systems A emergency battery packs and the associated group of signs and lamps that each battery pack controls, are listed in Description and Operation, Table 1.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737514

# 33-51-00

Page 101  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

### 2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 101).
- B. Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737515

**33-51-00**

Page 102  
Sep 29/89



# Concorde

## MAINTENANCE MANUAL

### 3. Trouble Shooting - System A

RB CAUTION: WHEN TROUBLESHOOTING SYSTEM A EMERGENCY LIGHTING, THE  
RB FLOOR PROXIMITY LIGHTING SYSTEM MUST FIRST BE  
RB DE-ACTIVATED I.A.W. 33-52-00 PAGE 201.

- A. Prepare to trouble shoot (Ref. para.2.). Ensure that pilots' and steward's EMERG light switches are at OFF and NORMAL respectively. Check that filament in pilots' EMERG switch toggle is lit.  
IF -

OK

NOT OK

1. Filament in toggle not lit - renew filament. If toggle still not lit - Chart 101.

- RB B. Set pilots' EMERG switch to "ARM" and check that toggle light is extinguished. Trip CB (2) and check that all 6 V emergency lamps, lanterns and exit signs are lit.  
IF -

OK

NOT OK

1. Individual filaments not lit - renew filaments.
2. One group of filaments not lit - remove associated battery from emergency battery pack and replace with a fully charged battery. If still not OK, renew associated battery pack.
3. No 6 V emergency lighting. Check all 6 V batteries. If not OK - renew or recharge batteries. If OK - Chart 102.

- RB C. Reset CB (2) and check that all 6 V emergency lighting is extinguished. Set pilots' EMERG switch to "ON" and check that all 6 V emergency lamps, lanterns and exit signs are lit.  
IF -

OK

NOT OK

1. No emergency lighting - Chart 103

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND


737516

**33-51-00**


Page 103  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL



### 4. Trouble Shooting - System B



EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737517

**33-51-00**

Page 104  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL

PILOTS' EMERG' LIGHT  
SWITCH TOGGLE NOT  
LIT WHEN AT 'OFF'

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

Set pilots'  
EMERG switch  
to "OFF"

Check for 28 V  
d.c. at  
terminal 9  
of Switch (3)

YES

Renew  
Switch (3)

NO

Check for 28 V  
d.c. output  
from CB (1).

YES

Locate and  
rectify O/C  
in wiring  
between CB  
(1) and  
Switch (3).

NO

Renew CB (1).

RB  
RB

RB

Chart 101

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737518

# 33-51-00

Page 105  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL

NO 6 V EMERGENCY  
LIGHTING WHEN POWER  
FAILURE SIMULATED.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-

Rest CB (1) .  
Set pilots' EMERG switch to "ON" and steward's EMERG switch to "NORMAL"

Check that all 6 V emergency filaments are lit.

YES

Set switch (3) to "ARM" and check for 28 V d.c. at terminal 12

NO

Renew Switch (3)

NO

See Chart 103.

YES

Check for 28 V at terminal 8 of Switch (4).

NO

Locate and rectify O/C in wiring between Switch (3) and Switch (4).

YES

Check for 28 V at terminal 9 of Switch (4).

NO

Renew Switch (4)

YES

Locate and rectify O/C in wiring between Switch (4) and emergency battery packs.

Chart 102

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737519

# 33-51-00

Page 106  
Sep 29/89


# Concorde

## MAINTENANCE MANUAL

NO 6 V EMERGENCY LIGHTING WHEN PILOTS' 'EMERG' SWITCH SET TO 'ON'.

### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO.
GROUND POWER SUPPLY	-
MULTIMETER	-



CHB3351001KAM0

Chart 103

R EFFECTIVITY: ALL

BA


Printed in England

**33-51-00**

Page 107  
Feb 28/81

# Concorde

## MAINTENANCE MANUAL



CIB3351001LANO

Chart 104

R EFFECTIVITY: ALL

BA


Printed in England

**33-51-00**

Page 108  
Feb 28/81

# Concorde

## MAINTENANCE MANUAL



CHB3351001/2A10

Chart 105

R

EFFECTIVITY: ALL

BA

Printed in England

**33-51-00**

Page 109  
Feb 28/81

# *Concorde*

## MAINTENANCE MANUAL

RB

ITEM NO. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP IDENT	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
(1) Circuit breaker 28 V	-	1-213	L831	Map ref. Q22	24-50-00 R/I	
(2) Circuit breaker 28 V	-	15-215	L9058	Map ref. C13	24-50-00 R/I	
(3) EMERG switch	-	4-211	L832	Flight compartment roof panel	33-00-00 R/I	
(4) EMERG switch	-	1-221	L833	Fwd. steward's control panel	33-20-00 R/I	
(5) NO SMKG switch	-	4-211	W194	Flight compartment roof panel	33-00-00 R/I	

Component Identification  
Table 101

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737546

# 33-51-00

Page 110  
Sep 29/89



# *Concorde*

## British airways

### MAINTENANCE MANUAL

#### EMERGENCY LIGHTING - MAINTENANCE PRACTICES

##### 1. General

The Floor Proximity Lighting System is controlled by the existing Pilot's Emergency Light Switch and operates in a similar manner to the existing Emergency Lights, e.g. with the Pilot's Emergency Light Switch selected to "ARM", in the event that 28 V d.c. main power is lost, the Floor Proximity Lights will automatically switch ON.

##### 2. Testing

A. There are two test modes.

- (1) "OFF TEST" - used to test the system without energising the floodlights thus conserving battery life. The LED's described above are used to determine system serviceability. This test lasts for 15 minutes.
- (2) "ON TEST" - used when testing the existing Overhead Emergency Lights and the Floor Proximity system. In this mode the Control Modules will transmit "OFF" commands for 15 minutes allowing sufficient time to check the LED monitors on the Aisle and Exit Units. The overhead Emergency Lights will be on during this period.

CAUTION: IF LEFT IN THIS TEST MODE FOR LONGER THAN 15 MINUTES THE FLOOR PROXIMITY LIGHTS WILL SWITCH ON.

B. "OFF TEST" Procedure

- (1) With the Pilot's Emergency Switch selected to "OFF", select the switch from "OFF" to "ARM" then wait at least 5 seconds.
- (2) Next, pausing not longer than 1/2 second at each selection cycle the switch as follows:

ON - ARM - ON - ARM - OFF

NOTE: The Floor Proximity system is now in "OFF TEST" mode and will remain so for 15 minutes. The Overhead Emergency Lights and the Floor Proximity Lights will not be illuminated.

To reset the system within this period, switch to "ARM", pause at least 1 second, then switch to "OFF", the Floor Proximity system will shutdown after approximately 15 seconds.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737520

**33-51-00**

Page 201  
Sep 29/89

***Concorde***  
**British airways**  
**MAINTENANCE MANUAL**

- (3) Check Aisle and Exit Unit monitor LED's to ensure that at least two Control Module signals are being received by each unit and Battery condition/Floodlight Filament continuity are satisfactory.

NOTE: The LED's will blink in a random manner if a unit is serviceable.

- (4) The "OFF TEST" will terminate automatically after 15 minutes.

C. "ON TEST" Procedure

- (1) With Pilot's Emergency Light Switch selected to "OFF", switch from "OFF" to "ARM", then wait at least 5 seconds.
- (2) Next, pausing not longer than 1/2 second at each selection, cycle the switch as follows:

ON - ARM - ON

NOTE: The Overhead Emergency lights will be ON and the Floor Proximity Lights will be OFF. The Floor Proximity Aisle units and the Exit Unit monitor LED's will be active. After 15 minutes the Floor Proximity system will switch ON.

To reset within this period switch to "ARM", pause at least 1 second then switch to "OFF". The Overhead Emergency Lights will extinguish and after 10 - 15 seconds the Floor Proximity system will shut down.

- (3) Check the serviceability of the Overhead Emergency lights. Check Aisle and Exit Unit monitor LED's to ensure that at least two Control Module signals are being received by each unit and Battery condition/Floodlight Filament continuity are satisfactory.

NOTE: The LED's will blink in a random manner if a unit is serviceable.

- (4) Complete the "ON TEST" procedure within 15 minutes.

CAUTION: IF THE ON TEST IS PROLONGED FOR LONGER THAN 15 MINUTES, THE NON RECHARGEABLE FLOODLIGHT BATTERIES FOR THE FLOOR PROXIMITY SYSTEM CAN BE DEPLETED TO UNACCEPTABLE LEVELS.

- (5) Terminate the test by selecting "ARM", pause at least 1 second, then select "OFF".

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737542

**33-51-00**

Page 202  
Sep 29/89

***Concorde***  
**British airways**  
**MAINTENANCE MANUAL**

**3. Additional Information/Requirements**

- A. During the "OFF TEST" and "ON TEST" procedure, random short duration floodlight operation may occur. This phenomenon is acceptable.
- B. To obviate damage to Aisle Light Floodlight wiring, care should be taken to ensure that lens assemblies are adequately supported when installing/removing aisle units to or from the seat brackets. The lens assembly swivels should be secured by use of the unit top cap and securing bolts (2 off) prior to sliding the unit into the seat brackets.
- C. The Battery Condition monitor LED's will not blink after the floodlights have been in operation until the battery pack voltage has had time to recover. Even short term Floodlight operation will necessitate at least a 5 minute wait before the Battery Monitor LED's are re-instated.
- D. It is emphasised that the Floor Proximity Lights are powered by limited life non-rechargeable batteries. Casual operation of the system is not permitted, the system is only to be checked at the routine intervals called up in the relevant maintenance schedules.
- E. The pilot's Emergency Light Switch must not be left selected to the "ARM" position if the electrical power is disconnected from the aircraft. In such cases the switch must be selected to "OFF" prior to removal of electrical power.
- F. The pilot's Emergency Light Switch must not be selected to "ON" except as required for routine testing.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737543

**33-51-00**

Page 203  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

### EMERGENCY LIGHTING - SERVICING

#### 1. General

- A. Servicing of the Emergency Lighting System consists of battery charging in situ after installation.

Each battery pack contains a removable cadmium-nickel battery, Page type D366-01-100. In the event of a battery failure, the faulty battery can be replaced with a fully charged battery, i.e., one that has been initially charged on the bench for at least 16 h before installation, or an uncharged battery which must be charged in situ for a minimum period of 16 h after installation. Instructions for the replacement of batteries are contained in Removal/Installation.

- RB B. When testing the Emergency Lighting System of aircraft with  
RB Floor Proximity Lighting Systems installed (Mod 33D022), it is  
RB important to note that the Pilots Emergency Light Switch will  
RB operate both the Overhead Emergency Lighting System and the  
RB Floor Proximity Lighting System. Extreme care must be  
RB exercised, whenever testing of the Emergency Lighting System  
RB is carried out to avoid depletion of the Floor Proximity  
RB Lighting System NON-RECHARGEABLE battery packs.

#### 2. Battery Packs - Charging In Situ

##### A. Prepare

- RB CAUTION: "ON TEST" MUST BE USED WHENEVER IT IS NECESSARY TO  
RB TEST THE OVERHEAD EMERGENCY LIGHTING.

- (1) Make available electrical ground power as detailed in 24-41-00.

##### B. Charge

- RB (1) Set the pilots' EMERG LIGHT switch on the flight  
compartment roof panel to "OFF", and check that the  
steward's EMERG light switch on the forward steward's  
control panel is at NORMAL. In this condition all  
emergency lighting batteries are being trickle-charged.
- (2) Allow the batteries to recharge for a minimum uninterrupted period of 16 h.

##### C. Conclusion

CAUTION: ALL CHECKS CARRIED OUT WITH EMERGENCY LIGHTS ON MUST BE COMPLETED AS QUICKLY AS POSSIBLE TO CONSERVE THE LIFE OF THE BATTERIES.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737544

**33-51-00**

Page 301  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

- RB (1) The Attendant's Emergency Light Switch will cause the  
RB Floor Proximity Lights to be energised and deplete the  
RB batteries. It must therefore not be used to turn the  
RB Emergency Lights ON unless absolutely necessary.
- RB (a) Use of the Emergency Light Test position of the  
RB Attendants panel Emergency Light Switch will cause  
RB the Floor Proximity Lights to come ON. This switch  
RB is not to be used for testing the existing Overhead  
RB Emergency Lights or Floor Proximity Lights.
- RB (2) Whenever it is necessary to test the existing Overhead  
RB Emergency Lighting, use must be made of the "ON TEST"  
RB Mode of the Floor Proximity Light System, as detailed in  
RB 33-51-00 page 201.
- (3) Switch off and disconnect electrical power as detailed  
in 24-41-00.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737545

**33-51-00**

Page 302  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

### EMERGENCY LIGHTING - REMOVAL/INSTALLATION

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

CAUTION: "ON TEST" MUST BE USED WHENEVER IT IS NECESSARY TO TEST THE OVERHEAD EMERGENCY LIGHTING.

CAUTION: ALL CHECKS WITH 6 V EMERGENCY LIGHTING ON MUST BE COMPLETED AS QUICKLY AS POSSIBLE TO CONSERVE THE LIFE OF THE BATTERIES.

#### 1. General (Ref. Fig. 401)

This topic contains instructions for the renewal of 6 V and 28 V emergency light filaments and 6 V batteries, and for the removal and installation of emergency lanterns, exit direction signs, over-door exit signs, door threshold lamps and battery packs.

To renew door threshold lamp filaments necessitates the removal of the complete threshold lamp assembly from the associated passenger door structure.

Each battery pack with its group number and the associated lamps and signs which it supplies, is shown in Description and Operation, Table 1.

Instructions for the removal and installation of the pilots' and steward's emergency light control switches are contained in 33-00-00 and 33-20-00 respectively.

RB The attendants Emergency Light switch will cause the Floor  
RB Proximity Lights to be energised and deplete the batteries and must  
RB therefore not be used to turn the Emergency Lights to ON unless  
RB absolutely necessary.

RB Use of the Emergency Light Test position of the Attendants panel  
RB Emergency Light switch installed on Concorde will cause the Floor  
RB Proximity Lights to come ON. This switch is not to be used for  
RB testing the existing Overhead Emergency Lights or Floor Proximity  
RB Lights.

#### 2. Emergency Light Filaments - Renewal

##### A. Prepare

- (1) Ensure that the pilots' EMERG light control switch and the NO SMKG switch on the flight compartment roof panel are at OFF and the steward's EMERG light control switch on the forward steward's control panel is at NORMAL.
- (2) Gain access to the appropriate filament by removing the associated lens or cover from the lamp or sign as follows:-

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737461


**33-51-00**






Page 401  
Sep 29/89


# Concorde

## MAINTENANCE MANUAL

CMB 33 51 00 4 AAM0



-  EMERGENCY LANTERNS
-  EXIT DIRECTION SIGNS
-  OVER-DOOR EXIT SIGNS
-  THRESHOLD LAMPS
-  BATTERY PACK  
(WITH GROUP NUMBER OF LAMPS SUPPLIED)



Location of Equipment  
Figure 401

EFFECTIVITY: ALL

BA

Printed in England

**33-51-00**

Page 402  
Jun 30/75

# *Concorde*

## MAINTENANCE MANUAL

### (a) Emergency Lanterns

- a1) Pull down the translucent lens to release the spring slips from the reflector and remove the lens.

### (b) Exit Direction Signs

- b1) Free the lower edge of the sign panel from its locating groove, (finger recesses are provided to facilitate this) and then ease the upper edge of the panel from its locating strip.

### (c) Over-door Exit Signs

- c1) For filaments behind the sign panel, pull the panel to release the spring clips from the lamp case and remove the panel. For filaments below the sign, release the two captive screws securing the lens to the case and remove the lens.

### (d) Door Threshold Lamps

- d1) See paragraph 7. Door Threshold Lamp.

## B. Renew Filament

- (1) For 28 V filaments, unscrew the filament retaining ring and remove the filament. Renew the filament and refit the retaining ring. For 6 V filaments, withdraw the filament from the holder and fit a replacement filament.

## C. Conclusion

- (1) Refit the associated lens or cover to the lamp or sign.
- (2) For 28 V filaments, set the NO SMOKING switch to "ON" and check that the appropriate filament is lit. Return the switch to "OFF".
- (3) For 6 V filaments, carry out "ON TEST" as detailed in 33-51-00 page 201.

## 3. Emergency Light Batteries - Renewal (Ref. Fig. 402)

### A. Equipment and Materials.

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737463

**33-51-00**

Page 403  
Sep 29/89



# Concorde

## MAINTENANCE MANUAL

### B. Prepare

- (1) Ensure that the pilots' EMERG switch on the flight compartment roof panel and the steward's EMERG light switch on the forward steward's control panel are at OFF and NORMAL respectively.

RB (2) Deactivate Floor Proximity Lights (33-52-00 page 201).

RB (3) Trip the CABIN EMERG LTS EXIT SIGN SUP circuit breaker  
RB L83, on panel 1-213, map ref. Q22. and EMERG LTS ARM/  
RB CHARGE SUP. circuit breaker L9058, on panel 15-215, map  
RB ref. C13, and fit safety clips.

R (4) Gain access to the appropriate battery pack as follows:-

R Before SB 33-019

- (a) Groups Nos. 1 and 2, 4 and 5, and 7: mounted in the forward, centre and rear vestibule roof respectively.

a1) Release the clamping strips from the transverse joints of the appropriate ceiling panel and remove the panel.

R After SB 33-019 For A/C 001-004,

R (a) Groups Nos. 1 and 2, 4 and 5 and 7: mounted in the  
R forward, centre and rear vestibule roof res-  
R pectively.

R a1) For Groups Nos. 1 and 2, 4 and 5: release  
R the clamping strips from the transverse joints  
R of the appropriate ceiling panel and remove the  
R panel.

R a2) For Group No. 7: open the access door on the  
R rear vestibule ceiling panel.

- (b) Groups Nos. 3 and 6: mounted between luggage bins on the left side of the forward cabin and the left side of the rear cabin respectively.

b1) Remove the screws securing the battery pack fairing to the bin support structure and un-hinge the fairing from its mounting.

- (c) Group No. 8: mounted behind the trim panel above the rear steward's control panel.

c1) Remove the trim panel; it is held in position by Velcro tape.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737464

# 33-51-00

Page 404  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

(d) Flight compartment battery pack: mounted in the flight compartment roof.

d1) Release the clamping strips from the appropriate ceiling panel and remove the panel.

### C. Renew Battery

- (1) Release the captive screws securing the battery pack cover to the case and remove the cover.
- (2) Support the battery and release the captive screws securing the battery retainer. Disconnect the yellow and blue wire connectors from the battery and withdraw the battery and retainer from the case.
- (3) Refit a replacement battery in the case and connect the yellow wire connector to the positive terminal and the blue wire connector to the negative terminal of the battery. Fit the retainer in the case and secure the retainer with the captive screws.
- (4) Refit the battery pack cover and secure it with the captive screws.
- (5) Refit the associated fairing or panel.

### D. Conclusion

- RB (1) Remove the circuit breaker clips and reset the CABIN EMERG  
RB LTD & EXIT SIGN SUP circuit breaker, and EMERG LTS  
RB ARM/CHARGE SUP. circuit breaker.
- RB (2) Set the pilots' EMERG switch to "ARM".
- RB (3) Trip the EMERG LTS ARM/CHARGE SUP. circuit breaker L9058,  
RB on panel 15-215, map ref. C13, and check that the 6 V  
RB filaments in the group of lamps supplied from the battery  
RB pack are lit.
- RB (4) Reset the EMERG LTS ARM/CHARGE SUP. circuit breaker and  
RB return the pilots' switch to "OFF".
- RB (5) Reactivate the Floor Proximity Lights (33-52-00 Page 201).
- RB (6) Carry out "OFF TEST" procedure (33-52-00 Page 501).

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737465

# 33-51-00

Page 405  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL

### 4. Emergency Lantern (Ref. Fig. 403)

**CAUTION:** OWING TO THE PROXIMITY OF A COMPASS COUPLER FLUX VALVE, WHICH IS HIGHLY SENSITIVE TO MAGNETIC INTERFERENCE, NON-MAGNETIC TOOLS MUST BE USED TO REMOVE AND INSTALL THE EMERGENCY LANTERN THIRD FROM THE FORWARD END OF THE REAR CABIN ROOF.

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Ensure that the pilots' EMERG switch on the flight compartment roof panel and the steward's emerg switch on the forward steward's control panel are at OFF and NORMAL respectively.
- (2) Deactivate Floor Proximity Lights (33-52-00 page 201).
- (3) Trip the EMERG LTS ARM/CHARGE SUP. circuit breaker L9058 on panel 15-215, map ref. C13, and the CABIN EMER LTS & EXIT SIGN SUP. circuit breaker L831 on panel 1-213, map ref. Q22, and the NO SMOKING SUP circuit breaker WB192, on panel 1-213, map ref. L9, and fit safety clips.

#### C. Remove

- (1) Pull down the emergency lantern lens to release the spring clips from the lantern reflector and remove the lens.
- (2) Remove the reflector securing screw and hinge the reflector down to gain access to the flying lead connections.
- (3) Using a suitable tool disconnect the flying leads from the module block.
- (4) Loosen the hinge securing screws and washers and remove the lantern assembly from the roof.

#### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the emergency lantern and secure the hinge to its mounting with the screws and washers.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND


737466

**33-51-00**

Page 406  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL



Battery Pack - Installation  
Figure 402

EFFECTIVITY: ALL


**33-51-00**

Page 407  
Nov 30/78

Printed in England

# Concorde

## MAINTENANCE MANUAL



CMB 33 51 00 4 CAMO

- Emergency Lantern and Door Threshold Lamp -  
Installation  
Figure 403

EFFECTIVITY: ALL

**33-51-00**

R

BA

Page 408  
Nov 30/78

Printed in England

# *Concorde*

## MAINTENANCE MANUAL

- (3) Using a suitable tool, connect the flying leads to the terminal block, ensuring that the connections are made in accordance with the cable identifications and the applicable wiring diagram.
- (4) Close the reflector and secure it with the securing screw.
- (5) Fit the lens to the reflector and push the lens up to engage the spring clips.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Carry out System A circuit - Operational Test, detailed in 33-51-00 Page 501.
- (3) Switch off and disconnect electrical ground power as detailed in 24-41-00.

RB  
RB

## 5. Exit Direction Sign (Ref. Fig. 404)

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

### B. Prepare

- (1) Ensure that the pilots' EMERG switch and the NO SMKG switch on the flight compartment roof panel are at OFF, and the steward's EMERG switch on the forward steward's control panel is at NORMAL.
- (2) Deactivate Floor Proximity Lights (33-52-00 page 201).
- (3) Trip the EMERG LTS ARM/CHARGE SUP. circuit breaker L9058 on panel 15-215, map ref. C13, and the CABIN EMER LTS & EXIT SIGN SUP. circuit breaker L831 on panel 1-212, map ref. Q22, and the NO SMOKING SUP. circuit breaker W192, on panel 1-213, map ref. L9, and fit safety clips.

RB  
RB  
RB  
RB  
RB

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737467

# 33-51-00

Page 409  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

### C. Remove

- (1) Using the finger recesses provided, free the lower edge of the sign panel from the locating groove in the exit direction sign, ease the upper edge of the panel from its retaining strip and remove the panel.
- (2) Remove the filaments at each end of the lamp case to gain access to the quick-release fasteners.
- (3) Release the quick-release fasteners securing the lamp case to the bulkhead and withdraw the case sufficiently to gain access to the electrical connector.
- (4) Disconnect the electrical connector and remove the exit direction sign from the bulkhead.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the exit direction sign and connect the electrical connector to the sign, ensuring that the mating surfaces are clean and undamaged.
- (3) Position the exit direction sign on its mounting and secure it with the quick-release fasteners.
- (4) Refit the filaments in the lamp case.
- (5) Fit the upper edge of the sign panel in the retaining strip and press the bottom edge of the panel into its locating groove.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- (3) Reactivate the Floor Proximity Lights (33-52-00 page 201).
- (4) Carry out "OFF TEST" ref. 33-51-00 page 201 to check the Floor Proximity Lighting system.
- (5) Carry out "ON TEST" ref. 33-51-00 page 201 to check the Overhead Emergency Lighting.
- (6) Set the NO SMKG switch to "ON" and check that all the 28 V filaments in the appropriate exit direction sign are lit. Return the switch to "OFF".

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND


737468

# 33-51-00

Page 410  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL



Exist Signs - Installation  
Figure 404

EFFECTIVITY: ALL

**33-51-00**

Page 411  
May 30/78

Printed in England



# Concorde

## MAINTENANCE MANUAL

- R (7) For the exit direction sign at the forward end of the forward cabin, close and bolt the forward toilet door and check that the 'toilets occupied' signs are lit.
- R (8) For exit direction signs at the forward end of the rear cabin and the rear end of the forward cabin, close and bolt all the centre toilet doors and check that the 'toilets occupied' signs in the appropriate exit direction sign are lit.
- R (9) Switch off and disconnect electrical ground power as detailed in 24-41-00.

### 6. Over-door Exit Sign (Ref. Fig. 404)

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

- (1) Ensure that the pilots' EMERG switch and the NO SMKG switch on the flight compartment roof panel are at OFF, and the steward's EMERG switch on the forward steward's control panel is at NORMAL.
- RB (2) Deactivate Floor Proximity Lights (33-52-00 page 201).
- RB (3) Trip the EMERG LTS ARM/CHARGE SUP. circuit breaker L9058 on panel 15-215, map ref. C13, and the CABIN EMER LTS & EXIT SIGN SUP. circuit breaker L831 on panel 1-213, map ref. Q22, and the NO SMOKING SUP. circuit breaker W192, on panel 1-213, map ref. L9, and fit safety clips.

#### C. Remove

- (1) Pull the sign panel to release the spring clips from the the case and remove the panel.
- (2) Remove the appropriate filaments to gain access to the securing screws.
- (3) Remove the screws and washers securing the exit sign assembly to the aircraft structure and withdraw the assembly sufficiently to gain access to the electrical connector.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737469

**33-51-00**

Page 412  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

- (4) Disconnect the electrical connector and remove the sign assembly.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Support the sign assembly and connect the electrical connector to the sign, ensuring that the mating surfaces are clean and undamaged.
- (3) Place the sign on its mounting and secure it with the screws and washers.
- (4) Refit the filaments in the case.
- (5) Fit the sign panel to the case and press inward to engage the spring clips.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clips and reset the circuit breakers tripped before removal.
- RB (3) Reactivate the Floor Proximity Lights (33-52-00 page 201).
- RB (4) Carry out "OFF TEST" ref. 33-51-00 page 201 to check the  
RB Floor Proximity Lighting system.
- RB (5) Carry out "ON TEST" ref. 33-51-00 page 201 to check the  
RB Overhead Emergency Lighting.
- R (6) Set the NO SMKG switch to "ON" and check that all the  
28 V filaments in the appropriate over-door exit sign are  
lit. Return the switch to "OFF".
- R (7) Switch off and disconnect electrical ground power as  
detailed in 24-41-00.

## 7. Door Threshold Lamp (Ref. Fig. 403)

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737470

# 33-51-00

Page 413  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

### B. Prepare

- (1) Ensure that the pilots' EMERG switch on the flight compartment roof panel and the steward's EMERG switch on the forward steward's control panel are at OFF and NORMAL respectively.

RB

- (2) Deactivate Floor Proximity Lights (33-52-00 page 201).
- (3) Trip the CABIN EMERG LTS EXIT SIGN SUP circuit breaker L831, on panel 1-213, map ref. Q22. and EMERG LTS ARM/CHARGE SUP. circuit breaker L9058, on panel 15-215, map ref. C 13, and fit safety clips.

### C. Remove

- (1) Unscrew the screws securing the door threshold lamp retaining ring to the door structure and remove the retaining ring.
- (2) Withdraw the lamp assembly from the door sufficiently to gain access to the terminal block.
- (3) To renew a filament, release the captive screws securing the front cover to the rear cover and separate the covers to gain access to the filaments.
- (4) To remove the lamp, disconnect the electrical cables from the terminal block and remove the assembly from the door.

### D. Install

- (1) Comply with the electrical safety precautions.
- (2) Ensure that four 6 V filaments are mounted in the rear cover, and secure the front cover to rear cover with the captive screws.
- (3) Support the lamp assembly and connect the electrical cables to the terminals, ensuring that the connections are made in accordance with cable identifications and the applicable wiring diagram.
- (4) Place the lamp assembly in its mounting in the door structure and secure it with the retaining ring.

### E. Conclusion

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Remove the safety clip and reset the circuit breaker tripped before removal.
- (3) Reactivate the Floor Proximity Lights (33052-00 page 201).

RB  
RB

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737510

**33-51-00**

Page 414  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL

RB (4) Carry out "OFF TEST" ref. 33-51-00 page 201 to check the  
RB Floor Proximity Lighting system.

RB (5) Carry out "ON TEST" ref. 33-51-00 page 201 to check the  
RB Overhead Emergency Lighting.

(6) As detailed in 24-41-00.

### 8. Emergency Battery Pack (Ref. Fig. 402)

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

#### B. Prepare

(1) Ensure that the pilots' EMERG switch on the flight compartment roof panel and the steward's EMERG switch on the forward steward's control panel are at OFF and NORMAL respectively.

RB (2) Deactivate Floor Proximity Lights (33-52-00 page 201).

RB (3) Trip the CABIN EMERG LTS EXIT SIGN SUP circuit breaker  
RB L831, on panel 1-213, map ref. Q22. and EMERG LTS ARM/  
RB CHARGE SUP. circuit breaker L9058 on panel 15-215, map ref.  
RB C13, and fit safety clips.

(4) Gain access to the appropriate battery pack as follows:-

R Before SB 33-019

(a) Groups Nos.1 and 2, 4 and 5, and 7: mounted in the forward, centre and rear vestibule roof respectively.

a1) Release the clamping strips from the transverse joints of the appropriate ceiling panel and remove the panel.

R After SB 33-019 For A/C 001-004,

R (a) Groups Nos.1 and 2, 4 and 5 and 7: mounted in the  
R forward, centre and rear vestibule roof respectively.

R a1) For Groups Nos.1 and 2, 4 and 5: release the  
R clamping strips from the transverse joints of the  
R appropriate ceiling panel and remove the panel.

R a2) For Group No.7: open the access door on the rear  
R vestibule ceiling panel.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737511

# 33-51-00

Page 415  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

(b) Groups Nos.3 and 6: mounted between luggage bins on the left side of the forward cabin and the left side of the rear cabin respectively.

b1) Remove the screws securing the battery pack fairing to the bin support structure and unhinge the fairing from its mounting.

(c) Group No.8: mounted behind the trim panel above the rear steward's control panel.

c1) Remove the trim panel; it is held in position by Velcro tape.

(d) Flight compartment battery pack: mounted in the flight compartment roof.

d1) Release the clamping strips from the appropriate ceiling panel and remove the panel.

### C. Remove

(1) Disconnect the electrical connector from the battery pack.

(2) Support the battery pack and remove the screws and washers securing the battery pack to its mounting brackets. Remove the pack from its mounting.

### D. Install

(1) Comply with the electrical safety precautions.

(2) Support the battery pack on its mounting brackets and secure it with the screws and washers.

(3) Connect the electrical connector to the battery pack, ensuring that the mating surfaces are clean and undamaged.

(4) Refit the associated fairing or panel.

### E. Conclusion

(1) Make available electrical ground power as detailed in 24-41-00.

(2) Remove the safety clip and reset the circuit breaker tripped before removal.

(3) Set the pilots' EMERG switch to "ARM".

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737512

**33-51-00**

Page 416  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

- (4) Trip the CABIN EMER LTS BAT CHG 7 EXIT SIGN SUP circuit breaker L831, on panel 1-213, map ref. Q22, and check that the 6 V filaments in the group of lamps supplied from the battery pack are lit.
- (5) Reset the CABIN EMER LTS BAT CHG 7 EXIT SIGN SUP circuit breaker.
- (6) Set the pilots' EMERG switch to "OFF".
- (7) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737513

**33-51-00**

Page 417  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

### EMERGENCY LIGHTING - ADJUSTMENT/TEST

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED IN 24-00-00.

RB CAUTION: DO NOT USE STEWARDS PANEL EMERGENCY LIGHT SWITCH TO TEST  
RB EMERGENCY LIGHTS.

#### 1. General

This topic contains test procedures detailed under separate headings as follows:

System A Filaments - Operational Test (Ref. para.2.)

Battery Packs - Condition Test (Ref. para.3.)

Battery Packs - Capacity Test (Ref. para.4.)

System A Circuit - Operational Test (Ref. para.5.)

System B Circuit - Operational Test (Ref. para.6.)

The battery packs are tested in situ.

To effect a complete Operational Test of the emergency Lighting, all three Operational Tests must be carried out.

System A provides 6 V emergency lighting for the passenger cabins and the vestibules, and 6 V to illuminate the door exit signs, door exit areas and exit direction signs, if the aircraft d.c. essential supplies fail. System B provides 28 V standby 'dim' lighting in the passenger cabins, vestibules and toilets if the aircraft a.c. supply feeding the main lighting system fails, and 28 V to illuminate the door exit signs, door exit areas and exit direction signs, when required, by the manual operation of a control switch.

Functional and System Tests are not considered necessary in this application.

#### 2. System A Filaments - Operational Test

##### A. Prepare to Test System A Filaments

CAUTION: ALL CHECKS WITH EMERGENCY LIGHTS ON MUST BE COMPLETED AS QUICKLY AS POSSIBLE TO CONSERVE THE LIFE OF THE BATTERIES.

RB CAUTION: TO PREVENT FLOOR PROXIMITY LIGHT ACTIVATION USE ONLY  
RB "ON TEST" PROCEDURE

- (1) Make available electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND 737414

# 33-51-00

Page 501  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL

- (2) Ensure that the EMERG lights control switch on the forward steward's control panel is at NORMAL.
- (3) Ensure that the EMERG lights control switch on the flight compartment roof panel is at OFF, and check that the filament in the toggle is lit.

### B. Test System A Filaments

RB CAUTION: OBSERVE "ON TEST" PROCEDURE EXACTLY TO PREVENT  
RB INADVERTENT FLOOR PROXIMITY LIGHT OPERATION.

RB (1) Carry out "ON TEST" procedure (Ref. 33-51-00 page 201).  
RB Check that:

RB (a) The filament lamp in the pilots toggle switch is  
RB extinguished when the switch is in the ARM position.

RB (b) All 6 V filaments in the emergency lamps, lanterns  
RB and exit signs listed in Table 501 are lit, removing  
RB covers (Ref. Removal/Installation) where necessary.

RB CAUTION: ON TEST MUST BE TERMINATED WITHIN 15 MINUTES TO  
RB AVOID INADVERTENT FLOOR PROXIMITY LIGHT ACTIVATION.

RB (2) Terminate "ON TEST" (Ref. 33-51-00 page block 200).

LOCATION OF FILAMENTS	QTY. OF 6 V FILAMENTS IN EACH LAMP
Flight compartment -	
Forward roof lamp	3
Rear roof lamp	3
Forward passenger door -	
'Exit' sign	7
Threshold lamp	4
Forward service door -	
'Exit' sign	7
Threshold lamp	4
Forward vestibule -	
Exit direction sign	5
Forward cabin -	
Emergency roof lantern (3)	4
Central passenger door -	
'Exit' sign	7
Threshold lamp	4
Central service door -	
'Exit' sign	7

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737415

# 33-51-00

Page 502  
Sep 29/89



# Concorde

## MAINTENANCE MANUAL

LOCATION OF FILAMENTS	QTY. OF 6 V FILAMENTS IN EACH LAMP
Threshold lamp	4
Centre vestibule - Exit direction sign (forward)	5
Exit direction sign (rear)	5
Rear cabin - Emergency roof lantern (4)	4
Rear left door - 'Exit' sign	7
Threshold lamp	4
Rear right door - 'Exit' sign	7
Threshold lamp	4
Rear vestibule - Exit direction sign	5

### Emergency Filaments - System A Table 501

#### C. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

#### R 3. Battery Packs - Condition Test

##### R A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clip	-

##### R B. Prepare to Test Battery Packs Condition

- R (1) Make available electrical ground power as detailed  
R in 24-41-00.

EFFECTIVITY: ALL

BA

Printed in England

# 33-51-00

Page 503  
Feb 29/80

# *Concorde*

## MAINTENANCE MANUAL

- RB        CAUTION:    ENSURE FLOOR PROXIMITY LIGHTS ARE DEACTIVATED.
- RB        (2)    Deactivate Floor Proximity Lights (33-52-00 page 201).
- RB        (3)    Set the pilots' EMERG lights control switch on the flight compartment roof panel to "ARM" and check that the EMERG lights control switch on the forward steward's control panel is at NORMAL.

### C. Test Battery Packs Condition

- RB        (1)    Trip the CABIN EMER LTS SUP circuit breaker L9058 on  
RB        panel 15-215, map ref. C13, and fit a safety clip.
- (2)    Check that the 6 V emergency lighting system is activated and allow the lights to remain lit for a period of 4 min. During this period, check that all filaments are lit. Renew any faulty filaments as detailed in Removal/Installation.
- (3)    After 4 min, conclude the test by setting the pilots' EMERG lights control switch to "OFF".
- (4)    If a group of emergency lights goes off within the 4 min period of activation, replace the associated battery with a fully charged battery.
- (5)    Remove the safety clip and reset the circuit breaker tripped in operation (1).
- RB        (6)    Set the pilots' EMERG lights control switch to "OFF" and allow the batteries to recharge for a minimum uninterrupted period of 2 h.

### D. Conclusion

- RB        (1)    Reactivate the Floor Proximity Lights (33-52-00 page  
RB        201).
- RB        (2)    Carry out "OFF TEST" procedure (33-52-00 page block 401).
- RB        (3)    Switch off and disconnect electrical ground power as detailed in 24-41-00.

### 4. Battery Packs - Capacity Test

NOTE:    The batteries must be in a continuous charging state for a minimum period of 16 h prior to the commencement of in-situ capacity testing.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737416

**33-51-00**

Page 504  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clip	-

### B. Prepare to Test Battery Capacity

- (1) Make available electrical ground power as detailed in 24-41-00.

RB CAUTION: ENSURE FLOOR PROXIMITY LIGHTS ARE DEACTIVATED.

RB (2) Deactivate Floor Proximity Lighting (33-52-00 page 201).

RB (3) Set the pilots' EMERG lights control switch on the flight compartment roof panel to "ARM" and check that the EMERG lights control switch on the forward steward's control panel is at NORMAL.

### C. Test Battery Capacity

RB (1) Trip the EMERG LTS ARM CHRG SUP circuit breaker L9058  
RB on panel 15-215, map ref. C13, and fit a safety clip.

(2) Check that the 6 V emergency lighting system is activated and that all 6 V filaments are lit. Renew any faulty filaments as detailed in Removal/Installation.

(3) Check that all filaments remain lit for 20 min.

(4) If a group of emergency lights goes off within 20 min of activation, replace the associated battery with a fully charged battery.

(5) Set the pilots' EMERG lights control switch to "OFF".

(6) Remove the safety clip and reset the circuit breaker tripped in operation (1).

(7) Restore the emergency battery system to the fully charged state by carrying out either of the following procedures:

(a) Set the pilots' EMERG lights control switch to "ARM" and allow the batteries to recharge for a minimum uninterrupted period of 16 h; on completion of charging, set the pilots' EMERG lights control switch to "OFF".

(b) Alternatively, replace all the batteries with fully charged batteries.

NOTE: If procedure (b) is carried out, further in-situ charging is not necessary.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737417

# 33-51-00

Page 505  
Sep 29/89

# *Concorde*

## MAINTENANCE MANUAL

### D. Conclusion

- (1) Carry out a System A Filaments - Operational Test (Ref. para.2.)
- RB (2) Reactivate Floor Proximity Lights (33-52-00 page block  
RB 200).
- RB (3) Carry out an "OFF TEST" procedure (33-52-00 page block  
500).
- RB (4) Switch off and disconnect electrical ground power as  
detailed in 24-41-00.

### 5. System A Circuit - Operational Test

#### A. Prepare to Test System A Circuit

CAUTION: ALL CHECKS WITH EMERGENCY LIGHTS ON MUST BE COMPLETED AS QUICKLY AS POSSIBLE TO CONSERVE THE LIFE OF THE BATTERIES.

- (1) Make available electrical ground power as detailed in 24-41-00.
- RB (2) Deactivate Floor Proximity Lights (33-52-00 page 201).
- RB CAUTION: ENSURE FLOOR PROXIMITY LIGHTS ARE DEACTIVATED  
RB BEFORE PROCEEDING WITH OPERATIONAL TEST.
- RB (3) Ensure that the EMERG lights control switch on the  
forward steward's control panel is at NORMAL.
- RB (4) Ensure that the EMERG lights control switch on the flight  
compartment roof panel is at OFF, and check that the  
filament in the toggle is lit.

#### B. Test System A Circuit

- RB (1) Set the flight compartment EMERG lights control switch to  
RB "OFF". Check that all emergency lights and signs are  
RB extinguished, and the toggle filament is illuminated.
- RB (2) Set the flight compartment EMERG lights control switch to  
RB "ARM". Check that all emergency lights and signs remain  
RB extinguished, and the toggle filament is extinguished.
- RB (3) Trip the EMERG LTS ARM/CHARGE SUP circuit breaker L9058  
RB on panel 15-215, map ref. C13. Check that the emergency  
RB lamps, lanterns and exit signs listed in Table 501, are  
RB lit.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737418

**33-51-00**

Page 506  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL

- RB (4) Set the EMERG lights control switch on the flight  
RB compartment roof panel to "OFF". Check that all emergency  
RB lights and signs are extinguished.
- RB (5) Set the EMERG lights control switch on the forward  
steward's control panel to "ON" and check that the  
emergency lamps, lanterns and exit signs listed in Table  
501 are lit.
- RB (6) Set the EMERG lights control switch on the flight  
compartment roof panel to "ON", and set the EMERG lights  
control switch on the forward steward's panel to "NORMAL".  
RB Check that the emergency lamps, lanterns and exit signs  
RB remain lit, and the switch toggle filament remains  
extinguished.
- RB (7) Set the EMERG lights control switch on the flight  
RB compartment roof panel to "ARM", then reset circuit breaker  
RB tripped in (3). Check that all emergency lamps, lanterns,  
RB and signs are extinguished.
- RB (8) Set the EMERG lights control switch on the flight  
RB compartment roof panel to "OFF" and check that all  
emergency lamps, lanterns, and signs remain extinguished.

### C. Conclusion

- RB (1) Reactivate Floor Proximity Lighting (33-52-00 page block  
RB 200).
- RB (2) Carry out "OFF TEST" procedure (33-52-00 page 401).
- RB (3) Switch off and disconnect electrical ground power as  
detailed in 24-41-00.

## 6. System B Circuit - Operational Test

### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clips	-

### B. Prepare

- (1) Make available electrical ground power as detailed in  
24-41-00.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737419

**33-51-00**

Page 507  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL

### C. Test Exit Sign Filaments

- (1) Set the NO SMKG switch on the flight compartment roof panel to "ON". Check that the six 28 V filaments in each of the door exit signs and the vestibule exit direction signs are lit.
- (2) Set the NO SMKG switch to "OFF" and check that the door exit sign filament lights and the vestibule exit direction sign filament lights are extinguished.
- (3) Carry out an Operational Test of the Passenger System (Ref. 35-21-00, Adjustment/Test) and check that the six 28 V filaments in each of the door exit signs and the vestibule exit direction signs are lit when the emergency oxygen services relay is energized.

### D. Test Cabin Dim Lighting

- (1) At the forward steward's control panel, set the FWD cabin SELECT switch to "FULL" and the FWD cabin CONTROL switch to "BRIGHT". Check that the roof and the wall R fluorescent lighting in the forward cabin is on and that the filament lighting is off. Set the switches to "OFF".
- (2) Repeat operation (1) with respect to the aft cabin, using the AFT cabin CONTROL and SELECT switches.
- (3) Trip the appropriate roof lighting supply circuit breaker listed below, and fit a safety clip.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
FWD CABIN CEILING LTS SUP	14-215	L453	D10
AFT CABIN RH CEILING LTS SUP	14-215	L454	C10

- (4) Set the FWD cabin SELECT switch to "FULL" and the FWD cabin CONTROL switch to "BRIGHT". Check that the filament and wall fluorescent lighting in the forward cabin is on and the roof fluorescent lighting is off. Set both switches to "OFF". Check that the filament lighting is off.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C765202

# 33-51-00

Page 508  
SEP.30/90

# Concorde

## MAINTENANCE MANUAL

- (5) Trip the appropriate wall lighting supply circuit breaker listed below, and fit a safety clip.

SERVICE	PANEL	CIRCUIT BREAKER	MAP REF.
FWD CABIN WALL LTS SUP	14-216	L452	C9
AFT CABIN WALL LTS SUP	14-216	L451	B9

- (6) Set the FWD cabin SELECT switch to "FULL" and the FWD cabin CONTROL switch to "BRIGHT". Check that the filament lighting in the forward cabin is on and that the wall and roof fluorescent lighting is off. Set both switches to "OFF".
- (7) Remove the safety clips and reset the associated cabin roof and wall fluorescent lighting supply circuit breakers.
- (8) Repeat operations (3) to (7) with respect to the aft cabin, using the AFT cabin CONTROL and SELECT switches.
- (9) Set the FWD cabin CONTROL switch to "DIM". Check that the forward cabin filament lighting is on, and that the roof and wall fluorescent lighting is off, regardless of the position of the FWD cabin SELECT switch. Return the CONTROL switch to "OFF".
- (10) Repeat operation (9) with respect to the aft cabin, using the AFT cabin CONTROL and SELECT switches.
- (11) Set the NO SMKG switch, on the flight compartment roof panel, to "ON". Check that the filament lighting in the forward and aft cabins is on. Return the switch to "OFF", and check that the filament lighting is extinguished.

### E. Test Toilet Dim Lighting

- (1) Trip the a.c. power failure relay supply circuit breaker, FLT DECK ROOF LTS SUP, L232, on panel 14-215, map ref.C11, and fit a safety clip.
- (2) In each toilet check that the standby filament is lit.
- (3) Remove the safety clip and reset the circuit breaker tripped in operation (1).
- (4) Check that the standby filament light in each toilet is extinguished.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C763856

# 33-51-00

Page 509  
SEP.30/90

# *Concorde*

## MAINTENANCE MANUAL

- (5) Set the NO SMKG switch on the flight compartment roof panel to "ON" and check that the filament lighting in the toilets is on. Return the switch to "OFF" and check that the filament lighting is extinguished.

### F. Test Vestibule Dim Lighting

- (1) Set the VESTIBULE lights control switch on the forward steward's control panel to "DIM" and check that the two filament lamps in each of the two forward vestibule lanterns are lit.
- (2) Set the VESTIBULE lights control switch to "BRIGHT" and check that the filament lights are extinguished and the two fluorescent tubes in each of the forward vestibule lanterns are lit.
- (3) Set the VESTIBULE lights control switch to "OFF" and check that the filament and fluorescent lights in each lantern are extinguished.
- (4) Repeat operations (1) to (3) from the centre and rear vestibule steward's panel, in turn, to test the associated centre and rear vestibule lantern.
- (5) Trip the a.c. power failure relay supply circuit breaker, FLT DECK ROOF LTS SUP, L232, on panel 14-215, map ref.C11, and fit a safety clip.
- (6) Set the VESTIBULE lights control switch on the forward steward's panel to "DIM". Check that the two filament lamps in each of the two forward vestibule lanterns are lit.
- (7) Set the VESTIBULE lights control switch to "BRIGHT". Check that the filament lamps in the vestibule lanterns remain lit, and that the fluorescent tubes remain unlit.
- (8) Remove the safety clip and reset the a.c. power failure circuit breaker. Check that the filament lamps in each forward vestibule lantern are extinguished, and the fluorescent tubes are lit.
- (9) Set the VESTIBULE lighting control switch to "OFF".
- (10) Repeat operations (1) to (7) from the centre and rear steward's panels, in turn, to test the associated centre and rear vestibule lantern.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C763857

# 33-51-00

Page 510  
SEP.30/90



# *Concorde*

## MAINTENANCE MANUAL

- (11) Set the NO SMKG switch on the flight compartment roof panel to "ON" and check that the filament lighting in the vestibules is on. Return the switch to "OFF" and check that the filament lighting is extinguished.

### G. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

C763858

**33-51-00**

Page 511  
SEP.30/90

**Concorde**  
**British airways**  
**MAINTENANCE MANUAL**

EMERGENCY ESCAPE PATH FLOOR PROXIMITY LIGHTING SYSTEM  
TROUBLE SHOOTING

WARNING: OBSERVE THE ELECTRICAL SAFETY PRECAUTIONS DETAILED  
IN 24-00-00.

1. General

The trouble shooting guide utilises "zones", where a zone is the transmission footprint of a given transmitter.


2. Preparation

- A. Ensure that the associated circuit breakers are set (Ref. Table 102).
- B. Make available electrical ground power as detailed in 24-41-00.
- C. Check adjacent aircraft are not transmitting "ON" signals.
- D. Ensure correct transmitter is fitted to aircraft (Ref. IPC 33-52-03, Fig 2).

3. Trouble shooting

The following pages are the trouble shooting procedures to be adopted for a given fault. In all cases an "OFF TEST" (Ref. 33-52-00 Page 501) must be carried out to verify the systems operation.

Carry out "OFF TEST"  
(Ref. 33-52-00 Page 501)



EFFECTIVITY: ALL

BA

C806849

**33-52-00**

Page 101  
Mar 31/95

**Concorde**  
British airways  
MAINTENANCE MANUAL

NOT OK

Zonal exit/aisle floodlights illuminate with the Pilots' emergency light switch in "ARM" or "OFF".  
Ref. Chart 105 Page 109

Individual exit/aisle floodlights illuminate with the Pilots' emergency light switch in "ARM" or "OFF".  
Ref. Chart 106 Page 110

Exit/aisle floodlights found ON.  
Ref. Chart 107 Page 111

Exit strobe light only found flashing.  
Ref. Chart 108 Page 112

Battery monitor LEDs on all exit/aisle units do not blink during an "OFF TEST". Ref. Chart 109 Page 114

Battery monitor LEDs on zonal exit/aisle units do not blink during an "OFF TEST". Ref. Chart 110 Page 115

Battery monitor LEDs on individual exit/aisle units do not blink during an "OFF TEST". Ref. Chart 111 Page 116

Battery monitor and transmitter status LEDs on all exit/aisle units do not blink during an "OFF TEST".  
Ref. Chart 112 Page 117

Battery monitor and transmitter status LEDs on zonal exit/aisle units do not blink during an "OFF TEST". Ref. Chart 113 Page 119

NOT OK

PRINTED IN ENGLAND

EFFECTIVITY: ALL

BA

C806850

**33-52-00**

Page 102  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

PRINTED IN ENGLAND

NOT OK

Battery monitor and transmitter status LEDs on individual exit/aisle units do not blink during an "OFF TEST".  
Ref. Chart 114 Page 121

Complete system will not remain in an "OFF TEST".  
Ref. Chart 115 Page 122

System in one zone, will not remain in an "OFF TEST".  
Ref. Chart 116 Page 124

Individual exit/aisle unit LEDs permanently ON.  
Ref. Chart 117 Page 125

All exit/aisle units appear insensitive during an "OFF TEST".  
Ref. Chart 118 Page 126

Zonal exit/aisle units appear insensitive during an "OFF TEST".  
Ref. Chart 119 Page 128

Individual exit/aisle units appear insensitive during an "OFF TEST".  
Ref. Chart 120 Page 129

Aircraft logic for Pilot's emergency lighting switch position

PINS	B	C	D
OFF	OPEN	28V	28V
ARM	OPEN	OPEN	28V
ON	28V	OPEN	OPEN

Table 101

EFFECTIVITY: ALL

BA

C806851

# 33-52-00

Page 103  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* ALL EXIT/AISLE FLOODLIGHTS\*  
 \* CONTINUALLY FLASH OR STAY \*  
 \* ILLUMINATED DURING AN \*  
 \* "OFF TEST". \*  
 \* \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	




Chart 101 (Sheet 1 of 2)

EFFECTIVITY: ALL

BA

C806852

**33-52-00**

Page 104  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\* \* \* \* \*

\* ALL EXIT/AISLE FLOODLIGHTS\*

\* CONTINUALLY FLASH OR STAY \*

\* ILLUMINATED DURING \*

\* AN "OFF TEST". \*

\* \* \* \* \*

YES

FLOODLIGHTS ILLUMINATED

Reinstate the "OFF TEST" (Ref. 33-52-00 Page 501) and disconnect the transmitters, one at a time (noting the order of disconnection), until the floodlights extinguish.

YES

NO

FLOODLIGHTS DO NOT EXTINGUISH  
Reset the system (Ref. 33-52-00 Page 503) and reconnect transmitters.  
Reinstate the "OFF TEST" (Ref. 33-52-00 Page 501) and disconnect the transmitters one at a time but in the reverse order to before until the floodlights extinguish.

If a transmitter or transmitter position is suspect, disconnect suspect transmitter and check aircraft logic is present at transmitter connector. (Ref. Table 101).

YES

NO

Connect suspect transmitter in another aircraft position and check the fault transfers.

Fault find the system (WDM 33-52-11).

YES

NO

Replace suspect transmitter.

Inspect transmitter connector at suspect aircraft position and repair as necessary.

Chart 101 (Sheet 2 of 2)

EFFECTIVITY: ALL

BA

C806853

# 33-52-00

Page 105  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* ZONAL EXIT/AISLE FLOODLIGHTS\*  
 \* CONTINUALLY FLASH OR STAY \*  
 \* ILLUMINATED DURING AN \*  
 \* "OFF TEST". \*  
 \* \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

Prepare to trouble shoot (Ref. Para.2).

Disconnect transmitter fitted in zone and check aircraft logic is present at the transmitter connector.  
 (Ref. Table 101).

YES

NO

Fault find the system  
 (WDM 33-52-11).

Connect suspect transmitter in another aircraft position and check the fault transfers.

YES

NO

Replace suspect transmitter.

Inspect transmitter connector at suspect aircraft position and repair as necessary.

Chart 102

EFFECTIVITY: ALL

BA

C806854

**33-52-00**

Page 106  
 Mar 31/95

# *Concorde*

## British airways

### MAINTENANCE MANUAL

\* \* \* \* \*

\* INDIVIDUAL EXIT/AISLE \*

\* FLOODLIGHT(S) CONTINUALLY \*

\* FLASH OR STAY ILLUMINATED \*

\* DURING AN "OFF TEST". \*

\* \* \* \* \*

#### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

Prepare to trouble shoot (Ref. Para.2).

Replace suspect exit/aisle unit(s) and if necessary associated battery pack(s).

Chart 103

EFFECTIVITY: ALL

BA

C806944

## 33-52-00

Page 107  
Mar 31/95



# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* ALL EXIT/AISLE FLOODLIGHTS \*  
 \* ILLUMINATE WITH THE PILOT'S \*  
 \* EMERGENCY LIGHT IN "ARM" \*  
 \* OR "OFF". \*  
 \* \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

Prepare to trouble shoot (Ref. Para.2).

Investigate which transmitter(s) is/are generating "ON" signals by observing which transmitter status LED on an exit/aisle unit blinks when that unit's floodlight illuminates.  
 (Ref. 33-52-20 & 30 Fig. 401).

Disconnect suspect transmitter(s) and check aircraft logic is present at the transmitter(s) connector(s). (Ref. Table 101).

NO

Fault find the system  
 (WDM 33-52-11).

YES

Connect suspect transmitter in another aircraft position and check the fault transfers.

YES

Replace suspect transmitter.

NO

Inspect transmitter connector at suspect aircraft position and repair as necessary.

Chart 104

EFFECTIVITY: ALL

BA

C806945

# 33-52-00

Page 108  
 Mar 31/95

PRINTED IN ENGLAND

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* ZONAL EXIT/AISLE FLOOD- \*  
 \* LIGHTS ILLUMINATE WITH THE\*  
 \* PILOT'S EMERGENCY LIGHT \*  
 \* SWITCH IN "ARM" OR "OFF". \*  
 \* \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	




Chart 105

EFFECTIVITY: ALL

BA

C806946

# 33-52-00

Page 109  
Mar 31/95

PRINTED IN ENGLAND

**Concorde**  
**British airways**  
**MAINTENANCE MANUAL**

\* \* \* \* \*  
\* INDIVIDUAL EXIT/AISLE \*  
\* FLOODLIGHT(S) ILLUMINATE \*  
\* WITH THE PILOT'S EMERGENCY \*  
\* LIGHT SWITCH IN "ARM" OR \*  
\* "OFF". \*  
\* \* \* \* \*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

Prepare to trouble shoot (Ref. Para.2).

Replace suspect exit/aisle unit(s) and if necessary associated battery pack(s).

PRINTED IN ENGLAND

Chart 106

EFFECTIVITY: ALL

BA

C806947

**33-52-00**

Page 110  
Mar. 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\* \* \* \* \*

\* EXIT/AISLE FLOODLIGHTS \*

\* FOUND ON. \*

\* \* \* \* \*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

**CAUTION:** REMOVING THE AIRCRAFT POWER WITHIN 15 SECONDS OF SWITCHING THE PILOTS EMERGENCY LIGHT SWITCH TO "OFF" MAY CAUSE THE AIRCRAFT'S EXIT/AISLE FLOODLIGHTS TO ILLUMINATE. MERELY REINSTATING AIRCRAFT POWER MAY NOT EXTINGUISH ALL EXIT/AISLE FLOODLIGHTS, THEREFORE IT WILL BE NECESSARY TO RESET THE SYSTEM BY SWITCHING THE PILOTS' EMERGENCY LIGHT SWITCH TO "ARM" FOR 5 SECONDS, THEN BACK TO "OFF" OR USING HAND HELD TRANSMITTER (87-3-1000-2).

Prepare to trouble shoot (Ref. Para.2).

Reset exit/aisle unit(s) using a hand held test transmitter (87-3-1000-2) and then carry out the "OFF TEST". (Ref. 33-52-00 Page 501).

Chart 107

EFFECTIVITY: ALL

BA

C806948

# 33-52-00

Page 111  
Mar 31/95

**Concorde**  
**British airways**  
**MAINTENANCE MANUAL**

\* \* \* \* \*  
\* EXIT STROBE LIGHT ONLY \*  
\* FOUND FLASHING \*  
\* \* \* \* \*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

**WARNING:** THE STROBE TUBE OPERATES AT A HIGH VOLTAGE AND CONSEQUENTLY BATTERY PACKS SHOULD NOT ROUTINELY BE REMOVED WHEN THE STROBE IS POWERED. HOWEVER, PRACTICALLY, THE BATTERY PACK CAN BE REMOVED WITH THE STROBE OPERATING IF RUBBER GLOVES ARE USED AND CARE TAKEN.

**CAUTION:** REMOVING THE AIRCRAFT POWER WITHIN 15 SECONDS OF SWITCHING THE PILOTS' EMERGENCY LIGHT SWITCH TO "OFF" MAY CAUSE THE AIRCRAFT'S EXIT/AISLE FLOODLIGHTS TO ILLUMINATE. MERELY REINSTATING AIRCRAFT POWER MAY NOT EXTINGUISH ALL EXIT/AISLE FLOODLIGHTS, THEREFORE IT WILL BE NECESSARY TO RESET THE SYSTEM BY SWITCHING THE PILOTS' EMERGENCY LIGHT SWITCH TO "ARM" FOR 5 SECONDS, THEN BACK TO "OFF" OR USING HAND HELD TRANSMITTER (87-3-1000-2).

**NOTE:** The exit unit strobe tube has a dedicated battery fitted within the unit battery pack. The operating current of this battery is less than the 9V incandescent bulb battery and therefore the strobe has a longer period of operation.

Prepare to trouble shoot (Ref. Para.2).

Reset the system by switching the Pilot's Emergency Light switch to "ARM" for 5 seconds, then back to "OFF". Check the strobe resets.

NO

YES

Switch OFF exit/aisle unit(s) using a hand held test transmitter (87-3-1000-2). Check that strobe resets.

Carry out "OFF TEST". (Ref. 33-52-00 Page 501).

NO

YES

Chart 108 (sheet 1 of 2)

EFFECTIVITY: ALL

BA

C806949

**33-52-00**

Page 112  
Mar 31/95

*Concorde*  
British airways  
MAINTENANCE MANUAL

\* \* \* \* \*  
\* EXIT STROBE LIGHT ONLY \*  
\* FOUND FLASHING \*  
\* \* \* \* \*

NO

Wait until the strobe flattens its battery. Replace the battery packs fitted to the suspect unit and carry out "OFF TEST". (Ref. 33-52-00 Page 501).

YES

Carry out "OFF TEST".  
(Ref. 33-52-00 Page 501).

PRINTED IN ENGLAND

Chart 108 (Sheet 2 of 2)

EFFECTIVITY: ALL

BA

C806950

**33-52-00**

Page 113  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* BATTERY MONITOR LEDs ON \*  
 \* ALL EXIT/AISLE UNITS DO \*  
 \* NOT BLINK DURING AN \*  
 \* "OFF TEST" \*  
 \* \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

Prepare to trouble shoot (Ref. Para.2).

Discontinue "OFF TEST" (Ref. 33-52-00 Page 501) and allow the exit/aisle unit batteries to recover charge for as long as practical.

Carry out "OFF TEST" (Ref. 33-52-00 Page 501) and check exit/aisle units LEDs blink.

NO

YES

Discontinue "OFF TEST" (Ref. 33-52-00 Page 501) and replace all exit/aisle unit battery packs. Carry out "OFF TEST".

Continue "OFF TEST". (Ref. 33-52-00 Page 501).

Chart 109

EFFECTIVITY: ALL

BA

C806951

# 33-52-00

Page 114  
Mar 31/95

PRINTED IN ENGLAND

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* BATTERY MONITOR LEDs ON \*  
 \* ZONAL EXIT/AISLE UNIT DO \*  
 \* NOT BLINK DURING AN \*  
 \* "OFF TEST". \*  
 \* \* \* \* \*

#### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

**NOTE:** After removing a suspect aisle unit battery pack inspect the connector pins for signs of an adhesive coating. This coating acts as an insulator and by carefully removing it with a suitable abradar (e.g. rubber eraser), the battery pack may be made serviceable.

Prepare to trouble shoot (Ref. Para.2).

Discontinue "OFF TEST" (Ref. 33-52-00 Page 501) and allow the exit/aisle unit batteries to recover charge for as long as practical.

Carry out "OFF TEST" (Ref. 33-52-00 Page 501) and note if exit/aisle units blink.

NO

YES

Discontinue "OFF TEST" (Ref. 33-52-00 Page 501) and replace defective exit/aisle unit battery packs and those fitted to "Red Spot" exit units associated with the zone. (Ref. 33-52-020 Fig. 401).

Continue "OFF TEST". (Ref. 33-52-00 Page 501).

Chart 110

EFFECTIVITY: ALL

BA

C806952

## 33-52-00

Page 115  
Mar 31/95



# Concorde

## British airways

### MAINTENANCE MANUAL

\* \* \* \* \*

\* BATTERY MONITOR LEDs ON \*

\* INDIVIDUAL EXIT/AISLE \*

\* UNITS DO NOT BLINK DURING \*

\* AN "OFF TEST" \*

\* \* \* \* \*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

**NOTE:** After removing a suspect aisle unit battery pack inspect the connector pins for signs of an adhesive coating. This coating acts as an insulator and by carefully removing it with a suitable abrader (e.g. rubber eraser), the battery pack may be made serviceable.




Chart 111

EFFECTIVITY: ALL

BA

C806953

# 33-52-00

Page 116  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* BATTERY MONITOR AND \*  
 \* TRANSMITTER STATUS LEDs \*  
 \* ON ALL EXIT/AISLE UNITS DO\*  
 \* NOT BLINK DURING AN "OFF \*  
 \* TEST" \*  
 \* \*\*\*\*\*

#### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2

GROUND POWER SUPPLY

Prepare to trouble shoot (Ref. Para.2).  
 If the aircraft has been electrically disconnected or if transmitter batteries have not been charged for over two weeks, then allow transmitter batteries to charge for as long as practical by leaving Pilots' Emergency Light Switch in "ARM/OFF".

Using a hand held test transmitter (87-3-1000-2) confirm that exit/aisle unit LEDs blink.

NO

YES

Carry out "OFF TEST"  
 (Ref. 33-52-00 Page 501)  
 to confirm serviceability.

Replace all exit/aisle unit battery packs and test system using hand held test transmitter (87-3-1000-2) and confirm unit LEDs blink.

NO

YES

Carry out "OFF TEST"  
 (Ref. 33-52-00 Page 501)  
 to confirm serviceability.

Confirm that the correct transmitter type is fitted to the aircraft (IPC 33-52-03 Fig. 2) and that the batteries are correctly connected (Ref. 33-52-20 Page 402). Test the system using hand held test transmitter (87-3-1000-2) and confirm unit LEDs blink.

NO

YES

Chart 112 (Sheet 1 of 2)

EFFECTIVITY: ALL

BA

C806954

## 33-52-00

Page 117  
 Mar 31/95

```

* * * * *
* BATTERY MONITOR AND
* TRANSMITTER STATUS LEDs
* ON ALL EXIT/AISLE UNITS
* DO NOT BLINK DURING AN
* "OFF TEST"
* * * * *

```



Page 118  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* BATTERY MONITOR AND \*  
 \* TRANSMITTER STATUS LEDs ON\*  
 \* ZONAL EXIT/AISLE UNITS DO \*  
 \* NOT BLINK DURING AN \*  
 \* "OFF TEST" \*  
 \* \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

**NOTE:** After removing a suspect aisle unit battery pack, inspect the connector pins for signs of an adhesive coating. This coating acts as an insulator and by carefully removing it with a suitable abrader (e.g. rubber eraser), the battery pack may be made serviceable.




Chart 113 (Sheet 1 of 2)

EFFECTIVITY: ALL

BA

C806965

# 33-52-00

Page 119  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* BATTERY MONITOR AND \*  
 \* TRANSMITTER STATUS LEDs \*  
 \* ON ZONAL EXIT/AISLE UNITS \*  
 \* DO NOT BLINK DURING AN \*  
 \* "OFF TEST" \*  
 \* \*\*\*\*\*

YES

Carry out "OFF TEST"  
 (Ref. 33-52-00 Page 501)  
 to confirm serviceability.

NO

Disconnect transmitter fitted in the zone and check that aircraft logic is present (Ref. Table 101) at transmitter connector.

YES

NO

Connect the suspect transmitter to another aircraft position, if the fault transfers replace the transmitter battery.

Fault find the system  
 (WDM 3-52-11).

Test the system using hand held test transmitter (87-3-1000-2) confirm unit LEDs blink.

Test the system using hand held test transmitter (87-3-1000-2) and confirm unit LEDs blink.

NO

YES

YES

NO

Inspect the transmitter connector at the suspect position and repair as necessary.

Test the system using hand held transmitter (87-3-1000-2) and confirm unit LEDs blink.

Carry out "OFF TEST"  
 (Ref. 33-52-00 Page 501)  
 to confirm serviceability.

YES

NO

Replace transmitter.

Chart 113 (Sheet 2 of 2)

EFFECTIVITY: ALL

BA

C806929

**33-52-00**

Page 120  
 Mar 31/95

PRINTED IN ENGLAND

# Concorde

## British airways

### MAINTENANCE MANUAL

\* \* \* \* \*

\* BATTERY MONITOR AND \*

\* TRANSMITTER STATUS LEDs \*

\* ON INDIVIDUAL EXIT/AISLE \*

\* UNITS DO NOT BLINK DURING \*

\* AN "OFF TEST" \*

\* \* \* \* \*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

**NOTE:** After removing a suspect aisle unit battery pack, inspect connector pins for signs of an adhesive coating. This coating acts as an insulator and by carefully removing it with a suitable abrader (e.g. rubber eraser), the battery pack may be made serviceable.

PRINTED IN ENGLAND




Chart 114

EFFECTIVITY: ALL

BA

C806930

# 33-52-00

Page 121  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\* \* \* \* \*

\* COMPLETE SYSTEM WILL NOT \*

\* REMAIN IN AN "OFF TEST" \*

\* \* \* \* \*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

**CAUTION:** REMOVING THE AIRCRAFT POWER WITHIN 15 SECONDS OF SWITCHING THE PILOTS' EMERGENCY LIGHT SWITCH TO "OFF", MAY CAUSE THE AIRCRAFT'S EXIT/AISLE FLOODLIGHTS TO ILLUMINATE. MERELY REINSTATING AIRCRAFT POWER MAY NOT EXTINGUISH ALL EXIT/AISLE FLOODLIGHTS, THEREFORE IT WILL BE NECESSARY TO RESET THE SYSTEM BY SWITCHING THE PILOTS' EMERGENCY LIGHT SWITCH TO "ARM" FOR 5 SECONDS THEN BACK TO "OFF", OR USING HAND HELD TRANSMITTER (87-3-1000-2).

Prepare to trouble shoot (Ref. Para.2).

Reset the system by switching the pilots' Emergency Light switch to "ARM" for 5 seconds, then back to "OFF". Carry out "OFF TEST" (Ref. 33-55-00 Page 501).

Disconnect each transmitter and check aircraft logic is correct (Ref. Table 101).

YES

NO

Reconnect transmitters one at a time and carry out "OFF TEST" (Ref. 33-52-00 Page 501). After re-connection check system remains in "OFF TEST".

Fault find the system (WDM 33-52-11).

NO

YES

Continue "OFF TEST" (Ref. 33-52-00 Page 501) to prove system serviceability.

Chart 115 (Sheet 1 of 2)

EFFECTIVITY: ALL

BA

C806970

## 33-52-00

Page 122  
Mar 31/95

PRINTED IN ENGLAND

*Concorde*  
British airways  
MAINTENANCE MANUAL

\* \* \* \* \*  
\* COMPLETE SYSTEM WILL NOT \*  
\* REMAIN IN AN "OFF TEST" \*  
\* \* \* \* \*

NO

Connect the suspected transmitter into another aircraft position and check the fault transfers.

YES

Replace suspected transmitter

NO

Inspect transmitter connector at suspect aircraft position and repair as necessary.

PRINTED IN ENGLAND

Chart 115 (Sheet 2 of 2)

EFFECTIVITY: ALL

BA

C806962

**33-52-00**

Page 123  
Mar 31/95



# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* SYSTEM IN ONE ZONE WILL \*  
 \* NOT REMAIN IN AN "OFF" \*  
 \* TEST". \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

**CAUTION:** REMOVING THE AIRCRAFT POWER WITHIN 15 SECONDS OF SWITCHING THE PILOTS' EMERGENCY LIGHT SWITCH TO "OFF", MAY CAUSE THE AIRCRAFT'S EXIT/AISLE FLOODLIGHTS TO ILLUMINATE. MERELY REINSTATING AIRCRAFT POWER MAY NOT EXTINGUISH ALL EXIT/AISLE FLOODLIGHTS, THEREFORE IT WILL BE NECESSARY TO RESET THE SYSTEM BY SWITCHING THE PILOTS' EMERGENCY LIGHT SWITCH TO "ARM" FOR 5 SECONDS, THEN BACK TO "OFF" OR USING HAND HELD TRANSMITTER (87-3-1000-2).

Prepare to trouble shoot (Ref. Para.2).

Reset the system by switching the Pilots' Emergency Light switch to "ARM" for 5 seconds, then back to "OFF". Carry out "OFF TEST" (Ref. 33-55-00 Page 501).

Disconnect transmitter in zone and check aircraft logic is correct (Ref. Table 101).

YES

NO

Connect transmitter in another zone and carry out "OFF TEST" (Ref. 33-52-00 Page 501) and check that the fault transfers.

Fault find the system (WDM 33-52-11).

YES

NO

Replace suspect transmitter.

Inspect transmitter connector at suspect aircraft position and repair as necessary.

Chart 116

EFFECTIVITY: ALL

BA

C806956

# 33-52-00

Page 124  
Mar 31/95

PRINTED IN ENGLAND

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* INDIVIDUAL EXIT/AISLE UNIT\*  
 \* LEDS PERMANENTLY "ON". \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

Prepare to trouble shoot (Ref. Para.2).

Replace suspect exit/aisle units and associated battery packs if required.

PRINTED IN ENGLAND

Chart 117

EFFECTIVITY: ALL

BA

C806957

## 33-52-00

Page 125  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* ALL EXIT/AISLE UNITS APPEAR \*  
 \* INSENSITIVE DURING AN \*  
 \* "OFF TEST". \*  
 \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

Prepare to trouble shoot (Ref. Para.2).

Confirm that all transmitters are generating "OFF" signals, by observing transmitter status LEDs on exit/aisle units. (Ref. 33-52-20 & 30 Fig. 401).

YES

NO

Reselect the "OFF TEST". (Ref. 33-52-00 Page 501).

Disconnect transmitter in zone and check aircraft logic is correct. (Ref. Table 101).

YES

NO

Fault find the system (WDM 33-52-11).

Change the transmitter battery.

Carry out "OFF TEST" (Ref. 33-52-00 Page 501) and check if fault still occurs.

YES

Change the transmitter.

YES

Chart 118 (Sheet 1 of 2)

EFFECTIVITY: ALL

BA

C806958

## 33-52-00

Page 126  
Mar 31/95

PRINTED IN ENGLAND

*Concorde*  
British airways  
MAINTENANCE MANUAL

\* \* \* \* \*  
\* ALL EXIT/AISLE UNITS APPEAR \*  
\* INSENSITIVE DURING AN \*  
\* "OFF TEST" \*  
\* \* \* \* \*

YES

Allow transmitter batteries to charge for as long as practical by leaving the pilots' Emergency Light switch in "OFF"

Check the range of each transmitter by observing which transmitter status LEDs blink on which exit/aisle units. (Ref. 33-52-20 & 30 Fig. 401).

From the above observation determine if any of the transmitters lacks power and replace.

PRINTED IN ENGLAND

Chart 118 (Sheet 2 of 2)

EFFECTIVITY: ALL

BA

C806967

**33-52-00**

Page 127  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* ZONAL EXIT/AISLE UNITS \*  
 \* APPEAR INSENSITIVE DURING \*  
 \* AN "OFF TEST". \*  
 \* \*\*\*\*\*

GROUND EQUIPMENT REQUIRED	
DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

Prepare to trouble shoot (Ref. Para.2).

Check that the transmitter fitted in the zone is transmitting by observing transmitter status LEDs on exit/aisle units. (Ref. 33-52-20 & 30 Fig. 401).

YES

NO

Disconnect transmitter in zone and check aircraft logic is correct. (Ref. Table 101).

YES

NO

Fault find the system (WDM 33-52-11).

Change the transmitter battery.

Carry out "OFF TEST" (Ref. 33-52-00 Page 501). Check if Exit/Aisle units remain insensitive.

YES

Change the transmitter.

Allow transmitter batteries to charge for as long as practical by leaving the Pilots' Emergency Light switch in "OFF".

Chart 119

EFFECTIVITY: ALL

BA

C806959

# 33-52-00

Page 128  
Mar 31/95

PRINTED IN ENGLAND

# Concorde

## British airways

### MAINTENANCE MANUAL

\*\*\*\*\*  
 \* INDIVIDUAL EXIT/AISLE UNITS \*  
 \* APPEAR INSENSITIVE DURING \*  
 \* AN "OFF TEST" \*  
 \*\*\*\*\*

#### GROUND EQUIPMENT REQUIRED

DESCRIPTION	PART NO
HAND HELD TEST TRANSMITTER	87-3-1000-2
GROUND POWER SUPPLY	

Prepare to trouble shoot (Ref. Para.2).

Replace exit/aisle unit battery pack(s)

Carry out "OFF TEST" (Ref. 33-52-00 Page 501). Check that the units are serviceable.

NO

Replace exit/aisle unit.

Carry out "OFF TEST" (Ref. 33-52-00 Page 501). Check that the units are serviceable.

NO

Determine which transmitter(s) is/are not received by the individual exit/aisle unit(s) (Ref. 33-52-20 & 30 Fig. 401) and trouble shoot suspect transmitter (Ref. Chart 119).

Chart 120

EFFECTIVITY: ALL

BA

C806969

## 33-52-00

Page 129  
Mar 31/95

**Concorde**  
British airways  
MAINTENANCE MANUAL

ITEM No. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
[1] Circuit breaker 28V DC cabin emergency lights battery charge and exit sign supply.		1-213	L831	Map Ref. Q22	24-50-00	33-51-01
[2] Circuit breaker 28V DC emergency lights ARM/CHARGE supply		15-215	L9058	Map Ref. C13	24-50-00	33-51-01
[3] Emergency ON/ARM/OFF Switch		4-211	L832	Flight Compt.roof panel	33-00-00	33-51-01
[4] Transmitter - Green		Stn. 532R Frame 20	L9060	Wardrobe ceiling RH	33-52-00	33-52-11
[5] Transmitter - Red		Stn. 1050R Frame 42	L9061	Wardrobe ceiling	33-52-00	33-52-11
[6] Transmitter - Yellow		Stn. 1632R Frame 68	L9062	Galley No.6	33-52-00	33-52-11
[7] Transmitter - Orange		Stn. 750R Frame 30	L9063	RH overhead stowage bin	33-52-00	33-52-11
[8] Exit Ident light		Zone 221 Frame 14	L858	Fwd. door LH	33-52-00	33-51-01

PRINTED IN ENGLAND

EFFECTIVITY: ALL

BA

C806960

**33-52-00**

Page 130  
Mar 31/95

**Concorde**  
British airways  
MAINTENANCE MANUAL

ITEM No. AND DESCRIPTION	ACCESS PANEL	PANEL/ ZONE	EQUIP. IDENT.	POSITION	MANUAL REF.	
					MAINT. TOPIC	WIRING DIAGRAM
[9] Exit Ident light		Zone 222 Frame 12	L834	Fwd. door RH	33-52-00	33-51-01
[10] Exit Ident light		Zone 223	L882	Ctr. door LH	33-52-00	33-51-12
[11] Exit Ident light		Zone 224	L845	Ctr. door RH	33-52-00	33-51-12
[12] Exit Ident light		Zone 242	L851	Rear door RH		33-51-12
[13] Exit Ident light		Zone 241	L878	Rear door LH		33-51-12
[14] Aisle lights		Zone 221- 244		Fwd. cabin at seats 1, 2, 6 and 10	33-52-00	
[15] Aisle lights		Zone 221- 244		Aft cabin at seats 11, 16, 20, 24 and 26	33-52-00	

Component Identification  
Table 102

EFFECTIVITY: ALL

BA

C806961

**33-52-00**

Page 131  
Mar 31/95



# Concorde

## MAINTENANCE MANUAL

### EMERGENCY ESCAPE PATH FLOOR PROXIMITY LIGHTING MAINTENANCE PRACTICES

#### 1. General (Ref. Fig. 501 and 502)

A. Before carrying out any extensive testing or trouble shooting of the Overhead Emergency Lighting, which cannot be accomplished by use of the "ON TEST", it is necessary to deactivate the Floor Proximity Lighting. This will prevent the depletion of the Floor Proximity Lighting non-rechargeable battery packs.

B. Deactivation of the Floor Proximity Lighting involves disconnecting the Floor Proximity Light Control Modules, 4 off, throughout the cabin.

NOTE: All the Control Modules must be disconnected.

C. After completion of the testing or trouble shooting the Floor Proximity Lighting must be reactivated by reconnecting all the Control Modules and carrying out the "OFF TEST" procedure (33-52-00 Page 501).

#### 2. Deactivation

A. Ensure the Pilots' Emergency Light Switch is set to OFF on the Flight Compartment Roof Panel.

B. Gain access to the Floor Proximity Lighting Control Modules (transmitters).

C. Disconnect the electrical connector at each Control Module.

#### 3. Reactivation

A. Ensure DC 'A' Main and DC 'A' Essential Power is, and will remain available.

B. Reconnect the electrical connector at each Control Module See Table 201 for locations.

COLOUR	FRAME	LOCATION
GREEN	20	IN WARDROBE
RED	42	IN WARDROBE
YELLOW	68	IN GALLEY
ORANGE	30	IN RIGHTHAND HAT RACK BETWEEN STOWAGE BIN 7 & 8 ZONE 223 (LOWER BOTH BINS FOR ACCESS) FWD CABIN

TABLE 201 CONTROL MODULE LOCATIONS

EFFECTIVITY: ALL

BA

C808836

**33-52-00**

Page 201  
Mar 31/95

R

PRINTED IN ENGLAND

# Concorde

## MAINTENANCE MANUAL

- C. Immediately after connecting a Control Module operate the Pilots' Emergency Light Switch from "OFF" to "ARM", pause at least one (1) second then select "OFF".

NOTE: System will shut down after 15 seconds.

- D. Repeat B. and C. at each Control Module in turn until all Control Modules are reconnected.
- E. Close any panels opened to gain access to Control Modules.
- F. Carry out "OFF TEST", as detailed in 33-52-00 Page 501.

NOTE: Use of the "OFF TEST" procedure will prevent any further depletion of the Overhead Emergency Light batteries.

#### 4. Conclusion

- A. Whenever the Floor Proximity Lights have been tested, any other aircraft in the immediate vicinity should be checked to ensure that inadvertent switch on of the floor proximity light has not occurred. The controlling radio signals may extend beyond the wingtips of the aircraft being tested.

#### 5. Battery Capacity

- A. In the event that a system is found to be inadvertently switched "ON" and has partially depleted the batteries, the system may still be considered serviceable provided that:

- (1) The system switches "OFF" on command (either by means of a hand-held test transmitter or the aircraft's transmitters).
- (2) The lights are not obviously dim and yellowish.

NOTE: The battery test LEDs will not blink (indicating battery capacity inadequate) subsequent to even a short period of floodlight illumination although the batteries will contain sufficient capacity to exceed the mandatory 10 minutes. A recovery period of up to 12 hours may be required before the test LEDs respond in the correct manner.

- B. Two additional green LEDs are used to determine the adequacy of the floodlight battery capacity and the continuity of the floodlight filaments.

- (1) On Aisle light units both these LEDs are used (Aisle light units have two floodlights).

EFFECTIVITY: ALL

BA

C808837

**33-52-00**

Page 202  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND

- RB (2) On Exit identifier units only one of the two  
RB additional LEDs is operational. This monitors the  
B battery condition and the continuity of the single  
B floodlight filament.  
B
- RB C. A blue spot on the lower front face of the white plastic  
RB reflector denotes a modified Exit identifier unit.  
B
- RB D. The Battery Condition Monitor LEDs (2 off green per Aisle  
RB light unit, 1 off green per Exit identifier unit) may  
B glow dimly when the system is shutdown. This is acceptable  
B and does not impact significantly on Floodlight battery  
B life. Reject units only if Battery Condition Monitor LEDs  
B produce full brilliance when the system is shutdown.
- RB E. When fitting Aisle/Exit identifier unit battery packs ensure  
B that the connector pin/sockets are free of contamination.  
B

### 6. Transmitters (Control Modules)

- RB A. The basic requirement is that a minimum of two transmitters  
B (Control Modules) be received at each Aisle light unit and  
B Exit identifier unit.  
B
- B B. All control modules must be serviceable.  
B

### 7. Aisle Floodlights

- RB A. An Aisle light unit may be inoperative provided that the  
B Aisle light unit forward and aft of it is serviceable,  
B all other positions must be serviceable.  
B
- B B. When replacing any seat with an Aisle light unit  
B installed, it is essential that the Aisle light unit and  
B its associated brackets are re-installed in the same  
B position.

### 8. Exit Identifier Lights

- B A. All Exit Identifier Lights must be serviceable, except  
B that the strobe tube may be unserviceable.  
B

B CAUTION: ANY DEVIATION IN ACCORDANCE WITH THE ABOVE  
B SERVICEABILITY MUST BE ACCOMPANIED BY AN ADD.

EFFECTIVITY: ALL

BA

C808838


33-52-00

Page 203  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



Aisle Light Unit  
Figure 201

EFFECTIVITY: ALL

BA


# 33-52-00

Page 204  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



Exit Identifier Unit  
Figure 202

RB

EFFECTIVITY: ALL

BA

# 33-52-00

Page 205  
Mar 31/95

**Concorde**  
MAINTENANCE MANUAL

B  
B  
B  
B  
B  
B  
B  
B  
B  
B

LOCATION			COLOUR CODE
STA 532	FR 20		GREEN
STA 1050	FR 42		RED
STA 1632	FR 68		YELLOW
STA 752	FR 30		ORANGE

FIG.204  
CONTROL MODULE LOCATIONS

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737835

**33-52-00**

Page 206  
Sep 29/89

# Concorde

## MAINTENANCE MANUAL

### FLOOR PROXIMITY LIGHTING - ADJUSTMENT/TEST

#### 1. General

RB A. When testing the Emergency Lighting System A, it is important to note that the Pilots' EMERG light control switch will operate both the Emergency Lighting System A and the Floor Proximity Lighting System. Extreme care must be exercised, whenever testing of the Floor Proximity Lighting System is carried out to avoid depletion of the Floor Proximity Lighting System NON-RECHARGEABLE battery packs.

RB NOTE: "ON TEST" (detailed in 33-51-00 Page 202 Para. 2.C.) must be used whenever it is necessary to test the Emergency Lighting System A, "OFF TEST" must be used whenever it is necessary to test the Floor Proximity Lighting.

B. The Stewards forward control panel Emergency light control switch will cause the Floor Proximity Lights to be energized and deplete the batteries and must therefore not be used to turn the Emergency Lights ON unless absolutely necessary.

C. Whenever it is necessary to test the Floor Proximity Lighting, use must be made of the "OFF TEST" Mode of the Floor Proximity Light System. This test is detailed in para 2. "OFF TEST".

RB D. "Blinking LEDs" battery condition monitor checks for each  
RB Aisle and Exit Identifier lights shall be carried out  
RB during the "ON TEST" and "OFF TEST".

#### 2. "OFF TEST"

NOTE: The Battery/Filament Monitor LEDs may not illuminate if the Floor Proximity Floodlights have been recently switched ON. The batteries require time to recover to full open-circuit voltage.

A. Ensure normal electrical power situation exists on aircraft, i.e. all busbars live.

B. Select Pilots' EMERG light control switch from "OFF" to "ARM", then wait at least 5 seconds.

C. Next, pausing not longer than 1/2 (half) second at each intermediate switch position, cycle the switch as follows:

ON - ARM - ON - ARM - OFF

EFFECTIVITY: ALL

BA

C808860


**33-52-00**

Page 501  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



CMB 33 52 00 5 AAMD 00

Aisle Light Unit  
Figure 501

EFFECTIVITY: ALL

BA

**33-52-00**


Page 502  
Mar 31/95



# Concorde

## MAINTENANCE MANUAL

PRINTED IN ENGLAND



CMB 33 52 00 5 ACMD 00

RB

Exit Identifier Light  
Figure 502

EFFECTIVITY: ALL

BA

# 33-52-00

Page 503  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

- D. Successful "OFF TEST" of each of the Floor Proximity Aisle Light Unit is indicated by rapid, random blinking of the Light Emitting Diodes at that unit (Ref. Fig. 501).
- (1) At least one Transmitter (TX) Status LED must blink, however, if only one Transmitter status LED is blinking, the Aisle Light Unit immediately fore and aft of that unit must have at least two TX Status LEDs blinking.
  - (2) Both Battery/Filament Monitor LEDs must blink.
  - (3) The two green LEDs shall blink approximately every six seconds. The blinking LEDs indicate the satisfactory condition of the battery for operating the two floodlights within the Aisle Light Unit. LEDs that do not blink indicate that the floodlight battery voltage has been reduced to a level where a battery change is required, it does not however mean that the batteries are completely discharged. They may if operated, continue to provide illumination of the floodlights after the blinking has stopped.

- E. Successful "OFF TEST" of each of the Floor Proximity Exit Identifier Lights is indicated by rapid, random blinking of the LEDs at that unit (Ref. Fig. 502).

- (1) At least two Transmitter status LEDs must blink.
- (2) One Battery/Filament Monitor LED must blink.
- (3) The upper green monitor LED of the Exit Identifier Lights must blink approximately every six seconds to indicate satisfactory condition of the battery within the unit. LEDs that do not blink indicate that the floodlight battery voltage has been reduced to a level where a battery change is required, it does not however mean that the batteries are completely discharged, they may if operated continue to provide illumination after the blinking has stopped.

NOTE: Occasional momentary switch on of the Floodlights may occur, this is acceptable during "OFF TEST"

### 3. Terminate "OFF TEST"

NOTE: "OFF TEST" will terminate automatically after 15 minutes of its start.

- A. At any time, after the first 15 seconds of the "OFF TEST", the test mode may be terminated by selecting "ARM", pausing for at least one second, then selecting "OFF".

EFFECTIVITY: ALL

BA

C808861

**33-52-00**

Page 504  
Mar 31/95

# Concorde

## MAINTENANCE MANUAL

NOTE: Test signal will continue for approximately 15 seconds after the test has been terminated.

CAUTION: ELECTRICAL POWER MUST BE MAINTAINED FOR AT LEAST 20 SECONDS.

### 4. Functional Test

CAUTION: THIS FUNCTIONAL TEST MUST BE CARRIED OUT ONLY AS REQUIRED BY THE APPROVED MAINTENANCE SCHEDULE, THIS TEST CONSIDERABLY DISCHARGES THE FLOOR PROXIMITY LIGHT NON-RECHARGEABLE BATTERY PACKS WHICH MUST BE REPLACED AFTER COMPLETION OF THIS TEST.

#### A. Equipment and Materials

DESCRIPTION	PART NO.
Circuit breaker safety clip	-

#### B. Prepare to Functionally Test Floor Proximity Lights

- (1) Make available electrical ground power as detailed in 24-41-00.
- (2) Set the pilots' EMERG lights control switch on the flight compartment roof panel to "ARM" and check that the EMERG lights control switch on the forward stewards control panel is at NORMAL.

#### C. Function Test Floor Proximity Lights

- (1) Trip the CABIN EMER LTS SUP circuit breaker L9058 on panel 15-215, map ref. C13, and fit a safety clip.
- (2) Check that the Floor Proximity Lighting Aisle Light Units are illuminated and the Exit Identifier Lights are illuminated and the strobe tubes are flashing.
- (3) Check that the upper green LED on the Exit Identifier Lights and the two green LEDs on the Aisle Lights all blink every six seconds.
- (4) After 4 minutes, conclude the test by setting the pilots' EMERG lights control switch to "OFF".
- (5) Remove the safety clip and reset the circuit breaker tripped in operation (1).

EFFECTIVITY: ALL

BA

C808862

**33-52-00**

Page 505  
May 31/95

# *Concorde*

## MAINTENANCE MANUAL

- RB (6) Replace the batteries in all the Floor Proximity Aisle Light Units and Exit Identifier lights.
- RB (7) Carry out "OFF TEST" procedure.
- RB (8) Allow the Emergency Lights batteries to recharge for a minimum uninterrupted period of 2 hours.

NOTE: The pilots' EMERG lights control switch can be in the OFF or ARM position to recharge the Emergency light batteries.

### D. Conclusion

- (1) Switch off and disconnect electrical ground power as detailed in 24-41-00.

PRINTED IN ENGLAND

EFFECTIVITY: ALL

BA

C808863

**33-52-00**

Page 506  
Mar 31/95

***Concorde***  
**British airways**  
**MAINTENANCE MANUAL**

CONTROL MODULE (TRANSMITTER)  
REMOVAL/INSTALLATION

1. Special Equipment Required

None.

2. Removal

- A. Ensure pilot's EMERG lights control switch, flight compartment overhead panel is set to "OFF".
- B. Gain access to control module (ref. Fig. 401).
- C. Disconnect electrical connector.
- D. Disconnect 4 screws and washers securing control module.
- E. Remove control module.
- F. Retain mounting plate.

3. Installation

- A. Ensure D.C. 'A' Main and D.C. 'A' Essential Power is available and will remain available until installation is complete.
- B. When changing control modules it is necessary to transfer the rechargeable battery pack from the off going to the on going unit.
- C. If the battery being transferred is obviously defective, e.g. broken connector leads, a replacement battery must be demanded. Ensure the 30 day battery shelf life has not expired.

NOTE: This requirement is not applicable to transferred batteries, which have been subject to trickle charge on the aircraft and hence have not been "on the shelf".

- D. When fitting new control modules or batteries to control modules ensure the battery retaining strap is effective. Pack out with material NPAS0842 or equivalent as required.
- E. Position antenna as shown on Fig. 401.
- F. At frames 20, 30, 42 and 68 secure antenna with a p-clip provided on control module.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737428


**33-52-10**

Page 401  
Sep 29/89


*Concorde*  
British airways  
MAINTENANCE MANUAL

CIC 33-004M 00A

FRAME 20 GREEN  
FRAME 42 RED  
WARDROBE CEILING - RH




FRAME 30 ORANGE  
R.H. OVERHEAD STOWAGE BIN



33 52 10 401 CON MM 00A

FRAME 68  
YELLOW  
GALLEY NO. 6



Control Module Locations  
and Antenna Positions  
Figure 401

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737430

33-52-10

Page 402  
Sep 29/89

***Concorde***  
**British airways**  
**MAINTENANCE MANUAL**

- G. Install Control Module using fixings removed previously.  
Ensure mounting plate is in position.

CAUTION: ENSURE D.C. 'A' MAIN AND D.C. 'A' ESSENTIAL POWER  
REMAINS AVAILABLE AND REMAINS AVAILABLE FOR 15  
SECONDS AFTER SETTING PILOTS SWITCH TO "OFF".

- H. Connect electrical connector.
- I. Operate pilot's EMERG light control switch on flight  
compartment overhead panel to "ARM." Pause at least one  
second, return switch to "OFF".
- J. Carry out "OFF TEST" as detailed in 33-52-00 page 501, ensure  
that the appropriate "colour" of signal is being received at  
the adjacent aisle or exit identifier light, as shown by the  
Transmitter Status LED's.
- K. Close any access panels opened.
- L. Remove electrical power if no longer required.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737429

**33-52-10**

Page 403  
Sep 29/89

***Concorde***  
**British airways**  
**MAINTENANCE MANUAL**

EXIT IDENTIFIER LIGHT  
REMOVAL/INSTALLATION -

1. Special Equipment Required

A. Warning Tag - DO NOT OPERATE, or local equivalent.

2. Removal (Ref. Fig.401)

WARNING: THE STROBE TUBE OPERATES AT HIGH VOLTAGE, TAKE PRECAUTIONS TO ENSURE FLOOR PROXIMITY LIGHTS ARE NOT OPERATED WHILE THE LENS IS REMOVED.

A. Position the pilots' EMERG Lights switch, flight compartment overhead panel to "OFF", attach a "DO NOT OPERATE" tag to switch.

B. Remove the three (3) screws securing the lens and remove lens.

C. Carefully lift the reflector assembly over the strobe tube.

CAUTION: TAKE CARE NOT TO STRAIN WIRING TO LAMP HOLDER.

D. Unplug the battery harness at printed circuit board. Note the orientation of the connector.

E. Remove the battery pack.

F. Remove the filister head screws located at each corner of the unit (4 off).

G. Refit the reflector assembly, taking care not to bend L.E.D.'s or strobe tube.

H. Refit the lens using three (3) screws removed previously.

3. Installation

WARNING: THE STROBE TUBE OPERATES AT HIGH VOLTAGE, TAKE PRECAUTIONS TO ENSURE FLOOR PROXIMITY LIGHTS ARE NOT OPERATED WHILE THE LENS IS REMOVED.

A. Position the pilots' EMERG Lights switch, flight compartment overhead panel to "OFF", attach a "DO NOT OPERATE" tag to switch.

B. Remove the three (3) screws securing the lens and remove lens.

C. Carefully lift the reflector assembly over the strobe tube.

CAUTION: TAKE CARE NOT TO STRAIN WIRING TO LAMP HOLDER.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737452

**33-52-20**

Page 401  
Sep 29/89



***Concorde***  
**British airways**  
**MAINTENANCE MANUAL**

- D. Install the unit into mounting bezel or on to mounting inserts using filister headed screws, one at each corner of the unit (4 off).

CAUTION: WHEN INSTALLING BATTERY PACKS WITH ALTERNATIVE PART NUMBERS, OBSERVE PRECAUTIONS DETAILED IN PARA 4.C BELOW.

- E. Install the battery pack and connect the battery harness to the printed circuit board, wires should not pass over strobe board.
- F. Refit reflector assembly, ensuring L.E.D.'s and strobe tube are correctly located in the holes and slots in the reflector. Take care not to bend L.E.D.'s and ensure the L.E.D.'s are visible through the reflector.
- G. Refit the lens using the three screws removed previously.
- H. Remove "DO NOT OPERATE" tag from pilots' EMERG light control switch.
- I. Carry out "OFF TEST" as detailed in 33-52-00 Page 501.

**4. Battery Replacement**

**A. Special Equipment Required.**

- (1) Warning Tag - DO NOT OPERATE, or local equivalent.

**B. Replacement**

WARNING: THE STROBE TUBE OPERATES AT HIGH VOLTAGE, TAKE PRECAUTIONS TO ENSURE FLOOR PROXIMITY LIGHTS ARE NOT OPERATED WHILE THE LENS IS REMOVED.

- (1) Position the pilots' Emergency Lights switch, flight compartment overhead panel to "OFF", attach a "DO NOT OPERATE" tag to switch.
- (2) Remove the three (3) screws securing the lens and remove lens.
- (3) Carefully lift the reflector assembly over the strobe tube.

CAUTION: TAKE CARE NOT TO STRAIN WIRING TO LAMP HOLDER.

- (4) Unplug the battery harness at printed circuit board.  
Note the orientation of the connector.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737453

**33-52-20**

Page 402  
Sep 29/89

**Concorde**  
**British airways**  
**MAINTENANCE MANUAL**

- (5) Remove the battery pack.

CAUTION: WHEN INSTALLING BATTERY PACKS WITH ALTERNATIVE PART NUMBERS, OBSERVE PRECAUTIONS DETAILED IN PARA 4.C. BELOW.

- (6) Install the battery pack and connect the battery harness to the printed circuit board, wires should not pass over strobe board.
- (7) Refit the reflector assembly, ensuring L.E.D.'s and strobe tube are correctly located in the holes and slots in the reflector. Take care not to bend L.E.D.'s and ensure the L.E.D.'s are visible through the reflector.
- (8) Refit the lens using the three screws removed previously.
- (9) Remove "DO NOT OPERATE" tag from pilots' Emergency Light switch.
- (10) Carry out "OFF TEST" as detailed in 33-52-00 page 501.

C. Installation of alternate battery packs.

CAUTION: INCORRECT INSTALLATION OF THE BATTERY PACK WILL CAUSE DAMAGE TO THE EXIT IDENTIFIER UNIT.

- (1) When fitting battery packs with alternative Pt. Nos. to Exit Identifier Units, be sure that the connector is installed with the orange wire nearest the battery and the black wire furthest from the battery. See Fig. 402.
- (2) Pack out with material NPSA0824 or equivalent as required.

EFFECTIVITY: ALL

BA

PRINTED IN ENGLAND

737454


**33-52-20**

Page 403  
Sep 29/89

# Concorde

## British airways

### MAINTENANCE MANUAL



PRINTED IN ENGLAND

CMB 33 52 20 4 AAWO 00

Exit Identifier Light  
Figure 401


EFFECTIVITY: ALL

BA

**33-52-20**

Page 404  
Mar 31/95

**Concorde**  
British airways  
MAINTENANCE MANUAL



Alternative Battery Installation  
Figure 402

*Concorde*  
British airways  
MAINTENANCE MANUAL

AISLE LIGHT UNIT - REMOVAL/INSTALLATION

1. Special Equipment Required

None.

RB 2. Removal (Ref. Fig. 401 and 403)

RB NOTE: The Housing assembly for the Aisle Light unit is part  
RB of the seat assembly.

RB A. Remove the Dzus Fastener securing the glazed door and  
RB unclip the door from its frame. Care should be taken as  
RB both the door and clip are very delicate and fragile.

RB B. Loosen the screw holding the Retainer Bar and allow the  
RB Retainer bar to hang loosely.

RB C. Remove the Aisle Light by carefully pulling on the Top Cap  
Cover.

RB 3. Battery Replacement (Ref. Fig. 402)

RB A. Remove the cover screw and remove the cover.

RB B. Remove the battery pack.

RB C. Install the replacement battery pack.

CAUTION: SOME BATTERY PACKS HAVE BEEN SUPPLIED WITH  
CONTAMINATED CONNECTORS, CHECK CONNECTOR FOR  
CONTAMINATION BEFORE INSTALLING.

RB (1) When installing the battery pack, ensure that the  
battery pack connector engages the wiring harness  
connector in the base of the unit.

(2) When installing an alternate battery pack, be sure that  
the unused pin of the battery pack flying lead mates  
with the unused pin on the connector socket.

RB (3) Pack out the Aisle Light Unit, as necessary with  
packer NPAS0824, or equivalent, to ensure battery  
pack fits well.

RB (4) Refit cover and screw.

EFFECTIVITY: ALL

BA

C808834

33-52-30

Page 401  
Mar 31/95

*Concorde*  
British airways  
MAINTENANCE MANUAL

RB 4. Installation (Ref. Fig. 401)

RB A. Slide the Aisle Light Unit into the Seat Lamp Housing,  
RB pushing home firmly to ensure the LEDs are clearly visible  
RB through the slot at the top right hand corner of the  
RB Housing assembly.

RB B. Fit the Retaining Bar into the recess on the mounting  
RB block and tighten the retainer bar screw to secure the  
RB Aisle Light Unit.

RB C. Refit the glazed door and tighten the Dzus Fastener.

RB CAUTION: PRE AND POST MOD 33F080 LIGHTS MUST NOT BE  
RB FITTED TO THE SAME AIRCRAFT.

RB 5. Conclusion

A. Carry out an "OFF TEST" as detailed in 33-52-00 Page 501.

PRINTED IN ENGLAND

EFFECTIVITY: ALL

BA

C808835


**33-52-30**

Page 402  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL



Aisle Light Unit Installation  
Figure 401

CMB 33 52 30 4 AAMD 00

RB

EFFECTIVITY: ALL

BA

# 33-52-30


Page 403  
Mar 31/95

# Concorde

## British airways

### MAINTENANCE MANUAL

PRINTED IN ENGLAND



Aisle Light Unit-Assembly  
Figure 402

EFFECTIVITY: ALL

BA

**33-52-30**



Page 404  
Mar 31/95



# Concorde

## British airways

### MAINTENANCE MANUAL



▲ DENOTES LOCATION OF AISLE FLOODLIGHT

Aisle Light Unit-Location  
Figure 403

EFFECTIVITY: ALL

BA

**33-52-30**

Page 405  
Mar 31/95

**END OF THIS  
SECTION**

**NEXT**